Intro. to Computer Architecture

Daniel Page

Department of Computer Science, University Of Bristol, Merchant Venturers Building, Woodland Road, Bristol, BS8 1UB. UK. (csdsp@bristol.ac.uk)

January 9, 2018

Keep in mind there are *two* PDFs available (of which this is the latter):

- 1. a PDF of examinable material used as lecture slides, and
- 2. a PDF of non-examinable, extra material:
 - the associated notes page may be pre-populated with extra, written explaination of material covered in lecture(s), plus
 - anything with a "grey'ed out" header/footer represents extra material which is useful and/or interesting but out of scope (and hence not covered).

Notes:	7
Notes:	

COMS12200 lecture: week #2

- ▶ Goal: implement a design(s) for integer addition, i.e.,
 - ► accepts *n*-bit **addends** x and y as input, and ► produces (n + 1)-bit **sum** r = x + y as output

which

- 1. functions correctly, and
- 2. is efficient (wrt. whatever metrics are deemed important).





COMS12200 lecture: week #2













Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

© Daniel Page (csdsp6bristol.ac.uk)
Intro. to Computer Architecture

git # 3b6f641 @ 2018-01-09



Addition in theory (1)

Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

Notes:		

Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

© Daniel Page (csdsp@bristol.ac.ul)
Intro. to Computer Architecture

git # 3b6f641 @ 2018-01-09



Addition in theory (1)

Example

Assuming ci = 0, the approach you know sets b = 10



Notes:		

Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

© Daniel Page (csdsp@bristol.ac.ul)
Intro. to Computer Architecture

git # 3b6f641 @ 2018-01-09



Addition in theory (1)

Example

Assuming ci = 0, the approach you know sets b = 10



Notes:		

Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

© Daniel Page (csdsp@bristol.ac.uk)
Intro. to Computer Architecture

git # 3b6f641 @ 2018-01-09



Addition in theory (1)

Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

Notes:		

Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

© Daniel Page (csdsp@bristol.ac.uk)
Intro. to Computer Architecture

git # 3b6f641 @ 2018-01-09



Addition in theory (1)

Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

Notes:		

Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

© Daniel Page (csdsp@bristol.ac.uk)
Intro. to Computer Architecture


git # 3b6f641 @ 2018-01-09



Addition in theory (1)

Example

Assuming ci = 0, the approach you know sets b = 10



Notes:			

Example

Assuming ci = 0, the approach you know sets b = 10

but it *also* applies for b = 2

© Daniel Page (csdsp@bristol.ac.ul)
Intro. to Computer Architecture

git # 3b6f641 @ 2018-01-09



Addition in theory (1)

Example

Assuming ci = 0, the approach you know sets b = 10



Notes:		
Notes.		

Algorithm **Input:** Two unsigned, *n*-digit, base-*b* integers *x* and *y*, and a 1-digit carry-in $ci \in \{0, 1\}$ **Output:** An unsigned, n-digit, base-b integer r = x + y, and a 1-digit carry-out $co \in \{0, 1\}$

```
1 r \leftarrow 0, c_0 \leftarrow ci
2 for i = 0 upto n - 1 step +1 do
 | r_i \leftarrow (x_i + y_i + c_i) \bmod b 
 | \mathbf{if} (x_i + y_i + c_i) = b \mathbf{then} c_{i+1} \leftarrow 0 \mathbf{else} c_{i+1} \leftarrow 1 
5 end
6 co \leftarrow c_n
7 return r, co
```



Addition in practice (1)

Definition

The behaviour of the component

is described by the truth table

Full-Adder							
ci	х	у	со	S			
0	0	0	0	0			
0	0	1	0	1			
0	1	0	0	1			
0	1	1	1	0			
1	0	0	0	1			
1	0	1	1	0			
1	1	0	1	0			
1	1	1	1	1			






	٠.	00	~1	NI

- Certain (subtle) features of the algorithm should be kept in mind:
- adding two *n*-digit integers produces an (*n* + 1)-digit result,
 instead of producing this directly (per the example), here the outputs are produced as a *separate* sum and carry-out,
 although the carry-in *could* be implicitly zero, here it is an explicit extra input,
 although the algorithm looks like it's got a loop in it, we can unroll this since *n* is fixed, and
 when *b* = 2, the body of the loop is a Boolean function: each of the inputs and outputs is a value in the set [0, 1].

Notes:		

Addition in practice (2)



© Daniel Page (csdsp@bristol.ac.uk) Intro. to Computer Architecture

git # 3b6f641 @ 2018-01-09



An Aside: Carry-out versus overflow

- ▶ The magnitude of a result is too large to represent in *n* bits if *either*
- 1. the inputs are *unsigned* and there is a carry-out, *or*
- 2. the inputs are *signed* but the sign of the result makes no sense

which are termed carry-out and overflow conditions.

- ► To cope, two steps are typically applied:
- 1. detect the condition, then
- 2. take some action, e.g.,
 - ▶ signal the condition somehow (e.g., via a status register or some form of exception) but **truncate** the result to *n* bits, or
 - **clamp** (or **saturate**) the result to the largest magnitude representable in *n* bits to "fix" it.

Notes:			

Notes:			

An Aside: Carry-out versus overflow

Example

Consider use of an unsigned representation:

Here, the carry-out indicates an error: the correct result r = 16 is too large for n = 4 bits.



Notes:

Notes:

An Aside: Carry-out versus overflow

Example

Consider use of a *signed* representation:

Irrespective of the carry-out, the signs of inputs and output make sense: there is no overflow, so r = 0 is correct.

Example

Consider use of a signed representation:

Irrespective of the carry-out, the signs of inputs and output make no sense: there is an overflow, so r = -8 is incorrect.

▶ Detection of an overflow condition is slightly more complicated than for carry; in computation of r = x + y, we need to check

$$x$$
 +ve y -ve \Rightarrow no overflow x -ve y +ve r +ve \Rightarrow no overflow x +ve y +ve r -ve \Rightarrow overflow x -ve y -ve r -ve \Rightarrow overflow x -ve y -ve y -ve x -ve y -ve x -ve x no overflow x -ve x

for example.

Conclusions

► Take away points:

- 1. The design strategy we used is important and (fairly) general-purpose:
- 1.1 explore and understand an approach in theory,
- 1.2 translate, formalise, and generalise the approach into an algorithm,
- 1.3 translate the algorithm into a hardware design,
- 1.4 refine (or select) the hardware design to satisfy any design constraints.
- 2. Computer arithmetic is an interesting special-case:
 - ▶ it's a broad topic with a rich history,
 - there's usually a large design space of potential approaches,
 - they're often easy to understand at an intuitive, high level,
 - correctness and efficiency of resulting low-level solutions is vital and challenging.

© Daniel Page (csdsp@bristol.ac.uk Intro. to Computer Architecture

git # 3b6f641 @ 2018-01-09



Additional Reading

- Wikipedia: Computer Arithmetic. URL: http://en.wikipedia.org/wiki/Category:Computer_arithmetic.
- D. Page. "Chapter 7: Arithmetic and logic". In: A Practical Introduction to Computer Architecture. 1st ed. Springer-Verlag, 2009.
- ▶ B. Parhami. "Part 2: Addition/subtraction". In: Computer Arithmetic: Algorithms and Hardware Designs. 1st ed. Oxford University Press, 2000.
- W. Stallings. "Chapter 10: Computer arithmetic". In: Computer Organisation and Architecture. 9th ed. Prentice-Hall, 2013.
- A.S. Tanenbaum and T. Austin. "Section 3.2.2: Arithmetic circuits". In: Structured Computer Organisation. 6th ed. Prentice-Hall, 2012.

	Notes:	
_		
	Notes:	

References

- [1] Wikipedia: Computer Arithmetic. URL: http://en.wikipedia.org/wiki/Category:Computer_arithmetic (see p. 51).
- [2] D. Page. "Chapter 7: Arithmetic and logic". In: A Practical Introduction to Computer Architecture. 1st ed. Springer-Verlag, 2009 (see p. 51).
- [3] B. Parhami. "Part 2: Addition/subtraction". In: Computer Arithmetic: Algorithms and Hardware Designs. 1st ed. Oxford University Press, 2000 (see p. 51).
- [4] W. Stallings. "Chapter 10: Computer arithmetic". In: Computer Organisation and Architecture. 9th ed. Prentice-Hall, 2013 (see p. 51).
- [5] A.S. Tanenbaum and T. Austin. "Section 3.2.2: Arithmetic circuits". In: Structured Computer Organisation. 6th ed. Prentice-Hall, 2012 (see p. 51).

© Daniel	Page (csdsp@bristol.ac.ul
Testura	to Commuton Anabitostum

it # 3b6f641 @ 2018-01-09



Notes:	