## Flux Capacitor



Single button actions			
1 Play	2 Music Player :	<b>3</b> Play	
"key1.mp3" [3001]	Previous song [3002]	"key3.mp3" [3003]	
<b>4</b> Play "key4.mp3" [3004]	<b>5 Music Player</b> : Play/Stop [3005]	<b>6</b> Play "key6.mp3" [3006]	
<b>7</b> Play "key7.mp3" [3007]	8 Music Player : Next song [3008]	<b>9</b> Play "key9.mp3" [3009]	
* Start command sequence	O Time Travel	# Abort command	
	<b>↑</b> Volume +		
<b>←</b> Chase speed -	<b>OK</b> Execute command	+ Chase speed +	
	<b>↓</b> Volume –		

## Flux Capacitor

Special key sequences	IR	TCD
Set original chase sequence	*1□←	3010
Set alternative chase sequence	*1×← <sup>7</sup>	301x
Disable <b>flux sound</b>	*20 <i>←</i> 7	3020
Enable <b>flux sound</b>	*21←	3021
Enable <b>flux sound</b> (30 seconds)	*22 <i>₊</i> 7	3022
Enable <b>flux sound</b> (60 seconds)	*23 <i>~</i>	3023
Set relative flux volume level (0-3)	*3×← <sup>7</sup>	303x
Select volume level (00 - 19)	*3××← <sup>7</sup>	33xx
Enable volume knob	*399₽	3399
Set minimum box light level (0-4)	*40x← <sup>7</sup>	340x
Music Player : Set folder number	*5x← <sup>7</sup>	305x
<b>Music Player</b> : Shuffle off	*222 <i>→</i>	3222
<b>Music Player</b> : Shuffle on	*555₽	3555
Music Player : Go to song 000	*888₽	3888
Music Player: Go to song xxx	*888xxx+ <sup>-7</sup>	3888xxx
Toggle <b>IR remote command lock</b>	*70↩	3070
Re-activate or connect WiFi	*77~	-
Reset chase speed	*80₽	3080
Toggle usage of Speed knob	*81↩	3081
Say current IP address	*90₽	3090
Enter TCD remote control mode*	*95₽	3095
Restart the Flux Capacitor	*64738₽	3064738
Delete static IP address	*123456+7	3123456
Forget learned IR rem. control	*654321 <i>↔</i>	3654321

Control of FC through TCD requires BTTFN connection.

<sup>\*</sup> Remote controlling the TCD keypad requires BTTFN connection. Keys 0-9 and OK are sent as brief presses; \*x sends key x as "held". # quits remote control mode.