1 Bugs in the book's *.jdeb 2 Problems in running Ozo 2.1 Debug-session does 2.2 Ozone does not exit 3 Troubleshooting debugge 3.1 Console output for a

3 Troubleshooting debugger connection-problems

3.1 Console output for a successful debugger connection

• From chapter 6, in the section "Attaching Ozone to the MCU" (page 139)

```
Disabled output of control characters
J-Link software found at: C:/Program Files/SEGGER/Ozone/JLink x64.dll
File.Open ("C:/projects/packtBookRTOS/Chapters5 6/Chapters5 6.jdebug");
Project.SetTraceSource ("SWO");
SWO active
Project.SetDevice ("STM32F767ZI");
Target core support plugin loaded.: C:/Program
Files/SEGGER/Ozone/Plugins/Core/CorePluginARM.dll
Project.SetHostIF ("USB", "");
Project.SetTargetIF ("SWD");
Project.SetTIFSpeed ("50 MHz");
Project.AddSvdFile
("C:\ST\STM32CubeIDE 1.5.1\STM32CubeIDE\plugins\com.st.stm32cube.ide.mcu.productdb.det
Project.AddSvdFile ("C:/Program Files/SEGGER/Ozone/Config/CPU/Cortex-M7.svd");
Project.SetOSPlugin ("FreeRTOSPlugin CM7");
File name resolved: "FreeRTOSPlugin CM7.js" was found at "C:/Program
Files/SEGGER/Ozone/Plugins/OS/FreeRTOSPlugin CM7.js"
RTOS awareness plugin loaded: C:/Program
Files/SEGGER/Ozone/Plugins/OS/FreeRTOSPlugin CM7.js.
File.Open ("C:\projects\packtBookRTOS\Chapters5 6\Debug\Chapter5 main.elf");
File.Open: completed in 200 ms
Debug.ReadIntoInstCache: updated instruction information within 1 code ranges
(0x08000200-0x08007A50)
RTT active
Debug.SetConnectMode (CM DOWNLOAD RESET);
Debug.Start();
Device "STM32F767ZI" selected.
Found SW-DP with ID 0x9BA02477
Found SW-DP with ID 0x9BA02477
DPv0 detected
Scanning AP map to find all available APs
AP[1]: Stopped AP scan as end of AP map has been reached
AP[0]: AHB-AP (IDR: 0x74770001)
Iterating through AP map to find AHB-AP to use
AP[0]: Core found
AP[0]: AHB-AP ROM base: 0xE00FD000
CPUID register: 0x411FC270. Implementer code: 0x41 (ARM)
Found Cortex-M7 r1p0, Little endian.
FPUnit: 8 code (BP) slots and 0 literal slots
CoreSight components:
ROMTb1[0] @ E00FD000
ROMTbl[0][0]: E00FE000, CID: B105100D, PID: 000BB4C8 ROM Table
ROMTb1[1] @ E00FE000
ROMTbl[1][0]: E00FF000, CID: B105100D, PID: 000BB4C7 ROM Table
ROMTb1[2] @ E00FF000
ROMTb1[2][0]: E000E000, CID: B105E00D, PID: 000BB00C SCS-M7
ROMTb1[2][1]: E0001000, CID: B105E00D, PID: 000BB002 DWT
ROMTb1[2][2]: E0002000, CID: B105E00D, PID: 000BB00E FPB-M7
ROMTb1[2][3]: E0000000, CID: B105E00D, PID: 000BB001 ITM
ROMTb1[1][1]: E0041000, CID: B105900D, PID: 001BB975 ETM-M7
ROMTb1[0][1]: E0040000, CID: B105900D, PID: 000BB9A9 TPIU-M7
Cache: Separate I- and D-cache.
I-Cache L1: 16 KB, 256 Sets, 32 Bytes/Line, 2-Way
D-Cache L1: 16 KB, 128 Sets, 32 Bytes/Line, 4-Way
Connected to target device.
Reset: Halt core after reset via DEMCR.VC CORERESET.
Reset: Reset device via ATRCR.SYSRESETREO.
Elf.GetBaseAddr(); // returns 0x8000000
Target.ReadU32 (0x08000000); // returns 0x20080000
Target.SetReg ("SP", 0x20080000);
Target.ReadU32 (0x08000004); // returns 0x8007959
Target.SetReg ("PC", 0x8007959);
J-Link: Flash download: Bank 0 @ 0x08000000: Skipped. Contents already match
Elf.GetBaseAddr(); // returns 0x8000000
Target.ReadU32 (0x08000000); // returns 0x20080000
```