

# (http://www.ualberta.ca/)

## CMPUT 229 - Computer Organization and Architecture I

### RISC-V-to-ARM Binary Translation - ALU

### Introduction

This lab introduces the ARM assembly language and asks you to write a program that translates a subset of RISC-V assembly into ARM assembly. This lab is the first of two ARM translation labs. This lab focuses on the translation of ALU instructions. The next lab, Lab ARM - Control, will translate control-flow instructions.

### Information

### The Advanced RISC Machines (ARM) Instruction Set

The ARM instruction set varies in quite a few ways from the RISC-V instruction set. It aims to cause fewer control-flow changes and pipeline flushes during the execution of the program. ARM has only 15 visible registers at any time, numbered R0 through R14. Of these, R13 is the **Stack Pointer**, equivalent to RISC-V's sp, and R14 is the **Link Register**, equivalent to RISC-V's return address ( ra) register. ARM also operates with 4-byte words.

The binary code for every ARM instruction begins with a 4-bit condition code that determines whether or not that instruction should execute. The binary format for a data processing instruction --- which supports ADD. SUB. OR and other ALU instructions with an immediate value --- is as shown below:

### **Data-Processing Immediate Format**

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
С	ond	ition	s	0	0	1		ОрС	ode		S	R	n Opera	and	1	B		natio	n		Rota	ate				nedia signe		bit ۱-	/alu	е	

- Conditions (bits 31-28) allow the instruction to be executed conditionally. The purpose is to get rid of branching, which can introduce delays when the outcome of the branch is predicted incorrectly. This conditional execution of instructions is called *predicated execution* because the condition can be seen as a predicate that controls the execution of the instruction. For the purposes of this lab, the conditions field for every instruction should be 1110 which allows for every instruction to always get executed. The next lab will elaborate on the conditions field and the various related flags.
- Bits 27-26 are 00 for all data-processing instructions. Bits 27-25 are part of another opcode, with 00x representing data-processing and miscellaneous instructions, where x specifies how the operands are supplied to the instruction.
- Immediate (bit 25) specifies whether the operands are two registers or a register and an immediate value. A 1 specifies an immediate value, while a 0 specifies an additional register.
- **Opcode** (bits 24-21) specifies the type of operation to perform on the two operands. Relevant opcodes are detailed later on.
- Status (bit 20) determines whether the outcome of this instruction alters the Status register, which is used by control-flow instructions. Control-flow instructions will be translated in the next lab. The Status bit should be 0 for all instructions in this lab.
- Rn (bits 19-16) contains the first operand for the ARM instruction.
- Rd (bits 15-12) is the register that contains the output of the instruction.
- Rotate (bits 11-8) The instruction uses a 32-bit immediate value, however only 8-bit immediate and 4-bit rotate fields are specified. To obtain the immediate, the value in the 4-bit rotate field is first shifted left a single bit and then that value is used to shift the 8-bit immediate right, with wraparound. Though this means that only some 32-bit immediates are possible, it allows for large powers of 2 to be more easily represented. The following gif illustrates the rotation.

The rotate field (highlighted below), when multiplied by two, is equal to 28.

																													2		0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1	0	0

First, the value in the 4 rotate bits is multiplied by 2 (or, equivalently, shifted left by a bit). Here, the value obtained after this shift is 28. Thereafter, the value in the 8 immediate bits, 0x77, is shifted to the right with wraparound by the value obtained from the previous calculation in bits. That is, 0x77 is shifted by 28 bits. The 32-bit value obtained after this 4-bit shift with wraparound, 0x00000770, will be used as the immediate in this instruction.

• Immediate (bits 7-0) is an unsigned 8-bit value that is rotated by the rotate field over 32 bits with wraparound, then used as the 32-bit second operand in the operation specified by the instruction

The data-processing immediate format explained above is used by the ARM instructions AND, OR, SUB and ADD with a single register operand and an immediate value.

An addi instruction with a negative immediate must be translated into the SUB instruction.

### **Data-Processing Register Format**

3	1	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	Co	ondi	ition	s	0	0	0	(	ОрС	ode		S	R	n pera	and	1	B	-	natio	n				Sh	ift *					m pera	and 2	2

This instruction format is for ARM data-processing instructions that use two registers as operands. The immediate bit (bit 25) is set to 0, and bits 11-0 hold the register for the second operand and a Shift field.

Bits 31-12 have the same fields as data-processing immediate instructions.

- Rm (bits 3-0) is the second operand for the instruction, after its content is shifted (see below).
- Shift (bits 11-4)

specify a shift to be performed on the register Rm prior to the operation. When bit 4 is set to 0 the shift amount is in bits 11-7. When bit 4 is set to 1 the shift amount is in the lowest byte of the content of Rs. Bits 6-5 specify the shift type as shown in the Shift Types table above. Rotate right performs a rightward shift in which bits that "fall off" the register are placed entering the

opposite side. | 11 10 9 8 7 6 5 4 | Shift Amount | Shift Type 0

11	10	9	8	7	6	5	4
Rs Sh	ift Re	egist	ter	0	Sh Ty	ift pe	1

	Shift Types									
00	Logical Left									
01	Logical Right Arithmetic Right									
10	Arithmetic Right									
11	Rotate Right									

Specifying Rotate Right 0 in the shift field shifts Rm rightwards 1, and places the Carry flag from the status register into bit 31. Flags are explained in the Lab ARM Control.

The data-processing register format is used by ARM instructions AND, OR, SUB and ADD that use two register operands as well as for all LSL, LSR and ASR instructions.

All (both I-type and R-type) RISC-V bit-shift operations should be translated into data-processing register-format instructions. The information in the Shift section describes how ARM immediate-value and register-value shifts should be encoded.

Immediate shifts in the Shift field should not be encoded with the function computeRotation specified below. Immediate shifts should be written as is because both RISC-V and ARM shift-immediate values are 5 bit fields treated as unsigned numbers.

For all bit-shift operations (i.e. LSL, LSR and ASR instructions), bits 19 to 16 must be 0 because RISC-V's R-type instructions do not have an immediate value and therefore the shift field should be 0 for all instructions that do not perform a shift. When necessary, the register is specified in bits 11-8.

### The Operations to Translate

RISC-V instructions must be translated into the following ARM instructions in this lab:

Instruction	Opcode	Description
AND	0000	bitwise AND of two register values or of one register value and an immediate value
OR	1100	bitwise OR of two register values or of one register value and an immediate value
ADD	0100	addition of two register values or of one register value and immediate value
SUB	0010	subtraction of one register value from another (specifically Rn - Rm)
LSL	1101	shifts register value in Rm left by specified number of bits. has shift type 00
LSR	1101	shifts register value in Rm right by specified number of bits without sign extension. has shift type 01
ASR	1101	shifts register value in Rm right by specified number of bits with sign extension. has shift type 10

## **Assignment**

Your assignment is to implement a binary translator from RISC-V to ARM for a subset of RISC-V assembly instructions. The subset implemented in this lab is not Turing complete because it only consists of arithmetic and logic operators. Once you complete the next lab --- translating conditional operators --- then you will have a Turing-complete set of operators and could as such, theoretically, compute anything with that subset.

### RISC-V Instructions to Translate

The following are all of the RISC-V instructions that you will need to handle in your binary translator. Additional constraints are put on some instructions to ensure simple translation to ARM instructions. In the encoding, s specifies a source register, t a target register, d a destination register and i an immediate value.

Instructi	ion	Encoding	Туре
ANDI	d, s, imm	iiii iiii iiii ssss s111 dddd d001 0011	I
AND	d, s, t	0000 000t tttt ssss s111 dddd d011 0011	R
ORI	d, s, imm	iiii iiii iiii ssss s110 dddd d001 0011	I
0R	d, s, t	0000 000t tttt ssss s110 dddd d011 0011	R
ADDI	d, s, imm	iiii iiii iiii ssss s000 dddd d001 0011	I
ADD	d, s, t	0000 000t tttt ssss s000 dddd d011 0011	R
SUB	d, s, t	0100 000t tttt ssss s000 dddd d011 0011	R
SRAI	d, s, imm	0100 000i iiii ssss s101 dddd d001 0011	I
SRLI	d, s, imm	0000 000i iiii ssss s101 dddd d001 0011	I

SLLI	d, s, imm	0000 000i iiii ssss s001 dddd d001 0011	
SRA	d, s, t	0100 000t tttt ssss s101 dddd d011 0011 R	2
SRL	d, s, t	0000 000t tttt ssss s101 dddd d011 0011 R	3
SLL	d, s, t	0000 000t tttt ssss s001 dddd d011 0011 R	3

RISC-V destination registers should be encoded as Rd s in ARM. For all instructions but shifts, translated source and target registers should be encoded as Rn and Rm respectively.

For shift instructions, the source register should be encoded as Rm and the target register should be encoded within the Shift field as described above.

### **Guarantees and Cautions**

- RISC-V's non bit-shift I type instructions use sign-extended 12-bit immediate values, ARM uses non sign-extended and rotated 8 bit values. To prevent this difference in format from becoming an issue, immediates that appear in the RISC-V code are guaranteed to be non-negative values that fit inside 8 bits given some valid rotation.
- All immediate values used to test immediate-instruction translation and the computeRotation function have a valid ARM translation and fit into the 12 immediate bits of RISC-V I-type instructions
- For RISC-V ADDI instructions the immediate values may be a negative value represented in 2's-complement n. If the immediate value of a RISC-V ADDI instruction is negative, that instruction translated to an ARM SUB instruction.
- A RISC-V SRAI instruction has a non-zero function7 (i.e. bit 30 is 1) which needs to be accounted for when extracting the immediate.
- An ARM Disassembler os provided. It indicates when the status bit is set by adding an S after the instruction type (e.g. ADD S R0, R1, R2). It also indicates when a non-shift data-processing register instruction has a shift by appending LL / LR / AR / RR alongside the shift amount at the very end of the instruction.
- For all inputs used for grading a correct ARM translation fitd into the 2kb's space preallocated in the common.s file.
- If you insert print ecall s to help debug, make sure to remove them before submitting your solution because it may result in lost marks.

### Register Translation

The ARM architecture exposes only 16 registers at a time to its instructions. A fully featured binary translator would need to recompute register allocation, which is beyond the scope of this assignment. Therefore, the translator will assume that only the RISC-V registers below appear in a valid RISC-V program.

RISC-V Register	ARM Register
t0 (x5)	RØ
t1 (x6)	R1
t2 (x7)	R2
s0 (x8)	R3
s1 (x9)	R4
s2 (x18)	R5
s3 (x19)	R6
s4 (x20)	R7
s5 (x21)	R8
s6 (x22)	R9
a0 (x10)	R10
a1 (x11)	R11
a2 (x12)	R12
sp (x2)	R13
ra (x1)	R14

### Specification

You are required to implement the following functions:

• RISCVtoARM\_ALU

This function translates RISC-V code that is stored in memory at address found in a0 into ARM code and stores that ARM code into the memory address found in a1.

- Arguments:
  - a0: pointer to memory containing a RISC-V function. The end of the RISC-V instructions is marked by the sentinel word 0xFFFFFFFF.
  - a1 : a pointer to pre-allocated memory where you will have to write ARM instructions.
- Return Values:
  - a0 : number of bytes that the instructions generated by RISCVtoARM\_ALU occupy.
- translateALU

This function translates a single ALU R-type or I-type instruction into an ARM instruction.

- Arguments:
  - a0 : untranslated RISC-V instruction
- Return Values:
  - a0 : translated ARM instruction.
- translateRegister

This function converts the number of a RISC-V register passed in a0 into the number of a corresponding ARM register.

- Arguments:
  - a0 : RISC-V register to translate.
- Return Values:
  - a0: translated ARM register.
- computeRotation

This function uses the immediate passed in a0 to generate rotate and immediate fields for an ARM immediate instruction. The function treats the immediate as an unsigned number.

- Arguments:
  - a0 : RISC-V immediate in the bottom 20 bits.
- Return Values:
  - a0: rotate in bits 11 to 8 and immediate in bits 7 to 0, with all other bits 0.

## **Testing**

Write short RISC-V programs using the subset of instructions provided, and convert them into binary files using the following command

rars "YOUR\_RISCV\_FILE" a dump .text Binary "YOUR\_DESIRED\_BINARY\_FILE"

The provided common.s (./Code/common.s) file loads RISC-V binary from a file and generates out.bin file after calling the functions specified above. This commons.s file should be included in your arm\_alu.s file. The program, starting in arm\_alu.s , takes the name of the file containing the test to load as an argument. Thus, it can be run using rars arm\_alu.s pa
RISCV\_BINARY\_FILE. The submitted solution must not contain the common.s attached. It also must not contain a main function

This assignment provides the program ARMDisassembler.s (../Code/ARMDisassembler.s) that prints ARM instructions in a textual representation.

The disassembler indicates when the status bit is set by adding an S after the instruction type (e.g. ADD S R0, R1, R2), and indicates when a non-shift data-processing register instruction has a shift by appending LL/LR/AR/RR alongside the shift amount at the very end of the instruction. Make sure to take all of this into account when analyzing the output.

The disassembler is designed to print instructions that follow the specifications. It prints question marks if no valid interpretation is possible.

You are responsible for creating test cases to ensure compliance with the assignment specification.

The disassembler can be run using:

rars ARMDisassembler.s pa out.bin

To view the bytecode contents of the generated out.bin files in a terminal, use the following command:

hexdump out.bin

Not all immediate values can be represented in a single data-processing immediate instruction. Some valid values can be found here (/validNumbers.txt).

Here are some test cases you can use to test your program:

RISC-V Program	RISC-V Binary	ARM Binary	<b>ARM Text Representation</b>
ITypes.s (/Code/testCases/ITypes.s)	ITypes.bin (/Code/testCases/ITypes.bin)	ITypes.out (/Code/testCases/ITypes.out)	ITypes.txt (/Code/testCases/ITypes.txt)
RTypes.s (/Code/testCases/RTypes.s)	RTypes.bin (/Code/testCases/RTypes.bin)	RTypes.out (/Code/testCases/RTypes.out)	RTypes.txt (/Code/testCases/RTypes.txt)
randomCalculation.s (./Code/testCases/randomCalculation.s)	randomCalculation.bin (/Code/testCases/randomCalculation.bin)	randomCalculation.out (/Code/testCases/randomCalculation.out)	randomCalculation.txt (./Code/testCases/randomCalculation.txt)

### Resources

 $More\ information\ about\ ARM\ instruction\ set\ encoding\ can\ be\ found\ here\ (https://developer.arm.com/documentation/ddi0406/cb/Application-Level-Architecture/ARM-Instruction-Set-Encoding).$ 

A PDF version of the GIF embedded in this page can be found here here (/immediate rotation visual.pdf).

 $Slides \ can \ be \ found \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdf) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ as \ a \ PDF \ and \ here \ (../Slides/Lab \ RISC-V \ to \ ARM-ALU.pdx) \ and \ a \ PDF \ and \ and$ 

## Marking Guide

Assignments too short to be adequately judged for code quality will be given a zero. Register translation is vital for all instructions. Therefore it is difficult for a binary translator that does not do correct register translation to pass ANY of the grading test cases. Please, ensure proper register translation according to the table above.

- 30% for correctly translating I-type instructions. 5% will be deducted from this 30% for every I-type instruction you translate incorrectly
- 30% for correctly translating R-type instructions. 5% will be deducted from this 30% for every R-type instruction you translate incorrectly
- $\bullet~10\%$  for correctly translating a RISC-V register into an ARM register
- 10% for correctly computing rotation
- 20% for code cleanliness, readability, and comments

A copy of the marksheet to be used can be found here (/Marksheet.txt). For the instruction translations, an incomplete set of translated instructions can still earn part marks.

## Submission

There is a single file to be submitted for this lab. The file name should be arm\_alu.s and it should contain only the code for the functions specified above. Make sure to not include a main function in your solution. Do not remove .include "common.s" from the top of your solution. To submit, keep the arm\_alu.s file in the Code directory of your submission repo, where the latest commit from the master branch will be marked. Your solution also MUST include the CMPUT 229 Student Submission License (./././CMPUT229-Copyright-student.txt) at the top of the file

containing your solution and you must include your name in the appropriate place in the license text.