Transmitter ID: 104308

```
(Preamble) (Transmitter ID) (PSI) (Battery Status) (Checksum)
```

Transmitter ID: 055872

(Battery)

0000 Good 0010 Low 0001 Critical

(Checksum)

- Ignore the first 2 digits ('00')
- Break the rest of the message into 12 nibbles (4 bit segments), leaving the last 8 bits
- Sum the nibbles to calculate the checksum, place the checksum into the last 8 bits
- Maximum checksum value is 10110100 (or 180 decimal)

(Transmitter ID)

Tx Code	Digit
1010	0
1011	1
1100	2
0011	3
1101	4
0101	5
0110	6
0111	7
1110	8
1001	9