ARCHITECTURE CONCEPTS: HARDWARE FOUNDATIONSFOR MODERN SOFTWARE



What is Computer Architecture?

- The science and art of designing computing platforms
 - -hardware, interface, system SW, and programming model
- Objective
 - Achieve a set of design goals
 - Performance
 - Performance/watt
 - etc













The Computer Engineering Hierarchy

- Plenty of Room
 - -Top: Leiserson et. al.

(expanded view)

• "There's plenty of room at the Top: What will drive computer performance after Moore's law?", Science, 2020

Computer Architecture

Problem Aigorithm Program/Language **System Software** SW/HW Interface Micro-architecture Logic Davicas Electrons

Computer Architecture (narrow view)

The Top

– Bottom: Feynmann

Technology

"There's Plenty of Room at the Bottom: An Invitation to Enter a New Field of Physics", a lecture given at Caltech, 1959 ortunity

Examples

01010011 01100011 01100101 00000000



Hardware architecture

Software

Software performance engineering

Removing software bloat

Tailoring software to hardware features

Algorithms

New algorithms

Hardware streamlining

New problem domains

New machine models

Processor simplification

Domain specialization

The Bottom

for example, semiconductor technology


Image source: https://science.sciencemag.org/content/368/6495/eaam9744



Motivating Example

Matrix Multiplication

```
for i in xrange(4096):
   for j in xrange(4096):
    for k in xrange(4096):
        C[i][j] += A[i][k] *
B[k][j]
```




Implementation	Running time (s)	Absolute speedup
Python	25,552.48	1x
Java	2,372.68	11x
C	542.67	47x
Parallel loops	69.80	366x
Parallel divide and conquer	3.80	6,727x
plus vectorization	1.10	23,224x
plus AVX intrinsics	0.41	62,806x



Motivating Example


Fault Tolerance in Quantum Computing

- Utility before FT
 - Evidence for the utility of quantum computing before fault tolerance
 - Time evolution of a 2D transverse-field line line mode
 - 127 qubit system
 - Demonstrated that a quantum computer can outperform a classical computer.





Scaling: Processor, Memory and Network



Data from Hennessy & Patterson, Morgan Kaufmann, 2nd & 5th eds., 1996 & 2011; D.E. Culler et al., Morgan Kaufmann, 1999.




What drives CA today

- Diversity in applications
 - -Cloud and IoT
- Energy & power constrained systems
- Multiple cores
- Heterogeneous systems-on-chip
- Technology scaling challenges
 - New emerging compute, storage, and communication device technologies



Some Trends



There is plenty of room both at the top and at the bottom but **much more so**

communicate well between and optimize across the top and the bottom



Incredibly Complex

- The Design of a Modern Processor
 - Fighter Plane
 - 10 k Parts
 - Intel Sandy Bridge E
 - 2.27 Billion Transistors
- Design Philosophy
 - Modularity
 - Hierarchy
 - Encapsulation
 - Regularity
 - Extensibility
- Design Patterns
 - Control/Datapath split

Application

Algorithm

PL

OS

ISA

μArch


RTL

Gates

Circuits


Devices

Technology





Fundamental Execution Cycle



Obtain instruction from program storage


Determine required actions and instruction size

Locate and obtain operand data

Compute result value or status


Deposit results in storage for later use

Determine successor instruction





What's a Clock Cycle?



- 10 levels of gates
 - clock propagation, wire lengths, drivers




What is "Computer Architecture"?

Applications


- Coordination of many levels of abstraction
- Under a rapidly changing set of forces

Design, Measurement, and Evaluation






Instruction Set Architecture






The Instruction Set: a Critical Interface

- Properties of a good abstraction
 - Lasts through many generations (portability)
 - -Used in many different ways (generality)
 - Provides convenient functionality to higher levels
 - Permits an efficient implementation at lower levels





Pipelined Instruction Execution





The Memory Abstraction

- Association of <name, value> pairs
 - -typically named as byte addresses
 - often values aligned on multiples of size
- Sequence of Reads and Writes
- Write binds a value to an address
- Read of addr returns most recently written value bound to that address

command (R/W)


address (name)

data (W)

data (R)




Levels of the Memory Hierarchy Upper Level





The Principle of Locality


- The Principle of Locality:
 - Program access a relatively small portion of the address space at any instant of time.
- Two Different Types of Locality:
 - <u>Temporal Locality</u> (Locality in Time): If an item is referenced, it will tend to be referenced again soon (e.g., loops, reuse)
 - Spatial Locality (Locality in Space): If an item is referenced, items whose addresses are close by tend to be referenced soon (e.g., straightline code, array access)
- Last 30 years, HW relied on locality for speed






The Cache Design Space

- Several interacting dimensions
 - cache size
 - block size
 - associativity
 - replacement policy
 - write-through vs write-back



- The optimal choice is a compromise
 - depends on access characteristics
 - workload
 - use (I-cache, D-cache, TLB)
 - depends on technology / cost
- Simplicity often wins





Processor performance equation

CPU time = Seconds = Instructions x Cycles x Seconds
Program Program Instruction Cycle

inst count Cycle time

	Inst Count	CPI	Clock Rate
Program	X		
Compiler	X	(X)	
Inst. Set.	X	X	
Organization		X	X
Technology			X



So, what does performance depend on ...

- #instructions in the program
 - Depends on the compiler



Frequency

- Depends on the transistor technology and the architecture
 - If we have more pipeline stages, then the time to traverse each stage reduces roughly proportionally
 - Given that each stage needs to be processed in one clock cycle, smaller the stage, higher the frequency
 - To increase the frequency, we simply need to increase the number of pipeline stages

IPC

- Depends on the architecture and the compiler
- A large part of this book is devoted to this aspect.



How to improve performance?

- There are **3** factors:
 - -IPC, #instructions, and frequency
 - −#instructions is dependent on the compiler → not on the architecture
- Let us look at IPC and frequency
- IPC

1 if there are no stalls, otherwise < 1

– What is the IPC of an in-order pipeline?

Methods to increase IPC

Forwarding

Having more not-taken branches in the code

Faster instruction and data memories