Introduction to Microcontrollers


Timers and Interrupts

Goals

- Know what a timer is, and what they are used for
- Know what interrupts are, and what they are used for
- Learn how to use interrupts with AVRs
- Learn how to make PWM signals with AVRs

Timers

- Also referred to as counters
- Main objective of a timer is to count
 - Count up
 - Count down
 - Count up then down
 - You name it
- So what is so special about counting?
 - Any thoughts?



The Power of Counting

- Periodic interrupts
 - Maybe a piece of code needs to happen periodically
 - Maybe a delay function that is non-blocking via ticks?
- Time-outs
 - Stop a task if it took to long?
- Waveform measurements
 - Frequency
 - Pulse-width
 - Number of events
- Waveform generation
 - Pulse-width
 - Frequency
- Noise cancellation
 - Maybe debounce a button with a single shot counter?
- This is just the possibility of ONE counter
 - By combining multiple we can create very complex circuits in hardware!

Luis Arias




Definitions

- CNT
 - Counter value Increments every clk_per
- TOP
 - Counter maximum value Overflow when CNT = TOP
 - Alternatively BTM for underflow, but TOP is more used
 - Some AVR peripherals call this PER for period
- CMP
 - Compare Toggle/Clear register CNT = CMP
 - Dependent on timer/counter. If Clear is used, register is set on overflow
 - Often used for waveform generation


Timer as Waveform Generator

- Typically we count UP
 - Reset CNT value on TOP
 - Overflow
- Typically we have one or more CMP registers
 - CMP0, CMP1, ..., CMPn
- Example: PWM
 - Pulse-Width Modulation
 - GPIO is '1' when CNT < CMP
 - GPIO is '0' when CNT > CMP




Timers as Waveform Generator

- PWM
 - Pulse-Width = ON time
 - Duty-Cycle = ON time / OFF time
- Frequency
 - 1/Period
 - Period = ON time + OFF time
- Timer/counter resolution
 - TOP register value determines
 - Frequency
 - Resolution for PWM
 - Not all duty cycles and frequencies can be synthesized
 - Dithering is an option




PWM

- Control external circuits
- Typical uses
 - LED dimming
 - DACs
 - Motor control
 - Voltage regulation
- Can be combined with software to create complex signals
 - Example: Sinusoidal PWM



Gotchas

- Some timer counters have double buffering
 - Registers updated on overflow
 - Makes sure timer always works as intended
- Not all timer counters can do everything
 - They are usually designed for some specific tasks
 - This is why we have so many variants



Timers in AVRs

Many different peripherals

Name

- TCA (Most newer AVRs)
- TCB (All newer AVRs)
- TCD (Some newer AVRs)
- TCE (Few newer AVRs)
- TCF (Few newer AVRs)
- RTC (All newer AVRs)
- ++

Common use

- Waveform generation
- Waveform measurement / Periodic interrupt
- Motor control
- Waveform generation
- Frequency generation
- Periodic interrupt

TCB

- Simplest timer counter
- AVR128DA48
 - 4 instances!
 - TCB0, TCB1, TCB2, TCB3

We will use it for periodic interrupts today

Peripheral Overview

The following table shows the peripheral overview of the entire AVR® DA(S) family. Further documentation describes only the AVR128DA28/32/48/64(S) devices.

Table 2. Peripheral Overview

Feature	AVR128DA28(S) AVR64DA28(S) AVR32DA28(S)	AVR128DA32(S) AVR64DA32(S) AVR32DA32(S)	AVR128DA48(5) AVR64DA48(S) AVR32DA48(S)	AVR128DA64(S) AVR64DA64(S)
Pins	28	32	48	64
Max. Frequency (MHz)	24	24	24	24
16-bit Timer/Counter type A (TCA)	1	1	2	2
16-bit Timer/Counter type B (TCB)	3	3	4	5
12-bit Timer/Counter type D (TCD)	1	1	1	1
Real-Time Counter (RTC)	1	1	1	1
USART	3	3	5	6
SPI	2	2	2	2
TWI/I ² C	1 ⁽¹⁾	2 ⁽¹⁾	2 ⁽¹⁾	2 ⁽¹⁾
12-bit Differential ADC (channels)	1 (10)	1 (14)	1 (18)	1 (22)
10-bit DA(S)C (outputs)	1(1)	1(1)	1(1)	1(1)
Analog Comparator (AC)	3	3	3	3
Zero-Cross Detectors (ZCD)	1	1	2	3

22. TCB - 16-Bit Timer/Counter Type B

22.1 Features

- 16-bit Counter Operation Modes:
 - Periodic interrupt
 - Time-out check
 - Input capture
 - On event
 - Frequency measurement
 - · Pulse-width measurement
 - Frequency and pulse-width measurement
 - 32-bit capture
 - Single-shot
 - 8-bit Pulse-Width Modulation (PWM)
- Noise Canceler on Event Input
- Synchronize Operation with TCAn

- Hardware can stop CPU from executing instructions and jump to a new place in memory and execute from there
 - New piece of code is called an Interrupt Service Routine (ISR)
 - Once ISR is complete, CPU jumps back to where it was previously and continues where it left off
- Perks
 - We can execute code on specific conditions
 - Especially useful for time sensitive operations

- Typical use cases
 - Communication
 - Example: Received data or ready for new data
 - Periodic interrupts
 - Example: Periodic measurements or actions
 - Safety critical hardware
 - Example: Brownout or Watchdog timeout
 - Measurements
 - Example: ADC conversion complete or ADC result above threshold
 - IO
 - Example: Change in IO logic
- AVR Event system
 - Some interrupts can be replaced by hardware in AVRs
 - Example: Start ADC on timer interrupt

- Pro
 - Perfect for time sensitive operations
 - Perfect for system timers
 - Perfect for rare occurrences
 - Do not need to check in main loop
 - Can prevent blocking code

- Con
 - Easy to abuse
 - Jumping from main.c at the wrong time can cause problems
 - Non-atomic instructions
 - Maybe a signal is left on too long?
 - ISR nesting
 - Timing issues
 - Race conditions
 - Deadlock
 - Stack depth

- Rules of thumb
 - Only use interrupts if it makes sense
 - Avoid using them to make things easy
 - Make ISRs short
 - Don't have many instructions in an ISR
 - Typical case: Read some register value, set a flag, clear interrupt, then back to main
 - Don't use interrupts for events that occur too frequently
 - SysTick is an exception
 - May become locked inside ISR
 - Round Robin
- If some interrupts are more time sensitive than others
 - Make them a higher priority!
 - Higher priority ISRs can interrupt other ISRs

- If some parts of your code should not be interrupted disable interrupts before doing these instructions and enable them after
- AVR
 - Global interrupt enable: sei()
 - Global interrupt disable: cli()
 - avr/interrupt.h must be included

Interrupts in practice

Small ISR = OK

Software flag = GOOD

```
volatile uint8_t tcb0_flag = 0;
|int main(void)
    while (1)
        if (tcb0_flag)
            tcb0_flag = 0;
            // Do something
ISR(TCB0_INT_vect)
    // Clear interrupt flag
    TCB0.INTFLAGS = TCB_CAPT_bm;
    // Set software flag
    tcb0_flag = 1;
```

Long ISR and use of functions = BAD

```
ISR(TCB0_INT_vect)
{
    // Clear interrupt flag
    TCB0.INTFLAGS = TCB_CAPT_bm;
    check_adc();
    compute_pid_values();
    check_buttons();
}
```

- LED toggle task
 - No _delay_ms()
 - Instead we use software
- Same as Arduino function millis()
- Non blocking!
- Many tasks can use the same system timer
- Of course we need to configure TCB0 to have an interrupt every 1 ms


```
volatile uint32 t millis = 0;
int main(void)
    uint32 t led millis last = 0, led millis delay = 500;
    while (1)
        // Check if 500 ms has passed
        if ((millis - led millis last) >= led millis delay)
            // Update last millisecond value
            led millis last = millis;
            PORTC.OUTTGL = PIN6 bm;
ISR(TCB0 INT vect)
    // Clear interrupt flag
    TCB0.INTFLAGS = TCB CAPT bm;
    millis++;
```

- To do
 - Select clk_tcb0 = F_CPU/1
 - Select CNTMODE = INT
 - Enable CAPT interrupt
 - Set TOP value
 - TOP = CCMP

22.3.3.1.1 Periodic Interrupt Mode

In the Periodic Interrupt mode, the counter counts to the capture value and restarts from BOTTOM. A CAPT interrupt and event is generated when the CNT is equal to TOP. If TOP is updated to a value lower than CNT, upon reaching MAX, an OVF interrupt and event is generated, and the counter restarts from BOTTOM.

Figure 22-3. Periodic Interrupt Mode



22.4 Register Summary

Offset	Name	Bit Pos.	7	6	5	4	3	2	1	0		
0x00	CTRLA	7:0		RUNSTDBY	CASCADE	SYNCUPD		CLKSEL[2:0]		ENABLE		
0x01	CTRLB	7:0		ASYNC	CCMPINIT	CCMPEN			CNTMODE[2:0			
0x02												
	Reserved											
0x03												
0x04	EVCTRL	7:0		FILTER		EDGE				CAPTEI		
0x05	INTCTRL	7:0							OVF	CAPT		
0x06	INTFLAGS	7:0							OVF	CAPT		
0x07	STATUS	7:0								RUN		
0x08	DBGCTRL	7:0								DBGRUN		
0x09	TEMP	7:0				TEMI	P[7:0]					
0x0A	CNT	7:0				CNT	[7:0]					
OXOA	CIVI	15:8	CNT[15:8]									
0x0C	CCMP	7:0				CCM	P[7:0]					
OXOC	CCIVIF	15:8				CCMF	[15:8]					

- f = (clk_cpu / DIV) / TOP
- TOP = clk_cpu / (DIV * f)
- f = 1000 [Hz] = 1/1000 [s]
- TOP = 4e6 / (1 * 1000) = 4e3
 - This is within the bounds of 16 bits
 - $2^16-1 = 65535$
- Technically 1 clock cycle is used to restart the counter
 - Let's ignore that for now

22.5.10 Capture/Compare

 Name:
 CCMP

 Offset:
 0x0C

 Reset:
 0x00

 Property:

The TCBn.CCMPL and TCBn.CCMPH register pair represents the 16-bit value TCBn.CCMP. The low byte [7:0] (suffix L) is accessible at the original offset. The high byte [15:8] (suffix H) can be accessed at offset $+ 0 \times 01$.

This register has different functions depending on the mode of operation:

- For Capture operation, these registers contain the captured value of the counter at the time the capture occurs
- In Periodic Interrupt, Time-Out Check and Single-Shot mode, this register acts as the TOP value
- In 8-bit PWM mode, TCBn.CCMPL and TCBn.CCMPH act as two independent registers: The period of the waveform is controlled by CCMPL, while CCMPH controls the duty cycle.

Bit	15	14	13	12	11	10	9	8				
	CCMP[15:8]											
Access	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W				
Reset	0	0	0	0	0	0	0	0				
Bit	7	6	5	4	3	2	1	0				
Г	CCMP[7:0]											
Access	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W				
Reset	0	0	0	0	0	0	0	0				

Bits 15:8 - CCMP[15:8] Capture/Compare Value High Byte

These bits hold the MSB of the 16-bit compare, capture and top value.

Bits 7:0 - CCMP[7:0] Capture/Compare Value Low Byte

These bits hold the LSB of the 16-bit compare, capture and top value.

Offset

0x00

0x01 0x02

22.4 Register Summary

Name

CTRLA

CTRLB

Bit Pos.

7:0

7:0

6

RUNSTDBY

ASYNC

CASCADE

CCMPINIT

SYNCUPD

CCMPEN

3

CLKSEL[2:0]

ENABLE

CAPTEI

CAPT

RUN DBGRUN

CNTMODE[2:0]

OVF

OVF

	 0x03 0x04	Reserved	7:0		FILTER		EDGE	
// Set PC6 as output	0x05	INTCTRL	7:0					
•	0x06	INTFLAGS	7:0					
PORTC.DIRSET = PIN6_bm;	0x07	STATUS	7:0					
	0x08	DBGCTRL	7:0					
// Set CNTMODE for TCB	0x09	TEMP	7:0				TEM	P[7:0]
TCBO.CTRLB = TCB CNTMODE INT gc;	0x0A	CNT	7:0				CNT	[7:0]
	UXUA	CIVI	15:8		CNT[15:			
// Enable TCB0 overflow interrupt	0x0C	ССМР	7:0				CCM	P[7:0]
•	UXUC	CCIVIF	15:8				CCMF	P[15:8]
<pre>TCB0.INTCTRL = TCB_CAPT_bm; // Calculate the TCB TOP Value TCB0.CCMP = (uint16_t)(((float)F_CPU // Enable TCB and set clock source to F_CPU TCB0.CTRLA = TCB_CLKSEL_DIV1_gc</pre>		000.0) - 0.5); Alte	ernativel	y set TO	CBO.CCM	IP = 400	00
ICB_ENABLE_DM;								

```
#define F CPU 4000000
#include <avr/io.h>
                                                                      uint32 t led millis last = 0, led millis delay = 500;
#include <avr/interrupt.h>
                                                                      while (1)
volatile uint32_t millis = 0;
                                                                          // Check if 500 ms has passed
jint main(void)
                                                                          if ((millis - led_millis_last) >= led_millis_delay)
    // Set PC6 as output
                                                                              // Update last millisecond value
    PORTC.DIRSET
                   = PIN6 bm;
                                                                              led_millis_last = millis;
    // Set CNTMODE for TCB
                                                                              PORTC.OUTTGL = PIN6 bm;
    TCB0.CTRLB
                    = TCB CNTMODE INT gc;
    // Enable TCB0 overflow interrupt
    TCB0.INTCTRL
                    = TCB_CAPT_bm;
                                                                      ISR(TCB0 INT vect)
    // Calculate the TCB TOP Value
    TCB0.CCMP
                    = (uint16_t)( ((float)F_CPU) / (1000.0) - 0.5 ); {
                                                                          // Clear interrupt flag
    // Enable TCB and set clock source to F_CPU DIV1
                                                                          TCB0.INTFLAGS = TCB_CAPT_bm;
    TCB0.CTRLA
                    = TCB CLKSEL DIV1 gc
                    TCB ENABLE bm;
                                                                          millis++;
    // Set Enable (Global) Interrupts
    sei();
```

- Final task for today
- Use TCA to control a servomotor
- TCA is bit more complicated than TCB
 - Fear not, it is actually not that hard to get going
 - Most of these registers can be ignored for now
- Follow example on github

21.4 Register Summary - Single Mode

Offset	Name	Bit Pos.	7	6	5	4	3	2	1	0
0x00	CTRLA	7:0	RUNSTDBY					CLKSEL[2:0]		ENABLE
0x01	CTRLB	7:0		CMP2EN	CMP1EN	CMP0EN	ALUPD		WGMODE[2:0]	
0x02	CTRLC	7:0						CMP2OV	CMP1OV	CMP0OV
0x03	CTRLD	7:0								SPLITM
0x04	CTRLECLR	7:0					CM	D[1:0]	LUPD	DIR
0x05	CTRLESET	7:0					CM	D[1:0]	LUPD	DIR
0x06	CTRLFCLR	7:0					CMP2BV	CMP1BV	CMP0BV	PERBV
0x07	CTRLFSET	7:0					CMP2BV	CMP1BV	CMP0BV	PERBV
0x08	Reserved									
0x09	EVCTRL	7:0		EVACTB[2:0]		CNTBEI		EVACTA[2:0]		CNTAEI
0x0A	INTCTRL	7:0		CMP2	CMP1	CMP0				OVF
0x0B	INTFLAGS	7:0		CMP2	CMP1	CMP0				OVF
0x0C 0x0D	Reserved									
0x0E	DBGCTRL	7:0								DBGRUN
0x0F	TEMP	7:0				TEM	P[7:0]			
0x10 0x1F	Reserved									
0x20	CNT	7:0					[7:0]			
		15:8				CNT[[15:8]			
0x22 0x25	Reserved									
0x26	PER	7:0				PER	[7:0]			
UX26	PER	15:8				PER[15:8]			
0x28	CMP0	7:0				CMP	[7:0]			
UX28	CIVIFO	15:8				CMP	[15:8]			
0x2A	CMP1	7:0				CMP	[7:0]			
UXZA	CIVIFI	15:8				CMP	[15:8]			
0x2C	CMP2	7:0				CMP	[7:0]			
UX2C	CIVIP2	15:8				CMP	[15:8]			
0x2E										
 0x35	Reserved									
0x36	PERBUF	7:0					JF[7:0]			
		15:8					F[15:8]			
0x38	CMPOBUF	7:0					UF[7:0]			
0,30	Cimi ODOI	15:8					JF[15:8]			
0x3A	CMP1BUF	7:0					UF[7:0]			
UNJ/	Cim Tool	15:8				CMPBU	JF[15:8]			
0x3C	CMP2BUF	7:0					UF[7:0]			
OASC	Citil ZDOF	15:8				CMPBU	JF[15:8]			

- Controlling a servo motor
 - Pulse-Width controlled
 - On-time determines position
 - Dependent on servomotor
 - Typically 1000us to 2000us
 - For our servo this is 500us to 2500us
 - Pulse repetition
 - Usually 20 ms = 50 Hz
- Our servomotor has three pins
 - 5V
 - GND
 - SIG This is the PWM signal that controls the position

		Selection (Guide for Clu	tch Servo		
Model	6kg 180°	6kg 300°	9g 180°	9g 300°	2kg 180°	2kg 300°
sku	SER0051	SER0057	SER0049	SER0053	SER0050	SER0056
Operating Voltage	4.8-6VDC	4.8-6V DC	4.8-6V DC	4.8-6V DC	4.8-6V DC	4.8-6V DC
Quiescent Current	≤10mA at 6.0V	≤10mA at 6.0V	≤8mA at 6.0V	≤8mA at 6.0V	≤8mA at 6.0V	≤8mA at 6.0V
No-load Curren	≤60mA at 6.0V	≤60mA at 6.0V	≤50mA at 4.8V ≤60mA at 6.0V	≤50mA at 4.8V ≤60mA at 6.0V	≤110mA at 4.8V ≤120mA at 6.0V	≤110mA at 4.8V ≤120mA at 6.0V
Stall Current	≤1.65A at 6.0V	≤1.65A at 6.0V	≤550mA at 4.8V ≤650mA at 6.0V	≤550mA at 4.8V ≤650mA at 6.0V	≤700mA at 4.8V ≤800mA at 6.0V	≤700mA at 4.8V ≤800mA at 6.0V
Rated Torque	≥4.4kg.com at 6.0V	≥4.4kg.com at 6.0V	≥0.32kgf·cm at 4.8V ≤0.4kgf·cm at 6.0V	≥0.32kgf·cm at 4.8V ≤0.4kgf·cm at 6.0V	≥0.45kgf·cm at 4.8V ≥0.55kgf·cm at 6.0V	≥0.45kgf·cm at 4.8V ≥0.55kgf·cm at 6.0V
Stall Torque	≥6kg·cm at 6.0V	≥6kg·cm at 6.0V	≥1.0kgf·cm at 4.8V ≤1.2kgf·cm at 6.0V	≥1.0kgf·cm at 4.8V ≤1.2kgf·cm at 6.0V	≥1.6kgf·cm at 4.8V ≥2.0kgf·cm at 6.0V	≥1.6kgf·cm at 4.8V ≥2.0kgf·cm at 6.0V
Operating Angle	180°±10°	300°±10°	180°±10°	300°±10°	180°±10°	300°±10°
Pulse Width Range	500~2500μs	500~2500μs	500~2500μs	500~2500μs	500~2500μs	500~2500μs
Communication Mode	PWM	PWM	PWM	PWM	PWM	PWM

- We know
 - Period = 20 ms = 50 Hz
 - On time = 500 to 2500 us
- To get the best resolution we need to have a large TOP value
 - TOP = f_clk_tca / f_pwm
 - For f_clk_tca = 4 MHz we get: 4e6 / 50 = 80000 This is larger than 2^16!!!
 - For f_clk_tca = 2 MHz we get 40000 < 2^16
- Prescaler value must be 2 when F_CPU = 4 MHz
- TOP must be 40000

Now for ON time

- 1000 us = 2000 Hz
 - CMP = 2 MHz / 2000 Hz = 1000
- 2000 us = 400 Hz
 - CMP = 2 MHz / 400 Hz = 5000
- General formula
 - duty cycle = 0 to 100
 - CMP = duty_cycle*((5000-1000)/100) + 1000
 - Simplify: CMP = duty_cycle*40 + 1000
 - Sanity check

$$0\% = 0 * 40 + 1000 = 1000$$

 $50\% = 50 * 40 + 1000 = 3000$
 $100\% = 100 * 40 + 1000 = 5000$

- Create a function that solves CMP value
 - TCA can use double buffering
 - By using double buffering the PWM signal is always valid

```
void servo_set(uint8_t duty_cycle)
{
    // Optional guard
    if (duty_cycle > 100)
    {
        duty_cycle = 100;
    }

    // Calculate compare value
    uint16_t cmp = duty_cycle * 40 + 1000;

    // Update CMPxBUF register. CMPx register us updated by buffer on overflow
    // This ensures that the pulse on time is always valid
    TCA0.SINGLE.CMP0BUF = cmp;
}
```


TCA is a unique peripheral as its registers are different depending on if it is in SPLIT mode, or SINGLE mode! We must therefore use TCAx.SINGLE.PERIPHERAL

- Setup
 - Calculate and set TOP value (PER)
 - Already calculated!
 - Pin override enable (CTRLB)
 - Make sure TCA can override OUT value for a physical pin
 - Set TCA to PWM mode (CTRLB)
 - WGMODE bits
 - Select prescaler value (CTRLA)
 - CLKSEL bits
 - Enable TCA instance (CTRLA)
 - ENABLE bit

21.4 Register Summary - Single Mode

0x01 CTRLB 7:0 CMP2EN CMP1EN CMP0EN ALUPD WGMODE[2:0] 0x02 CTRLC 7:0 CMP2OV CMP1OV CMP0OV 0x03 CTRLD 7:0 CMD[1:0] LUPD DIR 0x04 CTRLESET 7:0 CMD[1:0] LUPD DIR 0x05 CTRLESET 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x06 CTRLFSET 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x08 Reserved 0x08 EVCTRL 7:0 EVACTB[2:0] CNTBEI EVACTA[2:0] CNTAEI 0x0A INTCTRL 7:0 CMP2 CMP1 CMP0 OVF 0x0C Reserved OXD CMP1 CMP0 OVF	Offset	Name	Bit Pos.	7	6	5	4	3	2	1	0
Ox02	0x00	CTRLA	7:0	RUNSTDBY					CLKSEL[2:0]		ENABLE
0x03 CTRLD 7:0 SPLITM 0x04 CTRLECLR 7:0 CMD[1:0] LUPD DIR 0x05 CTRLESET 7:0 CMD[1:0] LUPD DIR 0x06 CTRLFCLR 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x07 CTRLFSET 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x08 Reserved CMP2 CMP1 CMP2BV CMP1BV CMP0BV PERBV 0x09 EVCTRL 7:0 EVACTB[2:0] CNTBEI EVACTA[2:0] CNTAEI 0x0A INTCTRL 7:0 CMP2 CMP1 CMP0 OVF 0x0C Reserved OVF OVF OVF OVF 0x0D DBGCTRL 7:0 TEMP[7:0] TEMP[7:0] OVE OVE 0x1D Reserved CNT[15:8]	0x01	CTRLB	7:0		CMP2EN	CMP1EN	CMP0EN	ALUPD		WGMODE[2:0]	
0x04 CTRLECLR 7:0 CMD[1:0] LUPD DIR 0x05 CTRLESET 7:0 CMD[1:0] LUPD DIR 0x06 CTRLFCLR 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x07 CTRLFSET 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x08 Reserved CMP2 CMP1 CMP0 CNTAEI CNTAEI 0x0A INTCTRL 7:0 CMP2 CMP1 CMP0 OVF 0x0B INTFLAGS 7:0 CMP2 CMP1 CMP0 OVF 0x0C Reserved OXOB TEMP(7:0] DBGRUN 0x0F TEMP 7:0 TEMP(7:0] CNT[7:0] 0x1G CNT[7:0] CNT[15:8] 0x2D Reserved CNT[15:8] 0x2D Reserved CNT[7:0] 0x2D CNT CNT[7:0] 0x2D <t< td=""><td>0x02</td><td>CTRLC</td><td>7:0</td><td></td><td></td><td></td><td></td><td></td><td>CMP2OV</td><td>CMP1OV</td><td>CMP0OV</td></t<>	0x02	CTRLC	7:0						CMP2OV	CMP1OV	CMP0OV
0x05 CTRLESET 7:0 CMD[1:0] LUPD DIR 0x06 CTRLFCLR 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x07 CTRLFSET 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x08 Reserved CMP2BV CMP1BV CMP0BV PERBV 0x09 EVCTRL 7:0 EVACTB[2:0] CNTAEI EVACTA[2:0] CNTAEI 0x0A INTCTRL 7:0 CMP2 CMP1 CMP0 OVF 0x0C Reserved OVF OVF OVF 0x0E DBGCTRL 7:0 CMP2 CMP1 CMP0 DBGRUN 0x1D Reserved CNT[7:0] CNT[7:0] CNT[7:0] 0x1F Reserved CNT[15:8] CNT[15:8] CNT[15:8] 0x22 Reserved PER 7:0 PER[7:0]	0x03	CTRLD	7:0								SPLITM
0x06 CTRLFCLR 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x07 CTRLFSET 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x08 Reserved CMP1BV CMP1BV CMP0BV PERBV 0x09 EVCTRL 7:0 EVACTB[2:0] CNTBEI EVACTA[2:0] CNTAEI 0x0A INTCTRL 7:0 CMP2 CMP1 CMP0 OVF 0x0B INTFLAGS 7:0 CMP2 CMP1 CMP0 OVF 0x0B DBGCTRL 7:0 TEMP[7:0] DBGRUN 0x1D Reserved TEMP[7:0] CNT[7:0] 0x1D TEMP 7:0 CNT[7:0] 0x2D CNT TS:8 CNT[15:8] 0x2D Reserved TS:8 CNT[15:8]	0x04	CTRLECLR	7:0					CME	[1:0]	LUPD	DIR
0x07 CTRLFSET 7:0 CMP2BV CMP1BV CMP0BV PERBV 0x08 Reserved 0x09 EVCTRL 7:0 EVACTB[2:0] CNTBEI EVACTA[2:0] CNTAEI 0x0A INTERING 7:0 CMP2 CMP1 CMP0 OVF 0x0B DBGCTRL 7:0 CMP2 CMP1 CMP0 DBGRUN 0x0F TEMP 7:0 CNT[7:0] 0x1D Reserved 0x1F Ox20 CNT 7:0 CNT[15:8] 0x22 Reserved 0x25 PER[7:0]	0x05	CTRLESET	7:0					CME	[1:0]	LUPD	DIR
0x08 Reserved 0x09 EVCTRL 7:0 EVACTB[2:0] CNTBEI EVACTA[2:0] CNTAEI 0x0A INTCRL 7:0 CMP2 CMP1 CMP0 OVF 0x0B INTELAGS 7:0 CMP2 CMP1 CMP0 OVF 0x0C Reserved Reserved DBGRUN 0x0F TEMP 7:0 TEMP[7:0] 0x10 Reserved CNT[7:0] 0x1F CNT[15:8] CNT[15:8] 0x22 Reserved 0x25 PER 7:0 PER[7:0]	0x06	CTRLFCLR	7:0					CMP2BV	CMP1BV	CMP0BV	PERBV
0x09 EVCTRL 7:0 EVACTB[2:0] CNTBEI EVACTA[2:0] CNTAEI 0x0A INTCTRL 7:0 CMP2 CMP1 CMP0 OVF 0x0B INTFLAGS 7:0 CMP2 CMP1 CMP0 OVF 0x0C Reserved Reserved DBGCTRL 7:0 DBGRUN 0x10 Reserved Reserved CNT[7:0] CNT[7:0] 0x20 CNT T5:8 CNT[15:8] CNT[15:8] 0x22 Reserved PER 7:0 PER[7:0]	0x07	CTRLFSET	7:0					CMP2BV	CMP1BV	CMP0BV	PERBV
0x0A INTCTRL 7:0 CMP2 CMP1 CMP0 OVF 0x0B INTFLAGS 7:0 CMP2 CMP1 CMP0 OVF 0x0C Reserved Reserved OVF OVF OVF 0x0E DBGCTRL 7:0 TEMP[7:0] TEMP[7:0] OVF	0x08	Reserved									
0x0B INTFLAGS 7:0 CMP2 CMP1 CMP0 OVF 0x0C Reserved 0x0D DBGCTRL 7:0 DBGRUN 0x0F TEMP 7:0 TEMP[7:0] TEMP[7:0] 0x10 Reserved CNT[7:0] CNT[7:0] 0x20 CNT 15:8 CNT[15:8] 0x22 Reserved PER[7:0]	0x09	EVCTRL	7:0		EVACTB[2:0]		CNTBEI		EVACTA[2:0]		CNTAEI
0x0C Reserved 0x0D 0x0E DBGCTRL 7:0 DBGRUN 0x0F TEMP 7:0 TEMP[7:0] 0x10 Reserved Reserved CNT[7:0] 0x20 CNT 7:0 CNT[15:8] CNT[15:8] 0x22 Reserved Reserved PER[7:0]	0x0A	INTCTRL	7:0		CMP2	CMP1	CMP0				OVF
Reserved	0x0B	INTFLAGS	7:0		CMP2	CMP1	CMP0				OVF
0x0F TEMP 7:0 TEMP[7:0] 0x10 Reserved CNT[7:0] 0x1F 7:0 CNT[7:0] 0x20 CNT 15:8 CNT[15:8] 0x22 Reserved Reserved PER[7:0]		Reserved									
0x10 Reserved 0x1F 7:0 CNT[7:0] 0x20 15:8 CNT[15:8] 0x22 Reserved 0x25 7:0 PER[7:0]	0x0E	DBGCTRL	7:0								DBGRUN
Reserved 0x1F 0x20	0x0F	TEMP	7:0				TEM	P[7:0]			
0x20 CNT 15:8 CNT[15:8] 0x22 Reserved 0x25 PER 7:0 PER[7:0]		Reserved									
15:8 CNT[15:8] 0x22 Reserved 0x25 0x26 PER 7:0 PER[7:0]	0×20	CNT	7:0				CNT	[7:0]			
Reserved 0x25 7:0 PER[7:0]	0.00	CIVI	15:8				CNT[[15:8]			
0x26 PER		Reserved									
15:8 PER[15:8]	0x26	PER	7:0				PER	[7:0]			
	UXZU	PER					_	-			


- Find which pins are physically connected to a TCA instance
- Development board pinout
 - PD0 PD2 are optional connections (Multiplexed)
- Default connections
 - PA0 PA2
 - We will use PA0
- WOn
 - WO0, WO1, WO2 available in all modes
 - WO3, WO4, WO5 available ONLY in SPLIT mode



VQFN64/ TQFP64	VQFN48/ TQFP48	VQFN32/ TQFP32	SOIC28/ SOIC28/	Pin name (1,2)	Spedal	ADC0	PTC	ACı	DACO	ZCDn	USARTn	SPIn	TWIn(4)	TCA0	ξĪ	TCBn	TCD	EVSYS	CCL-LUTIN
62	44	30	22	PA0	EXTCLK		XO/Y0				0,TxD			WO0					0,IN0
63	45	31	23	PA1			X1/Y1				0,RxD			WO1					0,IN1
64	46	32	24	PA2	TWI		X2/Y2				0,XCK		0,SDA(H)	WO2		0,WO		EVOUTA	0,IN2
1	47	1	25	PA3	TWI		X3/Y3				0,XDIR		0,SCL(H)	WO3		1,WO			0,OUT
2	48	2	26	PA4			X4/Y4				0,TxD ⁽³⁾	0,MOSI		WO4			0,WOA		
3	1	3	27	PA5			X5/Y5				0,RxD(3)	0,MISO		WO5			0,WOB		
4	2	4	28	PA6			X6/Y6				0,XCK ⁽³⁾	0,SCK					0,WOC		0,OUT ⁽³⁾
5	3	5	1	PA7	CLKOUT		X7/Y7	0,OUT 1,OUT 2,OUT		0,OUT 1,OUT 2,OUT	0,XDIR ⁽³⁾	0,55					0,WOD	EVOUTA (3)	
6				VDD															
7				GND															
8	4			PB0			X8/Y8				3,TxD			MO0(3)	WO0				4,IN0
9	5			PB1			X9/Y9				3,RxD			WO1 ⁽³⁾	WO1				4,IN1
10	6			PB2			X10/Y10				3,XCK		1,SDA(H) ⁽³⁾	WO2 ⁽³⁾	WO2			EVOUTB	4,IN2
- 11	7			PB3			X11/Y11				3,XDIR		1,SCL(H) ⁽³⁾	WO3 ⁽³⁾	WO3				4,OUT
12	8			PB4			X12/Y12				3,TxD ⁽³⁾	1,MOSI ⁽³⁾		WO4 ⁽³⁾	WO4	2,WO ⁽³⁾	0,WOA ⁽³⁾		
13	9			PB5			X13/Y13				3,RxD(3)	1,MISO(3)		WO5(3)	WO5	3,WO	0,WOB(3)		
14				PB6			X14/Y14				3,XCK ⁽³⁾	1,SCK ⁽³⁾	1,SDA(C) ⁽³⁾				0,WOC ⁽³⁾		4,OUT ⁽³⁾
15				PB7			X15/Y15				3,XDIR ⁽³⁾	1, SS⁽³⁾	1,SCL(C) ⁽³⁾				0,WOD(3)	EVOUTB (3)	
16	10	6	2	PC0							1,TxD	1,MOSI		WO0(3)		2,WO			1,IN0
17	11	7	2	DC1							1 DvD	1 MICO		WO1(3)		2 MO(3)			1 1811


- TCA0 is used
 - We use TCA0 in SINGLE mode
 - Only WO0, WO1, WO2 available
 - We can connect three servomotors because WO0, WO1, WO2 are independent!
 - Let us connect to WOO

Figure 4-1. AVR128DA48 Curiosity Nano Pinout



- Connect servo
 - VBUS to Supply pin (RED)
 - VBUS is always 5.0 V
 - GND to GND (BROWN)
 - Control signal to PAO (YELLOW)
- GPIO setup
 - Make PAO an OUTPUT
 - Set DIR register
 - For TCA0 to override PA0 we must set CMP0EN in TCA0.CTRLB

Figure 4-1. AVR128DA48 Curiosity Nano Pinout




21.5.2 Control B - Normal Mode

 Name:
 CTRLB

 Offset:
 0x01

 Reset:
 0x00

 Property:



Bits 4, 5, 6 - CMPEN Compare n Enable

In the FRQ and PWM Waveform Generation modes, the Compare n Enable (CMPnEN) bits will make the waveform output available on the pin corresponding to WOn.

Value	Description
0	Waveform output WOn will not be available on the corresponding pin
1	Waveform output WOn will override the output value of the corresponding pin

- To Do
 - Set PA0 as output
 - PER
 - Set period
 - CTRLB
 - Enable pin override on PAO
 - Set waveform mode to PWM single-slope
 - Only up-count
 - CTRLA
 - Set clock to F_CPU / 2
 - Enable TCA0

Bits 2:0 - WGMODE[2:0] Waveform Generation Mode

This bit field selects the Waveform Generation mode and controls the counting sequence of the counter, TOP value, UPDATE condition, interrupt condition, and the type of waveform generated. No waveform generation is performed in the Normal mode of operation. The waveform generator output will only be directed to the port pins if setting the corresponding CMPnEN bit for all other modes. The port pin direction must be set as output.

Table 21-7. Timer Waveform Generation Mode

Value	Group Configuration	Mode of Operation	TOP	UPDATE	OVF
0x0	NORMAL	Normal	PER	TOP(1)	TOP(1)
0x1	FRQ	Frequency	CMP0	TOP(1)	TOP(1)
0x2	-	Reserved	-	-	-
0x3	SINGLESLOPE	Single-slope PWM	PER	воттом	BOTTOM
0x4	-	Reserved	-	-	-
0x5	DSTOP	Dual-slope PWM	PER	воттом	TOP
0x6	DSBOTH	Dual-slope PWM	PER	воттом	TOP and BOTTOM
0x7	DSBOTTOM	Dual-slope PWM	PER	воттом	BOTTOM

```
void servo setup()
    #define TCA CLKDIV 2
    #define TCA FREQ 50.0
   // Calculate TOP value for TCA
    TCA0.SINGLE.PER
                       = (uint16\ t)(((float)F\ CPU)/((float)TCA\ CLKDIV))/TCA\ FREQ - 0.5);
                       = TCA SINGLE CMP0EN bm
    TCA0.SINGLE.CTRLB
                                                           // Enable pin override on CMP0 - WO0 - PD0
                        TCA SINGLE WGMODE SINGLESLOPE gc; // TCA0 in PWM mode (Single slope)
                       = TCA_SINGLE_CLKSEL_DIV2_gc
    TCA0.SINGLE.CTRLA
                                                           // Set F TCA = F CPU/2
                        TCA_SINGLE_ENABLE_bm;
int main(void)
    PORTA.DIRSET
                   = PIN0 bm;
    servo_setup();
```

- Test Servo motor!
 - Let the motor operate in peace
 - Otherwise the fuse on the development board may pop

- Optional tasks:
 - Connect enable servo motor control on another GPIO
 - Make the servo change position on button press

```
int main(void)
    PORTA.DIRSET
                    = PIN0 bm;
    servo_setup();
    while (1)
       servo_set(0); // Servo 0%
       _delay_ms(500);
       servo_set(50); // Servo 50%
       _delay_ms(500);
       servo_set(100); // Servo 100%
       _delay_ms(500);
```

Next time

- Learn how to use a basic sensor
- Learn how to use SPI to connect to other devices
- Focus on hands-on experience from next session

Questions?