



OPERATION WORK INSTRUCTIONS

PW 125

SHEARLINE

PILER Manual Piler 2 End stopper Adv and Ret operation

Page 1 of 2

No.	INSTRUCTIONS	KEY POINTS / CONTACTS
		<ul style="list-style-type: none"> + ENSURE PERSONNAL PROTECTIVE EQUIPMENT (PPE) IS WORN IN THIS AREA: <ol style="list-style-type: none"> 1 HARD HAT 2 STEEL CAP SHOES / BOOTS <p>PILER</p>
1		<p>If No fault conditions are present the Master On indication lamp will be ON.</p>
2	<p>For Any manual operation the manual button must be selected on the operator screen</p>	<p>This display can be found on the Piler Operator station</p>



OPERATION WORK INSTRUCTIONS

PW 125

SHEARLINE

PILER Manual Piler 2 End stopper Adv and Ret operation

Page 2 of 2

3		<p>There can only be one manual operation selected at a time.</p> <p>This will prevent any damage to equipment.</p> <p>The current display show NO.2 Piler</p> <p>Page1/4</p>
4	<p>A Select End Stopper operation switch. The switch will turn white when selected.</p> <p>B After selecting the End Stopper operation button the F1 push button can be pushed to move the end stopper forward.</p> <p>C To reverse the End stopper the F2 push button key must be used.</p>	<p>« Operation Switches »</p> <p>Note: During the ADV and RET operation the ADV or RET indication will flash. When the front stopper is fully ADV or fully RET the indication will be continuous.</p>

Prepared by: D.Botha