

ASSEMBLY INSTRUCTIONS:

- 1. Find a flat, level surface.
- 2. Place your chimenea on metal base.
- 3. Ensure base is stable and chimenea is aligned with the base.

Estimated assembly time: 3 minutes

Recommendations for Handling

General tips:

- · For OUTDOOR USE ONLY.
- · Apply a waterproof concrete sealer for added protection.
- · Keep a fire extinguisher nearby but never extinguish fire with water.
- · Supervise around children and pets.
- · Never leave fire unattended.
- · Avoid touching the Chimenea while in use.
- · Ensure Chimenea is dry before use.

Handling:

- · Terracotta is fragile; avoid dropping or banging it.
- · Carry Chimenea by gripping the mouth and supporting the neck-bowl junction.
- Alternatively, lift from the base with care and place on the iron stand.

Location:

 Place your Chimenea on a level, non-flammable surface, away from anything that could catch fire.

General Maintenance:

 Keep your Chimenea covered when not in use to prevent water damage. In freezing temperatures, store it indoors or cover it with a plastic cover.

Prepare for Use:

- Insulate the bowl with sand or pea stone, leaving 3-4 inches below the mouth's lower lip.
- · Use two bricks as a grate to elevate wood.
- Start with small fires to season your Chimenea, using kindling or fat wood.
- · Avoid using lighter fluid or any flame enhancers.
- Once seasoned, you can burn larger fires, but keep them controlled and centered to prevent damage. Remember, Chimeneas are for small fires and not as primary heat sources.