

PACKAGE CONTENTS:

- 1 Clay Chimney (A)
- 1 Clay Body (B)
- 1 Metal Stand (C) MADE IN MEXICO

ASSEMBLY INSTRUCTIONS:

- 1. Find a flat, level surface.
- 2. Place clay body (B) on metal base (C), ensuring the ridge aligns with the base.
- 3. Then, place clay chimney (A) on top of body (B). Estimated assembly time: 3 minutes

Recommendations for Handling

General tips:

- For OUTDOOR USE ONLY.
- Apply a waterproof concrete sealer for added protection.
- Keep a fire extinguisher nearby but never extinguish fire with water.
- Supervise around children and pets.
- Never leave fire unattended.
- Avoid touching the Chimenea while in use.
- Ensure Chimenea is dry before use.

Handling:

- Terracotta is fragile; avoid dropping or banging it.
- Carry Chimenea by gripping the mouth and supporting the neck-bowl junction.
- Alternatively, lift from the base with care and place on the iron stand.

Location:

• Place your Chimenea on a level, non-flammable surface, away from anything that could catch fire.

General Maintenance:

• Keep your Chimenea covered when not in use to prevent water damage. In freezing temperatures, store it indoors or cover it with a plastic cover.

Usage:

- Insulate the bowl with sand or pea stone, leaving 3-4 inches below the mouth's lower lip.
- Use two bricks as a grate to elevate wood.
- Start with small fires to season your Chimenea, using kindling or fat wood.
- Avoid using lighter fluid or any flame enhancers.
- Once seasoned, you can burn larger fires, but keep them controlled and centered to prevent damage. Remember, Chimeneas are for small fires and not as primary heat sources.