













*If you're using 5V you can optionally skip the 3.3~5V step-up. In that case, break the default solder connection in the jumper, and then solder the other terminal. You don't have to solder the two resistors at the collector of the NPN transistor, nor the NPN transistor.

Predator numbers Company: rogermiranda1000

◇嘉立创EDA

TITLE:

Sheet: 2/3 Drawn By: Roger Miranda Date: 2023-04-28

REV: 2.0

