SKETCH-N: A NODAL NEUTRON DIFFUSION CODE FOR SOLVING STEADY-STATE AND KINETICS PROBLEMS

VOL. II. USER GUIDE

Vyacheslav G. Zimin, Vladislav. I. Romanenko

July 29, 2025

Contents

	Abstract	6
	Acknowledgments	10
1	Introduction	11
2	Installation	13
2.1	Obtaining the source code	. 13
2.2	Compiling and Linking the Code	. 13
3	Starting the program	15
3.1	Parameters in the include file "parameters.fh"	. 15
3.2	Input Data in the Namelist File "SKETCH.INI"	. 17
3.3	Input Data in the SKETCH-N Input file	. 23
	3.3.1 General Reactor Model Data	. 24
	3.3.2 Macro Cross Section Data	. 24
	3.3.3 Geometry Description	. 31
	3.3.4 Control Rod Description	. 35
	3.3.5 Data for Internal Thermal-Hydraulics Model	. 39
3.4	Input Data for Calculations with an External Thermal-Hydraulics Mode	l 41
3.5	Output into the Text File "SKETCH.lst"	. 46
3.6	Output into the Binary File "SKETCH.grf"	. 49
3.7	Postprocessing of the SKETCH-N results	. 50
	3.7.1 Output of the Data versus Time	. 52
	3.7.2 Output of the Data at the Certain Time Moment	. 56
	3.7.3 Output of the Static Distributions	60

4	2D four-group KOEBERG PWR benchmark	62
4.1	Benchmark Problem Description	. 62
4.2	Include and Input Files	. 65
4.3	Steady-State Calculation and Output Files	. 67
5	3D NEACRP PWR rod ejection benchmark, case A1	69
5.1	Benchmark Problem Description	. 69
5.2	Include File "pwr_neacrp_a1.fh"	. 77
5.3	Input Files for the Steady-State Calculation	. 78
5.4	Steady-State Calculation and Output Files	. 79
5.5	Input Files for the Transient Calculation	. 80
5.6	Transient Calculation and Output Files	. 81
5.7	Postprocessing the Transient Results	. 82
6	Modified IAEA-2D Test Without Reflector	87
7	Conclusion	93
	Bibliography	94
A	2D FOUR-GROUP KOEBERG PWR BENCHMARK	98
A.1	CONTENT OF THE INCLUDE FILE	
	"KOEBERG2D.FH"	. 98
A.2	CONTENT OF THE INPUT NAMELIST FILE	
	"SKETCH.INI.KOEBERG2D.ST"	.102
A.3	CONTENT OF THE INPUT FILE	
	"KOEBERG2D.DAT"	. 106
A.4	CONTENT OF THE INPUT FILE WITH THE REFERENCE	
	SOLUTION "KOEBERG2D.REF"	.111
A.5	CONTENT OF THE OUTPUT FILE	
	"COMPARISON.DAT"	.112
В	3D NEACRP PWR ROD EJECTION BENCHMARK	115
B.1	CONTENT OF THE INCLUDE FILE	
	"PWR_NEACRP_A1.FH"	.115

B.2	CONTENT OF THE INPUT NAMELIST FILE	
	"SKETCH.INI.PWR_A1.ST"	. 119
B.3	CONTENT OF THE INPUT FILE	
	"PWR_NEACRP_A1.DAT"	. 123
B.4	CONTENT OF THE INPUT NAMELIST FILE	
	"SKETCH.INI.PWR_A1.KIN"	. 137
B.5	CONTENT OF THE POSTPROCESSOR INPUT NAMELIST FILE	
	"POSTPROC.INI.PWR_A1_KIN"	. 142
B.6	CONTENT OF THE POSTPROCESSOR INPUT DATA FILE	
	"PP_PWR_A1_KIN.DAT"	. 143
	Modified IAEA-2D Test Without Reflector	144
C.1	CONTENT OF THE INCLUDE FILE	
	"vver_iaea2d_nor.fh"	. 144
C.2	CONTENT OF THE INPUT NAMELIST FILE	
	"SKETCH.INI.VVER_IAEA2D_NOR_125.ST"	. 148
C.3	CONTENT OF THE INPUT FILE	
	"VVER_IAEA2D_NOR_125.DAT"	152
Li	st of Figures	
3	3.1 An example of the axial meshes in the TRAC and SKETCH-N code	42
1	4.1 Core configuration of the four-group KOEBERG PWR benchmark.	63
	4.2 Reference power distribution and eigenvalue for KOEBERG PWR	0.0
7	benchmark	. 65
	Delichinark	0.0
5	5.1 Core loading by assembly types for 3D NEACRP PWR rod ejection	
	benchmark, case A1	. 71
5	5.2 Core loading by control assembly types for 3D NEACRP PWR rod	
	ejection benchmark, case A1	. 72

5.3	Initial positions of the control assemblies for 3D NEACRP PWR rod ejection benchmark, case A1	76
5.4	Power and reactivity versus time for 3D NEACRP PWR rod	70
0.4	ejection benchmark, case A1	8/1
5.5	Time step size used by the SKETCH-N code for 3D NEACRP PWR	04
0.0	rod ejection benchmark, case A1	85
5.6	Average Doppler fuel temperature versus time for 3D NEACRP	00
0.0	PWR rod ejection benchmark, case A1	85
5.7	Maximum fuel centerline temperature versus time for 3D NEACRP	00
0.1	PWR rod ejection benchmark, case A1	86
	1 Wit for ejection benchmark, case A1	00
6.1	Core loading for the modified IAEA-2D test problem	88
6.2	Calculation results for the modified IAEA-2D test without reflector,	
	$\gamma = 0.125 \dots \dots$	91
6.3	Calculation results for the modified IAEA-2D test without reflector,	
	$\gamma = 0.5$	92
List	t of Tables	
3.1	Parameters describing the reactor geometry.	
3.2	Parameters describing the reactor core geometry	
3.3	Parameters describing the macro cross sections.	
3.4	Parameters describing the control rods	
3.5	Parameters used by internal thermal-hydraulics model	17
3.6	Parameters used for calculations with an external thermal-	
	hydraulics model	17
3.7	Variables defining a type of the problem and solution methods in	
	the namelist INT_PROBLEM	19

3.8	Names of the input, output and restart files defined in the namelist INT FILES.	20
3.9	Convergence criteria defined in the namelist INI CHEBYSHEV	21
	Parameters of the Chebyshev iterations defined in the namelist	∠ ⊥
5.10	INI CHEBYSHEV.	22
2 11	Time step size data defined in the namelist INI_TIME_STEP	23
	Variables of the namelist PostProc of the namelist file "PostProc.INI".	
	Meaning of the second character of the identifiers in the	ÐΙ
0.10	postprocessor input file FILE_INP.	53
4.1	Macro cross sections for four-group KOEBERG PWR benchmark	64
5.1	Axial material composition of the assemblies for 3D NEACRP PWR	
	rod ejection benchmark	71
5.2	Velocities and energy release of prompt neutrons for 3D NEACRP	
	PWR rod ejection benchmark	72
5.3	Decay constants and fractions of delayed neutrons for 3D NEACRP	
	PWR rod ejection benchmark	72
5.4	Data of the fuel assembly geometry for 3D NEACRP PWR rod	
	ejection benchmark.	75
5.5	Steady-state operation data for 3D NEACRP PWR rod ejection	
	benchmark	76
5.6	A comparison of the steady-state SKETCH-N results with the	
	PANTHER reference solution for the case A1 of the 3D NEACRP	
	PWR rod ejection benchmark	80
5.7	A comparison of the SKETCH-N results at the time of 5 s with the	
	PANTHER reference results for the case A1 of the 3D NEACRP	
	PWR rod ejection benchmark	82
5.8	A comparison of the SKETCH-N transient results with the	
	PANTHER reference results for the case A1 of the 3D NEACRP	
	PWR rod ejection benchmark	84
G 1	Diffusion constants for the modified IAEA-2D test	97
6.1	Diffusion constants for the modified IALA-2D test	01

Abstract

Program Name and Title

SKETCH-N: A nodal code for solving neutron diffusion equations of steady-state and kinetics problems.

Simulation scope

The SKETCH-N code solves neutron diffusion equations in x-y-z and hexagonal-z geometries for steady-state and neutron kinetics problems. The code can treat an arbitrary number of neutron energy groups and delayed neutron precursors.

Methods used

The polynomial, semi-analytic and analytic nodal methods based on the nonlinear iteration procedure can be used for spatial discretization of diffusion equations. The time integration of the neutron kinetics problem is performed by a fully implicit scheme with an analytical treatment of the delayed neutron precursors. The steady-state eigenvalue problems are solved by inverse iterations with Wielandt shift, the Chebyshev adaptive acceleration procedure is used for the neutron kinetics problems. The block symmetric Gauss-Seidel preconditioner is applied in the both iterative methods. The flux-weighting homogenization procedure is used for partially-rodded nodes to minimize a rod cusping effect. Simple one-phase model of the thermal-hydraulics of fuel assembly is included in the code. The code also has an interface module for a coupling with transient analysis codes, such as TRAC. The interface module performs a data exchange between the codes, synchronizes a time stepping and maps the neutronics data onto thermal-hydraulics spatial mesh and vice versa. The interface module is based on the message passing library PVM (Parallel Virtual Machine).

Limitations

The code can treat the neutron diffusion problems in Cartesian geometry. Few-

group macro cross sections and their dependencies are provided by a code user. The code does not have fuel burn-up modelling capabilities. An external thermal-hydraulics code is generally required for the calculation of the "real-life" problems.

Typical Running Time

The running time of the full-core case C1 of the PWR NEACRP rod ejection benchmark (2 neutron energy groups, 6 groups of the delayed neutron precursors, 884x18 neutronics nodes, 910 time steps) is 68 minutes on Sun UltraSPARC I (143 MHz) with an internal thermal hydraulics model.

Code features

Dimensions of a problem are specified as parameters in the include files, the code should be recompiled when the problem dimensions are changed. The code has PVM- based interface module developed for a coupling with transient thermal-hydraulics codes. The interface model has been used for a coupling of the SKETCH-N code with the J-TRAC (TRAC-PF1) and TRAC-BF1 codes.

Related and Auxiliary Programs

PVM library is used for the interface module of the code.

Status

The SKETCH-N code has been verified by solving the steady-state and neutron kinetics benchmark problems. The coupled J-TRAC/SKETCH-N code system has been verified against NEACRP PWR rod ejection and rod withdrawal benchmarks. NEACRP BWR cold water injection benchmark has been used for verification of the TRAC-BF1/SKETCH-N system.

References

Zimin V. G. "Nodal Neutron Kinetics Models Based on Nonlinear Iteration Procedure for LWR Analysis", PhD Thesis, Research Laboratory for Nuclear Reactors, Tokyo Institute of Technology, August 1997.

Zimin, V.G., and H. Ninokata, "Nodal Neutron Kinetics Model Based on Nonlinear Iteration Procedure for LWR Analysis," Ann. Nucl. Energy, 25, 507-528, 1998

Zimin, V.G., H. Ninokata, and L. R. Pogosbekyan "Polynomial and Semi-Analytic Nodal Methods for Nonlinear Iteration Procedure," Proc. of the Int. Conf. on the Physics of Nuclear Science and Technology, October 5-8, 1998, Long Island, New York, American Nuclear Society, vol. 2, pp. 994-1002, 1998

Zimin V. G., H. Asaka, Y. Anoda, and M. Enomoto, "Verification of the J-TRAC code with 3D Neutron Kinetics Model SKETCH-N for PWR Rod Ejection Analysis", Proc. of the 9 International Topical Meeting on Nuclear Reactor Thermal Hydraulics (NURETH 9), San Francisco, California, October 3- 8, CD-ROM, 1999.

Asaka, H., V. G. Zimin, T. Iguchi, and Y. Anoda, "Coupling of the Thermal-Hydraulic TRAC Codes with 3D Neutron Kinetics Code SKETCH-N", Proc. of OECD/CSNI Workshop on Advanced Thermal-Hydraulic and Neutronics Codes: Current and Future Applications, Barcelona, Spain, 10-13 April, 2000

Zimin, V. G., H. Asaka, Y. Anoda, E. Kaloinen and R. Kyrki-Rajamaki, "Analysis of NEACRP 3D BWR Core Transient Benchmark", Proc. of the 4 Intl. Conf. on Supercomputing in Nuclear Application SNA 2000, September 4-7, 2000, Tokyo, Japan.

Machine Requirements

A workstation under UNIX.

Program Language Used

Fortran 77 and Fortran 90

Other Programming or Operating Information or Restrictions

The interface module requires PVM installed on a computer. The PVM is a public domain software available from NETLIB [http://www.epm.ornl.gov/pvm/pvm_home.html].

Material Available

Source Code

Sample LWR Benchmark Problems Input and Output Files

SKETCH-N Manual, vol. I. Model Description

SKETCH-N Manual, vol. II User's Guide

Keywords

kinetics, three-dimensional, neutron diffusion, nodal methods, nonlinear iteration procedure, reactor transient analysis.

Contacts

Vyacheslav G. Zimin

Division 836 "Laboratory of Simulator Systems", National Research Nuclear University "MEPhI", Kashirskoe shosse, 31, Moscow, 115409, Russia

Abstract

 $Tel.: +7-963-648-87-81 \\ E-mail: vgzimin@mail.ru$

Acknowledgments

The finite-difference code SKETCH has been developed during my doctor study and work on the advanced fast breeder reactor analysis project at the Department of Theoretical and Experimental Reactor Physics of Moscow Engineering Physics Institute (MEPhI), Moscow, Russia in 1989-1994. I'm especially grateful to Dr. Nikolay V. Schukin of MEPhI for the encouragement and interest that he has contributed over the years. The nodal code SKETCH-N for LWR analysis has been developed during my doctor course study in the Research Laboratory of Nuclear Reactors of the Tokyo Institute of Technology, Tokyo, Japan in 1994-1997. Thanks a lot to the supervisor of my doctor thesis - Prof. Hisashi Ninokata for all time, which he spent teaching me, his tolerance, kindness and hospitality. During my doctor study I had very helpful and stimulating discussions with Mr. Hideaki Ikeda and Mr. Akitoshi Hotta, both of Toden Software and Prof. Toshikazu Takeda of Osaka University. An interface module for the coupling with the transient reactor analysis codes J-TRAC and TRAC-BF1 has been developed during my stay as a postdoctoral researcher at the Thermal Hydraulics Safety Research Laboratory, Department of Reactor Safety Research, Japan Atomic Energy Research Institute (JAERI) in 1997-2000. During this time numerous code improvements have been also done. The author wants to thank Mr. Hideaki Asaka and Dr. Yoshinari Anoda, both of JAERI for the interest to my work, help in many problems and excellent working conditions.

I also wish to thank Dr. Leonid R. Pogosbekyan, VNIIAES, Moscow, Russia for his contribution to the implementation of the analytical nodal method based on matrix function theory and other helpful and stimulating discussions.

The last but not the least thanks go to my wife Olya and to all my friends for their support and encouragement.

Chapter 1

Introduction

The SKETCH-N code (Zimin and Ninokata, 1998; Zimin et al., 2000) solves neutron diffusion equations in Cartesian and hexagonal-z geometries for steady-state and kinetics problems. The code can treat an arbitrary number of neutron energy groups and delayed neutron precursors. Polynomial, semi-analytic and analytic nodal methods based on the nonlinear iteration procedure can be used for spatial discretization of diffusion equations (Zimin et al., 1998; Zimin and Baturin, 2002). Time integration of the neutron kinetics equations is performed by the fully-implicit scheme with an analytical treatment of the delayed neutron precursors. Steady-state eigenvalue problems are solved by inverse iterations with a Wielandt shift accelerated by Chebyshev polynomials. An adaptive Chebyshev iterative procedure is used for neutron kinetics problems. The block symmetric Gauss-Seidel method is applied as a preconditioner in both the steady-state and transient problems. An automatic time step control based on the time step doubling technique is used in the code.

An extensive set of the steady-state and neutron kinetics LWR benchmarks has been calculated to verify the SKETCH-N code (Zimin et al., 1998; Zimin and Ninokata, 1998; Zimin and Baturin, 2002). The results show that the SKETCH-N code has acceptable accuracy and efficiency to be used in the LWR safety analysis and design. The code also has a simple thermal-hydraulics model, which can be used for analysis of PWR and VVER transients under single-phase flow conditions. An external thermal-hydraulics model should be used for the reactor calculations

with two-phase flow. PVM based interface module has been developed to simplify the coupling with an external thermal-hydraulics code. The interface have been used for the coupling with the J-TRAC (TRAC-PF1) code (Akimoto et al., 1989) for PWR analysis and the TRAC- BF-1 code (Borkowski et al., 1992) for BWR applications. The J-TRAC/SKETCH-N code system has been verified against NEACRP PWR rod ejection and rod withdrawal benchmarks (Zimin et al., 1999; Asaka et al., 2000), the NEACRP BWR cold water injection benchmark has been computed by the TRAC- BF1/SKETCH-N code system (Zimin et al., 2000).

In Chapter 2, we describe how to install the code.

In Chapter 3 the description of the SKETCH-N input and output files is given. The SKETCH-N postprocessing module, which can be used to extract the data from the SKETCH-N output binary file is also discussed.

In Chapter 4 till 5, the examples of the SKETCH-N application to the following problems:

- 2D four-group KOEBERG checker-board-loaded PWR (Müller and Weiss, 1991);
- 3D NEACRP PWR rod ejection benchmark, Case A1 (Finnemann and Galati, 1992).

2D PWR KOEBERG benchmark covered in Chapter 4 is the steady-state eigenvalue problem. It is a pure neutronics problem without feedbacks, which shows multigroup capabilities of the SKETCH-N code.

3D NEACRP PWR rod ejection benchmark discussed in Chapter 5 requires the both steady-state and neutron kinetics calculations with a thermal-hydraulics model. The coolant flow is under the single-phase condition and the internal thermal-hydraulics module of the SKETCH-N code is used. In the steady-state calculations, a critical boron search is performed. The transient is a super-prompt critical transient from the hot zero power conditions.

Chapter 2

Installation

2.1 Obtaining the source code

The SKETCH-N source code is presently available only from the following address: Author's Address (till 30 September 2000):

Vyacheslav G. Zimin

Thermal Hydraulics Safety Research Laboratory Department of Reactor Safety Research

Japan Atomic Energy Research Institute

Tokai-mura, Naka-gun, Ibaraki-ken, 319-1195, Japan Tel: +81-29-282-5357

Fax: +81-29-282-6728

E-mail: slava@lstf3.tokai.jaeri.go.jp;

2.2 Compiling and Linking the Code

The source code for SKETCH-N stored in the directory "Source". To build the code the one need to install "scons" on workstation open the terminal in the "Source" directory and type:

>scons

The source code for SKETCH-N postprocessor stored in the directory

Installation

>scons

[&]quot;Source/postproc". To build the code the one need to open the terminal in the

[&]quot;Source/postproc" directory and type:

Chapter 3

Starting the program

This chapter describes the code input and output data and the SKETCH-N postprocessing module.

3.1 Parameters in the include file "parameters.fh"

The include file "parameters.fh" contains the basic description of the reactor model dimensions and parameters. It is included into the file "sketch.fh" to define the array dimensions. If you change the problem you need to recompile the source code.

The variables defined in the file "parameters.fh" are separated into several groups: parameters describing the reactor geometry, parameters describing the reactor core, parameters describing the macro cross sections, parameters describing the control rods, parameters used by internal thermal-hydraulics model and parameters used for calculations with an external thermal-hydraulics model. They are defined in the Tables 3.1 – 3.6. Please, note that the variables given in the Table 3.5 are used only if the calculations are performed with the internal thermal-hydraulics model. The variables described in the Table 3.6 are used only if the external thermal-hydraulics model is used. In the case of pure neutronics calculations the values of parameters given in these tables can be set to 1.

Table 3.1: Parameters describing the reactor geometry.

Parameter Name	Description	
N_POLY	number of the bundles (assemblies) in the reactor model	
NCHM	maximum number of nodes per bundle (assembly) in X-Y	
	plane	
NH	number of the nodes in radial (X-Y) plane; if the	
	calculations are performed with 1 node per assembly	
	NH=N_POLY	
NDD	dimension of reactor model: 3D calculations NDD=3; 2D	
	calculations NDD=2; 1D calculations NDD=3;	
NXR	maximum number of bundles in X directions	
NX	maximum number of nodes in X direction	
NYR	maximum number of bundles in Y directions	
NY	maximum number of nodes in Y direction	
NZR	number of axial layers defining material composition of	
	the bundle;	
NZ	number of axial layers used for the calculations	
N_BUNDLE_TYPE	number of different bundle types	

Table 3.2: Parameters describing the reactor core geometry.

Parameter Name	Description
NP_Reactor_Core	number of fuel bundles in the reactor core
NZR_Core	number of axial layers in the reactor core

Table 3.3: Parameters describing the macro cross sections.

Parameter Name	Description	
NG	number of neutron energy groups	
MD	number of delayed neutron precursors	
NNODE	number of material compositions	
N_FEEDBACKS	number of feedbacks, presently 4: boron concentration,	
	coolant density or void, Doppler fuel temperature	

Table 3.4: Parameters describing the control rods.

Parameter Name	Description		
NN_CRod	number of control rods		
NN_CRod_Type	number of control rod types		
NN_CRod_Comp	number of control rod material compositions		
NN_CRod_E1	number of control rod elements, for example 2 for PWR:		
	absorber and driver		
NN_Crod_Bundle	number of the bundles covered by control rod: 1 in the		
	case of PWR and 4 in the case of BWR		

Table 3.5: Parameters used by internal thermal-hydraulics model.

Parameter Name	Description	
NN_FRD_FUEL	number of the heat conduction nodes in the fuel	
NN_FRD_CLAD	number of the heat conduction nodes in the cladding	

Table 3.6: Parameters used for calculations with an external thermal-hydraulics model.

Parameter Name	Description		
NN_RT_HC_TRAC	number of the heat conduction channels in the external		
	T/H model		
NN_RT_FD_TRAC	number of the fluid dynamics channels in the external		
	T/H model		
NN_Z_HC_TRAC	number of the axial layers of the heat conduction mesh in		
	the external T/H model		
NN_Z_FD_TRAC	number of the axial layers of the fluid dynamics mesh in		
	the external T/H model		

3.2 Input Data in the Namelist File "SKETCH.INI"

The file "SKETCH.INI" contains several namelists defining the SKETCH input data. The namelist INI_PROBLEM defines the type of the problem and solution methods used by the code. The variables are listed in the Table 3.7. The namelist INI_FILES defines the names of the input, output and restart files. The variables are given in the Table 3.8. The iteration convergence criteria are given in the

namelist INI_CONVERGENCE. The variables are given in the Table 3.9. We recommend to use the default values.

Table 3.7: Variables defining a type of the problem and solution methods in the namelist INT_PROBLEM.

Variable Name	Default value	Description
Problem Type	_	type of the computed problem:
		"Eigenvalue" - steady-state eigenvalue
		calculations
		"BoronSearch" - steady-state critical
		boron search
		"Kinetics" - neutron kinetics calculations
TH_Model	"None"	thermal-hydraulics model used for the
		calculations, variants
		"None" - no thermal-hydraulics model;
		"Internal" - SKETCH internal thermal-
		hydraulics model
		"External" - external thermal-hydraulics
		model
Nodal_Method	"SANM"	spatial discretization method used for
		calculations:
		"PNM" - polynomial nodal method;
		"SANM" - semi-analytic nodal method;
		"ANM" - analytic nodal method,
		"MCFD" - finite-difference method,
		"PNM1" - polynomial nodal method,
		algorithm based on matrix functions;
Kinetics_Method	"DRT"	method of the solution of kinetics
		equation:
		"DRT" - direct method, fully-implicit
		scheme;
		"IQS" - improved quasi-static method;
		"PNT" - point neutron kinetics
Iter_Solver	"CSA"	linear iterative solver for neutron kinetics
		calculations:
		"CSA" - Chebyshev Semi-Analytic
		method;
		"CSI" - Chebyshev Semi-Iterative
		method;
		"CG" - Conjugate Gradient method;
		"BCGSTAB" - BiConjugate Gradient
		Method STABilized,
		"TFQMR" - Transpose Free Quasi
		Minimal Residual Method;
		"FOM" - Arnoldi's Method
		"GMRES" - Generalized Minimal
		Residual Method

Table 3.8: Names of the input, output and restart files defined in the namelist INT_FILES .

Variable Name	Default value	Description
FILE_INPUT	11 11	name of the input file with the geometry
		and macro cross section data
FILE_MAP	11 11	name of the input file with the
		mapping matrices, used only if
		TH_Model="External"
FILE_DIST	11 11	name of the input file with the
		distributions (xenon, burnup, void
		history, etc.), used in the Ringhals-1
		BWR calculation;
FILE_CD	11 11	name of the input file with macro cross
		section tables, used in the Ringhals-1
		BWR calculation;
FILE_DMP_IN	11 11	Name of the input dump file for restart
FILE_DMP_OUT_ST	!! !!	Name of the output dump file to restart
		the steady-state calculations
FILE_DMP_OUT_KIN	11 11	Name of the output dump file to restart
		the kinetics calculations

Table 3.9: Convergence criteria defined in the namelist INI_CHEBYSHEV.

Variable Name		Description	
N_OUT_MAX	1	number of outer iterations for the	
		nonlinear iteration convergence test: in	
		the steady-state calculations; in the	
		kinetics calculations (1 nonlinear iteration	
		per time step);	
N_OUTER	10	maximum number of the outer iterations	
		per nonlinear iteration: in the steady-state	
		calculations; in the kinetics calculations (1	
		nonlinear iteration per time step);	
E_OUTER_L	1.E-5	convergence criterion for the steady-state	
		eigenvalue	
E_FLUX_L	1.E-5	convergence criterion for the neutron flux:	
		in the steady-state calculations; in the	
		kinetics calculations;	
N_INTER	2	maximum number of inner iteration per	
		outer iteration	
E_INTER	1.E-8	convergence criterion for the inner	
		iterations (never satisfied, fixed number	
		of inner iterations per outer iteration)	
E_BORON_START	1.E-2	accuracy of the eigenvalue estimate when	
		a critical boron search starts	
E_CRITICAL	1.E-5	convergence criterion for the critical boron	
		search	

The namelist INI_CHEBYSHEV defines the parameters used by the Chebyshev iterative methods. The variables are given in the Table 3.10. We recommend to use the default values. Please only note, that the convergence of the steady-state iterations can be significantly improve if you use the value of the Wieland shift DELTA_SHIFT not equal to zero. For the LWR calculations, the value DELTA_SHIFT in the interval [5,20] provide "optimal" convergence. Please, decrease the value of the Wieland shift if the iterations diverge.

Table 3.10: Parameters of the Chebyshev iterations defined in the namelist INI CHEBYSHEV.

Variable Name	Default Value	Description
XME_INI	0.8	estimate of the dominance ratio (steady-
		state calculations) or spectral radius
		(kinetics calculations) of the iterative
		matrix
XBE	0.0	\mid estimate of the minimum eigenvalue of the \mid
		iteration matrix
F_CHEB	0.0	adaptive parameter of the Chebyshev
		iterative method: F_CHEB=0.0 non-
		adaptive, default in the steady-state
		Calculations; F_CHEB=0.8 - adaptive,
		default in the kinetics calculations
NPOLLINS	5	number of the outer iteration when the
		Chebyshev method starts
DELTA_SHIFT	0.	inverse value of the Wieland shift in the
		steady-state iterations

The variables related to the time step size selection during neutron kinetics calculations are given in the namelist INI_TIME_STEP. The list is presented in Table 3.11. Even the default value of the flag I_AUTO specified the user defined time step, we strongly encourage to set I_AUTO=1 and to use the automatic time step size selection. In our experience, the time step doubling techniques used in the code is reliable and gives accurate solution.

Table 3.11: Time step size data defined in the namelist INI TIME STEP.

Variable Name	Default Value	Description
I_AUTO	0	flag of the automatic time step
		$ $ selection: I_AUTO=0 - user defined $ $
		\mid time step size; I_AUTO=1 - automatic \mid
		time step selection;
NP_VIEW	1	number of the time step size intervals
TTV(NP_VIEW)	1.	real array of dimension NP_VIEW -
		right end points of the time step
		size intervals [s]; the last value
		TTV(NP_VIEW) is the end of the
		transient;
DT_INPUT (NP_VIEW)	0.01	real array of dimension NP_VIEW -
		time step size for the time step
		intervals, [s].
ST_EPS	5.E-3	accuracy criterion of the automatic
		time step size selection
FACMAX	2.	maximum increase of the time step
		size per time step
DT_STEP_MAX	1.	maximum value of the time step size,
		[s]
N_ZAP	1	output into the SKETCH binary
		output file per each N_ZAPth time
		step

3.3 Input Data in the SKETCH-N Input file

The name of the SKETCH-N input file is defined under the variable FILE_INPUT in the namelist INI_FILES in the file "SKETCH.INI". The examples are given in the following Chapters. Here we present the list of all input data, which can be given in this file. The input file starts with 5 lines of the problem header, which is always input and is used in the SKETCH output files. The actual data starts on the line 6 and are given in the following form. First we have the identifier, which is 12 characters, actual data starts at the following line and are given in free format. Arbitrary number of the blank lines may precede or follow the data. The variable identifiers and input data are separated into several groups, related to the

SKETCH modules. The first characters of the identifier name give the abbreviation of the SKETCH-N module, the other characters encode the variable name. For example, the identifier XS_BASE_DATA stands for the basic macro cross section data of the XS module, CRD_MAT_COMP is the identifier of the control rod material compositions, etc. Some input cards can be omitted, for example the delayed neutron precursors parameters are not needed if only steady-state calculations are performed. If the data are needed, but the code can not find the identifier name in the input file, the code uses the default values and gives the warning message into the output file "Error.msg". If default values are not defined or the code has an error reading the input data, the execution is stopped with an error message into the error message file "Error.msg".

3.3.1 General Reactor Model Data

The first set of the data defines the general reactor model, the identifiers start with the characters CNT (CoNTrol). Their list is given below.

CNT_RCT_TYPE

Description: Reactor type, presently only "PWR" or "BWR"

Default value: "PWR"

CNT_RCT_POWR

Description: Reactor thermal power, [MWt]

Default value: -

3.3.2 Macro Cross Section Data

The set of the data related to macro cross sections is given under identifiers, which start with XS. The input data are described below.

XS_MODL_TYPE

Description: a type of the macro cross section model, two type are available: "POLYNOM" - polynomial representation

"TABLE" - table representation for the BWR Ringhals-1 stability benchmark Default value: "POLYNOM"

XS_BASE_DATA

Description: Basic set of the macro cross section data, the input has different form depending on the number of neutron energy groups NG.

Default value: -

Input data format:

The input form depends on the number of neutron energy groups. In the case of two-group calculations, the input is performed as follows:

```
D0 k = 1, NNODE
    read(io_unit,fmt=*, iostat=ios)
&    d(k,1),sik(k,2,1),sa(k,1),sf(k,1),sf_p(k,1),
&    d(k,2),sa(k,2), sf(k,2),sf_p(k,2),i
END D0
```

where

NNODE is a number of material compositions defined in the file "parameters.fh";

- d(k,*) is the diffusion coefficients or neutron transport cross section of the material composition k, D or Σ_{tr} ;
- sik(k,2,1) is the scattering macro cross section from group 1 into 2 of the material composition k, Σ_{s21} ;
- sa(k,*) is the absorption macro cross sections of the material composition k, Σ_a ;
- sf(k,*) is the production macro cross section of the material composition k, $\nu\Sigma_f$;
- $sf_p(k,*)$ is the fission macro cross sections of the material composition k, Σ_f ;
- i is the material composition number, not used in the code.

In the case of multigroup calculations NG>2, the input is performed as follows

```
D0 k = 1, NNODE
    read(io_unit,fmt=*, iostat=ios)
&        (d(k,n), sa(k,n), sf(k,n), sf_p(k,n), n = 1, NG)
    read(io_unit,fmt=*, iostat=ios)
&        ((sik(k,n,m), m = 1, NG), n = 1, NG), i
END D0
```

The difference is that for each material composition, the scattering macro cross sections are given after all others and all elements of the scattering matrix are given in the input. Please, note that self-scattering within an energy group is not considered in the diffusion theory and the diagonal elements of the scattering matrix should be zero.

Examples:

Two-group macro cross sections of the 1 material composition of the NEACRP PWR rod ejection benchmark are given below:

```
XS_BASE_DATA # Basic set of tke macro cross section data
    0.532058E-01  0.264554E-01  0.373279E-03  0.000000E-00  0.000000E-00
    0.386406E-00  0.177215E-01  0.000000E-00  0.000000E-00  1
```

Four-group macro cross sections of the 1 material composition of the 2D PWR KOEBERG benchmark are given below:

```
XS_BASE_DATA # Basic set of the macro cross section data
  2.491869 0.003654 0.008228 0.008228
  1.045224 0.002124 0.000536 0.000536
  0.677407 0.019908 0.007058 0.007058
  0.375191 0.067990 0.083930 0.083930
  0.0
            0.0
                     0.0
                              0.0
  0.063789 0.0
                     0.0
                              0.0
  0.000486 0.064381 0.0
                              0.001245
  0.0
            0.000003 0.050849 0.0
                                              1
```

XSP_POL_COEF

Description: derivatives of the macro cross sections with respect to feedbacks. The following set of feedbacks is used in the code: boron concentration [ppm], coolant density [g/cm³], coolant temperature [°C] and Doppler fuel temperature [°K]. Please, note that the units are not the SI units. The input form depends on the number of neutron energy groups.

Default value: 0.0 Input data format:

In the case of two-group calculations, the input is performed as follows

where

NNODE is a number of material compositions defined in the file "parameters.fh";

- N_FEEDBACK is a number of feedbacks defined in the file "parameters.fh", N_FEEDBACK=4;
- d_fb(i,*,k) is the derivative of the transport macro cross section Σ_{tr} with respect to *i*-th feedback for material composition k;
- sik_fb(i,2,1,k) is the derivative of the scattering macro cross section Σ_{s21} with respect to *i*-th feedback for material composition k;
- $sa_fb(i,*,k)$ is the derivative of the absorption macro cross section Σ_a with respect to *i*-th feedback for material composition k;
- sf_fb(i,*,k) is the derivative of the production macro cross section $\nu\Sigma_f$ with respect to *i*-th feedback for material composition k;
- $sf_p_f(i,*,k)$ is the derivative of the fission macro cross section Σ_f with

respect to i-th feedback for material composition k;

fdback00(i,k) is the reference value of *i*-th feedback for material composition k.

In the case of multigroup calculations NG>2, the input is performed as follows

The difference is that for each material composition and each feedback, the derivatives of the scattering macro cross sections are given after all others and all elements of the derivatives of the scattering matrix are given in the input. Examples:

Two-group derivatives of the macro cross sections of the 1 material composition of the NEACRP PWR rod ejection benchmark are given as:

```
XSP_POL_COEF # Macro cross section derivatives
0.611833E-07 0.791457E-09 0.187731E-06 0.000000E-00 0.000000E-00
0.517535E-05 0.102635E-04 0.000000E-00 0.000000E-00 1200.2
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 306.6
0.745756E-01 0.371310E-01 0.207688E-03 0.000000E-00 0.000000E-00
0.533634E-00 0.758421E-02 0.000000E-00 0.000000E-00 0.7125
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 891.45 1
```

XS_DIFF_FLAG

Description: Integer flag of the diffusion coefficient in the basic set of the macro

cross section data. If XS_DIFF_FLAG==1, the diffusion coefficient is given in the basic macro cross section set, otherwise it is the transport macro cross section.

Default value: 1

XS_FEED_INIT

Description: Initial values of the feedbacks used in the first thermal-hydraulics

iteration, real array of dimension N_FEEDBACK=4

Default value: 1.0

XS_CROD_COEF

Description: Differential macro cross sections for the control rod material compositions; the input form is the same as described above for the basic macro cross sections under identifier XS_BASE_DATA.

Default value: 0.0

XS_CROD_CUSP

Description: Homogenization method of the macro cross sections for the partially rodded nodes.

Two choices:

"FLUX-WEIGHTING" - flux-weighting homogenization

"VOLUME-WEIGHTING" - volume-weighting homogenization

Default value: "FLUX-WEIGHTING"

XS_NEUT_SPEC

Description: Prompt neutron spectrum, real array of dimension NG

Default value: -

XS_POWR_CONV

Description: Energy release per fission [Ws/fission], real array of dimension NG Default value: –

XS_POWR_COOL

Starting the program

Description: Part of the energy directly deposited into the coolant

Default value: 0.0

XS_NEUT_VELC

Description: Prompt neutron velocity $[\mathrm{cm/s}]$, real array of dimension NG

Default value: -

XS_PREC_ALFA

Description: Decay constants of the delayed neutron precursors [1/s], real array of dimension MD

Default value: –

XS_PREC_BETA

Description: Fraction of the delayed yields, the input can be absolute or relative values.

Default value: -

Input data format: Either relative or absolute values can be given. First you input the integer flag i_beta. If i_beta==0 the code expects absolute values of the delayed neutron fractions. If i_beta==1 the code first reads the total fraction of the delayed neutrons and then the relative fractions for each delayed neutron groups.

Examples:

The input of the relative fractions of the delayed neutron precursors for the NEACRP PWR rod ejection benchmark is given as:

```
XS_PREC_BETA
```

```
1 # Relative beta
0.0076 # Total yield
0.034 0.200 0.183 0.404 0.145 0.034 # Relative fractions (MD)
```

The input of the absolute fractions of the delayed neutron precursors for the NEACRP BWR cold water injection benchmark is given as:

```
XS_PREC_BETA
```

```
0 # Absolute beta
0.00026 0.00152 0.00139 0.00307 0.00110 0.00026 # bet(MD)
```

3.3.3 Geometry Description

The set of the data related to the reactor geometry model is given under identifiers, which start with GMT. The list of the identifier and the data descriptions are given as follows.

GMT_NUM_BNDL

Description: the numbering of the reactor bundles (assemblies), integer array of dimension (NXR, NYR)

Default value: -

Example: Reactor model of the NEACRP PWR rod ejection benchmark is described as follows:

```
GMT_NUM_BNDL # Numbering of the reactor assdemblies (bundles)
1 9 # 1
1 9 # 2
1 9 # 3
1 8 # 4
1 8 # 5
1 7 # 6
1 6 # 7
1 5 # 8
1 3 # 9
```

GMT_MSH_XDIR

Description: Number of points per interval and spatial mesh intervals in x-direction [cm], integer and real arrays of dimension (NXR)

Default value: -

Example: spatial mesh in x-direction for the NEACRP PWR rod ejection benchmark is defined as:

```
GMT_MSH_XDIR # Spatial mask in x-direction

1 10.803 2 21.606 2 21.606 2 21.606 2 21.606 2 21.606

2 21.606 2 21.606 2 21.606 # npx(NXR),kx(NXR)
```

where two mesh points are defined per interval 21.606 cm.

GMT_MSH_YDIR

Description: Number of points per interval and spatial mesh intervals in y-direction [cm], integer and real arrays of dimension (NYR)

Default value: -

GMT_MSH_ZDIR

Description: Number of points per interval and spatial mesh intervals in z-direction [cm], integer and real arrays of dimension (NZR)

Default value: -

GMT_COR_LOAD

Description: specification of the reactor loading by the material composition, first input is an integer array of dimension (N_POLY) describing reactor loading by bundle types, then for each bundle type we define the axial material composition. Default value: –

Input data format: First input of the core loading by the bundle types as follows.

```
READ(io_unit, fmt=*, iostat=ios)
& (core_Load(np), np = 1, N_POLY)
```

where

N_POLY is a number of the bundles (assemblies) in the reactor model.

core_Load(np) is a bundle type

Then, we input axial material composition for each bundle type as

```
DO i = 1, N_Bundle_Type READ(io_unit, fmt=*, iostat=ios)
& (Bundle_compos(n, i), n = 1, NZR)
END DO
```

where

N_Bundle_Type is a number of the bundle types in the reactor model; NZR is a number of axial layers in the reactor model;

Bundle_compos(n, i) is the material composition for each bundle type i and axial layer n;

Example:

Material compositions for NEACRP PWR rod ejection benchmark are defined as follows:

```
GMT_COR_LOAD # Core loading by the material compositions
  1 2 1 2 1 3 1 4 5
  2 1 6 1 6 1
    6 1 6 1 6 4 8 5
       6
        1 6 9 4 5
    6 1 6 1 4 8 5
  3 1
       6 9 4 8 5
  1 7 4 4 8 5
    4 8 5 5
  5 5 5 # core loading by the bundle types, Core_Load(N_POLY)
  1 4 15*4 1 # Material composition of the 1st bundle type
  1 5 15*9 1 # Material composition of the 2nd bundle type, etc.
  1 5 15*7 1 # nb =
  1 6 15*6 1 # nb =
  2 2 15*2 2 # nb =
  1 5 15*8 1 # nb =
  1 6 15*11 1 # nb =
  3 3 15*3 3 # nb =
  1 6 15*10 1 # nb =
```

GMT_BND_COND

Description: Boundary conditions (BC)

Default value: -

Input data format: At first, we input the integer flag i_dr of the boundary

conditions for the Left, Right, Up and Down boundaries. If i_dr==1 we define the logarithmic derivative of the neutron flux as a boundary condition constant, if i_dr==0 the extrapolated distance should be given as a boundary constant. Then we give the boundary condition constants as a real array of dimension NG for the Left, Right, Up and Down boundaries. The description of the boundary conditions in axial directions is performed in the same way. First we define a type of the boundary conditions for the Bottom and Top boundaries, then we give the boundary condition constants. In the case of 2D calculations, the type of the axial boundary conditions is omitted and the buckling array of dimension NG [cm²] is given instead of the boundary condition constants.

Example:

The boundary conditions for NEACRP PWR rod ejection benchmark are defined as follows:

```
GMT_BND_COND # Boundary conditions (BC)
1 0 1 0 # Type of the BC (Left, Right, Up, Down)
0. 0. 0. 0. 0. 0. 0. 0. # BC constants
0 0 # Type of the axial BC (Bottom, Top)
0. 0. 0. 0. # Bc constants for axial BC
```

The input data define the reflective boundary condition at the Left and Up boundaries and zero flux boundary conditions on the other boundaries.

An another example is the boundary conditions for four-group 2D KOEBERG PWR benchmark.

```
GMT_BND_COND # Boundary conditions (BC)

1 1 1 1 # Type of tke Bc (Left, Right, Up, Down)

0. 0. 0. 0. 0.5 0.5 0.5 0.5 0. 0. 0. 0.

0.5 0.5 0.5 0.5 # BC constants

0. 0. 0. 0. # Axial buckling
```

The input data define the reflective boundary conditions at the Left and Up boundaries and vacuum boundary conditions on the Right and Down boundaries. The problem is two-dimensional, the axial buckling is zero.

3.3.4 Control Rod Description

The set of the data related to the control rods is given under identifiers, which start with CRD. The list of the identifier and the data descriptions are given as follows.

CRD_COR_LOAD

Description: control rod types, integer array of dimension of the number of control rods NN_CRod.

Default value: 1

CRD_MAT_COMP

Description: material compositions for each control rod type NN_CRod_Type and control rod element NN_CRod_E1, integer array of dimension (NN_CRod_E1, NN_CRod_Type). Two control rod elements are usually defined: absorber and driver.

Default value: 1 Input data format:

```
DO n = 1, NN_CRod_Type READ(io_unit, fmt=*, iostat=ios)
& (CR_compos(ie, n), ie = 1, NN_CRod_El) END DO
```

Example:

The control rod material compositions for NEACRP PWR rod ejection benchmark are defined as follows:

CRD_MAT_COMP

```
1 3 \# Material composition for 1st type of cRD
```

2 3 # Material composition for 2nd type of cRD

CRD_LOCATION

Description: location of the control rods in the reactor core, an index of the assembly (bundle) covered by the control rod, an integer array of dimension (NN_CRod_Bundle, NN_CRod).

NN_CRod_Bundle is the number of assemblies (bundles) covered by control rod. In the case of PWR, NN_CRod_Bundle=1; in the case of BWR, NN_CRod_Bundle=4.

Default value: 0

Example:

The control rod positions for NEACRP PWR rod ejection benchmark, case A1 are defined as follows:

CRD_POSITION

Description: position of the control rods [cm]. A real array of dimension NN_CRod. In the case of PWR positions are defined from the reactor bottom; in the case of BWR positions are given from the reactor top.

Default value: 0.0

CRD_H_ROD_EL

Description: length of the control rods elements, [cm]. A real array of dimension (NN_CRod_El). NN_CRod_El is the number of the control rod elements, usually we have two elements: absorber and driver.

Default value: 0.0

The following control rod input data are read only for the neutron kinetics problems.

CRD_TOP_POSI

Starting the program

Description: Top in the case PWR or bottom in the case of BWR position of

the control rods;

Default value: height of the reactor model.

CRD_BOT_POSI

Description: Bottom in the case PWR or top in the case of BWR position of

the control rods; Default value: 0.0

CRD_TIM_STRT

Description: start time of the control rod movement, [s].

Default value: 0.0

CRD_TIM_END

Description: end time of the control rod movement, [s].

Default value: 1.E+30

CRD_NUM_MOVE

Description: Number of the moving control rods.

Default value: 0

CRD_IND_MOVE

Description: Indexes of the moving control rods, integer array of dimension of

the number of the moving control rods.

Default value: 0

CRD_MOV_TYPE

Description: A type of the control rod movement, two variants are available:

"LIN" is the linear movement of the control rods;

"SIN" is the sinusoidal movement of the control rods.

Default value: "LIN"

In the case of the linear movement of the control rods (CRD_MOV_TYPE=="LIN"), the data under identifier CRD_VEL_RODS may be given as follows

CRD_VEL_RODS

Description: Velocity of the moving control rods [cm]

Default value: 0.0

In the case of the sinusoidal movement of the control rods (CRD_MOV_TYPE=="SIN"), the data under identifiers CRD_SIN_AMPL and CRD_SIN_FREQ may be given as follows

CRD_SIN_AMPL

Description: Amplitude of the moving control rods [cm], real array of dimension of the number of the moving control rods.

Default value: 0.0

CRD_SIN_FREQ

Description: Frequency of the moving control rods [1/s], real array of dimension of the number of the moving control rods.

Default value: 1.0

CRD_FLG_SCRM

Description: Set of the data related to the reactor scram. If this identifier is given the scram is "ON", otherwise it is "OFF".

Default value: scram is "OFF"

Input data format: The following data should be given under this identifier:

```
read(io_unit,fmt=*,iostat=ios) v_rods_scram
read(io_unit,fmt=*,iostat=ios) Nrod_Scram
read(io_unit,fmt=*,iostat=ios)
& (Num_Rod_Scram(i), i= 1, Nrod_Scram)
read(io_unit,fmt=*,iostat=ios) Power_Scram
read(io_unit,fmt=*,iostat=ios) Time_Scram_Delay
```

where

v_rods_scram - velocity of the scram control rods;

Nrod_Scream - number of the control rods participating in scram;

Num_Rod_Scram - indexes of the control rods participating in scram;

Power_Scram - power level [MWt], when scram signal is activated;

Time_Scram_Delay - time delay [s] after the scram signal before the control rods start moving.

3.3.5 Data for Internal Thermal-Hydraulics Model

The set of the data related to the internal thermal-hydraulics model is given under identifiers, which start with TH and FRD. This data are input only the variable TH_Model="Internal" in the namelist INI_PROBLEM in the namelist file "SKETCH.INI". The list of the identifier and the data descriptions are given as follows.

```
TH_TEMC_INLT

Description: inlet coolant temperature, [K]

Default value: -

TH_TEMC_INLT

Description: coolant pressure, [MPa]

Default value: -

TH_MFRT_ASSM

Description: coolant mass flow rate per assembly, [kg/(m² s)]

Default value: -

TH_HYDR_DIAM

Description: equivalent hydraulic diameter, [m]

Default value: -

TH_HTCF_CNST
```

Starting the program

```
Description: constants of the Dittus-Boelter formula for the heat transfer
  coefficient Default value: 0.023, 0.4, 0.8
  Example:
  TH_HTCF_CNST # heat transfer coefficient constants (Dittus-Boelter)
  0.023 0.8 0.4 # const_DB, Pow_Reynolds, Pow_Prandtl
  TH_SURF_VOLM
  Description: ratio of the surface area of cladding to the volume of the coolant,
  [1/m]
  Default value: -
  TH_FLOW_AREA
  Description: relative flow area
  Default value: -
  FRD_RAD_PELT
  Description: radius of fuel pellet, [m]
  Default value: -
  FRD_RAD_CLAD
  Description: inner and outer radiuses of the cladding
  Default value: -
FRD_DNS_F&CL
  Description: densities of the fuel and cladding [kg/m<sup>3</sup>]
  Default value: -
  FRD_GAP_COND
  Description: gap conductance [watts/(K m<sup>2</sup>)]
  Default value: -
  FRD_ALF_DOPL
```

Description: interpolation parameter to compute the Doppler fuel temperature Default value: –

FRD_RAT_ASFL

Description: ratio of the assembly volume to fuel volume

Default value: –

FRD_POW_FROD

Description: power distribution inside a fuel rod, the real array Power_Pin of dimension NN_FRD_FUEL+1, if the identifier is missing the flat power distribution is assumed and Power_Pin=1.0

Default value: 1.0

3.4 Input Data for Calculations with an External Thermal-Hydraulics Model

If an external thermal-hydraulics code is used for the calculations, the code user should set the variable TH_Model="External" in the namelist IN_PROBLEM in the namelist file "SKETCH.INI" and prepare the input file with the data for the SKETCH-N interface module. A file name is specified under the variable FILE_MAP in the namelist INI_FILES in the file "SKETCH.INI". Till now the SKETCH-N code has been used for the calculations with the TRAC-PF1 and TRAC-BF1 codes, thus in the following we use the name TRAC as a name of the external thermal-hydraulics code. The input data of the file FILE_MAP contain the specification of the TRAC version, the conversion parameters between the TRAC and SKETCH units and the mapping matrices defining the mapping of the variables between the TRAC and SKETCH spatial meshes.

Before considering the input data let us describe the input format of the mapping matrices. Let us consider an example of the TRAC and SKETCH axial meshes, which is discussed in the vol. I of the SKETCH manual (Zimin, 2025) and shown again in Fig. 3.1. The mapping matrices for these spatial meshes are given as

$$SID_{NEUT}^{HC} = \begin{pmatrix} 1 & 1 & 0 & 0 & 0 \\ 0 & 0 & 1 & 0.5 & 0 \\ 0 & 0 & 0.5 & 0.5 \\ 0 & 0 & 0 & 0.5 \end{pmatrix}$$

$$SID_{NEUT}^{FD} = \begin{pmatrix} 1 & 1 & 1 & 0 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 0 & 1 \end{pmatrix}$$

where

 SID_{NEUT}^{HC} is the mapping matrix from the neutronics mesh into the heat conduction mesh;

 SID_{NEUT}^{FD} is the mapping matrix from the neutronics mesh into the fluid dynamics mesh.




Figure 3.1: An example of the axial meshes in the TRAC and SKETCH-N codes

Because the mapping matrices are very sparse, a compressed row storage (CRS) format is used for their input and storage (Barrett et al., 1994). Let us consider

the sparse $M \times N$ matrix A (M rows and N columns) with NNZ nonzero entries a_{ij} (i-th row, j-column). The data structure of the CRS format consists of three arrays:

- a real array val of dimension NNZ contains the real nonzero entries a_{ij} stored row by row, from row 1 to M.
- an integer array ja of dimension NNZ contains column indexes of the elements a_{ij} as stored in the array val.
- an integer array ia of dimension M+I contains the pointers to the beginning of each row in the arrays val and ja. Thus, the content of ia(i) is the position in the arrays val and ja, where the *i*-th row starts. By convention, ia(M+1)=NNZ+1.

The CRS format of the matrix SID_{NEUT}^{HC} is specified by the arrays {val, ja, ia} given below

val	1.	1.	1.	0.5	0.5	0.5	0.5
ja	1	2	3	4	4	4	4

The CRS format of the matrix $SID_{\rm NEUT}^{\rm FD}$ is given by the arrays {val, ja, ia} as

val	1.	1.	1.	1.	1.	1.
ja	1	2	3	4	5	4

Now let us consider the content of the input file FILE_MAP. The input file starts with 5 lines of the header, followed by the input data. Each data set has an identifier, which is 12 characters, actual data starts at the following line and are given in free format. Arbitrary number of the blank lines may precede or follow the data. This set of data is used by the PVM-based interface module and the identifiers start with the characters PVM. Their list is given below.

PVM_EXT_CODE

Description: A name of the external thermal-hydraulics code, two variants are available:

```
"TRAC-PF1" defines a coupling with the TRAC-PF1 code; "TRAC-BF1" defines a coupling with the TRAC-BF1 code.
```

The variants are different in several ways. At first, the SKETCH-N code sends a message with two arrays of the heat generation rate on the both heat conduction and fluid dynamics meshes to the TRAC-PF1; while to the TRAC-BF1 code SKETCH-N sends only the heat generation rate for the heat conduction spatial mesh. The second difference is that the TRAC-PF1 code sends two arrays of the fuel temperatures: centerline fuel temperature and fuel rod surface temperature. The SKETCH-N code computes the Doppler fuel temperature interpolating these two values. Only a one array with the computed Doppler fuel temperature is sent by the TRAC-BF1 code. The last difference is the treatment of the coolant temperature and density. The TRAC-PF1 code gives the face-average values and the node-average values are computed by the SKETCH code using the linear interpolation. The TRAC-BF1 sends the node-averaged values and no interpolation is needed.

Default value: -

PVM_CNV_UNIT

Description: Conversion constants of the TRAC units for coolant density (or void); coolant and fuel temperature into the SKETCH units. Three real constants C_RO_COOL, C_TEMP_COOL, C_TEMP_FUEL, are given as input. The SKETCH variables from the TRAC variables are computed as follows

```
RO_COOL_SKETCH = RO_COOL_TRAC * C_RO_COOL

TEMP_COOL_SKETCH = TEMP_COOL_TRAC + C_TEMP_COOL

TEMP_FUEL_SKETCH = TEMP_FUEL_TRAC + C_TEMP_FUEL
```

Default value: -

Example: In the TRAC-BF1 code the unit of the coolant density is kg/m³, the unit of the temperature is Kelvin degree. For NEACRP LWR benchmark

the SEKETCH-N macro cross sections are given as functions of the coolant density in g/cm³; coolant temperature in degrees of Celsius and Doppler fuel temperature in degrees of Kelvin. The conversion constants are given as

```
PVM_CNV_UNIT
1.E-03 -273.15 0.
```

PVM_MAP_NTHC

Description: Mapping matrices from the neutronics spatial mesh into the heat conduction spatial mesh. At first, 2D mapping matrix describing the correspondence of the meshes in x-y plane is given. The input is performed in the CRS format. The arrays ia, ja, val are given. The dimension of the array ia is equal to NN_RT_HC_TRAC+1, where NN_RT_HC_TRAC is the number of the heat conduction channels in the external T/H code. The arrays ja, val have the dimensions equal to the number of the nonzero elements of the mapping matrix. Their actual dimension is computed as ia(NN_RT_HC_TRAC+1)-1. Then, 1D mapping matrix describing the correspondence of the axial meshes is given in the same CRS format. The dimension of the array ia is equal to NN_Z_HC_TRAC+1, where NN_Z_HC_TRAC is a number of the axial layers of the heat conduction mesh in the external T/H code. The dimensions of the arrays ja, val is computed as ia(NN_Z_HC_TRAC+1)-1.

Default value: -

PVM_MAP_NTFD

Description: Mapping matrices from the neutronics spatial mesh into the fluid dynamics spatial mesh. The input format is the same as above for the data under identifier PVM_MAP_NTHC. The only difference is that the parameters NN_RT_FD_TRAC and NN_Z_FD_TRAC of the fluid dynamics spatial mesh are used to define the dimension of the arrays ia.

Default value: -

PVM_MAP_HCNT

Description: Mapping matrices from the heat conduction spatial mesh into the neutronics spatial mesh. The input format is the same as described above for the data under identifier PVM_MAP_NTHC. The only difference is that the parameters N_POLY and NZR of the neutronics spatial mesh are used to define the dimension of the arrays ia. If this identifier is omitted the mapping matrices are computed as transpose of the mapping matrices from the neutronics mesh into the heat conduction mesh given under identifier PVM_MAP_NTHC.

Default value: transpose of the mapping matrices from neutronics mesh into heat conduction mesh.

PVM_MAP_FDNT

Description: Mapping matrices from the fluid dynamics spatial mesh into the neutronics spatial mesh. The input format is the same as described as above for the data under identifier PVM_MAP_NTHC. The only difference is that the parameters N_POLY and NZR of the neutronics spatial mesh are used to define the dimension of the arrays ia. If this identifier is omitted the mapping matrices are computed as transpose of the mapping matrices from the neutronics mesh into the fluid dynamics mesh given under identifier PVM_MAP_NTFD.

Default value: transpose of the mapping matrices from neutronics mesh onto the fluid dynamics mesh.

3.5 Output into the Text File "SKETCH.lst"

The code writes a summary of the input data and calculation results into the file "Output/SKETCH.lst". Please note that if the file with this name exists it is overwritten. At first, the code writes a summary of the input data values of the code parameters from the file "sketch.fh"; data from the namelist file "SKETCH.lNl"; and data from the input file FILE_INPUT. If calculation is performed with an external thermal-hydraulics model the data taken from the file FILE_MAP are also output. In the case of the Ringhals-1 BWR calculation the next output is a summary of 3D static distributions taken from the input distribution file FILE_DIST. The static distributions include burnup, xenon, void history, control rod history, conversion history, steady-state power and void.

An output form is the same as discussed below for computed distributions. The next output data are control rod positions and summaries of computed distributions. In the steady- state calculations, initial data and computed results are given. In the transient calculations, the code writes these data at the beginner of the transient and at the time moments TTV(n), n=1,...,NP_VIEW. These time moments are defined in the namelist INI_TIME_STEP in the namelist file SKETCH.INI". The output distributions include power distribution and feedback distributions: boron concentration, coolant density and temperature, Doppler fuel temperature. If the internal thermal-hydraulics model is used in the calculation additional distributions are written. They are fuel centerline temperature, cladding inner surface temperature and fuel enthalpy. A summary of each distribution contains a core-averaged value, minimum and maximum values and their locations, average 2D and 1D values. Please note, that the averaging is performed over a reactor core, the values in reflectors are not taken into account. The output is also performed only for the reactor core. An example of the summary of the steadystate power distribution of the NEACRP PWR rod ejection benchmark, case A1 is given below

!=====		========	=======	======	:======	======	=====	======	======!
!				SKETCH-N	I				!
!Nodal	Neutron	${\tt Diffusion}$	Code for	Solving	Steady-	-State	and K	inetics	Problems!
!	Version	1.0 (c) S	lava 2000	e-mail:	na.vzin	nin@na-	net.o	rnl.gov	!
!	Date	& Time of	Calculat	ion : 8 A	lugust	2000	5:42:	06 pm	!
!=====	======	=======	======	======	======	======	=====	======	======!
Lines o	of the ou	utput with	control 1	rod posit	ions aı	re omit	ted		
!									!
			POWER	DISTRIBU	JTION				
I									

Total Reactor Power: 0.69375E-03 MWt

Average Power Density: 0.10308E-03 Wt/cm³

NODAL POWER PEAKING FACTORS Scaling Factor: 0.97008E+04 Average Value: 1.00000 3D Maximum Value: 2.87700 Reactor Location of 3D Maximum (X,Y,Z): 4 2 9 Location of 3D Maximum (X,Y,Z): 4 2 8 Core 3D Minimum Value: 0.05613 Reactor Location of 3D minimum (X,Y,Z): 7 3 17 Core Location of 3D minimum (X,Y,Z): 7 3 16 2D Maximum Value: 1.91131 Reactor Location of 2D Maximum (X,Y) : 2 4 Location of 2D Maximum (X,Y) : 2 4 Core 2D Minimum Value: 0.38227 Reactor Location of 2D minimum (X,Y) : 3 7 Core Location of 2D minimum (X,Y) : 3 7 1D Maximum : 1.50341 Reactor Location of the 1D Maximum (Z): 9 Location of the 1D Maximum (Z): 8 Core 1D Minimum : 0.13638 Reactor Location of the 1D minimum (Z): 17 Core Location of the 1D minimum (Z): 16 !-----! 2D RADIAL ASSEMBLY-AVERAGED POWER DENSITY 2 3 4 5 6 7 1 8 0.993 1.521 1.071 1.807 1.815 1.008 0.396 0.540

1.521 1.845 1.661 1.911 1.424 0.559 0.560 0.428

2:

```
1.071 1.661 1.015 1.448 0.730 0.726 0.382
3:
   1.807 1.911 1.448 1.435 1.016 0.945 0.541
4:
   1.815 1.424 0.730 1.016 0.542 0.671
   1.008 0.559 0.726 0.945 0.671
7:
   0.396 0.560 0.382 0.541
   0.540 0.428
1D AXIAL AVERAGE POWER DENSITY
   0.1980
2:
   0.2668
3:
   0.4218
4:
   0.6821
   0.9924
6:
   1.2422
7:
   1.4161
8:
   1.5034
9:
   1.4989
10: 1.4027
11: 1.2209
12: 0.9645
13: 0.6493
14: 0.4000
15: 0.2440
16: 0.1364
```

The similar output is given for the other distributions, please see the output files of the computed benchmark problems.

3.6 Output into the Binary File "SKETCH.grf"

SKETCH-N output into the text file contains only the summary of the computed distributions and the transient results are given at a few time moments. The

results of each time step are written into the binary file "SKETCH.grf". Please note, that if the file with this name exists it is overwritten. The binary file can be processed by a postprocessor after the calculations. The postprocessor input and output are discussed in the following section.

The output into the binary file contains several sets of the data. The first set of the data gives the reactor model description: the problem title, date and time of the calculation, reactor model geometry, etc. In the case of the Ringhals-1 BWR calculations, the next set of the data include static 3D distributions taken from the distribution file FILE_DIST. The static distributions include burnup, xenon, void history, control rod history, conversion history and steady-state power and void. The next set of the data is the calculation results written at the end of the steadystate calculation and at each time step of the transient calculation. The results include scalar data, vector data and 3D distributions. The scalar data include total reactor power, reactivity, time step size of the SKETCH code and time step size proposed by the external thermal-hydraulic code. The only one set of the vector data is present; it contains the positions of the control rods. The list of the output distributions includes power distribution, boron concentration, coolant density and temperature, Doppler fuel temperature. If the internal thermal-hydraulics model is used in the calculation the additional output distributions are fuel centerline temperature, cladding inner surface temperature and fuel enthalpy.

3.7 Postprocessing of the SKETCH-N results

A postprocessor is developed to convert the contents of the SKETCH-N binary file into the text form suitable for plotting and reading. The code is written in FORTRAN 90 language. To build the postprocessor please use the Makefile in the directory Source and type

• make ../POSTPROC

The first set of the postprocessor input data is given in the namelist file "PostProc.INI". The list of the variables is given in Table 3.12.

Table 3.12: Variables of the namelist PostProc of the namelist file "PostProc.INI".

Variable Name	Default Value	of the namelist file "PostProc.INI" Description
FILE_GRF	"Output/SKETCH.grf"	name of the SKETCH-N binary
	·	output file
FILE_INP	11.11	name of the input file for
		postprocessor
FILE_OUT	"Output/PostProc.lst"	name of the output file with the
		listing of the postprocessor run
FILE_TR_OUT	"Output/Proc_TR.lst"	name of the output file with the
		transient data given versus time
FILE_TM_OUT	"Output/Proc_TM.lst"	name of the output file with
		the transient data given at the
		certain time moment
TIME_OUTPUT	0.0	Time moment of the transient
		data written into the file
		FILE_TM_OUT
FILE_ST_OUT	$"Output/Proc_ST.lst"$	name of the output file with the
		static distributions
FMT_TR_R	"(E12.5)"	Output format for real data
		written in the file FILE_TR_OUT
FMT_TR_I	"(I5)"	Output format for integer data
		written in the file FILE_TR_OUT
FMT_TI_R	"(F6.3)"	Output format for real data
		written in the file FILE_TM_OUT
FMT_TI_I	"(I5)"	Output format for integer data
		written in the file FILE_TM_OUT
FMT_ST_R	"(F6.3)"	Output format for real data
		written in the file FILE_ST_OUT
FMT_ST_I	"(I5)"	Output format for integer data
	WATER ON	written in the file FILE_ST_OUT
TM_3D_OUTPUT	"YES"	Option of the output of 3D
		distribution: "YES" - 3D
		distributions are written into
		the output files FILE_TM_OUT,
		"NO" - 3D distributions are not
		written

Another input files of the postprocessor are the SKETCH-N output binary file, which is defined by the variable FILE_GRF, and the postprocessor input file specified by the variable FILE_INP. If the postprocessor input file FILE_INP is not

defined in the namelist, the code generates only the output listing file FILE_OUT with the description of the content of the SKETCH-N binary file FILE_GRF. The postprocessor may also generate three other output files FILE_TR_OUT, FILE_TM_OUT, and FILE_ST_OUT depending on the input in the file FILE_INP. The file FILE_TR_OUT contains the SKETCH transient results given versus time. The file FILE_TM_OUT gives the transient results at the certain time moment, which is defined by the variable TIME_OUTPUT in the namelist file. The file FILE_ST_OUT contains the static distributions. To generate any of these files, the input data in the file FILE_INP should be defined.

3.7.1 Output of the Data versus Time

Let us consider the input data, which define the content of the output file FILE_TR_OUT. At each time step of the calculation the SKETCH-N code writes the set of the data into the binary file "SKETCH.grf". A set includes scalar data, vector data and 3D distributions. The list of these data is discussed in the previous section and printed in the postprocessing listing file given under the variable FILE_OUT. For example, the transient results of the NEACRP PWR rod ejection benchmark include

```
Transient Data :
Scalar Data :
1 - Total Reactor Power, [MWt]
2 - Reactivity, [$]
3 - Time Step Size of tke SKETCH-N code, [ms]
4 - Time Step Size proposed by tke TRAC code, [ms]
Vector Data :
1 - control Rod Positions, [cm]; Dimension = 15
3D Distributions :
1 - Power, [Wt/cm^3]
2 - Boron concentration, [ppm]
3 - coolant Temperature, [c]
4 - coolant Density, [g/cm^3]
5 - Doppler Fuel Temperature, [K]
```

- 6 Fuel centerline Temperature, [K]
- 7 cladding Inner Surface Temperature, [K]
- 8- Fuel Enthalpy, [J/Kg]

The data set may be extended in the future, we recommend to check a content of the postprocessing output file FILE_OUT. The output, which is given in the output file FILE_TR_OUT, is defined by the variable identifiers given in the input file. The identifiers are five characters, which may be followed the additional data. The identifiers of the variables for the output into the file FILE_TR_OUT start with the character "T". The second character encodes the data type as shown in Table 3.13.

Table 3.13: Meaning of the second character of the identifiers in the postprocessor input file FILE_INP.

Character	Meaning
"S"	Scalar data
"V"	Vector Data
"D"	Distribution
"M"	Maximum or minimum value of the distribution, only for the data
	versus time, which identifier starts with "T"
"I"	Location of the maximum or minimum value of the distribution,
	only for the data versus time, which identifier starts with "T"

The next three characters give the index of the variable in the transient data list. For example, TS001 means the first scalar variable, which is the total reactor power; TV001 is the first vector data, which contains the control rod positions; TD005 is the fifth distribution, which is the Doppler fuel temperature. In the case of the scalar variables, the identifier of five characters totally defines the output variable.

In the case of the vector data, the five character identifier is followed by the index of the vector element given in the free format. For example the input

TV001 1

means the position of the first control rod.

In the case of the distribution, the five character identifier is followed by x-y-z coordinates of the spatial node. For example

TD005 1 1 1

means the Doppler fuel temperature of the node with x-y-z coordinates (1,1,1). Please note that the node coordinates are given for the reactor model grid, not the reactor core grid. The spatial grid includes a reactor core and reflectors. In addition to the values of distribution at the certain node of 3D spatial grid, the core-averaged values and average 2D and 1D values can be specified. The core-averaged values have the coordinates (0, 0, 0); average 1D distribution have zero x-y coordinates and nonzero z coordinates; average 2D distributions have nonezero x-y coordinates and zero z coordinate. For example, the input

TD005 0 0 0

defines the core-averaged Doppler fuel temperature; the input

TD005 0 0 1

specifies the average 1D Doppler fuel temperature at the axial layer 1; and the input

TD005 1 1 0

defines the average 2D Doppler fuel temperature of the bundle with x-y coordinates (1,1).

Maximum and minimum values of the distributions and their locations can be also given in the output file. The identifier TMxxx defines the maximum or minimum value of the distribution number xxx. This identifier is followed by the dimension index given with a "+" sign for the maximum value and "-" sign for minimum value. For example, the input

TM005 +3

means the maximum value of the 3D Doppler fuel temperature;

TM005 -1

means the minimum value of the average 1D Doppler fuel temperature.

The identifiers of the location of the maximum or minimum value are given in the similar form, they start with TLxxx, xxx stands for the number of the distribution, followed by the dimension index given with plus or minus sign.

For example, the input

TL005 +3

means the location of the maximum value of the 3D Doppler fuel temperature;

TM005 -1

means the location of the minimum value of the average 1D Doppler fuel temperature.

Finally let us consider an example of the postprocessor input for the transient results of the NEACRP PWR rod ejection benchmark. The contents of the input file is given below

```
! OUTPUT OF THE DATA VS. TIME
! Reactor Power, [MWt]
TS001
! Reactivity [$]
TS002
! Time Step Size, [ms]
TS003
! Position of the 1st control Rod [cm]
TV001 1
! Average Doppler Fuel Temperature [K]
TD005 0 0 0
! Maximum Fuel centerline Temperature [K]
TM006 3
! Location of the 3D Maximum Fuel centerline Temperature
TL006 3
```

The output format are define as "(F9.3)" for real variables and "(I5)" for integer variables. The postprocessor generate the output file FILE_TR_OUT, where the first column is the time in seconds and the other columns are defined by the input identifiers. The beginning of the file is given below

0.000	0.001	0.000	5.000	37.700	559.152	559.152	4	1	7
0.010	0.001	0.009	7.426	74.048	559.152	559.152	4	1	7
0.016	0.001	0.032	2.939	95.424	559.152	559.152	4	1	7

0.022	0.001	0.076	3.212	116.787	559.152	559.152	4	1	7
0.025	0.001	0.111	1.347	126.846	559.152	559.152	4	1	7
0.027	0.001	0.146	2.285	136.638	559.152	559.152	4	1	7
0.032	0.001	0.220	1.995	153.251	559.152	559.152	4	1	7
0.036	0.001	0.297	2.298	167.756	559.152	559.152	4	1	7
0.040	0.001	0.394	1.883	184.463	559.152	559.152	4	1	7
0.044	0.001	0.478	1.886	198.152	559.152	559.152	4	1	7
0.048	0.001	0.559	1.774	211.861	559.152	559.152	4	1	7
0.051	0.001	0.635	1.757	224.755	559.152	559.152	4	1	7
0.055	0.002	0.701	1.687	237.530	559.152	559.152	4	1	7

etc.

3.7.2 Output of the Data at the Certain Time Moment

A code user often wants to know the reactor data at the time moments, which are not know before the calculation is performed, for example, at the time of the power peak or at the time before scram control rods start moving.

The postprocessor provides a capability to output the SKETCH-N computed results at the user defined time moment. The time is defined by the variable TIME_OUTPUT in the namelist file "PostProc.INI". The output is written into the file FILE_TM_OUT. The output values are computed by a linear interpolation of the SKETCH results at the time interval, which includes the specified time moment. The output is defined by the variable identifiers given in the input postprocessor file FILE_INP. The identifiers are similar to the identifiers discussed in the previous section. The identifier has five characters, which may followed by additional data. The identifier for this output starts with the character "M". The second character encode of the type of the variable: "S" stands for scalar data; "V" defines the vector data and "D" means a distribution. The last three characters are the index of the variable in the SKETCH-N output transient data list, which is written in the postprocessor output listing file FILE_OUT. The example is given in the previous section. The identifier defines the output variable. In the case of the distribution, the output scaling factor may follow the identifier. If the scaling factor is not given, the default value 1.0 is used. Scaling factor may has the value 0.0. In this case, the core- averaged value of the distribution is used as the scaling factor for output.

Let us consider an example of the postrocessor input for the output of the transient values at the given time moment. The results of the NEACRP PWR rod ejection benchmark are considered. The time moment is 5.0 s, which is the end of the transient. The input for the postprocessor is given below,

```
MS001 # Reactor power [MWt]
MD001 0.0 # Power distribution; scaling factor is the core-averaged value
```

which define the output of the total reactor power and the power distribution normalised to the core- averaged value. The output format is "(F6.3)". The postprocessor output written into the file FILE_TM_OUT is shown below. Please note that only the results of the reactor core region are given in this output.

!=====	=======		!
!		PostProcessing of the SKETCH-N Results	!
!	Version	1.0 (c) Slava 2000 e-mail: na.vzimin@na-net.ornl.gov	!
!	Date	& Time of Calculation: 8 August 2000 5:42:06 pm	!
!=====	======		!
Input	SKETCH	*.grf File : Output/SKETCH.grf	
Input	PostProd	c *.dat File : Input/PostProc_PWR_AL_KIN.dat	
!=====	======		!
!		SKETCH-N	!
!Nodal	Neutron	Diffusion Code for Solving Steady-State and Kinetics Problems	!
!	Version	1.0 (c) Slava 2000 e-mail: na.vzimin@na-net.ornl.gov	!
!	Date	& Time of Calculation: 8 August 2000 5:42:06 pm	!
!=====	======		!
!			!
!		3D NEACRP PWR Rod Ejection Benchmark	!
!		(c) Slava March 1998	!
!			!
Output	of the	data in time moment = 0.50000E+01	
Tinoar	intorno	lation in interval [0 48070F+01 0 50000F+01]	

Starting the program

```
Interpolation factor = 1.00000
!-----!
Total Reactor Power, [MWt]
Scaling Factor = 0.10000E+01
0.13682E+03
!-----!
POWER, [Wt/cm<sup>3</sup>]
Scaling Factor = 0.49189E-01
!-----!
Distribution Summary:
Scaling Factor : 0.49189E-01
Average Value : 1.000
3D Maximum Value : 4.842
Reactor Location of 3D Maximum (X,Y,Z): 1 1 8
Core
      Location of 3D Maximum (X,Y,Z): 1 1 7
3D Minimum Value : 0.041
Reactor Location of 3D minimum (X,Y,Z): 7 3 17
Core
      Location of 3D minimum (X,Y,Z): 7 3 16
2D Maximum Value : 3.210
Reactor Location of 2D Maximum (X,Y) : 1 1
Core
      Location of 2D Maximum (X,Y) : 1 1
2D Minimum Value : 0.322
Reactor Location of 2D minimum (X,Y) : 3 7
      Location of 2D minimum (X,Y) : 3 7
Core
1D Maximum Value : 1.496
Reactor Location of the 1D Maximum (Z):
                                 9
      Location of the 1D Maximum (Z):
Core
```

8

Starting the program

```
1D Minimum Value
          :
             0.114
Reactor Location of the 1D minimum (Z):
                        17
    Location of the 1D minimum (Z):
                         16
!-----!
2D Distribution
!-----!
            3
               4
                    5
                         6
                            7
                                 8
 ____
      ____
          ____
              ____
                  ____
                      ----
                          ____
0.354
4: 1.770    1.863    1.373    1.292    0.884
                      0.794
                          0.449
5: 1.658    1.308    0.660    0.884    0.462
                      0.559
6: 0.893  0.495  0.625  0.794  0.559
7: 0.337  0.474  0.322  0.449
8: 0.445 0.354
!-----!
1D Distribution
2 0.253
3 0.341
4 0.534
5 0.842
6 1.172
7 1.389
8 1.494
9 1.498
10 1.419
11 1.271
12 1.069
13 0.825
14 0.548
15 0.335
```

•	114									!
CHAN	1	2	3	4	5	6	7	8	9	10
2:	0.700	0.669	0.425	0.458	0.344	0.223	0.107	0.088	0.669	0.573
3:	1.123	0.897	0.458	0.607	0.550	0.301	0.115	0.141	0.897	0.902
4:	1.807	1.413	0.697	0.954	0.885	0.470	0.174	0.226	1.413	1.441
5:	2.847	2.223	1.095	1.505	1.401	0.741	0.274	0.360	2.223	2.267
6:	3.915	3.064	1.517	2.089	1.949	1.034	0.384	0.506	3.064	3.126
7:	4.573	3.590	1.790	2.469	2.309	1.231	0.460	0.607	3.590	3.666
8:	4.847	3.817	1.915	2.648	2.482	1.330	0.500	0.661	3.817	3.900
9:	4.797	3.789	1.913	2.650	2.487	1.339	0.506	0.671	3.789	3.874
10:	4.491	3.556	1.805	2.503	2.353	1.272	0.483	0.641	3.556	3.638
11:	3.988	3.165	1.613	2.239	2.107	1.143	0.435	0.578	3.165	3.238
12:	3.335	2.650	1.355	1.881	1.772	0.963	0.368	0.489	2.650	2.712
13:	2.563	2.040	1.045	1.451	1.366	0.744	0.284	0.378	2.040	2.087
14:	1.697	1.352	0.694	0.963	0.907	0.494	0.189	0.251	1.352	1.383
15:	1.035	0.825	0.425	0.590	0.556	0.303	0.116	0.154	0.825	0.845
16:	0.623	0.498	0.259	0.359	0.338	0.185	0.071	0.094	0.498	0.510
17:	0.304	0.270	0.152	0.206	0.185	0.106	0.042	0.052	0.270	0.253

etc. till the bundle number 47.

3.7.3 Output of the Static Distributions

In the case of BWR Ringhals-1 calculations, the static distributions taken from the SKETCH input distribution file are written into the SKETCH output binary file. The postprocessor can also output these distributions into the text form in the file FILE_ST_OUT defined in the namelist file "PostProc.INI". The list of the static distributions is given in the postprocessor output file FILE_OUT. The output variables are specified by the identifiers given in the input postprocessor

file FILE_INP. The definition of the output variables is practically identical to that discussed in the previous section. The only difference that the identifiers for the output of the static distributions start with the character "S".

Chapter 4

2D four-group KOEBERG PWR benchmark

This chapter contains the description of the SKETCH-N calculation of the 2D four-group KOEBERG PWR benchmark (Müller and Weiss, 1991). The SKETCH-N input and output files for this problem are given in the directory "Samples/PWR_KOEBERG2D". The SKETCH-N results have been published in (Zimin et al., 1998).

4.1 Benchmark Problem Description

KOEBERG benchmark is 2D four-group pure neutronics eigenvalue problem (Müller and Weiss, 1991). The beginner of life core of Unit 1 of the KOEBERG nuclear power plant is modelled. The reactor model consists of 157 homogenised fuel assemblies of three enrichments and three different absorber loadings, each assembly having a width of 21.608 cm. The core is surrounded by a 21.608 cm homogenised reflector (2.8575 cm baffle homogenised with 18.7505 cm borated water). Vacuum boundary conditions are imposed on the outer reflector surface. A quarter-core reactor configuration is shown in Fig. 4.1. Four-group macro cross sections are given in Table 4.1.

The reference solution of this problem is computed by the LABAN-PEL nodal code using 6 order expansion of the neutron flux into Legendre polynomials (Müller

and Weiss, 1991). The reference eigenvalue and 2D assembly-averaged power distribution are given in Fig. 4.2.

1										_
		3	1	3	1	2	1	4	7	
	3	1	3	1	2	1	6	4	7	
	1	3	1	2	1	3	4	7	7	
	3	1	2	1	3	5	4	7		•
	1	2	1	3	1	4	7	7		
	2	1	3	5	4	7	7		•	
	1	6	4	4	7	7				
	4	4	7	7	7					
	7	7	7			•				
,				•						

Figure 4.1: Core configuration of the four-group KOEBERG PWR benchmark

Table 4.1: Macro cross sections for four-group KOEBERG PWR benchmark.

<u> ra</u> bi	<u>e 4.1:</u> N						PWKben	
Zone	Group	D_g	Σ_{ag}	$\nu \Sigma_{fg}$	Σ_{sg1}	Σ_{sg2}	Σ_{sg3}	Σ_{sg4}
1	1	2.491869	0.003654	0.008228	0.0	0.0	0.0	0.0
	2	1.045224	0.002124	0.000536	0.063789	0.0	0.0	0.0
	3	0.677407	0.019908	0.007058	0.000486	0.064381	0.0	0.001245
	4	0.375191	0.067990	0.083930	0.0	0.000003	0.050849	0.0
2	1	2.492653	0.003685	0.008295	0.0	0.0	0.0	0.0
	2	1.049844	0.002215	0.000713	0.063112	0.0	0.0	0.0
	3	0.676610	0.022012	0.009230	0.000478	0.063078	0.0	0.001543
	4	0.379481	0.085052	0.108244	0.0	0.000003	0.048420	0.0
3	1	2.491978	0.003684	0.008285	0.0	0.0	0.0	0.0
	2	1.051910	0.002221	0.000713	0.062765	0.0	0.0	0.0
	3	0.677084	0.022403	0.009214	0.000473	0.062404	0.0	0.001598
	4	0.381453	0.088077	0.108087	0.0	0.000003	0.047549	0.0
4	1	2.492535	0.003740	0.008459	0.0	0.0	0.0	0.0
	2	1.045298	0.002299	0.000923	0.063737	0.0	0.0	0.0
	3	0.674684	0.022621	0.011714	0.000486	0.064330	0.0	0.001630
	4	0.374240	0.091000	0.133600	0.0	0.000003	0.049518	0.0
5	1	2.492329	0.003730	0.008409	0.0	0.0	0.0	0.0
	2	1.051953	0.002315	0.000921	0.062737	0.0	0.0	0.0
	3	0.675683	0.023822	0.011675	0.000473	0.062376	0.0	0.001797
	4	0.380606	0.100246	0.134282	0.0	0.000003	0.046859	0.0
6	1	2.491521	0.003730	0.008400	0.0	0.0	0.0	0.0
	2	1.054029	0.002321	0.000921	0.062386	0.0	0.0	0.0
	3	0.676197	0.024196	0.011651	0.000468	0.061696	0.0	0.001852
	4	0.382434	0.103283	0.133974	0.0	0.000003	0.046005	0.0
7	1	2.119737	0.000466	0.0	0.0	0.0	0.0	0.0
	2	0.980098	0.000263	0.0	0.042052	0.0	0.0	0.0
	3	0.531336	0.004282	0.0	0.000322	0.044589	0.0	0.000978
	4	1.058029	0.116918	0.0	0.0	0.0	0.052246	0.0

 $\chi_1 = 0.745248; \quad \chi_2 = 0.254328; \quad \chi_3 = 0.000424; \quad \chi_4 = 0.0$

Figure 4.2: Reference power distribution and eigenvalue for KOEBERG PWR benchmark

4.2 Include and Input Files

The include and input files for the SKETCH-N code are given in the directory "Samples/PWR_KOEBERG2D" in the subdirectories lnclude and lnput, respectively. The include file "koeberg2d.fh" is the file, which is used in the compilation of the code under the name "parameters.fh". The list of the input files follows below:

- "SKETCH.lNl.KOEBERG2D.ST" is the namelist input file;
- "KOEBERG2D.DAT" is the input file with the reactor model data;
- "KOEBERG2D.ref" is the input file with the reference solution. The contents of the include and input files are given in the Appendix A.

The reactor model parameters, which defines the dimensions of the code arrays, are given in the file "koeberg2d.fh". The content of this file is presented in the Appendix A.1. Let us shortly outline the meaning of the input data, the detail description of the input variables is given in the Section 3.1. The quarter-core reactor model is used in the calculation. The reactor model has 64 assemblies, 47 assemblies are in the reactor core. The reactor spatial mesh 9x9 with 1 node per assembly is defined. 7 types of the assemblies are specified; in 2D calculations, they correspond to 7 material compositions. Four neutron energy groups are used. The problem is a steady-state eigenvalue problem and delayed neutron precursors

are not used in the calculations. However, the number of delayed neutron groups should be given in the parameter file and the number is defined as 1. There are no thermal-hydraulics feedbacks in this problem. However, in the SKETCH-N code, the number of feedbacks is fixed to 4 and should be given in the parameter file. The problem does not require the control rods and neither internal or external thermal-hydraulics model. However, the values of the parameters related to these models should be defined, in the file "koeberg2d.fh" we set them to 1. Please note that due to the static memory allocation used in the present version of the code, these parameters could not be zero. The content of the namelist file "SKETCH.INI.KOEBERG2D.ST" is given in the Appendix A.2. In the namelist INI_PROBLEM, we define that the problem type is an eigenvalue problem and that no thermal-hydraulics model is used. In the namelist INI_FILES, the input and restart files are given. The default convergence criterion 1.E-5 are used in the calculations. In the namelist INI_CHEBYSHEV, we set the inverse value of the Wieland shift to 10.0 to accelerate the convergence of the steady-state iterations. The reactor model data are given in the file "KOEBERG2D.DAT". The content of this file is given in the Appendix A.3. The data include the description of the spatial mesh, macro cross sections, core loading by material compositions and boundary conditions. The input data are prepared in accordance with the benchmark specification. The detail description of the input data identifiers is given in the Section 3.3. Only a few comments are added. The value of the reactor power is not important in this problem, because no feedbacks are considered and normalised 2D power distribution is required for a comparison. We used the value of the 1 MWt for the reactor power. In the benchmark specification (Müller and Weiss, 1991), the energy release per fission is not defined. We use a constant value 3.204E-11 [Ws/fission] for all neutron energy groups. The reactor model is defined in the quarter-core configuration. A spatial mesh with 1 node per assembly is used. The boundary conditions are reflective at the Up and Left boundaries and vacuum conditions at the Right and Down boundaries. Zero axial buckling is used. The file "KOEBERG2D.ref" is the input file with a reference solution. The contents of this file is shown in Appendix A.4. The file contains one line of a header, the reference eigenvalue and 2D assembly-averaged power distribution. The SKETCH-N code performs a comparison of the computed results with the given reference data.

4.3 Steady-State Calculation and Output Files

To perform the calculation we prepare the shell file "PWR_KOEBERG2D.sh", which is given in the directory Shell. The commands of the file are given below

```
>cd ../Include
>cp ../Samples/PWR_KOEBERG2D/Include/koeberg2d.fh parameters.fh
>cd ../Source
>scons
>cd ../Input
>cp ../Samples/PWR_KOEBERG2D/Input/KOEBERG2D.DAT KOEBERG2D.DAT
>cp ../Samples/PWR_KOEBERG2D/Input/KOEBERG2D.ref KOEBERG2D.ref
>cp ../Samples/PWR_KOEBERG2D/Input/KOEBERG2D.ref KOEBERG2D.ref
>cp ../Samples/PWR_KOEBERG2D/Input/SKETCH.INI.KOEBERG2D.ST SKETCH.INI
>cd ..
>./sketch.exe
>cd Shell
```

The shell file copies the include file and the input files into the working directories, builds the code and performs the calculation. The code output is given in the directory Output in the files "Error.msg", "SKETCH.lst", "SKETCH.grf". The error message file "Error.msg" contains some warnings, because several input identifiers are not given in the input file and default values are used. These warnings may be ignored. The input data and the calculation results are written into the text output file "SKETCH.lst". The sample of this file is "Samples/PWR KOEBERG2D/Output/SKETCH.lst". You can compare the computed power distribution and the eigenvalue with the values given in the sample file. The binary file "SKETCH.grf" may be processed by the SKETCH Examples of the postprocessor use are given in the following postprocessor. Chapters for transient benchmarks. The file "Comparison.dat" contains a comparison of the computed eigenvalue and 2D power distribution with the reference solution taken from the input file "KOEBERG2D.ref". The content of the file "Comparison.dat" is given in the Appendix A.5. The calculation performed using the semi-analytical nodal method on the spatial mesh with one node per assembly. An error in eigenvalue is 39 pcm. The maximum error in 2D assemblyaveraged power distribution is 2.0% for assembly (1,8). An average error in power

2D four-group KOEBERG PWR benchmark

distribution is 1%. The results may be slightly different on different computers because the code uses single precision arithmetic.

Chapter 5

3D NEACRP PWR rod ejection benchmark, case A1

This chapter contains the description of the SKETCH-N calculation of the case A1 of 3D NEACRP PWR rod ejection benchmark (Finnemann and Galati, 1992). The SKETCH-N input and output files for this problem are given in the directory "Samples/PWR NEACRP A1".

5.1 Benchmark Problem Description

The NEACRP PWR rod ejection benchmark is proposed by (Finnemann and Galati, 1992) and has been widely used for the verification of coupled neutronics/thermal-hydraulics codes (Finnemann et al., 1993). A PWR core model is derived from the real reactor geometry and operational data. The transients are initiated by a rapid ejection of a control rod at the hot zero power (cases A1, B1 and C1) or full power (cases A2, B2 and C2). Only the case A1 is considered in this report, the results of all the cases computed by the J-TRAC/SKETCH-N code are given in (Zimin et al., 1999). The reactor geometry has 1/8 core symmetry in the case A1. The width of assemblies is 21.606 cm. The reactor core height is 367.3 cm. The core is subdivided into 16 axial layers with heights of 7.7, 11.0, 15.0, 30.0 (10 layers), 12.8 (2 layers) and 8.0 cm from bottom to top. Top and bottom axial reflectors have thickness of 30.cm.

Fuel assemblies with different U-235 enrichment and different numbers of rods of burnable absorbers are present in the core. 11 different material compositions and the corresponding sets of cross sections are defined. The material compositions may be grouped into 9 assembly types. Core loading by assembly types is shown in Fig. 5.1. Axial material composition of each assembly type is shown in Table 5.1.

The radial arrangement of control assemblies (CA) is shown in Fig. 5.2. The total length of CA, which coincides with the absorber length, is 362.159 cm. The driver device section following the top of the absorbers is distinguished from the absorber via a different cross section data set. No tips of control rods is defined. The position of the lower CA absorber edge from the bottom of the lower reflectors is 37.7 cm for a completely inserted CA, and 401.183 cm for a completely withdrawn CA. Measured in units of steps, complete insertion or withdrawal of CA corresponds to 0 and 228 steps, respectively.

Two prompt neutron groups and six delayed neutron groups are used. Zero flux boundary conditions are imposed on the outer reflector surface. Velocities and the energy release per fission are given in Table 5.2. Table 5.3 shows the time constants and fractions of the delayed neutrons. No delayed neutron energy release is considered.




Figure 5.1: Core loading by assembly types for 3D NEACRP PWR rod ejection benchmark, case ${\rm A1}$

Table 5.1: Axial material composition of the assemblies for 3D NEACRP PWR rod ejection benchmark.

Axial Layer	Material composition of the assembly type number N										
Axiai Layei	1	2	3	4	5	6	7	8	9		
18 (top)	1	1	1	1	1	1	1	1	1		
3÷17	4	9	7	6	2	8	11	3	10		
2	4	5	5	6	2	5	6	3	6		
1 (bottom)	1	1	1	1	1	1	1	1	1		




Figure 5.2: Core loading by control assembly types for 3D NEACRP PWR rod ejection benchmark, case A1.

Table 5.2: Velocities and energy release of prompt neutrons for 3D NEACRP PWR rod ejection benchmark.

	Fast energy group	Thermal energy group
Neutron velocity [cm/s]	0.28E + 8	$0.44\mathrm{E}{+6}$
Energy release [Ws/fission]	0.3213E-10	0.3206E-10

Table 5.3: Decay constants and fractions of delayed neutrons for 3D NEACRP PWR rod ejection benchmark.

	J	
group	Decay constant $[1/s]$	Relative fraction of delayed neutrons
1	0.0128	0.034
2	0.0318	0.200
3	0.1190	0.183
4	0.3181	0.404
5	1.4027	0.145
6	3.9286	0.034
Total f	raction of delayed neutrons:	0.76 %

For each material composition the following macro cross sections are given

 $\Sigma_{tr1}, \Sigma_{tr2}$ are the transport macro cross sections;

 Σ_{a1}, Σ_{a2} are the absorption macro cross sections;

 Σ_{s21} is the scattering macro cross section from the group 1 into the group 2;

 Σ_{f1}, Σ_{f2} are the fission macro cross sections;

 $\nu\Sigma_{f1}, \nu\Sigma_{f2}$ are the production macro cross sections.

The macro cross sections depend on the following feedback variables c is the borom concentration [ppm];

 ρ is the coolant density $[g/cm^3]$;

 T_M is the coolant temperature [C];

 T_D is the Doppler fuel temperature [K].

The macro cross sections are expressed in terms of the feedback variables as

$$\Sigma = \Sigma_0 + (\partial \Sigma / \partial c)_0 (c - c_0) + (\partial \Sigma / \partial \rho)_0 (\rho - \rho_0) + (\partial \Sigma / \partial T_M)_0 (T_M - T_{M0}) +$$

$$(\partial \Sigma/\partial \sqrt{T_D})_0(\sqrt{T_D}-\sqrt{T_{D0}}),$$

where index 0 marks the reference values.

The reference macro cross sections, their derivatives and the feedback reference values are given for each material composition. We decided not to give the values in this section referring a reader to the benchmark specification (Finnemann and Galati, 1992) or to the content of the SKETCH-N input file, which is given in the Appendix B.3.

The macro cross section of the node with a control rod is determined by adding the differential cross section $\Delta \Sigma^{CR}$ to the cross section without control rod as

$$\Sigma^{\rm with~CR} = \Sigma^{\rm without~CR} + \Delta \Sigma^{CR}$$

The differential cross section $\Delta \Sigma^{CR}$ does not depend on the feedbacks. The contribution of the control rod driver is treated in the same way. The differential cross section of the absorbers and drivers are given in the benchmark specification

(Finnemann and Galati, 1992) and can be extracted from the SKETCH input file given in the Appendix B.3.

The Doppler fuel temperature is computed interpolating the fuel rod centerline temperature $T_{F,C}$ and the fuel rod surface temperature $T_{F,S}$ as

$$T_D = (1 - \alpha)T_{F,C} + \alpha T_{F,S},$$

where α is taken equal 0.7.

Data of the fuel assembly geometry are given in Table 5.4.

The UO₂ density without dishing is 10.412 g/cm³ (95 % of the theoretical density) at a temperature of 10 °C. The pellet dishing amounts to 1.248 %. The cladding material is Zircaloy-4 with a density of 6.6 g/cm³. The relations for the heat conductivity λ [W/(m °K)] and specific heat capacity c_p [J/(kg °K) of fuel and cladding are defined as follows

$$\lambda_{UO2} = 1.05 + 2150/(T - 73.15)$$

$$\lambda_{Zirkaloy-4} = 7.51 + 2.09 \times 10^{-2}T - 1.45 \times 10^{-5}T^2 + 7.67 \times 10^{-9}T^3$$

$$c_{p,UO2} = 162.3 + 0.3038T - 2.391 \times 10^{-4}T^2 + 6.404 \times 10^{-8}T^3$$

$$c_{p,Zirkaloy-4} = 252.54 + 0.11474T$$

where T is the temperature [°K].

Expansion effects of fuel and cladding are not considered in the benchmark.

The flat profile of the power density inside the fuel rod in radial direction is assumed.

The reactor is at the beginner of cycle 1 (zero EPFD: no Xenon or Iodine, no fuel depletion). The steady-state operation data are defined in Table 5.5. The thermal energy output is to be released for 98.1% in the fuel and for 1.9% in the coolant. The inlet mass flow through the core given in Table 5.5 is distributed uniformly among the channels. A homogeneous core pressure of 155 bar is assumed. The conductance of the helium-filled gap between fuel and cladding is assumed to be constant of $104 \, [\mathrm{W/(m2^\circ K)}]$.

The critical steady-state parameters of the core have to be found from a

search of the critical boron concentration for the given thermal power and control assembly (CA) positions. The transient is initiated by a rapid ejection of a control assembly from an initially critical core at the hot zero power condition in the case A1. The control rod ejection results in more than 1 reactivity insertion, which is terminated by a Doppler feedback. The time of the control rod ejection is 100 ms. No reactor scram is considered. Both the boron concentration and the positions of the other control assemblies are kept constant in the transient. The initial CA positions and location of the ejected CA are shown in Fig. 5.3. Five seconds of the transient should be computed.

A private communication of the author with Dr. M. P. Knight of Nuclear Electric Ltd. (Knight, 1998) resolves some ambiguities and omissions of the benchmark specification. They are as follows

- the HZP power level is not specified, but should be 1.0E-6 of the full power;
- the control assembly driver and absorber should have zero fission cross sections in the top reflector;
- the Doppler fuel temperature dependence is on $\sqrt{T_D}$ with T_D taken in the degrees of Kelvin, even though the values of $(T_D)_0$ given in the benchmark tables are in the degrees of Celsius.

Table 5.4: Data of the fuel assembly geometry for 3D NEACRP PWR rod ejection benchmark.

Pellet diameter	8.239 mm
Clad diameter	9.517 mm
Clad wall thickness	$0.571~\mathrm{mm}$
FR pitch	12.655 mm
Guide tube diameter (outside)	12.259 mm
Guide tube diameter (inside)	11.448 mm
Geometry	17x17 - 25
Number of fuel pins	264
Number of guide tubes	25

Table 5.5: Steady-state operation data for 3D NEACRP PWR rod ejection benchmark.

Core thermal output	2775 MW
Core inlet temperature	286 °C
Core pressure	155 bar
Net mass flow rate through core	$12893 \mathrm{\ kg/s}$




Figure 5.3: Initial positions of the control assemblies for 3D NEACRP PWR rod ejection benchmark, case A1

A reference solution of the benchmark is computed by the PANTHER code using fine temporal and spatial meshes (Finnemann et al., 1993). Recently, Knight and Bryce published a refined reference solution (Knight and Bryce, 1997), where additional sensitivity analysis is performed and uncertainties of the reference results are significantly decreased. The reference solution contains several key steady-state and transient parameters: critical boron concentration, 3D nodal power peaking factors, control rod worth, time and value of the power peak, power

at the time 5 s, maximum fuel centerline temperature at time 5 s etc. The given reference parameters are representative and provide compact representation of the both global and local data of the rod ejection transient.

5.2 Include File "pwr neacrp a1.fh"

The include file "pwr_neacrp_a1.fh" is the file, which is used under the name "parameters.fh" in the code compilation. The file is given in the directory "Samples/PWR_NEACRP_A1/Include". The content of the file is shown in the Appendix B.1.

Let us shortly outline a meaning of the input data, the detail description of the input variables is given in the Section 3.1. The quarter-core reactor model has 64 assemblies subdivided into 18 axial layers. The spatial mesh 17x17x18 is used with 4 nodes per assembly in x-y plane. The mesh has 221 nodes in each axial layers, overall 9 assembly types are defined.

Eleven material compositions are defined with the corresponding set of the macro cross sections. Two prompt neutron groups and six delayed neutron groups are used. Four feedback variables are boron concentration, moderator temperature, moderator density and Doppler fuel temperature. The reactor model contains 15 control rods of 2 types. Each control rod consists of two control rod elements: absorber and driver. Three types of the control rod materials are defined: two types of the control rod absorbers and driver material, which is the same for the both types of the control rods.

Spatial mesh of the heat conduction model in the fuel rod has 9 zones in the fuel and 2 zones in the cladding.

The parameters of the external thermal-hydraulics model describes the spatial mesh of the J-TRAC code, which has been used in the coupled J-TRAC/SKETCH-N calculations of this problem (Zimin et al., 1999). These parameters are not used in the present calculation.

5.3 Input Files for the Steady-State Calculation

The input files for the SKETCH-N code are given in the directory "Samples/PWR_NEACRP_A1/Input". The list of the input files follows below:

- "SKETCH.INI.PWR A1.ST" is the namelist input file;
- "PWR NEACRP A1.DAT" is the input file with the reactor model data.

The content of the namelist file "SKETCH.INI.PWR_A1.ST" is given in the Appendix B.2. In the namelist INI_PROBLEM, we define that the problem type is a critical boron search and that the internal thermal-hydraulics model is used. In the namelist INI_FILES, the input and restart files are given. The default convergence criterion 1.E-5 are used in the calculations.

The reactor model data are given in the file "PWR_NEACRP_A1.DAT". The content of this file is given in the Appendix B.3. The data include the description of the spatial mesh, macro cross sections and their derivations with respect to feedbacks, core loading by material compositions, boundary conditions, the description of the control rods and the data for the internal thermal-hydraulics model. The input data are prepared in accordance with the benchmark specification. The detail description of the input data identifiers is given in the Section 3.3. Only a few comments are added.

The reactor power is 693.75 W for the quarter-core reactor model. Two-group macro cross sections and their derivatives with respect to the boron concentration, the moderator temperature, the moderator density and square root of the Doppler fule temperature are given for eleven material compositions. The differential macro cross sections are specified for three types of the control rod materials. The spatial mesh 17x17x18 is defined with a mesh size of 10.803 cm in x and y directions. The core is loaded by 9 assembly types, which contains 11 material compositions. The boundary conditions are reflective at the Up and Left boundaries and zero flux conditions at the Right, Down, Bottom and Top boundaries. The control rod data contains the description of the control rod ejection, which is used only in transient calculation. The control rod velocity 3634.3 cm/s provides a control rod ejection in 100 ms. The data for the thermal hydraulics model are prepared based on

the benchmark specification. The Dittus-Boelter correlation is used to compute the heat transfer coefficient between the cladding and coolant. The radial heat conduction spatial mesh in the fuel rods is determined by the code, the mesh size provide an equal area of the heat conduction zones.

5.4 Steady-State Calculation and Output Files

To perform the steady-state calculation we prepare the shell file "PWR_NEACRP_A1_ST.sh", which is given in the directory "Shell". The commands of the file are given below:

```
>cd ../Include
>cp ../Samples/PWR_NEACRP_A1/Include/pwr_neacrp_a1.fh parameters.fh
>cp /b parameters.fh+,,
>cd ../Source
>scons -j8
>cd ../Input
>cp ../Samples/PWR_NEACRP_A1/Input/PWR_NEACRP_A1.DAT PWR_NEACRP_A1.DAT
>cp ../Samples/PWR_NEACRP_A1/Input/SKETCH.INI.PWR_A1.ST SKETCH.INI
>read
>cd ..
>./sketch.exe
>cd Shell
```

The shell file copies the include file and the input files into the working directories, builds the code and performs the calculation. The code output is given in the directory "Output" in the files "Error.msg", "SKETCH.lst", "SKETCH.grf". The restart file for the transient calculation "pwr_neacrp_A1_0.dat" is written in the directory "Restart". The error message file "Error.msg" contains some warnings, because several input identifiers are not given in the input file and default values are used. These warnings may be ignored. The input data and the calculation results are written into the text output file "SKETCH.lst". The sample of this file is "Samples/PWR_NEACRP_A1/Output/SKETCH.lst.PWR_A1_ST". A comparison of the SKETCH-N steady-state results with the PANTHER reference

solution is given in the Table 5.6. You can compare the computed results with the values given in the Table 5.6 and in the sample file. The binary file "SKETCH.grf" may be processed by the SKETCH postprocessor. Examples of the postprocessor use are given in the section 5.7 for the transient results.

Table 5.6: A comparison of the steady-state SKETCH-N results with the PANTHER reference solution for the case A1 of the 3D NEACRP PWR rod ejection benchmark.

Parameter	SKETCH-N	Derivation	PANTHER
	result	from the	reference
		reference	
Critical boron concentration, ppm	561.9	$+0.7~\mathrm{ppm}$	561.2
3D nodal power peaking factor	2.8770	-0.08 %	2.8792

5.5 Input Files for the Transient Calculation

The input files for the SKETCH-N transient calculation are given in the directory "Samples/PWR_NEACRP_A1/Input". The list of the input files follows below

- "SKETCH.INI.PWR A1.KIN" is the namelist input file;
- "PWR NEACRP A1.DAT" is the input file with the reactor model data.

The content of the namelist file "SKETCH.INI.PWR_A1.KIN" is given in the Appendix B.4. In the namelist INI_PROBLEM, we define that the problem type is a transient problem and that the internal thermal-hydraulics model is used. In the namelist INI_FILES, the input and restart files are given. The file "Restart/pwr_neacrp_A1_0.dat" generated in the steady-state calculation is used as an input restart file for the transient calculation. The default convergence criterion 1.E-4 is used in the calculations. In the namelist INI_TIME_STEP, the data for time stepping are defined. An automatic time step selection is used. Five seconds of the transient are computed. An initial guess of the first time step is 0.005 s. Accuracy criteria of the automatic time step control is 5.E-03. The reactor model data are given in the file "PWR_NEACRP_A1.DAT", which is already used in the steady-state calculation. The content of this file is given in the Appendix B.3 and is described in the section 5.3.

5.6 Transient Calculation and Output Files

To perform the transient calculation we prepare the shell file "PWR_NEACRP_A1_KIN.sh", which is given in the directory "Shell". The commands of the file are given below:

```
>cd ../Input
>cp ../Samples/PWR_NEACRP_A1/Input/SKETCH.INI.PWR_A1.KIN SKETCH.INI
>read
>cd ..
>./sketch.exe
>cd Shell
```

The file copies the namelist file into the working input directory and run the code. The code output is given in the directory "Output" in the files "Error.msg", "SKETCH.lst", "SKETCH.grf". The input data and the calculation results at the beginner and the end of the transient are written into the text listing file "SKETCH.lst". A sample is "Samples/PWR_NEACRP_A1/Output/SKETCH.lst.PWR_A1_KIN". A comparison of the SKETCH-N results at the time of 5 s with the PANTHER reference results is given in the Table 5.7. You can compare the computed results with the values given in the Table 5.7 and in the sample file. Other transient results can be extracted from the binary file "SKETCH.grf" by the SKETCH postprocessor. The postprocessor input and output files are discussed in the following section 5.7.

Table 5.7: A comparison of the SKETCH-N results at the time of 5 s with the PANTHER reference results for the case A1 of the 3D NEACRP PWR rod ejection

benchmark.

Parameter	SKETCH-N	Derivation from	PANTHER
	result	the reference	reference
Power at 5 s, %	19.72	+0.15~%	19.69
Average Doppler fuel	324.87	-0.02 °C	324.89
temperature at 5 s, °C			
Maximum fuel	681	+2 °C	679.30
centerline			
temperature at 5 s, °C			
Coolant outlet	293.1	-0.1 °C	293.22
temperature at 5 s, °C			

5.7 Postprocessing the Transient Results

In addition to the SKETCH-N results at the time of 5 s, which are available from the listing file "SKETCH.lst", we are interested in the following data:

- total reactor power versus time;
- reactivity versus time;
- time step size used by the code versus time;
- average Doppler fuel temperature versus time;
- maximum fuel centerline temperature versus time.

To extract this data from the SKETCH-N binary file "SKETCH.grf" the postprocessor is used. As discussed in the section 3.7, the postprocessor requires two input files: the namelist input file "PostProc.INI" and the input data file. The files are given in the directory "Samples/PWR NEACRP A1/Input" as:

- "PostProc.INI.PWR_A1_KIN" is the namelist input file;
- "PostProc_PWR_A1_KIN.dat" is the input data file for the postprocessor.

The content of the namelist file "PostProc.INI.PWR_A1_KIN" is given in the Appendix B.5. The meaning of the namelist variables is discussed in the section 3.7. We specify the input data file "PostProc_PWR_A1_KIN.dat", the output file "PostProc_PWR_A1_TIME.lst" for the data versus time and the output format of the real output data.

The content of the input data file for the postprocessor is given in the Appendix B.6. The meaning of the input identifiers is discussed in the section 3.7.1. The identifiers specify that the following variables are given versus time:

- total reactor power [MW];
- reactivity [\$];
- time step size used by the code [ms];
- average Doppler fuel temperature [°K];
- maximum fuel centerline temperature [°K].
- location of the maximum fuel centerline temperature [°K].

To run the postprocessor we prepare the shell file "PP_PWR_NEACRP_A1_KIN.sh", which is given in the directory "Shell". The commands of the file are given below:

```
>cd ../Input
>cp ../Samples/PWR_NEACRP_A1/Input/PostProc.INI.PWR_A1_KIN PostProc.INI
>cp ../Samples/PWR_NEACRP_A1/Input/PP_PWR_A1_KIN.dat PP_PWR_A1_KIN.dat
>cd ..
>./postproc
>cd Shell
```

The file copies the input files into the working input directory, compile and run the postprocessor. As a result two output postprocessor files are generated: the postprocessor listing file "PostProc.lst" and the output file "PostProc_PWR_A1_TIME.lst", which contains the data versus time. The examples of these files can be found in the directory "Samples/PWR_NEACRP_A1/Output". A code user can use these

data to analyse the transient and plot the graphs. Table 5.8 contains a comparison of the time and value of the power peak taken from the file "PostProc_PWR_A1_TIME.lst" with the PANTHER reference solution. Fig. 5.4 till 5.7 present the graphs plotted using the postprocessor output data. Please note that the reactor power in Table 5.8 and in Fig. 5.4 is normalised on the steady-state value.

Table 5.8: A comparison of the SKETCH-N transient results with the PANTHER reference results for the case A1 of the 3D NEACRP PWR rod ejection benchmark.

Parameter	SKETCH-N	Deviation from	PANTHER
	result	the reference	reference
Time to the power	0.546	$+0.01 { m \ s}$	0.5375
peak, s			
Power at the peak, %	128.8	+1.6 %	126.78




Figure 5.4: Power and reactivity versus time for 3D NEACRP PWR rod ejection benchmark, case ${\rm A1}$




Figure 5.5: Time step size used by the SKETCH-N code for 3D NEACRP PWR rod ejection benchmark, case ${\rm A1}$




Figure 5.6: Average Doppler fuel temperature versus time for 3D NEACRP PWR rod ejection benchmark, case ${\rm A1}$




Figure 5.7: Maximum fuel centerline temperature versus time for 3D NEACRP PWR rod ejection benchmark, case ${\rm A1}$

Chapter 6

Modified IAEA-2D Test Without Reflector

The test problem is a modification of the well-known IAEA-2D benchmark problem (Chao and Shatilla, 1995) for hexagonal geometry.

The core is slightly smaller than that of a VVER-1000 reactor, with 13 fuel assemblies along the core diameter. The core contains 13 fuel assemblies with inserted control rods (Fig. 6.1). The fuel assembly pitch size is 20 cm. The reflector is not modeled, and boundary conditions are specified as a logarithmic derivative. The diffusion neutron physics constants are provided in Table 6.1. Two variants are considered, differing in the values of γ — the logarithmic derivative at the boundary.

Table 6.1: Diffusion constants for the modified IAEA-2D test

Material	1	2	3	4
D_1	1.500	1.500	1.500	1.500
D_2	0.400	0.400	0.400	0.400
$\Sigma_{a1} + \Sigma_{1\to 2}$	3.00e-2	3.00e-2	3.00e-2	4.00e-2
Σ_{a2}	8.00e-2	8.50e-2	1.30e-1	1.00e-2
$\Sigma_{1\to 2}$	2.00e-2	2.00e-2	2.00e-2	4.00e-2
Σ_{f1}	0.00	0.00	0.00	0.00
Σ_{f2}	5.60e-2	5.60e-2	5.60e-2	0.00
$\nu\Sigma_{f1}$	0.00	0.00	0.00	0.00
$\nu\Sigma_{f2}$	1.35e-1	1.35e-1	1.35e-1	0.00




Figure 6.1: Core loading for the modified IAEA-2D test problem

The include and input files for the SKETCH-N code are given in the directory "Samples/VVER_IAEA2D_NOR" in the subdirectories Include and Input, respectively. The include file "vver_iaea2d_nor.fh" is the file, which is used in the compilation of the code under the name "parameters.fh". The list of the input files follows below:

- "SKETCH.INI.VVER_IAEA2D_NOR_125.ST" is the namelist input file (for $\gamma = 0.125$);
- "VVER_IAEA2D_NOR_125.DAT" is the input file with the reactor model data (for $\gamma = 0.125$);
- "VVER_IAEA2D_NOR_125.ref" is the input file with the reference solution (for $\gamma = 0.125$). The contents of the include and input files are given in the Appendix C.

The reactor model parameters, which defines the dimensions of the code arrays,

are given in the file "vver_iaea2d_nor.fh". The content of this file is presented in the Appendix C.1.

The content of the namelist file "SKETCH.INI.VVER_IAEA2D_NOR_125.ST" is given in the Appendix C.2. In the namelist INI_PROBLEM, we define that the problem type is an eigenvalue problem and that no thermal-hydraulics model is used. In the namelist INI_FILES, the input and restart files are given. The default convergence criterion 1.E-5 are used in the calculations. In the namelist INI_CHEBYSHEV, we set the inverse value of the Wieland shift to 0.0 to accelerate the convergence of the steady-state iterations.

The reactor model data are given in the file "VVER_IAEA2D_NOR_125.DAT". The content of this file is given in the Appendix C.3. The data include the description of the spatial mesh, macro cross sections, core loading by material compositions and boundary conditions. The input data are prepared in accordance with the benchmark specification.

The file "VVER_IAEA2D_NOR_125.ref" is the input file with a reference solution. The file contains one line of a header, the reference eigenvalue and 2D assembly-averaged power distribution. The SKETCH-N code performs a comparison of the computed results with the given reference data.

To perform the calculation we prepare the shell file "VVER_IAEA2D_NOR_0125.sh", which is given in the directory Shell. The commands of the file are given below

```
>cd ../Include
>cp ../Samples/VVER_IAEA2D_NOR/Include/vver_iaea2d_nor.fh
parameters.fh
>cd ../Source
>scons
>cd ../Input
>cp ../Samples/VVER_IAEA2D_NOR/Input/VVER_IAEA2D_NOR_125.DAT
    VVER_IAEA2D_NOR_125.DAT
>cp ../Samples/VVER_IAEA2D_NOR/Input/VVER_IAEA2D_NOR_125.ref
    VVER_IAEA2D_NOR_125.ref
>cp ../Samples/VVER_IAEA2D_NOR/Input/SKETCH.INI.VVER_IAEA2D_NOR_125.ST
    SKETCH.INI
```

>cd ..

>./sketch.exe

The shell file copies the include file and the input files into the working directories, builds the code and performs the calculation. The code output is given in the directory Output in the files "Error.msg", "SKETCH.lst", "SKETCH.grf". The error message file "Error.msg" contains some warnings, because several input identifiers are not given in the input file and default values are used. These warnings may be ignored. The input data and the calculation results are written into the text output file "SKETCH.lst". The sample of this file is "Samples/VVER_IAEA2D_NOR/Output/SKETCH.lst". You can compare the computed power distribution and the eigenvalue with the values given in the sample file. The binary file "SKETCH.grf" may be processed by the SKETCH postprocessor.

Reference solutions for this test problem were obtained by extrapolating the results of calculations performed using the DIF3D-FD program.

Solutions to the test problem obtained using the SKETCH-N program are presented in Figures 6.2 and 6.3.

```
A Comparison of the SKETCH Results with Input/
VVER IAEA2D NOR 125.ref
 VVER IAEA-2D No Reflector (0.125 log.
der.)
 POLYNOMIAL NODAL METHOD, TRADITIONAL
k eff Reference
                            0.99138
k eff SKETCH-N
                            0.99142
                        :
Error, [pcm]
                              4.
Comparison of the 2D Power Distribution
                         0.82
                         0.82
                         -0.0
                0.70
                      1.13
                             0.85
                0.70 1.13
                             0.85
                -0.4 -0.0
                             -0.0
        0.89 1.03
                    1.26 1.29
                                 0.82
        0.90
             1.04
                    1.26 1.28
                                 0.82
         0.3
                     0.1 -0.2
               0.3
                                -0.1
0.51
      0.82 0.61 1.23
                         1.43
                               1.20
                                     0.59
0.51
      0.83
            0.61
                  1.23
                         1.44
                               1.20
                                     0.59
 0.0
       0.4
            -0.1
                   0.2
                         0.1
                              -0.3
                                    -0.3
Average Error in Power Distribution, (abs*100):
                                                     0.2
    RMS Error in Power Distribution, (abs*100):
                                                     0.2
Maximum Error in Power Distribution, (abs*100):
                                                    -0.4
                                                    1.43
Maximum Reference Power Density
Maximum SKETCH-N Power Density
Error in Maximum Power Density
                                                    1.44
                                      (abs*100):
                                                    0.1
```

Figure 6.2: Calculation results for the modified IAEA-2D test without reflector, $\gamma = 0.125$

```
A Comparison of the SKETCH Results with Input/
VVER IAEA2D NOR 05.ref
 VVER IAEA-2D No Reflector (0.5 log.
der.)
 POLYNOMIAL NODAL METHOD, TRADITIONAL
k eff Reference
                           0.97808
k eff SKETCH-N
                           0.97802
                       :
Error, [pcm]
                            -6.
Comparison of the 2D Power Distribution
                           0.56
                           0.55
                           -0.3
                  0.78
                       1.07
                              0.58
                  0.78
                       1.07
                              0.57
                  -0.4
                       -0.3 -0.3
         1.21
               1.28
                     1.40
                           1.21
                                 0.54
               1.29 1.40
         1.22
                          1.21 0.54
          0.9
               0.6
                      0.2
                          -0.4
                                -0.4
0.74
      1.17 0.80 1.46
                        1.52
                              1.06
                                    0.32
0.74
      1.18
            0.80 1.47
                        1.52
                              1.05
                                    0.32
 0.4
       1.0
             0.1
                   0.6
                         0.1 - 0.6
                                   -0.4
Average Error in Power Distribution, (abs*100):
                                                   0.4
    RMS Error in Power Distribution, (abs*100):
                                                   0.5
Maximum Error in Power Distribution, (abs*100):
                                                   1.0
Maximum Reference Power Density
                                                  1.52
Maximum SKETCH-N Power Density
                                                  1.52
Error in Maximum Power Density
                                     (abs*100):
                                                   0.1
```

Figure 6.3: Calculation results for the modified IAEA-2D test without reflector, $\gamma=0.5$

Chapter 7

Conclusion

The basic features of the nodal three-dimensional neutron kinetics code SKETCH-N are summarized in the following:

- diffusion approximation;
- 3D, 2D and 1D reactor models in Cartesian and hexagonal-z geometry with arbitrary mesh size in any direction;
- arbitrary number of neutron energy groups and delayed neutron precursors;
- transverse-integrated polynomial, semi-analytic and analytic nodal methods with quadratic leakage approximation for spatial discretization;
- nonlinear iteration procedure for a solution of the nodal equations;
- fully-implicit scheme with analytic integration of the delayed neutron precursors for time discretization;
- adaptive time step control based on the step doubling technique;
- inverse iterations with Wieland shift accelerated by Chebyshev polynomials for the steady-state eigenvalue problems;
- adaptive Chebyshev acceleration procedure for the neutron kinetics problems;

- block symmetric Gauss-Seidel method as a preconditioner;
- consistent point kinetics option, where the point kinetics parameters are computed at each time step using the values of macro cross sections;
- internal thermal-hydraulics model for PWR operational transients with single-phase coolant flow;
- interface module based on the message passing library PVM for the coupling with external thermal-hydraulics codes, such as TRAC.

This user guide describes the code installation, input and output files. The examples of the code application to the following benchmark problem

- 2D four-group KOEBERG checker-board-loaded PWR (Müller and Weiss, 1991);
- 3D NEACRP PWR rod ejection benchmark, Case A1 (Finnemann and Galati, 1992);
- code has been also used for the other steady-state and transient problems:
- classical 2D & 3D International Atomic Energy Agency (IAEA) PWR problems;
- 2D Biblis PWR checker-board-loaded core;
- 2D Zion-1 PWR problem with explicit modeling of the baffle;
- 3D Langenbuch-Maurer-Werner (LMW) operational transient in a small PWR model;
- 2D & 3D super-prompt-critical rod drop accident in BWR;
- NEA/NSC PWR benchmark on uncontrolled rod withdrawal at zero power.

The results are given in the papers (Zimin et al., 1998; Zimin and Ninokata, 1998; Asaka et al., 2000).

Any suggestions about the code improvement and proposals to extend the code capabilities for the user's problems are welcome. The author's address is given in Chapter 2.

Bibliography

- Akimoto, H. et al. (1989). 18-th report on the best-estimate code development. J-TRAC user manual (version 62.1). Technical Report JAERI-Memo-63-478, JAERI. [In Japanese].
- Asaka, H., Zimin, V. G., Iguchi, T., and Anoda, Y. (2000). Coupling of the thermal hydraulics TRAC codes with 3D neutron kinetics code SKETCH-N. In Preliminary Proc. of the OECD/CSNI Workshop on Advanced Thermal-Hydraulic and Neutronics Codes: Current and Future Applications, Barcelona, Spain, 10-13 April, 2000, pages 1-15.
- Barrett, R., Berry, M., Chan, T. F., Demmel, J., Donato, J., Dongarra, J., Eijkhout, V., Pozo, R., Romine, C., and Van der Vorst, H. (1994). Templates for the solution of linear systems: building blocks for iterative methods. SIAM.
- Borkowski, J. A. et al. (1992). TRAC-BF1/MOD1: an advanced best-estimate computer program for BWR accident analysis. Model description. NUREG/CR-4356, EGG-2626, Vol. 1.
- Chao, Y. A. and Shatilla, Y. (1995). Conformal mapping and hexagonal nodal methods-II: implementation in the ANC-H code. *Nuclear Science and Engineering*, 121(2):210–225.
- Finnemann, H., Bauer, H., Galati, A., and Martinelli, R. (1993). Results of LWR core transient benchmarks. Technical Report NEA/NSC/DOC(93)25.
- Finnemann, H. and Galati, A. (1992). NEACRP 3-D LWR core transient benchmark: final specifications. Technical Report NEACRP-L-335 (Revision 1), January 1992.

- Knight, M. (1998). Private communication, e-mail of 23 november 1998.
- Knight, M. P. and Bryce, P. (1997). Derivation of a refined PANTHER solution to the NEACRP PWR rod ejection transients. In Proc. of the Joint Int. Conf. on Mathematical Methods and Supercomputing for Nuclear Applications, Saratoga Springs, N.Y., October 5-9, 1997, volume 1, pages 302–313. American Nuclear Society.
- Müller, E. and Weiss, Z. (1991). Benchmarking with the multigroup diffusion high-order response matrix method. *Annals of Nuclear Energy*, 18(9):535–544.
- Zimin, V. G. (2025). SKETCH-N: a nodal neutron diffusion code for solving steadystate and kinetics problems, vol. I. Model description.
- Zimin, V. G., Asaka, H., Anoda, Y., and Enomoto, M. (1999). Verification of the J-TRAC code with 3D neutron kinetics model SKETCH-N for PWR rod ejection analysis. In Proc. of the 9 International Topical Meeting on Nuclear Reactor Thermal Hydraulics (NURETH-9), San Francisco, California, October 3-8, 1998. American Nuclear Society. CD-ROM.
- Zimin, V. G., Asaka, H., Anoda, Y., Kaloinen, E., and Kyrki-Rajämaki, R. (2000). Analysis of NEACRP 3D BWR core transient benchmark. In *Proc. of the 4th Intl. Conf. on Supercomputing in Nuclear Application SNA-2000, Tokyo, Japan, September 4-7, 2000.* Japan Atomic Energy Research Institute. CD-ROM.
- Zimin, V. G. and Baturin, D. M. (2002). Polynomial nodal method for solving neutron diffusion equations in hexagonal-z geometry. *Annals of Nuclear Energy*, 29(9):1105–1117.
- Zimin, V. G. and Ninokata, H. (1998). Nodal neutron kinetics model based on nonlinear iteration procedure for LWR analysis. Annals of Nuclear Energy, 25:507-528.
- Zimin, V. G., Ninokata, H., and Pogosbekyan, L. R. (1998). Polynomial and semi-analytic nodal methods for nonlinear iteration procedure. In Proc. of the Int. Conf. on the Physics of Nuclear Science and Technology (PHYSOR98),

Bibliography

 $Long\ Island,\ New\ York,\ October\ 5-8,\ 1998,\ volume\ 2,\ pages\ 994–1002.$ American Nuclear Society.


2D FOUR-GROUP KOEBERG PWR BENCHMARK

A.1 CONTENT OF THE INCLUDE FILE "KOEBERG2D.FH"

1 =		====
!	PARAMETERS FOR KOEBERG-2D PWR BENCHMARK	!
!	(c) Slava 2 August 2000	!
! =		====
!	GeoMTry Module	!
!	${ t N_POLY}$ - number of the bundles (assemblies) in the reactor;	!
!	NH - number of the nodes in radial (X-Y) plane	!
!	with 1 node per assembly NH = N_POLY;	!
!	NZR - number of axial layers defining materail composition	!
!	of the bundle	!
!	NZ - number of axial lalers used for the calculations	!
!	NXR - maximum number of bundles in X directions	!
!	NX - maximum number of nodes in X direction	!
!	NYR - maximum number of bundles in Y directions	!
!	NY - maximum number of nodes in Y direction	!
!	NCHM - maximum number of nodes per bundle (assembly)	!

```
in X-Y plane
  NDD - reactor geometry dimensions
    (3D calculations NDD = 3; 2D calculations NDD = 2;
     1D calculations NDD = 3)
  N_BUNDLE_TYPE - number of different bundle types
! NDIR - number of orthogonal directions (3 - XYZ; 4 - HEX-Z)
INTEGER N_POLY, NH, NZR, NZ, NXR, NYR, NX, NY, &
NCHM, NDD, N_BUNDLE_TYPE, NDIR
PARAMETER (N_BUNDLE_TYPE = 7)
PARAMETER (N_{POLY} = 64, NH = 64)
PARAMETER (NZR = 1,
                NZ = 1
PARAMETER (NXR = 9,
                  NYR = 9
PARAMETER (NX = 9, NY = 9)
PARAMETER (NCHM = 1)
PARAMETER (NDD = 2)
parameter (NDIR = 3)
! End GeoMTry Module
! TH_Model
   NP_Reactor_Core - number of fuel bundles in the reactor core
                                                          !
   NZ_Core - number of axial layers in the reactor core (planes)
   NN_FRD_FA - number of the equivalent fuel rods per fuel assembly
   NN_FA_TYPE - number of the fuel assembly types
integer NP_Reactor_Core, NZR_Core, NN_FRD_FA, NN_FA_TYPE
parameter (NP_Reactor_Core = 47, NZR_Core = 16, &
NN_FRD_FA = 1, NN_FA_TYPE = 1)
!-----
! End TH Model
```

```
! XS Module (Cross Section & Neutron Kinetics Constant)
   NG - number of neutron energy groups
   NNODE number of material compositions (dimension of the XS arrays) !
   MD - number of delayed neutron groups
   N_FEEDBACKS - number of feedbacks (boron concentration, moderator
    temperature, moderator density or void, doppler fuel temperature) !
INTEGER NNODE, NG, MD, N_FEEDBACK, MH
PARAMETER(NNODE = 7, NG = 4)
PARAMETER(MD = 1)
PARAMETER(N_FEEDBACK = 4)
PARAMETER(MH = 11)
1_____
! End End TH_Model
! CRD control rod Module
    NN_CRod_Comp - Number of Control Rod Compositions
    NN_CRod - Number of Control Rods
    NN_CRod_El - Number of the Rod Materials (Absorber + Driver = 2)!
    NN_CRod_Type - Number of Control Rod Types
    NN_Crod_Bundle - Number of the Bundles covered by CR
                         ("PWR" - 1, "BWR" - 4)
!-----
INTEGER NN_CRod, NN_CRod_Comp, NN_CRod_E1, NN_CRod_Type, &
NN_Crod_Bundle
PARAMETER (NN_CRod_El = 1, NN_CRod = 1, NN_CRod_Comp = 1,&
NN_CRod_Type = 1, NN_Crod_Bundle = 1 )
!-----
! End CRD control rod Module
! Fuel RoD (FRD) Heat Conduction Model
    NN_FRD_FUEL - Number of the heat conduction nodes in the fuel
    NN_FRD_CLAD - Number of the heat conduction nodes in the cladding!
```



A.2 CONTENT OF THE INPUT NAMELIST FILE "SKETCH.INI.KOEBERG2D.ST"

```
SKETCH-N version 1.0: Nodal Neutron Diffusion Code for
                                                               С
          Solving Steady-State & Kinetics Problems
С
                                                               С
С
                                                               С
           Moscow Engineering Physics Institute
              Tokyo Institute of Technology
C
                                                               C
            Japan Atomic Energy Research Institute
С
С
      Author: Vyacheslav G. Zimin
С
                                                               C
С
                 (c) 1999 All Rights Reserved
С
                                                               С
С
                                                               С
                          NOTICE
С
С
                                                               С
  Permission to use, copy, modify, and distribute this software and
                                                               С
  its documentation for any purpose and without fee is hereby granted
                                                               С
  provided that the above copyright notice appear in all copies and
                                                               C
  that both the copyright notice and this permission notice appear in
  supporting documentation.
С
                                                               С
С
                                                               С
  Neither the Institutions nor the Author make any
                                                               С
  representations about the suitability of this software for any
                                                               С
          This software is provided "as is" without express or
                                                               С
  implied warranty.
|-----|
! INI\_PROBLEM - the basic problem description & solution methods
                                                                ļ
! Problem_Type - type of the computed problem
               "Steady-State", Burnup", "Kinetics" / "Steady-State"
                                                               /!
```

```
! Steady_State_Type - type of the steady-state problem
                 "Eigenvalue", "BoronSearch"
                                                    / "Eigenvalue"
                                                                     /!
! Nodal_Method - Choice of the Nodal Method:
              "PNM", "SANM", "ANM", "MCFD", "PNM1"
                                                             / "SANM" / !
! TH_Model - Thermal-hydraulics Model Used for the Calculations
                                                             / 'None' / !
           (Possible Choices 'Internal', 'External', 'None', 'SKAZKA')
! Kinetics_Method - Method of the Solution of Kinetics Equation
      "DRT"-Direct; "IQS"- Improved Quasi-Static; "PNT" - point
                                                             / "DRT"
! Iter_Solver - iterative solvers for kinertics :
                 CSA, CSI, CG, BCGSTAB, TFQMR, FOM, GMRES
                                                             / "CSA" /
! TRL_Approx - transverse leakage approximation
                                                             / "QLA" /
           (Possible Choices 'QLA', 'Flat')
                                                             / "Smith"/ !
! NonlinearIterations - nonlinear iteration procedure
           ( Possible Choices "Smith", "Moon")
! Xe_Sm_Model - model of Xe and Sm for burnup
                                                             / "none" / !
           ( Possible Choices "nn", "ss", "st", "ts", "tt" )
|-----|
! INI_FILES - name of the input and restart files
! File_Input- Input File Name of the Geometry Data
! File_Reference - Name of the Reference Solution File
! File_Dist - name of the DIST*.txt file with distributions for
             Ringhals
! File_CD - name of the CD*.txt file with XS Tables (Ringhals)
           - Input File for the Mapping to the TRAC Geometry
! File_Map
              Only for the Coupling with the TRAC
                                                                11-11
! File_DMP_In - Input Restart File
! File_DMP_Out_st - Output Restart File for
                                Steady-State Calculations
! File_DMP_Out_Kin - Output Restart File for
                                            Calculations
```

```
! INI_CONVERGENCE - convergence criterion
                                                                      !
! N_Out_Max - Convergence Criterion for the Nonlinear Iterations
                                                 Steady-State
                                                              /1 /
                                                 Kinetics
                                                              /1000 / !
! N_Outer - Number of outer per nonlinear (thermalhydraulics)
                                                 Steady-State
                                                              /10 /
                                                 Kinetics
                                                              /1000/
! E_Boron_Start - Accuracy of the Eigenvalue when critical boron
           search starts
                                                              /1.E-2/ !
! E_Critical - Convergence Criterion of the Boron Critical Search
                                                              /1.E-5/!
! E_Outer_L - Converence Criterion for the Eigenvalue (Local)
                                                              /1.E-5/!
! E_Flux_L - Convergence Criterion for the Flux
                                                 Steady-State
                                                              /1.E-5/!
                                                              /1.E-4/!
                                                 Kinetics
            - Number of internal iterations per outer
                                                              /2 /!
! E_Inter - Converence Criterion for the Innner Iterations
                                                              /1.E-8/!
|-----|
|-----
! INI_CHEBYSHEV - Parameters for Chebyshev acceleration procedure
! Xbe - Estimate of Minimum Eigenvalue of the Iteration Matrix
                                                              /0.0
                                                                    /!
! Xme_Ini - Estimate of the Dominance Ratio (Spectral Radius)
                                                              /0.8 / !
! F_Cheb - Adaptive Parameter of the Chebyshev Procedure
                                                                      !
          (Non-Adaptive - 0, Adaptive - 0.65-0.85)
                                                 Steady-State
                                                              /0.0
                                                                    /!
                                                 Kinetics
                                                              /0.8 / !
                                                                    /!
! NPolins - Number of the Iteration when Chebyshev Starts
                                                              / 5
                                                              / 0.
                                                                    /!
! Delta_Shift - Inverse Value of the Wieland shift
```

```
! INI_TIME_STEP - Time Step Size Selection
                                                                               !
! I_Auto - Flag of the Automatic Time Step Selection
                                                                             /!
                                                                       0
                                                                             /!
! NP_View - Number of Time Step Interval
                                                                       1
! Ttv - Time Moments of the Time Step Intervals
                                                                               !
        Ttv(NP_View) - End of the Transien
                                                                             /!
                                                                       1.
! Dt_Input(NP_View) - Time Step Size for the Time Interval
                                                                               !
          [Ttv(i-1) - Ttv(i)]
                                                                  / 0.01
                                                                             /!
! St_Eps - Accuracy Criterion of the Automatic Time Step Control /
                                                                     5.E-03 / !
! Facmax - Maximum Increase of the Time Step Size
                                                                             /!
! Dt_Step_Max - Maximum Time Step Size (s)
                                                                       1.
                                                                             /!
! N_Zap - Output into GRF file at the N_ZAPth Time Step
                                                                        1
                                                                             /!
&INI_PROBLEM
Problem_Type = "Steady-State"
TH_Model = "None"
&END
&INI_FILES
FILE_INPUT
           = "Input/KOEBERG2D.DAT"
File_Reference = "Input/KOEBERG2D.ref"
FILE_DMP_OUT_ST = "Restart/koeberg2d.dat"
&END
&INI_CONVERGENCE
&END
&INI_CHEBYSHEV
Delta_Shift = 10.
&END
&INI_TIME_STEP
&END
```

A.3 CONTENT OF THE INPUT FILE "KOEBERG2D.DAT"

```
KOEBERG-2D PWR BENCHMARK
      (c) Slava August 2000
                                                                     !
1______1
CNT_RCT_TYPE ## REACTOR TYPE
"PWR"
CNT RCT POWR ## REACTOR POWER (MWt)
1.
XS_BASE_DATA ## Basic set of the Macro Cross Section Data
2.491869 0.003654 0.008228 0.008228
1.045224 0.002124 0.000536 0.000536
0.677407 0.019908 0.007058 0.007058
0.375191 0.067990 0.083930 0.083930
0.0
   0.0
              0.0
                     0.0
0.063789 0.0
               0.0
                       0.0
0.000486 0.064381 0.0
                       0.001245
0.0 0.000003 0.050849 0.0
                                1 Type
2.492653 0.003685 0.008295 0.008295
1.049844 0.002215 0.000713 0.000713
0.676610 0.022012 0.009230 0.009230
0.379481 0.085052 0.108244 0.108244
```

```
0.0
         0.0
                  0.0
                           0.0
0.063112 0.0
                  0.0
                           0.0
0.000478 0.063078 0.0
                           0.001543
0.0
         0.000003 0.048420 0.0
                                     2 Type
2.491978 0.003684 0.008285 0.008285
1.051910 0.002221 0.000713 0.000713
0.677084 0.022403 0.009214 0.009214
0.381453 0.088077 0.108087 0.108087
0.0
         0.0
                  0.0
                           0.0
0.062765 0.0
                  0.0
                           0.0
0.000473 0.062404 0.0
                           0.001598
0.0
         0.000003 0.047549 0.0
                                     3 Туре
2.492535 0.003740 0.008459 0.008459
1.045298 0.002299 0.000923 0.000923
0.674684 0.022621 0.011714 0.011714
0.374240 0.091000 0.133600 0.133600
0.0
         0.0
                  0.0
                           0.0
0.063737 0.0
                  0.0
                           0.0
0.000486 0.064330 0.0
                           0.001630
0.0
         0.000003 0.049518 0.0
                                      4 Type
2.492329 0.003730 0.008409 0.008409
1.051953 0.002315 0.000921 0.000921
0.675683 0.023822 0.011675 0.011675
0.380606 0.100246 0.134282 0.134282
```

```
0.0 0.0
                  0.0
                           0.0
0.062737 0.0
                  0.0
                           0.0
0.000473 0.062376 0.0
                           0.001797
0.0
        0.000003 0.046859 0.0
                                     5 Type
2.491521 0.003730 0.008400 0.008400
1.054029 0.002321 0.000921 0.000921
0.676197 0.024196 0.011651 0.011651
0.382434 \ 0.103283 \ 0.133974 \ 0.133974
0.0
        0.0
                  0.0
                          0.0
0.062386 0.0
                  0.0
                           0.0
0.000468 0.061696 0.0
                           0.001852
0.0
        0.000003 0.046005 0.0
                                       6 Type
2.119737 0.000466
                       0.0
                                0.0
0.980098 0.000263
                       0.0
                                0.0
0.531336 0.004282
                                0.0
                       0.0
1.058029 0.116918
                                0.0
                       0.0
0.0
        0.0
                  0.0
                           0.0
0.042052 0.0
                  0.0
                           0.0
0.000322 0.044589 0.0
                           0.000978
0.0
        0.0
                  0.052246 0.0
                                      7 Type
```

XS_DIFF_FLAG

1 ## Parameter 1 - Diffusion Coefficient, 0 - Transport XS

XS_NEUT_SPEC 0.745248 0.254328 0.000424 0.0 ## xp(NG) XS_POWR_CONV 3.204E-11 3.204E-11 3.204E-11 ## pow_conv GMT_NUM_BNDL ## Numbering of the reactor assdemblies (bundles) 1 9 # 1 1 9 # 2 1 9 # 3 1 8 # 4 1 8 # 5 1 7 # 6 1 6 # 7 1 5 # 8 1 3 # 9 GMT_MSH_XDIR ## Spatial Mesh in X direction 1 10.804 1 21.608 1 21.608 1 21.608 1 21.608 1 21.608 1 21.608 1 21.608 ##npx(NXR),hx(NXR) GMT_MSH_YDIR ## Spatial Mesh in Y direction

GMT_COR_LOAD ## Core Loading with Bundle Types

1 21.608 ##npy(NYR),hy(NYR)

1 21.608

1 10.804 1 21.608 1 21.608 1 21.608 1 21.608 1 21.608

Appendix A

```
1 3 1 3 1 2 1 4 7
3 1 3 1 2 1 6 4 7
1 3 1 2 1 3 4 7 7
3 1 2 1 3 5 4 7
1 2 1 3 1 4 7 7
2 1 3 5 4 7 7
1 6 4 4 7 7
4 4 7 7 7
7 7 7
        1(N_POLY, NZR)
1 \ 1 \ ## \ nb = 1
2 \ 2 \# nb = 2
3 \ 3 \ ## \ nb = 3
4 \ 4 \ ## \ nb = 4
5 \ 5 \ ## \ nb = 5
6 6 ## nb = 6
7 7 \# nb = 7
GMT_BND_COND ## Boundary Conditions
1 1 1 1 ## i_DR
0. 0. 0. ## Buckling
|-----|
! End of the Koeberg-2D PWR Input Data
```

ļ

A.4 CONTENT OF THE INPUT FILE WITH THE REFERENCE SOLUTION "KOEBERG2D.REF"

PWR KOEBERG 2D 4-group Reference Solution

1.007954

1.0058 1.0858 1.0445 1.1639 1.1319 1.2147 0.9596 0.8331 1.0858 1.0263 1.1305 1.1054 1.2430 1.0617 1.0420 0.6425 1.0445 1.1305 1.0929 1.2236 1.0581 1.0390 0.9684 1.1639 1.1054 1.2236 1.0363 0.9988 0.9813 0.6504 1.1319 1.2430 1.0581 0.9988 0.7860 0.6670 1.2147 1.0617 1.0390 0.9813 0.6670 0.9596 1.0420 0.9684 0.6504 0.8331 0.6425

- * The reference assembly-averaged core power distribution

 * for the KOEBERG 2D 4-group Benchmark Higher-Order RM Method

 * 1x1 P6 E. Z. Muller & Z. J. Weiss
- * Annals of Nuclear Energy, vol. 18, pp 535-544, 1991 *

A.5 CONTENT OF THE OUTPUT FILE "COMPARISON.DAT"

A Comparison of the SKETCH Results with Input/KOEBERG2D.ref PWR KOEBERG 2D 4-group Reference Solution

SEMI-ANALYTICAL NODAL METHOD

Comparison of the 2D Power Distribution

1	2	3	4	5	6	7	8	
1:	1	2	3	4	5	6	7	8
1:	1.01	1.09	1.04	1.16	1.13	1.21	0.96	0.83
1:	0.99	1.07	1.03	1.15	1.13	1.21	0.97	0.85
1:	-1.9	-1.9	-1.5	-1.4	-0.6	-0.2	1.0	1.7
2:	9	10	11	12	13	14	15	16
2:	1.09	1.03	1.13	1.11	1.24	1.06	1.04	0.64
2:	1.07	1.01	1.11	1.09	1.24	1.06	1.05	0.65
2:	-1.9	-1.6	-1.8	-1.1	-0.7	0.2	1.2	1.2

Appendix A

```
3:
       17
               18
                     19
                            20
                                   21
                                          22
                                                 23
3:
     1.04
            1.13
                   1.09
                          1.22
                                 1.06
                                        1.04
                                               0.97
3:
     1.03
            1.11
                   1.08
                          1.21
                                 1.06
                                        1.04
                                               0.98
     -1.5
            -1.8
                   -1.2
                          -1.1
                                 -0.3
3:
                                         0.6
                                                1.4
        24
               25
4:
                     26
                            27
                                   28
                                          29
                                                 30
            1.11
                   1.22
                          1.04
4:
     1.16
                                 1.00
                                        0.98
                                               0.65
4:
     1.15
            1.09
                   1.21
                          1.03
                                 1.00
                                        1.00
                                               0.66
      -1.4
            -1.1
                   -1.1
                          -0.4
                                  0.2
4:
                                         1.5
                                                0.5
5:
       31
              32
                                   35
                     33
                            34
                                          36
5:
            1.24
                   1.06
                          1.00
                                 0.79
                                        0.67
     1.13
                          1.00
5:
     1.13
            1.24
                   1.06
                                 0.80
                                        0.68
5:
      -0.6
            -0.7
                   -0.3
                           0.2
                                  1.4
                                         0.8
6:
       37
              38
                     39
                            40
                                   41
6:
     1.21
            1.06
                   1.04
                          0.98
                                 0.67
     1.21
            1.06
                          1.00
6:
                   1.04
                                 0.68
6:
      -0.2
             0.2
                    0.6
                           1.5
                                  0.8
7:
       42
               43
                     44
                            45
7:
            1.04
     0.96
                   0.97
                          0.65
7:
     0.97
            1.05
                   0.98
                          0.66
7:
      1.0
             1.2
                    1.4
                           0.5
8:
       46
              47
8:
     0.83
            0.64
8:
     0.85
            0.65
8:
      1.7
             1.2
```

Average Error in Power Distribution, (abs*100): 1.0

RMS Error in Power Distribution, (abs*100): 1.1

Maximum Error in Power Distribution, (abs*100): -1.9

Appendix A

Number of FA with the Maximum Error	:	9
Maximum Reference Power Density	:	1.24
Number of FA with the Maximum Reference Power	:	13
Maximum SKETCH-N Power Density	:	1.24
Number of FA with the Maximum SKETCH-N Power	:	13
Error in Maximum Power Density (abs*100)	:	-0.7

3D NEACRP PWR ROD EJECTION BENCHMARK

B.1 CONTENT OF THE INCLUDE FILE "PWR_NEACRP_A1.FH"

1 –		
! !	PARAMETERS FOR NEACRP PWR ROD EJECTION PROBLEM, CASE A1 (c) Slava 10 December 1999	! !
•	GeoMTry Module	!
!	N_POLY - number of the bundles (assemblies) in the reactor;	!
!	NH - number of the nodes in radial (X-Y) plane	!
!	with 1 node per assembly $NH = N_POLY$;	!
!	NZR - number of axial layers defining materail composition	!
!	of the bundle	!
!	NZ - number of axial lalers used for the calculations	!
!	NXR - maximum number of bundles in X directions	!
!	NX - maximum number of nodes in X direction	!
!	NYR - maximum number of bundles in Y directions	!
!	NY - maximum number of nodes in Y direction	!
!	NCHM - maximum number of nodes per bundle (assembly)	!

```
in X-Y plane
  NDD - reactor geometry dimensions
    (3D calculations NDD = 3; 2D calculations NDD = 2;
     1D calculations NDD = 3)
  N_BUNDLE_TYPE - number of different bundle types
  NDIR - number of orthogonal directions (3 - XYZ; 4 - HEX-Z)
1_____
integer N_POLY, NH, NZR, NZ, NXR, NYR, NX, NY, &
NCHM, NDD, N_BUNDLE_TYPE, NDIR
parameter (N_POLY = 64, NH = 221 ) ! 221; 884
parameter (NZR = 18, NZ = 18)
parameter (NXR = 9, NYR = 9)
parameter (NX = 17, NY = 17)
parameter (NCHM = 4)
parameter (NDD = 3)
parameter (N_BUNDLE_TYPE = 9)
parameter (NDIR = 3)
!----
! End GeoMTry Module
! TH Model
   NP_Reactor_Core - number of fuel bundles in the reactor core
   NZ_Core - number of axial layers in the reactor core (planes)
   NN_FRD_FA - number of the equivalent fuel rods per fuel assembly !
   NN_FA_TYPE - number of the fuel assembly types
integer NP_Reactor_Core, NZR_Core, NN_FRD_FA, NN_FA_TYPE
parameter (NP_Reactor_Core = 47, NZR_Core = 16 , &
NN_FRD_FA = 1, NN_FA_TYPE = 1)
! End TH_Model
! XS Module (Cross Section & Neutron Kinetics Constant)
```

```
NG - number of neutron energy groups
!
   NNODE number of material compositions (dimension of the XS arrays) !
!
   MD - number of delayed neutron groups
   N_FEEDBACKS - number of feedbacks (boron concentration, moderator
    temperature, moderator density or void, doppler fuel temperature) !
        NNODE, NG, MD, N_FEEDBACK, MH
parameter(NNODE = 11, NG = 2)
parameter(MD = 6)
parameter(N_FEEDBACK = 4)
PARAMETER(MH = 11)
1______
! End End TH Model
! CRD control rod Module
     NN_CRod_Comp - Number of Control Rod Compositions
     NN_CRod - Number of Control Rods
     NN_CRod_El - Number of the Rod Materials (Absorber + Driver = 2)!
     NN_CRod_Type - Number of Control Rod Types
     NN_Crod_Bundle - Number of the Bundles covered by CR
                           ("PWR" - 1, "BWR" - 4)
INTEGER NN_CRod, NN_CRod_Comp, NN_CRod_El, NN_CRod_Type, &
NN_Crod_Bundle
PARAMETER (NN_CRod_E1 = 2, NN_CRod = 15, NN_CRod_Comp = 3, &
NN_CRod_Type = 2, NN_Crod_Bundle = 1)
!-----
! End CRD control rod Module
! Fuel RoD (FRD) Heat Conduction Model
     NN_FRD_FUEL - Number of the heat conduction nodes in the fuel
     NN_FRD_CLAD - Number of the heat conduction nodes in the cladding!
     NN_FRD_TOTAL - Total number of the heat conduction nodes
```

! in the fuel rod !
!
INTEGER NN_FRD_FUEL, NN_FRD_CLAD, NN_FRD_TOTAL
PARAMETER (NN_FRD_FUEL=9, NN_FRD_CLAD = 2, &
NN_FRD_TOTAL = NN_FRD_FUEL + NN_FRD_CLAD)
!
! End Fuel RoD (FRD) Heat Conduction Model
!======================================
! PVM Interface Module for TRAC !
! NN_RT_HC_TRAC-Number of nodes of heat conduction R-T spatial mesh !
! NN_RT_FD_TRAC-Number of nodes of fluid dynamics R-T spatial mesh !
! $NN_Z_HC_TRAC-Number$ of axial layers of heat conduction spatial mesh !
! $NN_Z_FD_TRAC-Number$ of axial layers of fluid dynamics spatial mesh $$!
!
INTEGER NN_RT_HC_TRAC, NN_RT_FD_TRAC, NN_Z_HC_TRAC, NN_Z_FD_TRAC
PARAMETER (NN_Z_HC_TRAC = 15, NN_Z_FD_TRAC = 14, &
NN_RT_HC_TRAC = 27, NN_RT_FD_TRAC = 27)
!
! End PVM Interface Module for TRAC !
!
! THAT'S ALL !
!======================================

B.2 CONTENT OF THE INPUT NAMELIST FILE "SKETCH.INI.PWR A1.ST"

```
SKETCH-N version 1.0: Nodal Neutron Diffusion Code for
                                                                С
          Solving Steady-State & Kinetics Problems
С
                                                                С
С
                                                                С
           Moscow Engineering Physics Institute
              Tokyo Institute of Technology
C
                                                                C
            Japan Atomic Energy Research Institute
С
С
      Author: Vyacheslav G. Zimin
С
                                                                C
С
                 (c) 1999 All Rights Reserved
С
                                                                С
С
                                                                С
                          NOTICE
С
С
                                                                С
  Permission to use, copy, modify, and distribute this software and
С
                                                                С
  its documentation for any purpose and without fee is hereby granted
                                                                С
  provided that the above copyright notice appear in all copies and
                                                                C
  that both the copyright notice and this permission notice appear in
  supporting documentation.
С
                                                                С
С
                                                                С
  Neither the Institutions nor the Author make any
                                                                С
  representations about the suitability of this software for any
                                                                С
          This software is provided "as is", without express or
                                                                С
  implied warranty.
|-----|
                                                                 ļ
! INI_PROBLEM - the basic problem description & solution methods
! Problem_Type - type of the computed problem
               "Steady-State", Burnup", "Kinetics" / "Steady-State"
                                                               /!
```

```
! Steady_State_Type - type of the steady-state problem
                 "Eigenvalue", "BoronSearch"
                                                    / "Eigenvalue"
                                                                     /!
! Nodal_Method - Choice of the Nodal Method:
              "PNM", "SANM", "ANM", "MCFD", "PNM1"
                                                             / "SANM" / !
! TH_Model - Thermal-hydraulics Model Used for the Calculations
                                                             / 'None' / !
           (Possible Choices 'Internal', 'External', 'None', 'SKAZKA')
! Kinetics_Method - Method of the Solution of Kinetics Equation
      "DRT"-Direct; "IQS"- Improved Quasi-Static; "PNT" - point
                                                             / "DRT"
! Iter_Solver - iterative solvers for kinertics :
                 CSA, CSI, CG, BCGSTAB, TFQMR, FOM, GMRES
                                                             / "CSA" /
! TRL_Approx - transverse leakage approximation
                                                             / "QLA" /
           (Possible Choices 'QLA', 'Flat')
                                                             / "Smith"/ !
! NonlinearIterations - nonlinear iteration procedure
           ( Possible Choices "Smith", "Moon")
! Xe_Sm_Model - model ofXe and Sm for burnup
                                                             / "none" / !
           ( Possible Choices "nn", "ss", "st", "ts", "tt")
|-----|
! INI_FILES - name of the input and restart files
! File_Input- Input File Name of the Geometry Data
! File_Reference - Name of the Reference Solution File
! File_Dist - name of the DIST*.txt file with distributions for
             Ringhals
! File_CD - name of the CD*.txt file with XS Tables (Ringhals)
           - Input File for the Mapping to the TRAC Geometry
! File_Map
              Only for the Coupling with the TRAC
                                                                11-11
! File_DMP_In - Input Restart File
! File_DMP_Out_st - Output Restart File for
                                Steady-State Calculations
! File_DMP_Out_Kin - Output Restart File for
                                           Calculations
```

```
! INI_CONVERGENCE - convergence criterion
                                                                      !
! N_Out_Max - Convergence Criterion for the Nonlinear Iterations
                                                 Steady-State
                                                              /1 /
                                                 Kinetics
                                                               /1000 / !
! N_Outer - Number of outer per nonlinear (thermalhydraulics)
                                                 Steady-State
                                                               /10 /
                                                 Kinetics
                                                               /1000/
! E_Boron_Start - Accuracy of the Eigenvalue when critical boron
           search starts
                                                               /1.E-2/ !
! E_Critical - Convergence Criterion of the Boron Critical Search
                                                              /1.E-5/!
! E_Outer_L - Converence Criterion for the Eigenvalue (Local)
                                                              /1.E-5/!
! E_Flux_L - Convergence Criterion for the Flux
                                                 Steady-State
                                                              /1.E-5/!
                                                              /1.E-4/!
                                                 Kinetics
            - Number of internal iterations per outer
                                                              /2 /!
! E_Inter - Converence Criterion for the Innner Iterations
                                                              /1.E-8/!
|-----|
|-----
! INI_CHEBYSHEV - Parameters for Chebyshev acceleration procedure
! Xbe - Estimate of Minimum Eigenvalue of the Iteration Matrix
                                                              /0.0
                                                                    /!
! Xme_Ini - Estimate of the Dominance Ratio (Spectral Radius)
                                                              /0.8 / !
! F_Cheb - Adaptive Parameter of the Chebyshev Procedure
                                                                      !
          (Non-Adaptive - 0, Adaptive - 0.65-0.85)
                                                 Steady-State
                                                              /0.0
                                                                    /!
                                                 Kinetics
                                                              /0.8 / !
                                                                    /!
! NPolins - Number of the Iteration when Chebyshev Starts
                                                              / 5
                                                               / 0.
                                                                    /!
! Delta_Shift - Inverse Value of the Wieland shift
```

```
! INI_TIME_STEP - Time Step Size Selection
                                                                              !
! I_Auto - Flag of the Automatic Time Step Selection
                                                                       0
                                                                            /!
                                                                            /!
! NP_View - Number of Time Step Interval
                                                                       1
! Ttv - Time Moments of the Time Step Intervals
                                                                              !
        Ttv(NP_View) - End of the Transien
                                                                            /!
                                                                       1.
! Dt_Input(NP_View) - Time Step Size for the Time Interval
          [Ttv(i-1) - Ttv(i)]
                                                                  / 0.01
                                                                            /!
! St_Eps - Accuracy Criterion of the Automatic Time Step Control / 5.E-03 / !
! Facmax - Maximum Increase of the Time Step Size
                                                                            /!
! Dt_Step_Max - Maximum Time Step Size (s)
                                                                       1.
                                                                            /!
! N_Zap - Output into GRF file at the N_ZAPth Time Step
                                                                       1
                                                                            /!
&INI_PROBLEM
Problem_Type = "Steady-State"
Steady_State_Type = "BoronSearch"
TH_Model = "Internal"
Iter_Solver="GMRES"
&END
&INI_FILES
FILE_INPUT
           = 'Input/PWR_NEACRP_A1.DAT'
FILE_DMP_OUT_KIN = 'Restart/pwr_neacrp_A1_0.dat'
&END
&INI_CONVERGENCE
&END
&INI_CHEBYSHEV
&END
&INI_TIME_STEP
&END
```

B.3 CONTENT OF THE INPUT FILE "PWR_NEACRP_A1.DAT"

	. <u>!</u>
3D NEACRP PWR Rod Ejection Benchmark, case A1	!
(c) Slava March 1998	!
	!
	. !
CNT_RCT_TYPE # REACTOR TYPE	
'PWR"	
CNT_RCT_POWR # REACTOR POWER (MWt)	
593.75E-06	
(S_BASE_DATA # Basic set of the Macro Cross Section Data	
0.532058E-01 0.264554E-01 0.373279E-03 0.000000E-00 0.000000E-00	
0.386406E-00 0.177215E-01 0.000000E-00 0.000000E-00 1	
0.295609E-00 0.231613E-01 0.118782E-02 0.000000E-00 0.000000E-00	
0.245931E+01 0.252618E-00 0.000000E-00 0.000000E-00 2	
0.295609E-00 0.200808E-01 0.118782E-02 0.000000E-00 0.000000E-00	
0.245931E+01 0.252618E-00 0.000000E-00 0.000000E-00 3	
0.222117E-00 0.182498E-01 0.871774E-02 0.498277E-02 0.190224E-02	
0.803140E-00 0.652550E-01 0.839026E-01 0.343581E-01 4	
0.221914E-00 0.180040E-01 0.906133E-02 0.557659E-02 0.214498E-02	
0.795538E-00 0.723354E-01 0.998629E-01 0.408938E-01 5	

```
0.221715E-00 0.177670E-01 0.938496E-02 0.615047E-02 0.237972E-02
0.789253E-00 0.789203E-01 0.114667E-00 0.469561E-01
                                                                 6
0.222039E-00 0.171381E-01 0.931692E-02 0.555010E-02 0.213629E-02
0.776230E-00 0.796328E-01 0.985576E-01
                                         0.403596E-01
                                                                 7
0.222083E-00 0.168501E-01 0.940032E-02 0.554083E-02
                                                       0.213318E-02
0.769969E-00 0.821087E-01 0.980059E-01
                                         0.401338E-01
                                                                 8
0.222127E-00 0.165626E-01 0.948286E-02 0.553137E-02
                                                       0.213003E-02
0.763813E-00 0.845912E-01 0.974109E-01
                                         0.398902E-01
                                                                 9
0.221836E-00 0.169043E-01 0.963720E-02 0.612382E-02
                                                       0.237097E-02
0.770705E-00 0.861187E-01 0.113241E-00 0.463724E-01
                                                                10
0.221878E-00 0.166175E-01 0.971937E-02 0.611444E-02 0.236781E-02
0.764704E-00 0.885488E-01 0.112635E-00 0.461246E-01
                                                                11
XSP_POL_COEF # Macro Cross Sections polynomila coefficients
0.611833E-07 0.791457E-09 0.187731E-06 0.000000E-00 0.000000E-00
0.517535E-05 0.102635E-04 0.000000E-00 0.000000E-00
                                                         1200.2
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
                                                          306.6
0.745756E-01 0.371310E-01 0.207688E-03 0.000000E-00 0.000000E-00
0.533634E-00 0.758421E-02 0.000000E-00 0.000000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.00000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
                                                         891.45 # 1
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
0.776184E-03 0.844695E-04 0.000000E-00 0.000000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.00000E-00
```

```
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
                                                         306.6
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
                                                       0.7125
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.00000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
                                                       891.45 # 2
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.00000E-00
0.776184E-03 0.844695E-04 0.000000E-00 0.000000E-00
                                                       1200.2
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.00000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
                                                        306.6
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.00000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
0.000000E-00 0.000000E-00 0.000000E-00 0.000000E-00
                                                       891.45 # 3
0.347809E-07 -0.108590E-06 0.128505E-06 -0.112099E-08 -0.548361E-09
-0.976510E-05 0.708807E-05 -0.243045E-05 -0.995273E-06
-0.203310E-05  0.809676E-06  0.212191E-06  0.124709E-06
                                                       0.445177E-07
-0.108674E-03 -0.315597E-04 -0.416439E-04 -0.170531E-04
                                                             306.6
0.135665E-00 0.293195E-01 0.155185E-02 0.920694E-03 0.318680E-03
0.992628E-00 0.252662E-01 0.247746E-01 0.101452E-01
                                                           0.7125
-0.309197E-04 -0.275536E-04 0.349709E-04 0.640134E-06
                                                       0.222662E-06
-0.137292E-03 -0.371806E-04 -0.563037E-04 -0.230564E-04
                                                            891.45 # 4
0.353826E-07 -0.106951E-06 0.126709E-06 -0.167880E-08 -0.777980E-09
1200.2
-0.198080E-05 0.858474E-06 0.226000E-06 0.135145E-06
                                                       0.488317E-07
-0.906150E-04 -0.321435E-04 -0.453102E-04 -0.185545E-04
                                                             306.6
0.135748E-00 0.292696E-01 0.161491E-02 0.964160E-03 0.336573E-03
0.981985E-00 0.286667E-01 0.314993E-01 0.128990E-01
                                                           0.7125
-0.308607E-04 -0.276766E-04 0.351798E-04 0.997431E-06
                                                       0.369389E-06
-0.117481E-03 -0.377039E-04 -0.604155E-04 -0.247402E-04
                                                            891.45 # 5
```

```
0.359838E-07 -0.105374E-06 0.124986E-06 -0.221038E-08 -0.996653E-09
-0.192434E-05 0.903494E-06 0.239939E-06 0.149084E-06 0.545978E-07
-0.762786E-04 -0.323776E-04 -0.478475E-04 -0.195937E-04
                                                         306.6
0.135827E-00 0.292154E-01 0.168015E-02 0.101410E-02 0.357207E-03
0.972267E-00 0.319571E-01 0.381097E-01 0.156060E-01
                                                       0.7125
-0.309165E-04 -0.278390E-04 0.353841E-04 0.141847E-05 0.542384E-06
-0.101337E-03 -0.377558E-04 -0.630960E-04 -0.258379E-04
                                                        891.45 # 6
0.337806E-07 -0.100873E-06 0.119869E-06 -0.171323E-08 -0.777980E-09
-0.673744E-05 0.629310E-05 -0.255359E-05 -0.104561E-05
                                                        1200.2
-0.269634E-05 0.701311E-06 0.248530E-06 0.140773E-06
                                                   0.488317E-07
-0.762435E-04 -0.300119E-04 -0.420202E-04 -0.172074E-04
                                                         306.6
0.131033E-00 0.282489E-01 0.168397E-02 0.981951E-03 0.336573E-03
0.934697E-00 0.314240E-01 0.351588E-01 0.144016E-01
                                                       0.7125
-0.313746E-04 -0.273550E-04 0.348699E-04 0.945431E-06 0.369389E-06
-0.108271E-03 -0.372748E-04 -0.579662E-04 -0.237320E-04
                                                        891.45 # 7
0.332495E-07 -0.988578E-07 0.117585E-06 -0.172421E-08 -0.793325E-09
1200.2
-0.307905E-05 0.617380E-06 0.261854E-06 0.143235E-06 0.522555E-07
-0.733397E-04 -0.291929E-04 -0.407701E-04 -0.166956E-04
0.129379E-00 0.278895E-01 0.171972E-02 0.988437E-03 0.346474E-03
0.918171E-00 0.324715E-01 0.363251E-01 0.148808E-01
                                                       0.7125
-0.315503E-04 -0.272381E-04 0.347274E-04 0.926078E-06 0.339044E-06
-0.105521E-03 -0.371808E-04 -0.571108E-04 -0.233804E-04
                                                        891.45 # 8
0.327201E-07 -0.968489E-07 0.115319E-06 -0.173502E-08 -0.796917E-09
1200.2
-0.353877E-05 0.516547E-06 0.274313E-06 0.146019E-06 0.534283E-07
-0.713711E-04 -0.283041E-04 -0.394319E-04 -0.161475E-04
                                                         306.6
0.127682E-00 0.275202E-01 0.174989E-02 0.995175E-03 0.349236E-03
0.901293E-00 0.335945E-01 0.374499E-01 0.153431E-01
                                                       0.7125
```

```
-0.317281E-04 -0.271169E-04 0.346026E-04 0.905802E-06 0.330425E-06
-0.102525E-03 -0.370201E-04 -0.561543E-04 -0.229872E-04
                                                               891.45 # 9
0.343859E-07 -0.993312E-07 0.118186E-06 -0.224335E-08 -0.996653E-09
-0.586898E-05 0.608443E-05 -0.277657E-05 -0.113696E-05
                                                              1200.2
-0.263907E-05 0.744320E-06 0.264289E-06 0.155858E-06 0.545978E-07
-0.639554E-04 -0.303509E-04 -0.444431E-04 -0.181997E-04
0.131116E-00 0.281877E-01 0.175528E-02 0.103522E-02 0.357207E-03
0.924925E-00 0.349853E-01 0.420693E-01 0.172298E-01
                                                             0.7125
-0.314192E-04 -0.275049E-04 0.350637E-04 0.135642E-05 0.542384E-06
-0.938886E-04 -0.371403E-04 -0.605052E-04 -0.247739E-04
                                                              891.45 # 10
0.338559E-07 -0.973291E-07 0.115917E-06 -0.225369E-08 -0.101112E-08
-0.538345E-05 0.591697E-05 -0.270780E-05 -0.110878E-05
                                                              1200.2
-0.302147E-05 0.659521E-06 0.279060E-06 0.158814E-06 0.586765E-07
-0.616984E-04 -0.295626E-04 -0.431588E-04 -0.176738E-04
                                                               306.6
0.129463E-00 0.278259E-01 0.179499E-02 0.104291E-02 0.368921E-03
0.908456E-00 0.361032E-01 0.433215E-01 0.177435E-01
                                                             0.7125
-0.315908E-04 -0.273835E-04 0.349119E-04 0.133336E-05 0.506596E-06
-0.917126E-04 -0.369909E-04 -0.596284E-04 -0.244141E-04
                                                              891.45 # 11
XS_DIFF_FLAG
0 # Parameter 1 - Diffusion Coefficient, 0 - Transport XS
XS_FEED_INIT
1000.0 286.0 0.7540387 559.15 # Feedback0 (Boron, T_Coolant, Ro_coolant, T_fuel)
XS_CROD_COEF
0.373220E-02 -0.319253E-02 0.247770E-02 -0.102786E-03 -0.377989E-04
-0.219926E-01 0.255875E-01 -0.282319E-02 -0.115483E-02
```

```
0.374092E-02 -0.314239E-02 0.242926E-02 -0.122634E-03 -0.459250E-04 -0.167503E-01 0.256478E-01 -0.328086E-02 -0.134262E-02
```

0.697102E-02 -0.119034E-02 0.879034E-04 -0.655496E-04 -0.197926E-04 -0.113498E-01 0.170043E-02 -0.146252E-02 -0.599154E-03

XS_NEUT_SPEC

 $1.0 \ 0.0 \ \# \ xp(NG)$

XS_POWR_CONV

3.213E-11 3.206E-11 # pow_conv

XS_POWR_COOL

0.019 # Percent of the Power Directly Deposited into coolant

XS_NEUT_VELC

0.28E+08 0.44E+06 # v(NG)

XS_PREC_ALFA

0.0128 0.0318 0.1190 0.3181 1.4027 3.9286 # alfa(MD)

XS_PREC_BETA

- 1 # Relative Beta
- 0.0076 # bet
- 0.034 0.200 0.183 0.404 0.145 0.034 # bet(MD)

```
XS_PREC_SPEC
1.0 \ 0.0 \ \# \ xm(NG)
GMT_NUM_BNDL # Numbering of the reactor assdemblies (bundles)
1 9 # 1
1 9 # 2
1 9 # 3
1 8 # 4
18#5
1 7 # 6
1 6 # 7
1 5 # 8
1 3 # 9
GMT_MSH_XDIR # Spatial Mesh in X direction
1 10.803 2 21.606 2 21.606 2 21.606 2 21.606 2 21.606
2 21.606 2 21.606 2 21.606 #npx(NXR),hx(NXR)
GMT_MSH_YDIR # Spatial Mesh in Y direction
1 10.803 2 21.606 2 21.606 2 21.606 2 21.606 2 21.606
2 21.606 2 21.606 2 21.606 #npy(NXR),hy(NXR)
GMT_MSH_ZDIR # Spatial Mesh in Z direction
1 30.0 1 7.7
               1 11.0 1 15.0 1 30.0 1 30.0 1 30.0 1 30.0 1 30.0
1 30.0 1 30.0 1 30.0 1 30.0 1 12.8 1 12.8 1 8.0 1 30. # npz(NZR),hz(NZR)
```

GMT_COR_LOAD # Core Loading with Bundle Types

- 1 2 1 2 1 3 1 4 5
- 2 1 6 1 6 1 7 4 5
- 1 6 1 6 1 6 4 8 5
- 2 1 6 1 6 9 4 5
- 1 6 1 6 1 4 8 5
- 3 1 6 9 4 8 5
- 1 7 4 4 8 5
- 4 4 8 5 5
- 5 5 5 # CORE_LOAD
- 1 4 15*4 1 # nb = 1
- 1 5 15*9 1 # nb = 2
- $1 \ 5 \ 15*7 \ 1 \ \# \ nb = 3$
- 1 6 15*6 1 # nb = 4
- $2 \ 2 \ 15*2 \ 2 \# nb = 5$
- 1 5 15*8 1 # nb = 6
- 1 6 15*11 1 # nb = 7
- 3 3 15*3 3 # nb = 8
- 1 6 15*10 1 # nb = 9

GMT_BND_COND # Boundary Conditions

- 1 0 1 0 # i_DR
- 0. 0. 0. 0. 0. 0. 0. # DR
- 0 0 # i_DZ
- 0. 0. 0. # DZ

CRD_COR_LOAD

1 1 1

```
1
             1
             1
                    2
1
       1
1
1
       1
1
1
       2
CRD_MAT_COMP
1 3 # Material Composition for 1st type of CR
2 3 # Material Composition for 2nd type of CR
{\tt CRD\_LOCATION} \ \# \ {\tt Locations} \ \ {\tt of the control \ rods} \ \ {\tt in \ the \ reactor \ core}
1
       3
                    7
11
              15
19
       21
             23
                    25
31
38
       40
45
51
               # nrods(IRODS)
       53
CRD_POSITION # Position of the control rods (PWR from the Bottom of the Reactor)
37.7 37.7
                    37.7
401.183
               37.7
37.7 37.7
            37.7 37.7
401.183
37.7 37.7
37.7
37.7 37.7
               # zrods(IRODS)
```

 ${\tt CRD_ROD_CUSP} \ \ {\tt \#} \ \ {\tt homogenization} \ \ {\tt of} \ \ {\tt XS} \ \ {\tt for} \ \ {\tt partially} \ \ {\tt rodded} \ \ {\tt nodes}$

"FLUX_WEIGHTING"

CRD_H_ROD_EL # Height of the control rod elements

362.159 1000. H_Rod_El(NESUZ)

CRD_TIM_STRT # Time when control rods start moving

0.0

CRD_VEL_RODS # velocities of the moving rods

3634.830 # Velocity of the Control Rod (cm/sec)

CRD_NUM_MOVE # Total Number of the moving crods

1 # Total Number of the Ejected CR

CRD_IND_MOVE # Index of the moving rods

1 # Index of the Ejected CR

CRD_TOP_POSI # Maximum Top position of the Moving Control Rods

401.183

CRD_BTM_POSI # Minimum Bottom Position of the Moving Control Rod

37.7

```
TH_TEMC_INLT # Inlet Coolant Temperature, K
559.15
TH_PRES_COOL # Coolant Pressure (Mpa)
15.5
TH_MFRT_ASSM # Coolant Flow Rate per Assembly ! Kg/(m^2*sec)
3291.266
TH_HYDR_DIAM # Equivalent Diameter (m)
1.1909E-02
TH_HTCF_CNST # Heat Transfer Coefficient Constants (Dittus-Boelter)
0.023 0.8 0.4 ! Const_DB, Pow_reynolds, Pow_Prandtl
TH_SURF_VOLM # ratio of the surface area of cladding to the volume of the coolant (1/m)
3.163461E+2
TH_FLOW_AREA # Relative Flow Area
0.5344937
FRD_RAD_PELT # Radius of Fuel Pellet (m)
4.1195001E-03
```

```
FRD_RAD_CLAD # Radius of the Cladding (Inner, Outer)
4.1875001E-03 4.7585000E-03
FRD_DNS_F&CL # Density of the Fuel, Cladding (KG/m^3)
1.0412E+04 6.6E+03
FRD_GAP_COND # Gap Conductance watts/(K m^2)
1.E+04
FRD_ALF_DOPL # Parameter to compute the Doppler Temperature
0.7
TH_RAT_FLAS # Ratio of the Fuel Volume to Assembly Volume
0.301505
|-----|
             Input Data for SKAZKA T/H Module
{\tt ASS\_ROU\_CLAD}
0.1000000E-04
ASS_LBS_SIEV
20.25  0.30  0.30  0.30  0.30  0.30  0.30  0.30  0.30  0.30  0.35
    2
         3
             4
                  5
                      6
                        7 8
                                    9
                                         10
                                             11
                                                  12
```

```
ASS_HEI_DWCH
0.0
ASS_HEI_UPCH
4.273
ASS_HEI_CORE
0.0
ASS_TYP_CULC
1
AS1_AREA_ASS
4.6682E-02
AS1_DEN_BUND
0.0
TH_MAP_PARTS # Part of assemly represented in NEUTRON - YH_partass
0.25 \quad 0.500 \ 0.500 \ 0.500 \ 0.500 \ 0.500 \ 0.500 \ 0.500
0.500 1.000 1.000 1.000 1.000 1.000 1.000
0.500 1.000 1.000 1.000 1.000 1.000 1.000
0.500 1.000 1.000 1.000 1.000 1.000 1.000
0.500 1.000 1.000 1.000 1.000 1.000
0.500 1.000 1.000 1.000 1.000
```

B.4 CONTENT OF THE INPUT NAMELIST FILE "SKETCH.INI.PWR A1.KIN"

```
SKETCH-N version 1.0: Nodal Neutron Diffusion Code for
                                                                С
          Solving Steady-State & Kinetics Problems
С
                                                                С
С
                                                                С
           Moscow Engineering Physics Institute
              Tokyo Institute of Technology
C
                                                                C
            Japan Atomic Energy Research Institute
С
С
      Author: Vyacheslav G. Zimin
С
                                                                C
С
                 (c) 1999 All Rights Reserved
С
                                                                С
С
                                                                С
                          NOTICE
С
С
                                                                С
  Permission to use, copy, modify, and distribute this software and
С
                                                                С
  its documentation for any purpose and without fee is hereby granted
                                                                С
  provided that the above copyright notice appear in all copies and
                                                                C
  that both the copyright notice and this permission notice appear in
  supporting documentation.
С
                                                                С
С
                                                                С
  Neither the Institutions nor the Author make any
                                                                С
  representations about the suitability of this software for any
                                                                С
          This software is provided "as is", without express or
                                                                С
  implied warranty.
|-----|
! INI\_PROBLEM - the basic problem description & solution methods
                                                                 ļ
! Problem_Type - type of the computed problem
               "Steady-State", Burnup", "Kinetics" / "Steady-State"
                                                               /!
```

```
! Steady_State_Type - type of the steady-state problem
                 "Eigenvalue", "BoronSearch"
                                                    / "Eigenvalue"
                                                                     /!
! Nodal_Method - Choice of the Nodal Method:
              "PNM", "SANM", "ANM", "MCFD", "PNM1"
                                                             / "SANM" / !
! TH_Model - Thermal-hydraulics Model Used for the Calculations
                                                             / 'None' / !
           (Possible Choices 'Internal', 'External', 'None', 'SKAZKA')
! Kinetics_Method - Method of the Solution of Kinetics Equation
      "DRT"-Direct; "IQS"- Improved Quasi-Static; "PNT" - point
                                                             / "DRT"
! Iter_Solver - iterative solvers for kinertics :
                 CSA, CSI, CG, BCGSTAB, TFQMR, FOM, GMRES
                                                             / "CSA" /
! TRL_Approx - transverse leakage approximation
                                                             / "QLA" /
           (Possible Choices 'QLA', 'Flat')
                                                             / "Smith"/ !
! NonlinearIterations - nonlinear iteration procedure
           ( Possible Choices "Smith", "Moon")
! Xe_Sm_Model - model ofXe and Sm for burnup
                                                             / "none" / !
           ( Possible Choices "nn", "ss", "st", "ts", "tt")
|-----|
! INI_FILES - name of the input and restart files
! File_Input- Input File Name of the Geometry Data
! File_Reference - Name of the Reference Solution File
! File_Dist - name of the DIST*.txt file with distributions for
             Ringhals
! File_CD - name of the CD*.txt file with XS Tables (Ringhals)
           - Input File for the Mapping to the TRAC Geometry
! File_Map
              Only for the Coupling with the TRAC
                                                                11-11
! File_DMP_In - Input Restart File
! File_DMP_Out_st - Output Restart File for
                                Steady-State Calculations
! File_DMP_Out_Kin - Output Restart File for
                                           Calculations
```

```
! INI_CONVERGENCE - convergence criterion
                                                                      !
! N_Out_Max - Convergence Criterion for the Nonlinear Iterations
                                                 Steady-State
                                                              /1 /
                                                 Kinetics
                                                               /1000 / !
! N_Outer - Number of outer per nonlinear (thermalhydraulics)
                                                 Steady-State
                                                               /10 /
                                                 Kinetics
                                                               /1000/
! E_Boron_Start - Accuracy of the Eigenvalue when critical boron
           search starts
                                                               /1.E-2/ !
! E_Critical - Convergence Criterion of the Boron Critical Search
                                                              /1.E-5/!
! E_Outer_L - Converence Criterion for the Eigenvalue (Local)
                                                              /1.E-5/!
! E_Flux_L - Convergence Criterion for the Flux
                                                 Steady-State
                                                              /1.E-5/!
                                                              /1.E-4/!
                                                 Kinetics
            - Number of internal iterations per outer
                                                              /2 /!
! E_Inter - Converence Criterion for the Innner Iterations
                                                              /1.E-8/!
|-----|
|-----
! INI_CHEBYSHEV - Parameters for Chebyshev acceleration procedure
! Xbe - Estimate of Minimum Eigenvalue of the Iteration Matrix
                                                              /0.0
                                                                    /!
! Xme_Ini - Estimate of the Dominance Ratio (Spectral Radius)
                                                              /0.8 / !
! F_Cheb - Adaptive Parameter of the Chebyshev Procedure
                                                                      !
          (Non-Adaptive - 0, Adaptive - 0.65-0.85)
                                                 Steady-State
                                                              /0.0
                                                                    /!
                                                 Kinetics
                                                              /0.8 / !
                                                                    /!
! NPolins - Number of the Iteration when Chebyshev Starts
                                                              / 5
                                                               / 0.
                                                                    /!
! Delta_Shift - Inverse Value of the Wieland shift
```

```
! INI_TIME_STEP - Time Step Size Selection
                                                                              !
! I_Auto - Flag of the Automatic Time Step Selection
                                                                       0
                                                                            /!
                                                                            /!
! NP_View - Number of Time Step Interval
                                                                       1
! Ttv - Time Moments of the Time Step Intervals
                                                                              !
        Ttv(NP_View) - End of the Transien
                                                                            /!
                                                                       1.
! Dt_Input(NP_View) - Time Step Size for the Time Interval
          [Ttv(i-1) - Ttv(i)]
                                                                  / 0.01
                                                                            /!
! St_Eps - Accuracy Criterion of the Automatic Time Step Control /
                                                                     5.E-03 / !
! Facmax - Maximum Increase of the Time Step Size
                                                                            /!
! Dt_Step_Max - Maximum Time Step Size (s)
                                                                       1.
                                                                            /!
! N_Zap - Output into GRF file at the N_ZAPth Time Step
                                                                       1
                                                                            /!
&INI_PROBLEM
Problem_Type = "Kinetics"
TH_Model = "Internal"
Iter_Solver="CSI"
&FND
&INI_FILES
FILE_INPUT
               = 'Input/PWR_NEACRP_A1.DAT'
File_DMP_In = 'Restart/pwr_neacrp_A1_0.dat'
FILE_DMP_OUT_KIN = 'Restart/pwr_neacrp_A1_5.dat'
&END
&INI_CONVERGENCE
&END
&INI_CHEBYSHEV
&END
&INI_TIME_STEP
i_auto = 1
```

NP_VIEW = 1
TTV(1) = 5.
dt_input(1) = 0.005
ST_EPS = 5.E-03
&END

B.5 CONTENT OF THE POSTPROCESSOR INPUT NAMELIST FILE "POSTPROC.INI.PWR A1 KIN"

```
! File_grf - *.grf file generated by SKETCH.exe
                                                     "Output/SKETCH.grf"
! File_Inp - ASCII Input File for PostProcessor
! File_Out - ASCII Output File
                                                     "Output/PostProc.lst" !
! File_TR_Out - ASCII Output File
                                                     "Output/PProc_TR.lst" !
! File_TM_Out - ASCII Output File
                                                     "Output/PProc_TM.lst" !
! File_ST_Out - ASCII Output File
                                                     "Output/PProc_ST.lst" !
! fmt_tr_r - Output Format for Transient Real Data
                                                               "(E12.5)"
! fmt_tr_i - Output Format for Transient Integer Data
                                                               "(I5)"
                                                                          !
! fmt_ti_r - Output Format for Time Moment Real Data
                                                               "(F6.3)"
! fmt_ti_i - Output Format for Time_Moment Integer Data
                                                               "(I5)"
! fmt_st_r - Output Format for Steady-State Distributions
                                                               "(F6.3)"
                                                               "(I5)"
! fmt_st_i - Output Format for Staedy-State Distributions
                                                               "0.0"
! Time_Output - Output Time for Distributions
|-----|
&PostProc
File_grf =
             "Output/SKETCH.grf"
File_Inp =
             "Input/PP_PWR_A1_KIN.dat"
File_TR_Out = "Output/PP_PWR_A1_KIN_TIME.lst"
fmt_tr_r = "(F9.3)"
```

&END

B.6 CONTENT OF THE POSTPROCESSOR INPUT DATA FILE "PP PWR A1 KIN.DAT"

- ! INPUT OF THE DATA VS. TIME
- ! Reactor Power [MWt]

TS001

! Reactivity [\$]

TS002

! SKETCH-N Time Step Size, [ms]

TS003 0.001

! Average Doppler Fuel Temperature

TD005 0 0 0

! Maximum Fuel Centerline Temperature

TM006 3

! Location of the 3D Maximum Fuel Centerline Temperature

TL006 3

Modified IAEA-2D Test Without Reflector

C.1 CONTENT OF THE INCLUDE FILE

 $"vver_iaea2d_nor.fh"$

1 =		====
!	PARAMETERS FOR IAEA-2D VVER (No Reflector) BENCHMARK (c) Slava 23 November 2000	!
	(C) Blava 25 November 2000	•
•		:====
!	GeoMTry Module	!
!	$ exttt{N}_{ exttt{POLY}}$ - number of the bundles (assemblies) in the reactor;	!
!	NH - number of the nodes in radial $(X-Y)$ plane	!
!	with 1 node per assembly $NH = N_POLY$;	!
!	NZR - number of axial layers defining materail composition	!
!	of the bundle	!
!	NZ - number of axial lalers used for the calculations	!
!	NXR - maximum number of bundles in X directions	!
!	NX - maximum number of nodes in X direction	!
!	NYR - maximum number of bundles in Y directions	!
!	NY - maximum number of nodes in Y direction	!
!	NCHM - maximum number of nodes per bundle (assembly)	!

```
in X-Y plane
  NDD - reactor geometry dimensions
    (3D calculations NDD = 3; 2D calculations NDD = 2;
     1D calculations NDD = 3)
  N_BUNDLE_TYPE - number of different bundle types
!-----
INTEGER N_POLY, NH, NZR, NZ, NXR, NYR, NX, NY, &
NCHM, NDD, N_BUNDLE_TYPE, NDIR
PARAMETER (N_BUNDLE_TYPE = 4)
PARAMETER (N_POLY = 127, NH = 127)!
PARAMETER (NZR = 1, NZ = 1)
PARAMETER (NXR = 13, NYR = 13)
PARAMETER (NX = 13, NY = 13)
PARAMETER (NCHM = 1)
PARAMETER (NDD = 3)
PARAMETER (NDIR = 4)
! End GeoMTry Module
! TH Model
   NP_Reactor_Core - number of fuel bundles in the reactor core
   NZ_Core - number of axial layers in the reactor core (planes)
   NN_FRD_FA - number of the equivalent fuel rods per fuel assembly !
   NN_FA_TYPE - number of the fuel assembly types
integer NP_Reactor_Core, NZR_Core, NN_FRD_FA, NN_FA_TYPE
parameter (NP_Reactor_Core = 127, NZR_Core = 1 , &
NN_FRD_FA = 1, NN_FA_TYPE = 1)
!-----
! End TH_Model
! XS Module (Cross Section & Neutron Kinetics Constant)
```

```
NG - number of neutron energy groups
!
   NNODE number of material compositions (dimension of the XS arrays) !
!
   MD - number of delayed neutron groups
   N_FEEDBACKS - number of feedbacks (boron concentration, moderator !
    temperature, moderator density or void, doppler fuel temperature) !
INTEGER NNODE, NG, MD, N_FEEDBACK, MH
PARAMETER(NNODE = 4, NG = 2)
PARAMETER(MD = 1)
PARAMETER(N_FEEDBACK = 4)
PARAMETER(MH = 11)
1______
! End End TH Model
! CRD control rod Module
     NN_CRod_Comp - Number of Control Rod Compositions
     NN_CRod - Number of Control Rods
     NN_CRod_El - Number of the Rod Materials (Absorber + Driver = 2)!
     NN_CRod_Type - Number of Control Rod Types
     NN_Crod_Bundle - Number of the Bundles covered by CR
                           ("PWR" - 1, "BWR" - 4)
INTEGER NN_CRod, NN_CRod_Comp, NN_CRod_El, NN_CRod_Type, &
NN Crod Bundle
PARAMETER (NN_CRod_El = 1, NN_CRod = 1, NN_CRod_Comp = 1,&
NN_CRod_Type = 1, NN_Crod_Bundle = 1 )
!-----
! End CRD control rod Module
! Fuel RoD (FRD) Heat Conduction Model
     NN_FRD_FUEL - Number of the heat conduction nodes in the fuel
     NN_FRD_CLAD - Number of the heat conduction nodes in the cladding!
     NN_FRD_TOTAL - Total number of the heat conduction nodes
```

! in the fuel rod !	
!INTEGER NN_FRD_FUEL, NN_FRD_CLAD, NN_FRD_TOTAL	
PARAMETER (NN_FRD_FUEL=1, NN_FRD_CLAD = 1,&	
NN_FRD_TOTAL = NN_FRD_FUEL + NN_FRD_CLAD)	
!	
! End Fuel RoD (FRD) Heat Conduction Model !	
!	
! PVM Interface Module for TRAC !	
! $NN_RT_HC_TRAC-Number$ of nodes of heat conduction R-T spatial mesh !	
! NN_RT_FD_TRAC-Number of nodes of fluid dynamics R-T spatial mesh !	
! $NN_Z_HC_TRAC-Number$ of axial layers of heat conduction spatial mesh !	
! $NN_Z_FD_TRAC-Number$ of axial layers of fluid dynamics spatial mesh $$!	
!	
INTEGER NN_RT_HC_TRAC, NN_RT_FD_TRAC, NN_Z_HC_TRAC, NN_Z_FD_TRAC	
PARAMETER (NN_Z_HC_TRAC = 1, NN_Z_FD_TRAC = 1,&	
NN_RT_HC_TRAC = 1, NN_RT_FD_TRAC = 1)	
!	
! End PVM Interface Module for TRAC !	
!	
! THAT'S ALL !	
ļ=====================================	

C.2 CONTENT OF THE INPUT NAMELIST FILE "SKETCH.INI.VVER IAEA2D NOR 125.ST"

```
SKETCH-N version 1.0: Nodal Neutron Diffusion Code for
                                                                С
С
          Solving Steady-State & Kinetics Problems
                                                                С
С
                                                                С
           Moscow Engineering Physics Institute
C
                                                                C
              Tokyo Institute of Technology
C
                                                                C
            Japan Atomic Energy Research Institute
С
С
      Author: Vyacheslav G. Zimin
С
                                                                C
С
                 (c) 1999 All Rights Reserved
С
                                                                С
С
                                                                С
                          NOTICE
С
С
                                                                С
  Permission to use, copy, modify, and distribute this software and
С
                                                                С
  its documentation for any purpose and without fee is hereby granted
                                                                С
  provided that the above copyright notice appear in all copies and
                                                                C
  that both the copyright notice and this permission notice appear in
  supporting documentation.
С
                                                                С
С
                                                                С
  Neither the Institutions nor the Author make any
                                                                C.
  representations about the suitability of this software for any
                                                                С
          This software is provided "as is" without express or
                                                                С
  implied warranty.
|-----|
! INI\_PROBLEM - the basic problem description & solution methods
                                                                 ļ
! Problem_Type - type of the computed problem
                                                                 ļ
                                                           11-11
               "Eigenvalue", BoronSearch", "Kinetics"
                                                               /!
```

```
! Nodal_Method - Choice of the Nodal Method:
              "PNM", "SANM", "ANM", "MCFD", "PNM1"
                                                             / "SANM" / !
                                                             / 'None' / !
! TH_Model - Thermal-hydraulics Model Used for the Calculations
            (Possible Choices 'Internal', 'External', 'None')
! Kinetics_Method - Method of the Solution of Kinetics Equation
      "DRT"-Direct; "IQS"- Improved Quasi-Static; "PNT" - point
                                                             / "DRT"
! Iter_Solver - iterative solvers for kinertics :
                 CSA, CSI, CG, BCGSTAB, TFQMR, FOM, GMRES
                                                             / "CSA" /
|-----|
! INI_FILES - name of the input and restart files
! File_Input- Input File Name of the Geometry Data
! File_Reference - Name of the Reference Solution File
! File_Dist - name of the DIST*.txt file with distributions for
                                                                \Pi/\Pi
             Ringhals
                                                                11-11
! File_CD - name of the CD*.txt file with XS Tables (Ringhals)
           - Input File for the Mapping to the TRAC Geometry
! File_Map
              Only for the Coupling with the TRAC
! File_DMP_In - Input Restart File
                                                                11.11
! File_DMP_Out_st - Output Restart File for
                                Steady-State Calculations
! File_DMP_Out_Kin - Output Restart File for
                                Kinetics
                                            Calculations
|-----|
! INI_CONVERGENCE - convergence criterion
                                                                        !
! N_Out_Max - Convergence Criterion for the Nonlinear Iterations
                                                  Steady-State
                                                                /1 /
                                                                /1000 / !
                                                  Kinetics
! N_Outer - Number of outer per nonlinear (thermalhydraulics)
                                                  Steady-State
                                                                /10 / !
```

! Kinetics	/1000/	,	,
! E_Boron_Start - Accuracy of the Eigenvalue when critical boron	/1000/		
! search starts	/1.E-2) /	
! E_Critical - Convergence Criterion of the Boron Critical Search	/1.E-5		
! E_Outer_L - Converence Criterion for the Eigenvalue (Local)	/1.E-5		
! E_Flux_L - Convergence Criterion for the Flux	/ 1 . 11 - 0	,	
<u> </u>	/1.E-5	5/	
! Kinetics	/1.E-4		
! N_Inter - Number of internal iterations per outer	/1.6 -		
! E_Inter - Converence Criterion for the Innner Iterations	/2 /1.E-8		
!=====================================		-	
•			•
!======================================			= 1
! INI_CHEBYSHEV - Parameters for Chebyshev acceleration procedure			!
! Xbe - Estimate of Minimum Eigenvalue of the Iteration Matrix	/0.0	/	!
! Xme_Ini - Estimate of the Dominance Ratio (Spectral Radius)	/0.8	/	!
! F_Cheb - Adaptive Parameter of the Chebyshev Procedure	·	٠	!
! (Non-Adaptive - 0, Adaptive - 0.65-0.85)			!
•	/0.0	/	!
! Kinetics	/0.8		!
! NPolins - Number of the Iteration when Chebyshev Starts	/ 5		!
! Delta_Shift - Inverse Value of the Wieland shift	/ 0.		!
- !====================================	,		= !
!======================================	======		=!
! INI_TIME_STEP - Time Step Size Selection			!
! I_Auto - Flag of the Automatic Time Step Selection /	0	/	!
! NP_View - Number of Time Step Interval /	1	/	
! Ttv - Time Moments of the Time Step Intervals		•	!
! Ttv(NP_View) - End of the Transien /	1.	/	!
! Dt_Input(NP_View) - Time Step Size for the Time Interval		•	!
	0.01	/	!
	5.E-03	/	!

```
/!
! Facmax - Maximum Increase of the Time Step Size
                                                                        2
! Dt_Step_Max - Maximum Time Step Size (s)
                                                                             /!
                                                                       1.
                                                                             /!
! N_Zap - Output into GRF file at the N_ZAPth Time Step
                                                                        1
&INI_PROBLEM
Problem_Type = "Steady-State"
Steady_State_Type = "Eigenvalue"
TH_Model = "None"
Nodal_Method = "PNM"
&END
&INI_FILES
FILE_INPUT
                = "Input/VVER_IAEA2D_NOR_125.DAT"
FILE_REFERENCE = "Input/VVER_IAEA2D_NOR_125.ref"
FILE_DMP_OUT_ST = "Restart/VVER_IAEA2D_NOR_125.dat"
&END
&INI_CONVERGENCE
&END
&INI_CHEBYSHEV
Delta\_Shift = 0.
&END
&INI_TIME_STEP
&END
```

C.3 CONTENT OF THE INPUT FILE "VVER_IAEA2D_NOR_125.DAT"

! -		!
!	IAEA-2D VVER Input Data (NO Reflector, albedo 0.125)	!
!	(c) Slava 23 November 2000 MEPhI	!
!		!
! -		!

CNT_RCT_TYPE ## REACTOR TYPE

"PWR"

CNT_RCT_POWR ## REACTOR POWER (MWt)

1.

XS_BASE_DATA ## Basic set of the Macro Cross Section Data

1.5 0.4	0.02 0.08	0.01 0.135	0.0 0.135	0.0
1.5	0.02 0.085	0.01 0.135	0.0 0.135	0.0
1.5	0.02 0.130	0.01 0.135	0.0 0.135	0.0
1.5 0.4	0.04 0.01	0.00	0.0	0.0

XS_DIFF_FLAG

```
1 ## Parameter 1 - Diffusion Coefficient, 0 - Transport XS
XS_NEUT_SPEC
1.0 0.0 ## xp(NG)
XS_POWR_CONV
3.204E-11 3.204E-11 ## pow_conv
GMT_CRD_TYPE # Coordinate System ("XYZ" or "HEX-Z")
"HEXZ"
GMT_NUM_BNDL ## Numbering of the reactor assdemblies (bundles)
  7
1
1
  8
1
  9
1
  10
1
  11
1
  12
1
  13
   13
3
  13
4
  13
5
  13
6
  13
7
  13
GMT_MSH_RDIR ## Spatial Mesh for HEX Geometry
20.
```

```
GMT_COR_LOAD ## Core Loading with Bundle Types
1 1 1 1 1 1 1
1 2 2 2 2 2 2 1
1 2 2 2 3 2 2 2 1
1 2 2 2 2 2 2 2 1
1 2 3 2 3 2 3 2 3 2 1
1 2 2 2 2 2
              2 2 2 2 2 1
1 2 2 2 3 2
             3
                 2 3 2 2 2 1
1 2 2 2 2 2
              2 2 2 2 2 1
1 2 3 2 3 2 3 2 3 2 1
1 2 2 2 2 2 2 2 2 1
1 2 2 2 3 2 2 2 1
1 2 2 2 2 2 2 1
1 1 1 1 1 1 1 1 (N_POLY, NZR)
1 \ 1 \ ## \ nb = 1
2 \ 2 \# nb = 2
3 \ 3 \ ## \ nb = 3
4 \ 4 \ ## \ nb = 4
GMT_BND_COND ## Boundary Conditions
         1 1 ## type of boubdary condition (radial Ext. Dist. - 0, Log. Der. - 1)
0.125 0.125 0.125 0.125
                          0.125 0.125
                                        0.125 0.125
                                                       0.125 0.125
                                                                   0.125 0.125
0. 0. ## bound. condit. (axial Ext.Dist.-0, Log.Der.-1) BUCKLING(NG)
```

! End of the IAEA-2D VVER Input Data (NO Reflector, albedo 0.125)

|-----|