The CP/M® Z-80® Microcomputer

$\mathbf{ZSID}^{^{\text{IM}}}$ Symbolic instruction debugger

COMMAND SUMMARY

Z-80 VERSION

DIGITAL RESEARCH

COPYRIGHT

Copyright © 1979, 1981 by Digital Research. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Digital Research, Post Office Box 579, Pacific Grove, California, 93950.

TRADEMARKS

CP/M is a registered trademark of Digital Research. Z-80 is a registered trademark of Zilog. ZSID is a trademark of Digital Research.

All information contained herein is proprietary to Digital Research.

ABOUT THIS MANUAL

The starting point for this PDF file was the plain text contained in the file zsid.txt (OCR'd from a CP/M manual) zipped in the file zsid-m.zip, that was downloaded from www.cpm.z80.de, The Unoficial CP/M Web Site.

Please, enter in this site to know how you can help to the CP/M community working on CP/M manuals.

Miguel I. García López, 24 May 2007.

ZSID COMMAND SUMMARY

- Startup
- 1.2 Response
- Letter commands Command line Literal numbers Decimal numbers 1.3
- 1.4
- 1.5
- 1.6 1.7
- Characters
- 1.8
- 1.9
- Symbol references
 Qualified symbols
 Symbolic expressions 1.10
- Unary plus/minus 1.11
- 2.1 2.2 2.3 2.4 Assemble
- Call
- Display memory Fill memory
- 2.5 Go to program
- 2.6 2.7 2.8 Hex values Input line
- List code
- 2.9 Move memory
- Pass counter
- 2.11 2.12 2.13 Read code/symbols
- Set memory
- Trace mode
- 2.14 Untrace mode
- 2.15 Examine cpu state
- 3.1 ZSID utilities
- The hist utility
- 3.2 3.3 The trace utility
- 4.1 Implementation notes
- 5.1 z80 mnemonics
- Z80-cpu instruction set 5.2

1.1 / STARTUP

- (1) ZSID
- (2) ZSID x.y
- (3) ZSID x.HEX
- (4) ZSID x.UTL(5) ZSID x.y u.v

Form (1) starts ZSID without a test program, (2) loads the test program x.y (y is normally COM), (3) loads x.HEX in Intel "hex" format, (4) loads and executes utility x, (5) loads x.y with the symbol table u.v (normally x.SYM).

Example:

ZSID SORT.COM SORT.SYM

1.2 / RESPONSE

- (1) #
- (2) SYMBOLS
- (3) NEXT PC END nnnn pppp eeee

Form (1) indicates ZSID is ready to accept commands, (2) indicates machine code loaded, commencing symbol table load, (3) shows successful machine code and/or symbol load where nnnn, pppp, and eeee are hexadecimal values giving the next unfilled machine code location, the initial program counter, and the last free memory location, respectively.

1.3 / LETTER COMMANDS

Α	Assemble	М	Move
C	Call	Р	Pass Point
D	Display	R	Read
F	Fill Memory	S	Set Memory
G	Go	Т	Trace
Н	Hex	U	Untrace
I	Input Line	Χ	Examine
L	List Mnemonic	S	

1.4 / COMMAND LINE

ZSID reads commands from the system console following the # prompt. Each command line is based upon the command letter and optional symbolic expressions. All CP/M line editing is available on 64 character lines terminated by carriage returns. A space serves as a comma delimiter.

ZSID terminates whenever control-C is typed.

1.5 / LITERAL NUMBERS

ZSID uses the hexadecimal number base, consisting of the decimal digits 0-9 along with the hex digits A-F. Numbers exceeding four digits are truncated to the right.

Examples are:

30 3F 3f FF3E F3

1.6 / DECIMAL NUMBERS

Decimal numbers are preceded by a #, and consist of decimal digits 0-9. Numbers exceeding 65535 are truncated to the rightmost 16 bits.

Examples are:

#48 #9999 #65535 #0

1.7 / CHARACTERS

ZSID accepts graphic ASCII characters within paired string apostrophes). Strings of length greater than two are truncated to the right. The rightmost character of a two character string becomes the least significant byte. A one character string has a high order 00 byte, zero length strings are disallowed, and a pair of apostrophes within a string reduces to a single apostrophe. Lower case letters are not translated in strings.

Examples are:

'a' 'A' 'xv' '#' ''

1.8 / SYMBOL REFERENCES

ZSID symbolic expressions may involve symbol references when a symbol table is present:

- @s

Form (1) denotes the address of symbol s, (2) denotes the 16-bit value at .s, (3) denotes the 8-bit value at .s, where s is a sequence of characters matching a symbol table element.

1.9 / QUALIFIED SYMBOLS

ZSID searches for a symbol match starting at the first symbol loaded until the first symbol matches. When duplicate symbols exist, a qualified reference of the form

s1/s2/.../sn

matches symbols from left to right as the search proceeds sequentially through the symbol table.

An example is:

ALPHA/GAMMA/I

1.10 / SYMBOLIC EXPRESSIONS

Expressions consist of a left to right sequence of literal numbers, decimal numbers, character strings, and symbol references, separated by plus ("+") and minus ("-") operators. Values are added or subtracted, accordingly, with no overflow checks, to produce the final 16-bit result.

A leading minus, as in -x, is computed as 0-x. A leading plus, as in +x, is computed as x'+x, where x' is the value of the last expression typed. A sequence of $n \land s$ produces the n'th stacked value in the program under test (see the G command). Blanks are not allowed within expressions.

Examples are given with individual commands.

1.11 / UNARY PLUS/MINUS

For convenience, symbolic expressions may be preceded by either a plus or minus sign taking the forms

- (1) +x (2) -x

where x is a symbolic expression. Form (1) is computed as x'+x, where x' is the value of the last symbolic expression typed by the operator, or zero if no expression has been entered.

For example

D.GAMMA+5.+#10

is equivalent to

D. GAMMA+5, .GAMMA+5+#10

Form (2) is computed as 0-X and thus

R-100

is equivalent to

RFF00

2.1 / ASSEMBLE

Form (1) begins in-line assembly at location s, where each successive address is displayed until a null line or "." is entered by the operator. Form (2) is equivalent to (1) with assumed starting address derived from last assembled, listed, or traced address. Form (3) removes the assembler/ disassembler module, discards existing symbol information, and disables subsequent A or L commands. In this case, machine hex code is displayed in subsequent traces.

Examples:

A100 A#100 A.CRLF+5 A@GAMMA+@X-=IA + 30

2.2 / CALL

- (1) Cs (2) Cs,b (3) Cs,b,d

Form (1) performs a direct call from ZSID to location s in memory, without disturbing the CPU state of the program under test, and is most often used with ZSID Utilities. In this case, registers BC=0000, DE=0000. Form (2) calls s with data BC=b, DE=0000, while form (3) also fills DE=d.

Examples:

C100 C#4096 **C.DISPLAY** C@JMPVEC+=X C.CRLF,#34 C.CRLF,@X,+=X

2.3 / DISPLAY MEMORY

- (1) (2) Ds
- Ds,f
- D
- (3) (4) D,f
- (5) DWS DWs,f
- DW
- DW, f

Form (1) types memory contents in 8-bit format starting at location s for 1/2 screen with graphic ASCII to the right of each line, (2) is similar, but ends at location f. Form (3) continues the display from the last displayed location, or the value of the HL register pair following CPU state display, for 1/2 screen, (4) is similar, but terminates at location f. Forms (5) through (8) are equivalent to (1) through (4), but display in word format (16-bits).

Examples:

DF3F D#100,#200 D.gamma, .DELTA+#30 d, GAMMÁ DW@ALPHA,+#100

2.4 / FILL MEMORY

Fs,f,d

Fills memory with 8-bit data d starting at location s, continuing through location f.

Examples:

F100,3FF,ff f.gamma,+#100,#23 F@ALPHA, +=I, =X

2.5 / GO TO PROGRAM

- (1)G
- Gp
- (2) (3) G,a
- (4) (5) Gp,a
- G,a,b
- (6) Gp,a,b
- Form (1) starts the program under test from the current PC without breakpoints. Execution is in real time. Form (2) is equivalent, but sets PC=p before execution, (3) starts from the current PC with a breakpoint at location a, (4) is similar to (3) but sets the PC to p. Form (5) is equivalent to (3) but sets breakpoints at a and b, while (6) presets the PC to p before execution. Upon encountering a breakpoint (or an externally provided RST 7), the break address is printed in the form:

and the optional breakpoints are cleared. Forms given by (7) parallel (1) through (6), except "pass points" are not traced until the corresponding pass count becomes zero (see P command). The symbol "^" in an expression produces the topmost stacked value, which is used to be a break fallowing a subsputing call Given that a breakpoint has set a break following a subroutine call. Given that a breakpoint has occurred at a subroutine, the command

G, A

continues execution with a return breakpoint set.

Examples:

```
G100
G100,103
G.CRLF,.PRINT,#1024
G@JMPVEC+=I,.ENDC,.ERRC
G,.errsub
G,.ERRSUB,+30
-G100,+10,+10
```

2.6 / HEX VALUES

- (1) Ha,b
- (2) Ha
- (3) H

Form (1) produces the hexadecimal sum (a+b) and difference (a-b) of operands. Form (2) performs number conversion by typing the value of a in the format:

```
hhhh #ddddd 'c' .ssss
```

where hhhh is a's hex value, dddd is the decimal value, c is the ASCII value, if it exists, and ssss is the symbolic value, if it exists. Form (3) prints the hex values for each symbol table element (abort with rubout).

Examples:

```
H100,200
H#1000,#965
H.GAMMA+=I,@ALPHA-#10
H#53
H@X+=Y-5
```

2.7 / INPUT LINE

```
Ic1c2...cn
```

Initializes default low memory areas for the R command or the program under test, as if the characters c1 through cn had been read and setup at the console command processor level. Default FCB's are initialized, and the default buffer is set to the initial input line.

Examples:

```
I x.dat
ix.inp y.out
I a:x.inp b:y.out $-p
ITEST.COM
I TEST.HEX TEST.SYM
```

2.8 / LIST CODE

- (1) Ls (2) Ls,f
- (3) L
- (4) -L..

Form (1) lists disassembled machine code starting at location s for 1/2 screen, (2) lists mnemonics from location s through f (abort typeouts with rubout). Form (3) lists mnemonics from the last listed, assembled, or traced location for 1/2 screen. Form (4) parallels (1) through (3), but labels and symbolic operands are not printed. Labels are printed in the form

ssss:

ahead of the lines to which they correspond.

Non-z80 mnemonics are printed as

where hh is the hex value at that location.

Examples:

```
L100
L#1024,#1034
L.CRLF
L@ICALL,+30
-L.PRBUFF+=I,+'A'
```

2.9 / MOVE MEMORY

Ms,h,d

Move data values from start address s through h address h to destination address d. Data areas may overlap during the move process.

Examples:

```
M100,1FF,300
M.X,.Y,.Z
M.GAMMA,+FF,.DELTA
M@alpha+=x,+#50,+100
```

2.10 / PASS COUNTER

- (1) Pp
- (2) Pp,c
- (3) P (4) -Pp
- (5) B

A "pass point" is a program counter location to monitor during execution of a test program. A pass point has an associated "pass counter" in the range 1-FF (0-#255) which is decremented each time the test program executes the pass point address. When a pass count reaches 1, the pass point becomes a permanent breakpoint and the pass count remains at 1. Unlike a temporary breakpoint (see G), pass points with pass count 1 stop execution following execution of the instruction at the break address. Form (1) sets a pass point at address p with pass count 1, (2) sets pass point p with pass count c, (3) displays active pass points and counts, (4) clears the pass point at p (equivalent to Pp,0), and (5) clears all pass points. Up to 8 pass points can be active at any time. CPU registers are displayed when executing a pass point, with the header

```
nn PASS hhhh .ssss
```

showing the pass count nn and address hhhh with optional symbol ssss. Registers are not displayed if -G or -U is in effect until the pass count reaches 1. Execution can be aborted during the pass trace with rubout.

Examples:

```
P100,ff
P.BDOS
P@ICALL+30,#20
-P .CRLF
```

2.11 / READ CODE/SYMBOLS

- (1) R
- (2) Rd

The I command sets up code and symbol files for subsequent loading with the R command. Form (1) reads optional code and optional symbols in preparation for program test, (2) is similar, but loads code and/or symbols with the bias valued. The sequence:

Sets up machine code file x.y (y is usually COM), and reads machine code to the transient area. If y is HEX, the file must be in Intel "hex" format. The sequence:

also reads the symbol file u.v (u is usually the same as x, and v is normally SYM). The form:

skips the machine code load, and reads only the symbol file.

when a symbol file is specified, the response

SYMBOLS

shows the start of the symbol file read operation. Thus, a "?" error before the SYMBOL message indicates a machine code read error, while "?" following the SYMBOL message shows a symbol file read error.

Examples:

I COPY.COM
R
I SORT.HEX SORT.SYM
R
I merge.com merge.sym
R1000
I * test.sym
R-#256

2.12 / SET MEMORY

- (1) Ss (2) SWs
- Form (1) sets memory locations in 8-bit format, (2) sets memory in 16-bit "word" format. In either case, each address is displayed, along with the current content. If a null line is entered, no change is made, and the next address is prompted. If a value is typed, then the data is changed and the next address is prompted. Input terminates with either invalid input, or a single "." from the console. Long ASCII input is entered with form (1) by typing a leading quote (") followed by graphic characters, terminated by a carriage return.

The examples show underlined console input:

```
S100

0100 C3 34

0101 24 #254

0102 CF

0103 4B "Ascii

0108 6E =X+5

0109 D4 .

SW.X+#30

2300 006D 44F

2302 4F32 @GAMMA

2304 33E2

2306 FF11 0+.X+=I-#20

2308 348F .
```

2.13 / TRACE MODE

- (1) Tn (2) T (3) Tn,c (4) T,c (5) -T ... (6) TW ...
- (7) -TW ...

Form (1) traces n program steps, showing the CPU state at each step, while (2) traces one step. Form (3) is used with ZSID utilities, and "calls" the utility function c at each trace step. Form (4) is similar to (3), but traces only one step. Form (5) parallels (1) to (4), but disables symbols.

Form (6) parallels (1) to (4), but performs "trace without call"

Form (6) parallels (1) to (4), but performs "trace without call" showing only local execution. Form (7) is similar to (6) with symbols disabled.

Examples:

```
T100
T#30,.COLLECT
-TW=I,3E03
```

2.14 / UNTRACE MODE

(1) U ... (2) -U (3) UW ... (4) -UW ...

U performs the same function as T, except the register state is not displayed. Forms (2) and (4), however, disable intermediate pass point trace (see P). U and T both run fully monitored, with automatic breaks at each instruction.

Execution can be aborted with rubout.

Examples:

```
Uffff
U#10000,.COLLECT
UW=GAMMA,.COLLECT
```

2.15 / EXAMINE CPU STATE

- (1) X (2) Xf
- (3) Xr

Form (1) displays the CPU state in the format:

f A=a B=b D=d H=h S=s P=p i s

where f is the "flag state," a is the Z80 accumulator content, b is the 16-bit BC register pair value, d is the DE value, h is the HL value, s is the SP value, p is the PC value, i is the decoded instruction at p, and s is symbolic information. The flag are represented by dashes ("-") when false, and their letters when true:

Carry Zero Minus Even parity Interdigit carry

Form (2) allows flag state change, where f is one of C,Z,M,E, or I. The current state is displayed (either "-" or the letter). Enter the value 1 for true, 0 for false, or null for no change. Form (3) allows register state change, where r is one of A, B, D, H, S, or P. Symbol information is given at s when i references an address, including LDAX and STAX. The form "=mm" is printed for memory referencing instructions (e.g., INR M, ADD M), where mm is the memory value before execution.

Examples with operator input underlined:

XM M O XB 3E04 3EFF XP 446E .CRLF+10

3.1 / ZSID UTILITIES

Utilities execute with ZSID to provide additional debugging facilities.

A utility is loaded initially by typing:

ZSID x.UTL

where x is the utility name. Upon loading, the utility is setup for execution with ZSID, and responds with:

.INITIAL = iiii .COLLECT = CCCC .DISPLAY = dddd

where iiii, cccc, and dddd are three absolute address entries to the utility for (re)initializing, collecting debug data, and displaying collected information, respectively. The ZSID symbol table contains these three entry names. A utility is reinitialized by typing:

Ciiii or C.INITIAL

The display information is obtained by typing:

Cdddd or C.DISPLAY

while data collection occurs during monitored execution using the T or U commands, where the second argument gives the collection address.

Examples are:

Uffff,.collect U#1000,3403 TW1000,.COLLECT UW@GAMMA,.COLLECT

Pass points may be set during data collection to stop the monitoring at the end of program areas under test. The actual initialization, collection, and display functions depend upon the particular ZSID utility.

3.2 / THE HIST UTILITY

The HIST utility creates a histogram of program execution between two locations given during initialization. Program addresses are monitored during U or T mode execution, with summary data displayed at any time. Upon startup or reinitialization, HIST prompts with:

TYPE HISTOGRAM BOUNDS:

Respond with:

aaaa, bbbb

for a histogram between locations aaaa and bbbb, inclusive. Collect data in U or T mode, then display results. Output is scaled to the maximum collected value, accumulating until reinitialization.

An example:

ZSID HIST.UTL TYPE HISTOGRAM BOUNDS 100, A00 .INITIAL = 3E03.COLLECT = 3E06.DISPLAY = 3E09**#I SORT.COM SORT.SYM** #R **SYMBOLS** #UFF,.COLLECT
(register display and break) #C.DISPLAY (histogram display) U1000, COLLECT (display and eventual break) C.DISPLAY (updated histogram display) #C.INITIAL (histogram bounds reset)

3.3 / THE TRACE UTILITY

The TRACE utility provides a dynamic backtrace of up to 256 instructions which ended at the current break address. Instruction address collection occurs only in U or T mode. Pass points can be active, however, during the data collection, and will halt execution when the pass count becomes 1. Initialization clears the accumulated instructions, collection records the instruction address in a wraparound buffer, and display prints the backtrace in decoded mnemonic form with symbol references and labels when they occur. If "-A" Is in effect, only instruction addresses are given. In this case, TRACE is loaded by typing:

ZSID #-A #I TRACE.UTL #R ADDRESSES ONLY An example of normal operation:

ZSID TRACE.UTL
READY FOR SYMBOLIC BACKTRACE
#I MERGE.COM MERGE.SYM
#R
#UFFF,.COLLECT
(register display, wait, break)
#C.DISPLAY
(symbolic backtrace appears)

4.1 / IMPLEMENTATION NOTES

The ZSID program operates in about 10K bytes, and self-relocates directly below the BDOS (overlaying the CCP area). The ZSID symbol table fills downward from the base of ZSID. As the table fills, the BDOS jump address is altered to reflect the reduced free space. Programs which "size" memory using the BDOS jump address should not be started until all symbols are loaded.

The "-A" command increases the free space by about 4K bytes. Any existing symbol information must be reloaded after issuing the command.

Programs will trace up to the BDOS where tracing is discontinued until control returns to the calling program.

ROM subroutine tracing is discontinued when ROM is entered through a call or jump and resumed upon return to the calling program in RAM.

Use rubout to abort programs running fully monitored in T or U mode, and an externally provided restart (RST 7) when running unmonitored with ${\sf G}.$

5.1 / Z80 MNEMONICS

The Z80 mnemonics which follow (reproduced with permission from Zilog Corporation), can be entered directly in assembly mode (see A), and are produced by ZSID in list mode (see L). Data fields can consist of symbolic expressions. Given that "A100" has been typed, and that the symbols X, Y, and Z exist, the following is valid input:

```
LD
      A,B
      A,OFF
LD
     B,#255
(HL),'x'
LD
LD
I D
JP
      100
CALL .X
      Z,@Y
JΡ
      HL,@X+=Z
LD
      .X/Y+5
```

Notable differences between MAC and the ZSID "A" command are that no pseudo operations are allowed, operands are ZSID symbolic expressions*, labels cannot be inserted, and register references must be names, not numbers.

*In particular, note that

```
LD HL, 'ab'
```

fills H with 'a' and L with 'b' due to the nature of ZSID expressions, which is counter to the MAC convention.

The Z80 is a Federally registered trademark of Zilog Corporation.

5.2 / Z80-CPU INSTRUCTION SET

OBJ CODE	SOURCE STATEMENT	OPERATION
8E DD8E05 FD8E05 8F 88 89 8A 8B 8C 8D CE20	ADC A, (HL) ADC A, (IX+d) ADC A, (IY+d) ADC A,A ADC A,B ADC A,C ADC A,D ADC A,E ADC A,E ADC A,H ADC A,L ADC A,n	Add with Carry Operand to Acc.
ED4A ED5A ED6A ED7A	ADC HL,BC ADC HL,DE ADC HL,HL ADC HL,SP	Add with Carry Reg Pair to HL
86 DD8605 FD8605 87 80 81 82 83 84 85 C620	ADD A, (HL) ADD A, (IX+d) ADD A, (IY+d) ADD A,A ADD A,B ADD A,C ADD A,D ADD A,E ADD A,H ADD A,L ADD A,n	Add Operand to Acc.
09 19 29 39	ADD HL,BC ADD HL,DE ADD HL,HL ADD HL,SP	Add Reg. Pair to HL
DD09 DD19 DD29 DD39	ADD IX,BC ADD IX,DE ADD IX,IX ADD IX,SP	Add Reg. Pair to IX
FD09 FD19 FD29 FD39	ADD IY,BC ADD IY,DE ADD IY,IY ADD IY,SP	Add Reg. Pair to Iy
A6 DDA605 FDA605 A7 A0 A1 A2 A3 A4 A5 E620	AND (HL) AND (IX+d) AND (IY+d) AND A AND B AND C AND D AND E AND H AND L AND n	Logical 'AND' of Operand and Acc.
	BIT 0,(HL) BIT 0,(IX+d) BIT 0,(IY+d) BIT 0,A BIT 0,B BIT 0,C BIT 0,D BIT 0,E BIT 0,H	Test Bit b of Location or Reg.

```
CB45
              BIT 0,L
CB4E BIT 1,(HL)
DDCB054E BIT 1,(IX+d)
FDCB054E BIT 1,(IY+d)
              BIT 1,A
CB4F
              BIT 1,B
CB48
              BIT 1,C
BIT 1,D
BIT 1,E
CB49
CB4A
СВ4В
              BIT 1,H
CB4C
CB4D BIT 1,L
CB56 BIT 2,(HL)
DDCB0556 BIT 2,(IX+d)
FDCB0556 BIT 2,(IY+d)
CB57 BIT 2,A
              BIT 2,B
BIT 2,C
BIT 2,D
CB50
CB51
CB52
              BIT 2,E
CB53
CB54 BIT 2,H
CB55 BIT 2,L
CB5E BIT 3,(HL)
DDCB055E BIT 3,(IX+d)
FDCB055E BIT 3,(IY+d)
              BIT 3,A
BIT 3,B
BIT 3,C
CB5F
CB58
CB59
              BIT 3,D
CB5A
              BIT 3,E
BIT 3,H
BIT 3,L
CB5B
CB5C
CB5D
              BIT 4,(HL)
CB66
DDCB0566 BIT 4, (IX+d)
FDCB0566 BIT 4, (IY+d)
              BIT 4,A
CB67
              BIT 4,B
CB60
              BIT 4,C
CB61
              BIT 4,D
CB62
              BIT 4,E
BIT 4,H
CB63
CB64
              BIT 4,L
CB65
              BIT 5, (HL)
CB6E
DDCB056E BIT 5, (IX+d)
FDCB056E BIT 5,(IY+d)
CB6F BIT 5,A
              BIT 5,B
CB68
              BIT 5, C
CB69
              BIT 5,D
BIT 5,E
СВ6А
св6в
              BIT 5,H
CB6C
              BIT 5,L
CB6D
              BIT 6,(HL)
CB76
DDCB0576 BIT 6,(IX+d)
FDCB0576 BIT 6,(IY+d)
              BIT 6,A
CB77
CB70
              BIT 6,B
              BIT 6,C
BIT 6,D
BIT 6,E
CB71
CB72
СВ73
              BIT 6,H
CB74
              BIT 6,L
CB75
CB7E BIT 7,(HL)
DDCB057E BIT 7,(IX+d)
FDCB057E BIT 7,(IY+d)
              BIT 7,A
CB7F
СВ78
              BIT 7,B
              BIT 7,C
BIT 7,D
CB79
CB7A
              BIT 7,E
СВ7В
              BIT 7,H
CB7C
```

CB7D	BIT 7,L	
DC8405 FC8405 D48405 C48405 F48405 EC8405 E48405 CC8405	CALL C,nn CALL M,nn CALL NC,nn CALL NZ,nn CALL P,nn CALL PE,nn CALL PO,nn CALL Z,nn	Call Subroutine at Location nn if Condition True
CD8405	CALL nn	Unconditional Call to Subroutine at nn
3F	CCF	Complement Carry Flag
BE DDBE05 FDBE05 BF B8 B9 BA BB BC BD FE20		Compare Operand with Acc.
EDA9	CPD	Compare Location (HL) and Acc. Decrement HL and BC
EDB9	CPDR	Compare Location (HL) and Acc. Decrement HL and BC. Repeat until BC = 0
EDA1	CPI	Compare Location (HL) and Acc. Increment HL and Decrement BC
EDB1	CPIR	Compare Location (HL) and Acc. Increment HL, Decrement BC Repeat until BC = 0
2F	CPL	Complement Acc. (1's Comp).
27	DAA	Decimal Adjust Acc
35 DD3505 FD3505 3D 05 0B 0D 15 1B 1D 25 2B DD2B FD2B 2D 3B	DEC (HL) DEC (IX+d) DEC (IY+d) DEC A DEC B DEC BC DEC C DEC D DEC DE DEC DE DEC E DEC H DEC HL DEC IX DEC IY DEC L DEC SP	Decrement Operand
F3	DI	Disable Interrupts
102E	DJNZ e	Decrement B and Jump Relative if B=0
FB	EI	Enable Interrupts

E3 DDE3 FDE3	EX (SP),HL EX (SP),IX EX (SP),IY	Exchange Location and (SP)
08	EX AF,AF'	Exchange the Contents of AF and AF'
EB	EX DE,HL	Exchange the Contents of DE and HL
D9	EXX	Exchange the Contents of BC, DE, HL with Contents of BC', DE', HL' Respectively
76	HALT	HALT (Wait for Interrupt or Reset)
ED46 ED56 ED5E	IM 0 IM 1 IM 2	Set Interrupt Mode
ED78 ED40 ED48 ED50 ED58 ED60 ED68	IN A,(C) IN B,(C) IN C,(C) IN D,(C) IN E,(C) IN H,(C) IN L,(C)	Load Reg. with Input from Device (C)
34 DD3405 FD3405 3C 04 03 0C 14 13 1C 24 23 DD23 FD23 2C 33	INC (HL) INC (IX+d) INC (IY+d) INC A INC B INC BC INC C INC D INC DE INC E INC E INC H INC HL INC IX INC IY INC L INC SP	Increment Operand
DB20	IN A,(n)	Load Acc. with Input from Device n
EDAA	IND	Load Location (HL) with Input from Port (C), Decrement HL and B
EDBA	INDR	Load Location (HL) with Input from Port (C), Decrement HL and Decrement B, Repeat until B=0
EDA2	INI	Load Locatron (HL) with Input from Port (C), Increment HL and Decrement B
EDB2	INIR	Load Location (HL) with Input from Port (C), Increment HL and Decrement B, Repeat until B=0
C38405 E9 DDE9 FDE9	JP nn JP (HL) JP (IX) JP (IY)	Unconditional Jump to Location
DA8405 FA8405 D28405 C28405	JP C,nn JP M,nn JP NC,nn JP NZ,nn	Jump to Location if Condition True

```
F28405
           JP P,nn
EA8405
           JP PÉ,nn
           JP PO, nn
E28405
          JP Z,nn
CA8405
382E
                              Jump Relative to PC+e if
           JR C,e
302E
          JR NC,e
                              Condition True
202E
           JR NZ,e
282E
           JR Z,e
                              Unconditional Jump Relative to PC+e
182E
           JR e
02
           LD (BC),A
                              Load Source to Destination
12
77
              (DE),A
           LD
           LD
              (HL),A
70
          LD (HL),B
              (HL),C
(HL),D
71
           LD
72
           LD
              (HL),E
73
           LD
74
           LD
              (HL),H
75
           LD
              (HL),L
3620
              (HL),n
(IX+d),A
           LD
DD7705
           LD
DD7005
           LD
              (IX+d),B
DD7105
          LD
              (IX+d),C
DD7205
DD7305
              (IX+d),D
           LD
              (IX+d), E
           LD
              (IX+d),H
DD7405
           LD
DD7505
           LD
              (IX+d),L
DD360520 LD
              (IX+d),n
FD7705
           LD
              (IY+d),A
FD7005
           LD
              (IY+d),B
FD7105
           LD
              (IY+d),C
FD7205
              (IY+d),D
           LD
FD7305
FD7405
              (IY+d),E
           LD
              (IY+d),H
           LD
              (IY+d),L
FD7505
           LD
FD360520 LD
              (IY+d),n
              (nn),A
328405
           LD
ED438405 LD
              (nn), BC
ED538405 LD
              (nn),DE
228405
              (nn),HL
           LD
DD228405 LD
              (nn), IX
FD228405
          LD
              (nn), IY
          LD (nn),SP
LD A,(BC)
ED738405
          LD
0A
          LD A, (DE)
LD A, (HL)
LD A, (IX+d)
LD A, (IY+d)
1A
7E
DD7E05
FD7E05
3A8405
           LD A, (nn)
7F
           LD A,A
          LD A,B
78
79
           LD A,C
7A
          LD A,D
7в
           LD A,E
7C
           LD A,H
          LD A,I
ED57
7D
           LD A,L
          LD A,n
3E20
          LD A,R
ED5F
          LD B,(HL)
LD B,(IX+d)
LD B,(IY+d)
46
DD4605
FD4605
47
           LD B,A
40
           LD B,B
41
           LD B,C
42
           LD B,D
43
           LD B,E
44
           LD B,H
```

```
45
            LD B,L
0620
           LD B,n
ED4B8405 LD BC,(nn)
018405 LD BC,nn
           LD C, (HL)
4E
           LD C, (IX+d)
LD C, (IY+d)
DD4E05
FD4E05
           LD C,A
LD C,B
4F
48
49
            LD C,C
4A
           LD C,D
LD C,E
4B
4C
           LD C,H
4D
           LD C,L
0E20
            LD C,n
           LD D,(HL)
LD D,(IX+d)
LD D,(IY+d)
56
DD5605
FD5605
            LD D,A
57
50
           LD D,B
51
52
           LD D,C
            LD D,D
           LD D,E
53
54
            LD D,H
55
           LD D,L
            LD D,n
1620
ED5B8405 LD DÉ,(nn)
118405
           LD DE, nn
           LD E,(HL)
LD E,(IX+d)
LD E,(IY+d)
5E
DD5E05
FD5E05
5F
            LD E,A
58
            LD E,B
59
           LD E,C
           LD E,D
LD E,E
5A
5в
5C
           LD E,H
5D
            LD E,L
1E20
           LD E,n
           LD H, (HL)
LD H, (IX+d)
66
DD6605
FD6605
            LD H, (IY+d)
67
           LD H,A
60
            LD H,B
61
            LD H,C
62
           LD H,D
63
            LD H,E
64
           LD H,H
65
            LD H,L
2620
           LD H,n
2A8405
            LD HL, (nn)
218405
           LD HL, nn
           LD I,A
ED47
DD2A8405 LD IX, (nn)
DD218405 LD IX,nn
FD2A8405 LD IY, (nn)
FD218405 LD IY, nn
6E LD L, (HL)
DD6E05 LD L, (IX+d)
FD6E05
            LD L,(IY+d)
           LD L,A
6F
68
            LD L,B
69
            LD L,C
6A
           LD L,D
6в
            LD L,E
6C
           LD L,H
6D
            LD L,L
2E20
           LD L,n
           LD R,A
ED4F
ED7B8405 LD SP, (nn)
```

F9 DDF9 FDF9 318405	LD SP,HL LD SP,IX LD SP,IY LD SP,nn	
EDA8	LDD	Load Location (DE) with Location (HL) Decrement DE, HL and BC
EDB8	LDDR	Load Location (DE) with Location (HL) Repeat until BC = 0
EDA0	LDI	Load Location (DE) with Location (HL) Increment DE, HL, Decrement BC
EDB0	LDIR	Load Location (DE) with Location (HL) Increment DE, HL, Decrement BC and Repeat until BC = 0
ED44	NEG	Negate Acc. (2's Complement)
00	NOP	No Operation
B6 DDB605 FDB605 B7 B0 B1 B2 B3 B4 B5 F620	OR (HL) OR (IX+d) OR (IY+d) OR A OR B OR C OR D OR E OR H OR L OR n	Logical "OR" of Operand and Acc.
EDBB	OTDR	Load Output Port (C) with Location (HL) Decrement HL and B, Repeat until B=0
EDB3	OTIR	Load Output Port (C) with Location (HL), Increment HL, Decrement B, Repeat until B=0
ED79 ED41 ED49 ED51 ED59 ED61 ED69	OUT (C),A OUT (C),B OUT (C),C OUT (C),D OUT (C),E OUT (C),H OUT (C),L	Load Output Port (C) with Reg.
D320	OUT (n),A	Load Output Port (n) with Acc.
EDAB	OUTD	Load Output Port (C) with Location (HL). Decrement HL and B
EDA3	OUTI	Load Output Port (C) with Location (HL). Increment HL and Decrement B
F1 C1 D1 E1 DDE1 FDE1	POP AF POP BC POP DE POP HL POP IX POP IY	Load Destination with Top of Stack

```
F5
           PUSH AF
                               Load Source to Stack
C5
           PUSH BC
D5
           PUSH DE
E5
           PUSH HL
DDE5
           PUSH IX
           PUSH IY
FDE5
CB86 RES 0,(HL)
DDCB0586 RES 0,(IX+d)
                               Reset Bit b of Operand
FDCB0586 RES 0, (IY+d)
           RES 0,A
RES 0,B
CB87
CB80
           RES 0,C
CB81
           RES 0,D
CB82
           RES 0,E
CB83
CB84
           RES 0,H
           RES 0,L
CB85
           RES 1,(HL)
CB8E
DDCB058E RES 1,(IX+d)
FDCB058E RES 1,(IY+d)
           RES 1,A
CB8F
CB88
           RES 1,B
           RES 1,C
CB89
           RES 1,D
CB8A
СВ8В
           RES 1,E
CB8C
           RES
                1,H
           RES 1,L
CB8D
CB96
           RES 2, (HL)
DDCB0596 RES 2,(Ix+d)
FDCB0596 RES 2,(IY+d)
CB97 RES 2,A
           RES 2,B
RES 2,C
СВ90
CB91
           RES 2,D
RES 2,E
RES 2,H
CB92
CB93
CB94
           RES 2,L
CB95
CB9E
           RES 3,(HL)
DDCB059E RES 3,(Ix+d)
FDCB059E RES 3,(IY+d)
CB9F
           RES 3,A
           RES 3,B
CB98
CB99
           RES 3,C
           RES 3,D
RES 3,E
СВ9А
св9в
           RES 3,H
св9с
           RES 3,L
CB9D
CBA6 RES 4,(HL)
DDCB05A6 RES 4,(IX+d)
FDCB05A6 RES 4,(IY+d)
CBA7
           RES 4,A
           RES 4,B
CBA0
           RES 4,C
CBA1
CBA2
           RES 4,D
           RES 4,E
CBA3
CBA4
           RES 4,H
           RES 4,L
CBA5
CBAE RES 5, (HL)
DDCB05AE RES 5, (IX+d)
FDCB05AE RES 5, (IY+d)
           RES 5,A
CBAF
CBA8
           RES 5,B
               5,C
CBA9
           RES
           RES 5,D
CBAA
CBAB
           RES 5,E
           RES 5,H
CBAC
           RES 5,L
CBAD
           RES 6,(HL)
CBB6
DDCB05B6 RES 6,(IX+d)
FDCB05B6 RES 6, (IY+d)
```

```
CBB7
          RES 6,A
CBB0
          RES 6,B
          RES 6,C
CBB1
          RES 6,D
CBB2
          RES 6,E
CBB3
CBB4
          RES 6,H
          RES 6,L
CBB5
CBBE RES 7,(HL)
DDCB05BE RES 7,(IX+d)
FDCB05BE RES 7, (IY+d)
          RES 7,A
RES 7,B
RES 7,C
CBBF
CBB8
CBB9
          RES 7,D
CBBA
CBBB
          RES 7,E
          RES 7,H
CBBC
          RES 7,L
CBBD
                              Return from Subroutine
C9
          RET
                              Return from Subroutine if Condition True
D8
          RET C
          RET M
F8
          RET NC
D<sub>0</sub>
C0
          RET NZ
F0
          RET P
          RET PE
RET PO
E8
E0
C8
          RET Z
ED4D
          RETI
                              Return from Interrupt
                              Return from Non
ED45
          RETN
                              Maskable Interrupt
CB16 RL (HL)
DDCB0516 RL (IX+d)
                              Rotate Left Through Carry
FDCB0516 RL (IY+d)
CB17
          RL A
CB10
          RL B
CB11
          RL C
CB12
          RL D
CB13
          RL E
CB14
          RL H
CB15
          RL L
17
          RLA
                              Rotate Left Acc. Through Carry
CB06
                              Rotate Left Circular
          RLC (HL)
DDCB0506 RLC (IX+d)
FDCB0506 RLC (IY+d)
CB07
          RLC A
CB00
          RLC B
CB01
          RLC C
CB02
          RLC
               D
CB03
          RLC E
CB04
          RLC H
          RLC L
CB05
                              Rotate Left Circular Acc.
07
          RLCA
ED6F
                              Rotate Digit Left and Right
          RLD
                              between Acc. and Location (HL)
CB1E
          RR (HL)
                              Rotate Right Through Carry
DDCB051E RR (IX+d)
FDCB051E RR (IY+d)
          RR A
CB1F
CB18
          RR B
CB19
          RR C
CB1A
          RR D
```

```
CB1B
           RR E
CB1C
           RR H
CB<sub>1</sub>D
           RR L
                               Rotate Right Acc. Through Carry
1F
           RRA
           RRC (HL)
RRC (IX+d)
RRC (IY+d)
CB0E
                               Rotate Right Circular
DDCB050E
FDCB050E
CB0F
           RRC A
CB08
           RRC B
CB09
           RRC C
           RRC D
CB0A
СВ0В
           RRC E
CB0C
           RRC H
CB0D
           RRC L
0F
                               Rotate Right Circular Acc.
           RRCA
ED67
           RRD
                               Rotate Digit Right and Left
                               Between Acc. and Location (HL)
c7
           RST 00H
                               Restart to Location
CF
           RST 08H
D7
           RST 10H
           RST 18H
RST 20H
DF
E7
EF
           RST 28H
F7
           RST 30H
FF
           RST 38H
           SBC A, n
SBC A, (HL)
DE20
                               Subtract Operand
9E
                               from Acc. with Carry
           SBC A, (IX+d)
SBC A, (IY+d)
SBC A,A
SBC A,B
DD9E05
FD9E05
9F
98
99
           SBC A,C
           SBC A,E
SBC A,H
9A
9в
9c
9D
           SBC A,L
ED42
           SBC HL,BC
           SBC HL, DE
SBC HL, HL
ED52
ED62
           SBC HL,SP
ED72
37
           SCF
                               Set Carry Flag (C=1)
CBC6 SET 0,(HL)
DDCB05C6 SET 0,(IX+d)
                               Set Bit b of Location
FDCB05C6 SET 0, (IY+d)
           SET 0,A
SET 0,B
CBC7
CBC0
           SET 0,C
CBC1
CBC2
           SET 0,D
           SET 0,E
CBC3
           SET 0,H
CBC4
           SET 0,L
CBC5
           SET 1,(HL)
CBCE
DDCB05CE SET 1,(IX+d)
FDCB05CE SET 1, (IY+d)
CBCF SET 1,A
CBC8
           SET 1,B
CBC9
           SET 1,C
CBCA
           SET 1,D
           SET 1,E
SET 1,H
CBCB
CBCC
           SET 1,L
CBCD
           SET 2,(HL)
CBD6
```

```
DDCB05D6 SET 2, (Ix+d)
FDCB05D6 SET 2,(IX+d)
FDCB05D6 SET 2,(IY+d)
CBD7 SET 2,A
CBD0 SET 2,B
              SET 2,6
SET 2,C
SET 2,D
SET 2,E
SET 2,H
SET 2,L
CBD1
CBD2
CBD3
CBD4
CBD5
              SET 3,B
CBD8
CBDE SET 3,(HL)
DDCB05DE SET 3,(IX+d)
FDCB05DE SET 3,(IY+d)
              SET 3,A
CBDF
              SET 3,C
CBD9
              SET 3,E
SET 3,E
SET 3,H
CBDA
CBDB
CBDC
              SET 3,L
CBDD
CBE6 SET 4,(HL)
DDCB05E6 SET 4,(IX+d)
FDCB05E6 SET 4,(IY+d)
              SET 4,A
CBE7
              SET 4,B
CBE0
CBE1
              SET 4,C
              SET 4,D
CBE2
              SET 4,E
CBE3
CBE4
              SET 4,H
              SET 4,L
CBE5
CBEE SET 5, (HL)
DDCB05EE SET 5, (IX+d)
DDCB05EE SET 5,(IY+d)
CBEF SET 5,A
              SET 5,B
SET 5,C
SET 5,D
CBE8
CBE9
CBEA
              SET 5,E
CBEB
              SET 5,H
CBEC
CBED SET 5,L
CBF6 SET 6,(HL)
DDCB05F6 SET 6,(IX+d)
FDCB05F6 SET 6,(IY+d)
              SET 6,A
CBF7
              SET 6,B
SET 6,C
CBF0
CBF1
              SET 6,D
CBF2
              SET 6,E
CBF3
CBF4 SET 6,H
CBF5 SET 6,L
CBFE SET 7,(HL)
DDCB05FE SET 7,(IX+d)
FDCB05FE SET 7,(IY+d)
              SET 7,A
SET 7,B
SET 7,C
CBFF
CBF8
CBF9
              SET 7,D
CBFA
              SET 7,E
SET 7,H
SET 7,L
CBFB
CBFC
CBFD
                                        Shift Operand Left Arithmetic
CB26
              SLA (HL)
DDCB0526 SLA (IX+d
FDCB0526 SLA (IY+d)
CB27
              SLA À
CB20
              SLA B
CB21
              SLA C
CB22
              SLA D
CB23
              SLA E
CB24
              SLA H
CB25
              SLA L
```

```
CB2E
                    SRA (HL)
         DDCB052E SRA (IX+d)
FDCB052E SRA (IY+d)
         CB2F
                    SRA A
         CB28
                    SRA B
         CB29
                    SRA C
         CB2A
                    SRA D
         CB2B
CB2C
                    SRA E
                    SRA H
         CB2D
                    SRA L
         CB3E SRL (HL)
DDCB053E SRL (IX+d)
                                       Shift Operand Right Logical
         FDCB053E SRL (IY+d)
         CB3F
                    SRL A
         CB38
                    SRL B
         CB39
                    SRL C
         СВ3А
                    SRL D
         СВ3В
                    SRL E
         CB3C
                    SRL H
         CB3D
                    SRL L
                    SUB (HL)
SUB (IX+d)
                                       Subtract Operand from Acc.
         96
         DD9605
         FD9605
                    SUB (IY+d)
         97
                    SUB A
         90
                    SUB B
         91
                    SUB C
         92
                    SUB D
         93
                    SUB E
         94
                    SUB H
         95
                    SUB L
         D620
                    SUB n
                    XOR (HL)
XOR (IX+d)
                                       Exclusive "OR" Operand and Acc.
         ΑE
         DDAE05
         FDAE05
                    XOR (IY+d)
         AF
                    XOR A
         Α8
                    XOR B
         Α9
                    XOR C
                    XOR D
         AA
         AΒ
                    XOR E
         AC
                    XOR H
         AD
                    XOR L
         EE20
                    XOR n
Example Values
                    584H
         EQU
         EQU
                    5
                    20H
         EQU
                    30H
```

Note that ZSID accepts an address instead of a byte value in the jmp relative commands.

nn

d

n

e