Diode Cheat Sheet

Rafael Marinho

General Constants

electron charge:
$$q=1.6\times 10^{-19}$$

$$\mu_n\approx 1350\,cm^2/(V\cdot s)$$
 Boltzmann's constant: $k=1.38\times 10^{-23}$
$$\mu_p\approx 480\,cm^2/(V\cdot s)$$

$$\mu_n \approx 1350 \, cm^2 / (V \cdot s)$$


 $\mu_p \approx 480 \, cm^2 / (V \cdot s)$

$$D_n \approx 34 \, cm^2/s$$

 $D_p \approx 12 \, cm^2/s$

PN Junction

General semiconductor equations



Semiconductor type		
	p-type	n-type
electron density	$n \approx N_D$	$n \approx \frac{n_i^2}{N_A}$
hole density	$p \approx \frac{n_i^2}{N_D}$	$p \approx N_A$

$$I_{diff,tot} = Aq(\mu_n n + \mu_p p) \cdot E$$

$$I_{drift,tot} = Aq\left(D_n \frac{dn}{dx} - D_p \frac{dp}{dx}\right)$$

if thermal equilibrium:
$$\left\{ \begin{array}{lcl} |I_{drift,n}| &= i & |I_{diff,n}| \\ \\ |I_{drift,p}| &= & |I_{diff,p}| \end{array} \right.$$

General values

$$\begin{array}{ll} e^- \; {\rm density} \; ({\rm Si}) & n_i = 5.2 \times 10^{15} \cdot T^{3/2} \exp \left[\frac{-Eg}{2kT} \right] \\ e^- \; {\rm density} \; @ \; 300 {\rm K} & n_i \approx 10^{10} \\ \\ {\rm thermal} \; {\rm voltage} & V_T = \frac{kT}{q} = \frac{D}{\mu} \\ \\ {\rm internal} \; {\rm voltage} & |V_0| = -\frac{kT}{q} \ln \left[\frac{N_A N_D}{n_i^2} \right] \\ \\ {\rm Saturation} \; {\rm Current} & I_S = Aqn_i^2 \left[\frac{D_n}{N_A L_n} + \frac{D_p}{N_D L_p} \right] \\ \\ {\rm Forward} \; {\rm Current} & I_D = I_S \exp \left[\left(\frac{V_D}{V_T} \right) - 1 \right] \end{array}$$

Diode Modeling

Exponential model

$$I_D = I_S \exp\left(\frac{V_D}{\eta V_T}\right)$$

Small-signal model

