## Documentation


# ContaminationFlow on Linux and Windows

Hoai My Van, Rudolf Schönmann

# **Contents**

| 1. | Gen  | erai Structure                        | 1               |
|----|------|---------------------------------------|-----------------|
| 2. | Con  | taminationFlow Linux                  | 2               |
|    | 2.1. | Call of Application from Command line | 3               |
|    | 2.2. | Communication                         | 4               |
|    | 2.3. | Usage of boost Library                | 4               |
|    | 2.4. | New Quantities                        | 5               |
|    | 2.5. | Iterative Algorithm                   | 6               |
|    |      | 2.5.1. Initialization of simulation   | 6               |
|    |      | 2.5.2. Simulation on subprocesses     | 7               |
|    | 2.6. | Update main buffer                    | 9               |
|    | 2.7. | Summary                               | 10              |
| 3. | Con  | taminationFlow Windows                | 12              |
|    | 3.1. | Graphical User Interface              | 12              |
|    | 3.2. | -                                     | 12              |
|    | 3.3. | New Quantities                        | 12              |
|    |      |                                       | 13              |
| Α. | Forn | nulas for new Quantities              | 14              |
| В. | Data | atypes                                | 16              |
|    |      | · ·                                   | 16              |
|    | B.2. | Functions                             | 16              |
| c  | Ovo  | rview of new Classes and Functions    | 17              |
| C. |      |                                       | 17              |
|    |      |                                       | 20              |
|    | O.Z. | C.2.1. molflowlinux_main.cpp          | 20              |
|    |      | 11                                    | $\frac{20}{21}$ |
|    |      | Tr Tr                                 | 21              |
|    |      | 1 1                                   | 21              |
|    |      | Tr Tr                                 | 21<br>22        |
|    |      | C.2.6. UpdateSubProcess.cpp           |                 |
|    |      |                                       | 23              |
|    |      | 0.2.1. Optimizatili 100c55.0pp        | ചാ              |

# 1. General Structure



General structure for ContaminationFlow simulation

- ullet Code adapted from Molflow
- $\bullet$  Contamination Flow Windows primary used to create Geometry and to view simulation results through the  ${\rm GUI}$
- ContaminationFlow Linux primary used for simulation and calculation of counters, profiles, etc.
- Loadbuffer contains information of geometry
- Hitbuffer contains information such as hit counters, profiles, etc.
- Import and export of buffer files for communication between ContaminationFlow Windows and ContaminationFlow Linux
- Export of simulationHistory for ContaminationFlow Linux

# 2. ContaminationFlow Linux

- Parallel simulation on several sub processes
- Processing and control of data in main process
- Update and accumulation of hit counters and other information such as profiles
- SimulationHistory, final hitbuffer and used parameters exported to results folder




Figure 2.1.: Processing of data in main and sub processes

## 2.1. Call of Application from Command line

#### New class ProblemDef

- Defines parameters used for simulation
- Possible adaptation of default paramaters through input file
- Creates result folder for simulation if desired
  - Final resultbuffer
  - Final covering, input file and console output as text files

## Application with custom parameters using input file

Call of ContaminationFlow Linux application in the command line:

```
$ module load mpi
$ mpirun -n N MolflowLinux inputfile save
```

with the following command line parameters:

- N: desired number of worker processes; simulation on K=N-1 worker processes
- MolflowLinux: path to application, e.g. ~/MolflowLinux/Debug/MolflowLinux
- inputfile: path to file that defines simulation parameters
- save: determines whether result directory is created (1: true, 0:false); default: 1 and the input file defining the following parameters:
  - loadbufferPath: path to loadbuffer file, contains geometry, e.g. ~/loadbuffer
  - hitbufferPath: path to hitbuffer file, contains counters, etc., e.g. ~/hitbuffer
  - simulationTime: simulation time per iteration step; default: 10.0
  - unit: simulation time unit; default: s
  - maxTime: maximum simulation time; default: 10.0
  - maxUnit: maximum simulation time unit; default: y
  - *iterationNumber*: number of iterations; default: 43200
  - particleDia: diameter of particles; default: 2.76E-12
  - $E_{de}$ : binding energy of a particle on pure substrate; default: 1E-21
  - $H_{vap}$ : vaporization enthalpy of a particle in case of multilayer contamination; default: 0.8E-19
  - $W_{tr}$ : transition width between monolayer and multilayer properties; default: 1
  - *sticking*: constant sticking coefficient for all facets, set to zero, not used at the moment; default: 0
  - targetPaticles: minimum number of desorbed particles per iter.; default: 1000
  - targetError: average statistical uncertainty (error) to be achieved for each iteration, calculated as the average (weighted with the facets area) of the normalized standard deviation of events per facet; default: 0.001
  - hitRatioLimit: Ratio at which hits are ignored, default: 0
  - Tmin or  $t\_min$ : minimum time for step size; default: 1E-4
  - maxStepSize or t\_max: maximum time for step size; default: max
  - maxSimPerIt: maximum simulation steps per iteration; default: max
  - coveringMinThresh: minimum covering (through multiplication); default: 10000

- histsize: Size of history lists; default: max
- *vipFacets*: very important facets: facets with have their own target error. input in inputfile as alternating sequence of facet numbers and respective target errors separated via blanks; default: []

## **Terminology**

- Simulation time: desired computation time until check if target is reached for iteration
- Simulated time: physical time in the simulated system, e.g. flight time or residence time of a particle
- Maximum simulation time: desired total simulated time
- Step size: desired simulated time per particle for iteration

## 2.2. Communication

## Import and export of buffer files

• New Databuff struct that replaces Dataport struct from MolFlow Windows

```
typedef unsigned char BYTE;
typedef struct {
   signed int size;
   BYTE *buff;
} Databuff;
```

- New functions <code>importBuff(·)</code> and <code>exportBuff(·)</code> for import of buffer files and export of Databuff struct
- New functions checkReadable(·) and checkWriteable(·) to check if file is readable or writeable

## Communication between worker processes via MPI

- Main process 0 sends Databuff struct containing loadbuffer and Databuff struct containing hitbuffer and required simulationHistory values to sub processes using MPI\_Bcast(·)
- Sub processes send updated Databuff struct containing hitbuffer and required simulationHistory values to main process 0 using MPI\_Send(·) and MPI\_Recv(·)

## 2.3. Usage of boost Library

## Multiprecision

- Increase precision for variables if required
- Avoid overflow for integer and underflow for floating point numbers

## 2.4. New Quantities

## New counter covering

- Number of carbon equivalent particles on facet
- Increases with adsorption, decreases with desorption
- Extracted from new hitbuffer counter from Simulationcalc.cpp file in getCovering(·)

## Coverage

- Number of monolayers of adsorbed particles
- Calculated from covering, particle diamieter (previously gas mass) and facet area
- Coverage computed from Simulationcalc.cpp file in calcCoverage(·)

## Sticking factor

- Ratio adsorbed particles to impinging particles
- Set to 0, can be adapted for all facets through input file

## Binding energy

- Either  $E_{de}$  or  $H_{vap}$
- Depending on the how many layers of particles are adsorbed.
- If coverage is smaller than a monolayer, it will be decided at random.

## Desorption

- Number of particles desorbing
- Calculated from binding energy, covering, temperature and step size
- Desorption computed from Simulationcalc.cpp file in calcDesorption(·)

#### Outgassing

- Number of particles from outgassing
- Calculated from facet outgassing, temperature, and outgassing time
- Outgassing computed from Worker.cpp file in CalcTotalOutgassingWorker()

## $K_{\rm real/virtual}$

- Number of real particles represented by test particles
- Calculated from desorption & outgassing and number of desorbed molecules
- $K_{\text{real/virtual}}$  computed from Simulationcalc.cpp file in GetMoleculesPerTP( $\cdot$ )

### **Statistical Error**

- Event error: calculated from hits and desorbed particles (of facet and total)
- Covering error: calculated from adsorbed and desorbed particles (of facet and total)
- Used to determine significance of simulation results of iteration

### Step size

- Minimum time between adsorption and desorption
- Step size computed from UpdateMainProcess.cpp file in getStepSize()

## **Particle Density**

- $\bullet$  Calculated from sum over reciprocal of orthogonal velocity, facet area and  $K_{\rm real/virtual}$
- Particle density computed from Simulationcalc.cpp file in calcParticleDensity(·)

#### **Pressure**

- Calculated from sum over orthogonal velocity, facet area, gas mass and  $K_{\rm real/virtual}$
- Pressure computed from Simulationcalc.cpp file in calcPressure(·)

#### Start time

- Determines time of desorption/outgassing for particle based on the distribution
- Desorption rate: exponential distribution for whole iteration
- Outgassing: uniform distribution of limited time for whole simulation
- Start time computed from Simulationcalc.cpp file in calcStartTime(·)

## 2.5. Iterative Algorithm

## 2.5.1. Initialization of simulation




Figure 2.2.: Overview: Initialize simulation

#### New class to store Simulation History

• SimulationHistory class

```
template <typename T> class HistoryList {
public:
    HistoryList();
    pair<vector<double>,vector<vector<T>>> historyList;
    vector<T> currentList;
};
```

```
class SimulationHistory {
public:
   SimulationHistory();
   SimulationHistory(Databuff *hitbuffer);

HistoryList<llong> coveringList;
HistoryList<double> hitList;
HistoryList<double> hitList;
HistoryList<double> errorList_event;
HistoryList<double> errorList_covering;
HistoryList<double> particleDensityList;
HistoryList<double> pressureList;

double lastTime;
int currentStep;
};
```

- In SimulationLinux.h and SimulationLinux.cpp file
- Updated after each iteration in UpdateParticleDensityAndPressure(·), UpdateCovering(·), UpdateErrorMain(·) from UpdateMainProcess.cpp file
- Recorded quantities: covering, error (event and covering), particle density and pressure for each facet and iteration, total hits and desorbed particles for each facet
- lastTime: simulated time (accumulated time steps) instead of computation time

## 2.5.2. Simulation on subprocesses

#### **Calculate Step Size**

- Use simHistory—currentStep to calculate logarithmic step size
- Calculation in UpdateMainProcess.cpp file in getStepSize()

## **Calculate Covering Threshold**

- Set lower threshold for covering for each facet to prevent covering getting negative
- Stop simulation once threshold is reached
- Threshold set in setCoveringThreshold(·) from Iteration.cpp file

### Multiply small covering

- Multiply covering so that smallest covering  $\geq$  ProblemDef::coveringThreshMin
- Multiply covering threshold with same factor
- Calculation in checkSmallCovering(·) from SimulationLinux.cpp file

#### Calculate desorption

- Desorption calculated from current covering values
- Calculation in UpdateDesorption(·) from UpdateSubProcess.cpp file




Figure 2.3.: Overview: simulation on sub processes

## **Create Particle**

- Facet randomly selected based on total desorption and outgassing
- Desorption or outgassing randomly selected based on ratio on facet
- Start time randomly generated based on distribution of desorption or outgassing
- Calculation in StartFromSource(·) from SimulationMC.cpp file

#### Calculate residence time

- Sojourn time randomly calculated from binding energy, facet temperature and sojourn frequency
- Calculation in PerformBounce(·) from SimulationMC.cpp file

## Target error reached?

- Calculate statistical error in UpdateError() from UpdateSubProcess.cpp file
- Total error calculated from summing facet error weighted with facet area
- Error to check can be either covering or event error (currently covering)
  - Check if vip facets reached their own target error
  - Check if total error reached target error
- Facets with error=inf are not considered
  - Facets that reached ProblemDef::hitRatioLimit
  - Facets with no events or covering change
  - If vip facet: own target error automatically reached
  - If normal facet: facet error and area not used for calculation
- Check in checkErrorSub(·) from UpdateSubProcess.cpp file

## 2.6. Update main buffer




Figure 2.4.: Overview: update of covering in hitbuffer

## Before summation of subprocesses

- Calculate step size in UpdateMainProcess.cpp file in getStepSize() depending on, if the target error was reached
- Multiply covering in hitbuffer of main process in checkSmallCovering(·) from SimulationLinux.cpp file if covering is multiplied in sub processes

#### **Error Calculation**

- Calculate statistical error per facet and total error analogous to calculation in subprocesses
- Save error per facet in simHistory—errorList
- $\bullet \ \ {\tt Management\ in} \ \ {\tt UpdateErrorMain(\cdot)} \ \ {\tt from} \ \ {\tt UpdateMainProcess.cpp} \ \ {\tt file}$ 
  - ⇒ Increase simHistory→currentStep if target errors reached

## **Calculate & Update Covering**

- ullet  $K_{
  m real/virtual}$  computed from Simulationcalc.cpp file in GetMoleculesPerTP(ullet)
- Divide covering in hitbuffer if previously multiplied
- Use  $K_{\text{real/virtual}}$  to calculate new covering
- Save new covering in simHistory—coveringList and hitbuffer
- Calculation in UpdateCovering(·) from UpdateMainProcess.cpp file
- Update buffers in UpdateCoveringPhys(·) from UpdateMainProcess.cpp file

## Calculate & Update Statistics

- Calculate mean and standard deviation of quantity over last p→rollingWindowSize iterations
- Update statistics in HistoryList::updateStatistics(·) from SimulationLinux.h file

## 2.7. Summary




Figure 2.5.: Overview: ContaminationFlow application

## **General Pipeline**

- Initialize MPI, ProblemDef p and SimulationHistory simHistory
- Load geometry into Simulation sHandle using LoadSimulation()
- Iteration until desired maximum simulation time is reached:
  - Reset hitbuffer counters using initbufftotero(·)
  - Broadcast simHistory→coveringList using MPI\_Bcast(⋅)
  - Set covering threshold covthresh using setCoveringThreshold(·)
  - Update simulation values using simHistory→updateStepSize(·),
     UpdateSticking(·), UpdateDesorption(·), CalcTotalOutgassingWorker(·)
  - Multiply covering and covthresh with simHistory—smallCoveringFactor if covering is small
  - Simulation in sub processes
    - Simulate until targetParticles and targetError or covthresh reached
    - Update hitbuffers of sub processes from sHandle using UpdateSubHits(·)
       from UpdateSubProcess.cpp
  - Update Main process:
    - Send hitbuffer to main process using MPI\_Send(·) and MPI\_Recv(·)
    - Update of hitbuffer in UpdateMainHits(·) from UpdateMainProcess.cpp
  - Update error of iteration using UpdateErrorMain(·) from UpdateMainProcess.cpp
  - Calculate real covering in main process using  $K_{\text{real/virtual}}$  in UpdateCovering(·) from UpdateMainProcess.cpp, save in simHistory
  - Update real covering in hitbuffer of main process in UpdateCoveringphys(·) from UpdateMainProcess.cpp
  - Update statistics using simHistory—coveringList.updateStatistics(·)
- Export final results (hitbuffer and simulationHistory) to results folder
- Close MPI

# 3. ContaminationFlow Windows

• Create Geometry and set parameters such as initial coverage and temperature

## 3.1. Graphical User Interface

Add screenshot of GUI

#### **New GUI elements**

- "Particles out" renamed to Contamination level
  - Text field for covering
  - Text field for coverage
- New facet properties
  - Effective surface factor
  - Facet depth and facet volume
  - Diffusion coefficient
  - Concentration and gas mass
- Window for CoveringHistory (reworked to SimulationHistory in ContaminationFlow Linux)
- PressureEvolution window expanded
  - Added list that contains information of graph
  - Option to show only selected facets or all
  - List exportable

## 3.2. Communication

## Import and export of buffer files via GUI

• New Databuff struct

```
typedef unsigned char BYTE;
typedef struct
  signed int size;
  BYTE *buff;
Databuff;
```

- New functions importBuff(·) and exportBuff(·) for import and export of buffer files/Databuff struct
- New options in file menu: Export buffer and Import buffer

## 3.3. New Quantities

## New counter covering

• Covering computed in SimulationMC.cpp file in updatecovering(·)

- Added covering counter to hitbuffer
- Added covering to GUI, can be defined through textfield

## New facet property effetiveSurfaceFactor

• Defines increase of facet area due to texture

## New facet property facetDepth

• Defines depth of facet

## New facet property diffusionCoefficient

• Defines diffusion coefficient

## New facet property concentration

• Defines concentration = mass of particles in volume

## Removal of irrelevant quantities

- Sticking factor and pumping speed removed from GUI
- calcSticking() and calcFlow() in Molflow.cpp file not used anymore
- Flow not needed for iterative Algorithm

## 3.4. Iterative algorithm

## New class to store covering for all facets at any time

- In HistoryWin.cpp and HistoryWin.h file
- std::vector<std::pair<double,std::vector<double>>> pointintime\_list to store points in time and respective covering for all facets
- New GUI option to add and remove entries for pointintime\_list
- New GUI option to export or import a complete list

# A. Formulas for new Quantities

**Constants** 

$$k_b = 1.38 \, 10^{-23}$$
  
 $h = 6.626 \, 10^{-34}$  (A.1)  
 $N_A = 6 \, 10^{23}$ 

**Variables** 

$$T = \text{Facet temperature}$$
 (A.2)

Number of carbon equivalent particles of one monolayer

$$N_{mono} = \frac{\text{Area of Facet } [\text{m}^2]}{\text{ProblemDef::particleDia}^2 [\text{m}^2]}$$
(A.3)

Carbon equivalent relative mass factor

$$\Delta N_{surf} = \frac{\text{carbon equivalent gas mass}}{12.011} \tag{A.4}$$

Covering  $\theta^*$ 

$$\theta^* = N_{\text{particles on facet}}$$
 (A.5)

Coverage  $\theta$ 

$$\theta = \frac{\theta^*}{N_{mono}/\Delta N_{surf}} \tag{A.6}$$

Binding Energy E

$$E = \begin{cases} E_{de}, & \text{if particle binds with substrate} \\ H_{vap}, & \text{if particle binds with adsorbate} \end{cases}$$
 (A.7)

Residence Time  $\tau$ 

$$A = \exp\left(-E/(k_b T)\right), \ \tau_0 = \frac{k_b T}{h}$$

$$\tau = \frac{-\ln(rnd) \cdot \tau_0}{A}$$
(A.8)

Step Size  $t_{step}$ 

 $t_{min} = \text{ProblemDef::t\_min}$ 

 $t_i = t_{min} \cdot \exp\left(i \cdot \ln(\text{ProblemDef::maxTimeS}/T_{min})/\text{ProblemDef::iterationNumber}\right)$ 

$$t_{step} = \min(t_{currentStep+1} - t_{currentStep}, \text{ProblemDef::t\_max})$$
(A.9)

### **Desorption** des

$$\tau_0 = \frac{h}{k_b T}, \ \tau_{subst} = \tau_0 \cdot \exp\left(\frac{E_{de}}{k_b T}\right), \ \tau_{ads} = \tau_0 \cdot \exp\left(\frac{H_{vap}}{k_b T}\right), \ t_{ads} = \tau_{ads} \cdot (\theta - 1)$$

$$des = \begin{cases} 0, & \text{if } \theta = 0 \text{ or } T = 0 \\ \theta \cdot (1 - \exp(-t_{step}/\tau)), & \text{else if } \theta \le 1 \\ t_{step}/\tau_{ads}, & \text{else if } \theta - 1 \ge t_{step}/\tau_{ads} \\ \theta - 1 + (1 - \exp(-(t_{step} - t_{ads}/\tau))), & \text{else if } \theta - 1 < t_{step}/\tau_{ads} \end{cases}$$
(A.10)

## **Outgassing** out

$$out = \frac{\text{Facet outgassing}}{k_b T} \tag{A.11}$$

## **Particle Density**

$$density = \frac{\text{sum over reciprocal of orthogonal velocity}}{\text{Area of Facet } [\text{m}^2] \cdot t_{step}} \cdot K_{\text{real/virtual}}$$
(A.12)

## Pressure [mbar]

$$density = \frac{\text{sum over orthogonal velocity}}{\text{Area of Facet } [\text{m}^2] \cdot t_{step}} \cdot \frac{\text{carbon equivalent gas mass}}{1000/N_A} \cdot 0.01 \cdot K_{\text{real/virtual}}$$
(A.13)

## Small covering factor

mincov = Smallest covering on a single facet that desorbs

 $small\ covering\ factor = \begin{cases} 1, & \text{if}\ mincov \geq ProblemDef::coveringMinThresh} \\ 1 + 1.1 \cdot (ProblemDef::coveringMinThresh/mincov), & \text{otherwise} \end{cases}$  (A.14)

 $K_{\text{real/virtual}}$ 

$$K_{\text{real/virtual}} = \frac{\sum_{\text{facets}} \left( out + des \right)}{\text{number of total desorbed molecules/small covering factor}}$$
(A.15)

#### **Error**

$$\operatorname{error}(counter) = \begin{cases} inf & \text{if } (counter) \text{ on facet } = 0 \\ \left(\frac{1}{(counter) \text{ on facet}} \cdot \frac{1 - (counter) \text{ on facet}}{\operatorname{total}(counter)}\right)^{0.5} & \text{, else} \end{cases}$$
(A.16)

error\_covering = error(adsorbed particles + desorbed particles)
error\_event = error(hits + desorbed particles)

# **B.** Datatypes

# **B.1. Class Members**

| Name                            | Datatype                         | Alias    |
|---------------------------------|----------------------------------|----------|
| SimulationHistory::coveringList | boost::multiprecision::uint_128t | covBoost |
| FacetHitBuffer::covering        | llong                            | covLlong |
| FacetProperties::desorption     | boost::multiprecision::float128  | desBoost |
| Simulation::coveringThreshold   | llong                            |          |

# **B.2. Functions**

| Function              | Output Datatype                          | Relevant Input |
|-----------------------|--|----------------|
| getCovering()         | boost::multiprecision::float128          | covBoost       |
| getCovering()         | llong                                    | covLlong       |
| calcCoverage()        | boost::multiprecision::float128 or llong | getCovering()  |
| calcDesorption()      | boost::multiprecision::float128          | calcCoverage() |
| calctotalDesorption() | boost::multiprecision::float128          | desBoost       |
| GetMoleculesPerTP()   | boost::multiprecision::float128          | desBoost       |

# C. Overview of new Classes and Functions

# C.1. New Classes

| HistoryList        |   |  |
|--------------------|---|--|
| historyList        | list containing history respective facet values             |  |
| currentList        | list containing facet values at current step                |  |
| statisticsList     | list containing facet statistics over last iterations       |  |
| currIt             | current iteration number                                    |  |
| reset()            | Resets lists  |  |
| initCurrent()      | Initializes size of currentList                             |  |
| initStatistics()   | Initializes size of statisticsList                          |  |
| initList()         | Initializes size of historyList                             |  |
| appendCurrent()    | Appends currentList to historyList                          |  |
| appendList()       | Append input list to historyList                            |  |
| updateStatistics() | Calculates statistics and save to statisticsList            |  |
| convertTime()      | Converts time for better clarity                            |  |
| print()            | Print historyList to terminal, optinal message              |  |
| printCurrent()     | Print currentList as table to terminal, optional message    |  |
| printStatistics()  | Print statisticsList as table to terminal, optional message |  |
| write()            | Write historyList to file                                   |  |
| erase()            | delete desired point in historyList                         |  |
| empty()            | Checks if historyList is empty                              |  |
| setCurrent()       | Set value of desired facet in currentList                   |  |
| getCurrent()       | Get value of desired facet in currentList                   |  |
| setLast()          | Set value of desired facet from historyList                 |  |
| getLast()          | Get value of desired facet from historyList                 |  |

| SimulationHistory   |  |  |
|---------------------|--|--|
| coveringList        | of class HistoryList, stores covering history                  |  |
| errorList_event     | of class HistoryList, stores error history for events          |  |
| errorList_covering  | of class HistoryList, stores error history for covering        |  |
| hitList             | of class HistoryList, stores hits for each facet               |  |
| desorbedList        | of class HistoryList, stores desorbed particles for each facet |  |
| particleDensityList | of class HistoryList, stores particle density for each facet   |  |
| pressureList        | of class HistoryList, stores pressure for each facet           |  |
| numFacet            | number of Facets   |  |
| numSubProcess       | number of sub processes used for simulation                    |  |
| flightTime          | Simulated flight time for iteration                            |  |
| nParticles          | Simulated particles for iteration                              |  |
| lastTime            | Total simulated time = last time in Lists                      |  |
| currentStep         | step of logarithmic time step calculation in getStepSize()     |  |
| stepSize            | current step size  |  |
| stepSize_outgassing | current step size of outgassing impulse                        |  |
| updateHistory()     | Reset and update   |  |
| updateStepSize()    | Calculate stepSize and stepSize_outgassing                     |  |
| appendList()        | Updates coveringList   |  |
| erase()             | Erases desired point in history                                |  |
| print()             | Print to terminal  |  |
| write()             | Write to file  |  |

| ProblemDef  |  |  |
|---|--|--|
| resultpath  | Path of result folder  |  |
| outFile   | Path of file that contains terminal output                       |  |
| loadbufferPath  | Path of loadbuffer file  |  |
| hitbufferPath   | Path of hitbuffer file   |  |
| $simulationTime$ , unit $\Rightarrow$ simulationTimeMS                                | Computation time of each iteration in milliseconds               |  |
| $\begin{array}{c} \text{maxTime, maxUnit} \\ \Rightarrow \text{maxTimeS} \end{array}$ | Maximal total simulated time in seconds                          |  |
| iterationNumber   | Number of iterations of simulation                               |  |
| particleDia   | Diameter of particles  |  |
| E_de, H_vap   | Parameters to calculate binding energy, see eq. A.7              |  |
| sticking  | Sticking factor for all facets                                   |  |
| targetParticles/-Error  | Target values for each iteration                                 |  |
| hitRatioLimit   | threshold of hitratio at which hits are ignored                  |  |
| coveringMinThresh   | Minimum covering, multiplication to this if covering low         |  |
| t_min, t_max  | Minimum/ Maximum step size                                       |  |
| maxSimPerIt   | Maximun simulation steps per iteration                           |  |
| histSize  | Size of history lists (most recent values in memory)             |  |
| vipFacets   | alterning: vip facet and target error, e.g. 1 0.001 3 0.002      |  |
| outgassingTimeWindow  | Duration of outgassing impulse                                   |  |
| counterWindowPercent  | Percentage of step size at which velocity counters are increased |  |
| desWindowPercent  | Percentage of step size at which desorption occurs               |  |
| rollingWindowSize   | Number of iterations over which statistics are calculated        |  |
| createOutput()  | Create output directory and file                                 |  |
| readInputfile()   | Initialization from input file                                   |  |
| printInputfile()  | Print to terminal  |  |
| writeInputfile()  | Write to terminal  |  |

# C.2. New Functions

# C.2.1. molflowlinux\_main.cpp

| Preprocessing        |  |  |
|----------------------|--|--|
| parametercheck()     | Checks validity of input parameters from input file Defines values for ProblemDef object p |  |
| importBuff()         | Import load- and hitbuffer to main process   |  |
| MPLBcast()           | Send loadbuffer to sub processes   |  |
| LoadSimulation()     | Load geometry from loadbuffer  |  |
| initCoveringThresh() | Initialize covering threshold  |  |
| UpdateSojourn()      | Enable sojourn time for each facet   |  |
| simHistory           | Initialize SimulationHistory object  |  |

|  | Simulation Loop  |  |
|--|--|--|
| initbufftozero()                                     | Reset all hitbuffer counters except covering                             |  |
| MPI_Bcast()  | Send simHistory—coveringList and simHistory—currentStep to sub processes |  |
| setCoveringThreshold()                               | Sets covering threshold for each facet                                   |  |
| updateStepSize()                                     | Calculates step sizes for desorption and outgassing                      |  |
| UpdateDesorption()                                   | Sets desorption for each facet, ends simulation if 0                     |  |
| CalcTotalOutgassingWorker()                          | Calculates total outgassing for iteration                                |  |
| checkSmallCovering()                                 | multiplies covering to reach threshold if necessary                      |  |
| simulateSub()  | Simulation on sub processes  |  |
| MPI_Send(), MPI_Recv()                               | Send sub hitbuffer to main process                                       |  |
| UpdateMCMainHits()                                   | Add simulation results to main hitbuffer                                 |  |
| UpdateParticleDensityAndPressure()                   | Calculate and save particle density and pressure                         |  |
| UpdateErrorMain()                                    | Calculate and save error of iteration to simHistory                      |  |
| UpdateCovering()                                     | Calculate and save new covering to simHistory                            |  |
| UpdateCoveringphys()                                 | Saves current covering to hitbuffer                                      |  |
| simHistory→erase()                                   | Adapt historyList size of to p→histSize                                  |  |
| updateStatistics()                                   | Statistics over p→rollingWindowSize iterations                           |  |
| End simulation if maximum simulation time is reached |  |  |

| Postprocessing     |                           |
|--------------------|---------------------------|
| exportBuff()       | Export final hitbuffer    |
| simHistory→write() | Export simulation history |

## C.2.2. SimulationLinux.cpp

|   | simulateSub()   |
|---|---|
| <pre>simHistory-&gt;updateHistory()</pre> | Update SimulationHistory object from sHandle  |
| smallCoveringFactor                       | If covering is small: Covering is multiplied by smallCoveringFactor to be able to have statistics without overflow of the covering variable |
| targetParticles, targetError              | Calculate target values from overall target and number sub processes  |
| SimulationRun()                           | Simulate for desired simulation time  |
| UpdateError()                             | Calculate current error of sub process  |
| CheckErrorSub()                           | Checks if total error reached targetError and if vip facets reached own target  |
| UpdateMCSubHits()                         | Save simulation results to hitbuffer  |

| Small covering       |  |  |
|----------------------|--|--|
| CheckSmallCovering() | If covering is small, find smallCoveringFactor to reach $p\rightarrow coveringMinThresh$ |  |
| Undo multiplication  | In UpdateCovering()  |  |

| Others        |   |
|---------------|---|
| get_path()    | Get path of executable                  |
| printStream() | Print input string to terminal and file |

## C.2.3. Iteration.cpp

| Set Covering Threshold to avoid negative covering |   |
|---|---|
| initCoveringThresh()                              | Initializes size of covering threshold vector |
| setCoveringThreshold()                            | Sets covering threshold for each facet        |

## C.2.4. Buffer.cpp

| Buffer functions  |  |
|-------------------|--|
| Databuff struct() | signed int size<br>BYTE *buff                        |
| checkReadable()   | Checks if file can be opened for reading             |
| checkWriteable()  | Checks if file can be openend or created for writing |
| importBuff()      | Imports buffer file to Databuff struct               |
| exportBuff()      | Exports Databuff struct to buffer file               |

# C.2.5. Calculations in SimulationCalc.cpp etc.

| SimulationCalc.cpp     |  |
|------------------------|--|
| getCovering()          | Get covering from hitbuffer or simHistory  |
| getHits()              | Get number of hits from hitbuffer  |
| getnbDesorbed()        | Get number of total desorbed<br>molecules from hitbuffer                         |
| getnbAdsorbed()        | Get number of total adsorbed molecules from hitbuffer                            |
| calcNmono()            | see eq. A.3  |
| calcdNsurf()           | see eq. A.4  |
| calcCoverage()         | see eq. A.6  |
| calcStickingnew()      | sets sticking coefficient to p—sticking  |
| calcDesorption()       | see eq. A.10   |
| GetMoleculesPerTP()    | see eq. A.15   |
| calctotalDesorption    | calculates desorption for startFromSource()                                      |
| calcOutgassingFactor() | Calculate factor to determine outgassing particles                               |
| calcPressure()         | see eq. A.13   |
| calcParticleDensity()  | see eq. A.12   |
| calcStartTime()        | Calculate start time of particle depending on desorption/outgassing distribution |

| worker.cpp                          |   |
|-------------------------------------|---|
| ${\bf CalcTotalOutgassingWorker()}$ | see eq. A.11, calculate outgassing distribution |
|                                     | for startFromSource()                           |

| SimulationLinux.cpp |  |
|---------------------|--|
| convertunit()       | Converts simutime $\cdot$ unit to milliseconds |

# C.2.6. UpdateSubProcess.cpp

| Update sHandle paramters from hitbuffer |                                      |
|---|--------------------------------------|
| UpdateSticking()                        | Update sticking                      |
| UpdateDesorption()                      | Update desorption                    |
| UpdateSojourn()                         | Enable residence time for all facets |

| Error calculations |  |  |
|--------------------|--|--|
| UpdateErrorSub()   | Calculates error per facet, see eq. A.16 Saves to simHistory                       |  |
| UpdateErrorAll()   | Sums up total error of facets & weights by facet area for all possible error types |  |
| UpdateError()      | Returns total error of desired error type  |  |
| CheckErrorSub()    | Checks if total error and vip facet error reached target                           |  |

| Update hitbuffer  |  |
|-------------------|--|
| initbufftozero()  | Sets hitbuffer except covering to zero               |
| UpdateMCSubHits() | Saves simulation results from sHandle into hitbuffer |

# C.2.7. UpdateMainProcess.cpp

| Update main hitbuffer from sub hitbuffer |   |
|--|---|
| UpdateMCMainHits()                       | Add simulation results from sub hitbuffer to main hitbuffer |

| Update real covering in hitbuffer  |   |  |
|------------------------------------|---|--|
| getStepSize()                      | Calculates step size for current step, see eq. A.9  |  |
| UpdateCovering()                   | Uses Krealvirt to calculate new covering Saved to simHistory→coveringList   |  |
| UpdateCoveringphys()               | Saves current real covering to hitbuffer  |  |
| UpdateErrorMain()                  | Calculates total error for each facet, see eq. A.16 Saves to simHistory—errorList_event and simHistory—errorList_covering |  |
| UpdateParticleDensityAndPressure() | Calculate pressure and particle density, see eq. A.12, A.13   |  |
| CalcPerIteration()                 | Calculates total error (covering and event) and covering over all facets per iteration                                    |  |