Lecture Title

PRAESIDIUM PRAESIDIUM

Course Code: 0052

Course Title: Computer Organization and Architecture

Dept. of Computer Science Faculty of Science and Technology

| Lecturer No: | 10 | Week No: | 10 | Semester: | |
|--------------|----|----------|----|-----------|--|
| Lecturer: | | | | | |

Overview: ROTATE



- Rotates work like the shifts, except that when a bit Is shifted out one end of an operand it is **put back in the other end**.
- These instructions can be used to **examine** and/or **change bits or groups of bits**.
- *** Logic, shift, and rotate instructions is used to do binary and hexadecimal I/O.
- The ability to read and write numbers will let us solve a great variety of problem.

Example SHR




- ➤ **Problem:** Suppose DH contains 8Ah and CL contains 2. What are the values of DH and CF after the Instruction SHR DH,CL is executed?
- > **Solution:** The value of DH in binary is 10001010.
- ➤ After two right shifts, CF=1
- The new value of DH is obtained by **erasing the rightmost two bits** and adding two 0 bits to the left end, thus DH =00100010b

 = 22h.





- The SAR Instruction (shift arithmetic right) operates like SHR, with one difference: the **msb retains Its original value**. The syntax is:
- SAR destination,1
- > SAR destination, CL



Division by Right Shift



- > A Left shift doubles the destination's value,
- Similarly, it's reasonable to guess that a right shift might divide it by
 This Is correct for even numbers.
- For odd numbers, a right shift halves it and rounds down to the nearest integer.
- For example, if BL contains 00000101 = 5, then after a right shift. BL will contain 00000010 = 2

Signed and Unsigned Division



- In case of division by right shifts, we need to make a distinction between signed and unsigned numbers.
- If an **unsigned** interpretation is being given, **SHR** should be used.
- For a **signed** interpretation, **SAR** must be used, because it preserves the sign.
- ➤ **Problem:** Use right shifts to divide the unsigned number 65143 by 4. Put the quotient in AX
- To divide by 4, two right shifts are needed. Since the dividend is unsigned, we use SHR. The code is
 - MOV AX, 65143
 - MOV CL2
 - SHR AX,2

SAR




- Example: If AL contains -15, give the decimal value of AL after SAR AL,1 is performed.
- Solution: Execution of SAR AL,1 divides the number by 2 and rounds down.
 - ➤ Dividing -15 by 2 yields -7.5, and after rounding down we get -8.
 - ➤ In terms of the binary contents, we have -15=11110001b. After shifting, we have 11111000b= -8.

*** We will see some MUL and DIV for multiplication operations that are not limited to power of 2 only. However, MUL and DIV is much slower than SHIFT operation

Rotate Instructions




- The instruction ROL (rotate left) shifts bits to the left. The msb shifted into the rightmost bit.
- The CF also gets the bit shifted out of the msb.
- You can think of the destination bits forming a circle, with the least significant bit following the msb in the circle.
- > ROL destination, 1
- and
- ROL destination, CL



Rotate Right (ROR)



- The instruction ROR (rotate right) works just like ROL except that the bits are rotated to the right.
- > The rightmost bit is shifted into the msb, and also into the CF
- > ROR destination, 1
- and
- ROR destination, CL



ROL, ROR and CF



- In ROL and ROR, CF reflects the bit that is rotated out.
- ROL and ROR can be used to inspect the bits in a byte or word, without changing the contents.
- Example: Use ROL to count the number of 1 bits in BX, without changing BX. Put the answer in AX.
- > Solution:

XOR AX,AX MOV CX,16

> TOP:

ROL BX,1
JNC NEXT

INC AX


> NEXT:

LOOP TOP

RCL (Rotate Carry Left)




- The Instruction RCL (Rotate through Carry LEFT) shifts the bits of the destination to the left.
- The msb is shifted Into the CF and the previous value of CF is shifted Into the rightmost bit.
- In other words, RCL works like Just like ROL, except that CF is part of the circle of bits being rotated. The syntax is:
- RCL destination,1
- and
- RCL destination, CL







- The Instruction RCR (Rotate through Carry RIGHT) works just like RCL except the bits are rotated to the right. The syntax is:
- > RCR destination,1
- and
- RCR destination, CL







- Suppose DH contains 8Ah, CF= 1, and CL contains 3.
- What are the values of DH and CF after the instruction RCR DH,CL is executed?

Solution:

| | CF | DH |
|----------------------------|----|----------------|
| initial values . | 1 | 10001010 |
| after 1 right rotation | 0 | 11000101 |
| after 2 right rotations | 1 | 01100010 |
| after 3 right rotations | 0 | 10110001 = B1h |

Effect of the rotate instructions on the flags

```
SF, PF, ZF reflect the result

AF is undefined

CF = last bit shifted out

OF = 1 if result changes sign on the last rotation
```





- Expectation: If AL contains 11011100, we want to make it 00111011
- Use SHL to shift the bits out the left end of AL Into CF.
- Then use RCR to move them Into the left end of another register (i.e. BL)
- Run the above operation 8 times for 8 bits

```
MOV CX,8 ; number of operations to do
REVERSE:

SHL AL,1 ; get a bit into CF
RCR BL,1 ; rotate it into BL
LOOP REVERSE ; loop until done
MOV AL,BL ; AL gets reversed pattern
```

Binary and Hex Input & Output



- ➤ **Binary Input:** Lets assume a program reads In a binary number from the keyboard, followed by a carriage return. [i.e. string of 0's and 1's]
- Conversion in bit value needs to be done as soon as the input character is entered.
- > After that collect the bits in register.
- To read a binary number from keyboard and store it in BX:

```
Clear BX /* BX will hold binary value */
Input a character /* '0' or '1' */
WHILE character <> CR DO

Convert character to binary value
Left shift BX
Insert value into 1sb of BX
Input a character
END_WHILE
```

Example: Process Input 110



```
Clear BX
  BX = 0000 0000 0000 0000
Input character '1', convert to 1
Left shift BX
  BX = 0000.0000 0000 0000
Insert value into 1sb
  BX = 0000 0000 0000 0001
Input character '1', convert to 1
Left shift BX
  BX = 0000 0000 0000 0010
Insert value into 1sb
  BX = 0000 0000 0000 0011
Input character '0' ;- convert' to 0
Left shift BX
 BX - 0000 0000 0000 0110
Insert value into 1sb
 BX = 0000 0000 0000 0110
BX contains 110b.
```

Assembly Conversion for input processing (110)



```
XOR BX,BX ;clear BX
MOV AH,1 ;input char function
INT 21H ;read a character

WHILE:

CMP AL,ODH ;CR?

JE END_WHILE;yes, done
AND AL,OFH ;no, convert to binary value
SHL BX,1 ;make room for new value
OR BL,AL ;put value into EX
INT 21H ;read a character
JMP WHILE ;loop back

END WHILE:
```

Binary Output



- Outputting the contents of BX in binary also involves the shift operation.
- Algorithm for Binary output:

```
FOR 16 times DO

Rotate left BX /* BX holds output value,

put msb into CF */

IF CF = 1

THEN

output '1'

ELSE

output '0'

END_IF,

END_FOR
```

Write an assembly code to process the Binary output for this problem.

Hex Input



- ➤ Hex input consists of digits ("0" to "9") and letters ("A" to "F") followed by a carriage return.
- For simplicity, we will assume that
- Only uppercase letters are used, and
- The user inputs no more than four hex characters.
- The process of converting characters to binary values is more Involved than it was for binary input, and BX must be **shifted four times** to make room for a hex value.

Algorithm for hex input



```
Clear BX /* BX will hold input value */
input hex character
WHILE character <> CR DO
 convert character to binary value
 left shift BX 4 times
 insert value into lower 4 bits of BX
 input a character
END WHILE
```





Clear BX BX = 0000 0000 0000 0000 Input '6', convert to 0110 Left shift BX 4 times BX = 0000 0000 0000 0000 Insert value into lower 4 bits of BX BX = 0000 0000 0000 0110Input 'A', convert to Ah = 1010 Left shift BX 4 times BX = 0000 0000 0110 0000 Insert value into lower 4 bits of BX BX = 0000 0000 0110 1010Input 'B', convert to 1011 Left shift BX 4 times BX - 0000 0110 1010 0000 Insert value into lower 4 bits of BX BX = 0000 0110 1010 1011 BX contains 06ABh.



Assembly Code for Processing 6AB

```
XOR BX, BX ; clear BX
              MOV CL,4 ; counter for 4 shifts
              MOV AH,1 ;input character function
                  21H
                         ;input a character
              INT
WHILE :
              CMP AL, ODH
                            ; CR?
              JE
                  END WHILE ; yes, exit
; convert character to binary value
              CMP AL, 39H ;a digit?
              JG
                  LETTER. ; no, a letter
; input is a digit
                  AL, OFH ; convert digit to binary value
              AND
                          ;go to insert in BX
              JMP SHIFT
LETTER:
              SUB AL, 37H ; convert letter to binary value
SHIFT:
                            ; make room for new value
              SHL BX, CL
;insert value into BX
                            ; put value into low 4 bits
                  BL, AL
              CR
                            of BX .
                            ;input a character
                  21H
              INT
                  WHILE
                           ;loop until CR
              JMP
END WHILE:
```

Algorithm for Hex Output



```
FOR 4 times DO
  Move BH to DL /* BX holds output value */
  shift DL 4 times to the right
  IF DL < 10
   THEN
  -convert to character in '0' .. '9'.
  ELSE
  convert to character in 'A' .. 'F'
 END 'IF
 output character
 Rotate BX left 4 times
END FOR
```

Conversion of 4CA9h to Binary



```
BX - '4CA9h' - 0100 1100 1010 1001
Move BH to DL
  DL = 0100 1100
Shift DL 4 times to the right
  DL = 0000 0100
Convert to character and output
 DL = '0011 0100 = 34h = '4'
Rotate BX left.4 times
  BX = 1100 1010 1001 0100
Move BH to DL
- DL = 1100 1010
Shift DL 4 times to the right
  DL = 0000 1100
Convert to character and output
  DL = 0100 0011 = 43h = 'C'
Rotate BX left 4 times
  BX = 1010 1001 0100 1100
Move BH to DL .
DL = 1010 - 1001
Shift DL 4 times to the right
 DL - 0000 1010
Convert, to character and output
 DL = 0100 0010 = 42h = 'B'
Rotate BX left 4 times
 BX = 1001 0100 1100 1010
Move BH to DL
 DL = 1001 0100
Shift DL 4 times to the right
  DL - 0000 1001
Convert to character and output
  DL = 0011 1001 - 39h - '9'
Rotate BX 4 times to the left
  BX = 0100 1100 1010 1001 = original contents
```

Write an assembly code to process the Binary output for this problem.

References



- Assembly Language Programming and Organization of the IBM PC, Ytha Yu and Charles Marut, McGraw Hill, 1992. (ISBN: 0-07-072692-2).
- http://faculty.cs.niu.edu/~byrnes/csci360/notes/360shift.htm

Books



- Assembly Language Programming and Organization of the IBM PC, Ytha Yu and Charles Marut, McGraw Hill, 1992. (ISBN: 0-07-072692-2).
- Essentials of Computer Organization and Architecture, (Third Edition), Linda Null and Julia Lobur
- W. Stallings, "Computer Organization and Architecture: Designing for performance", 67h Edition, Prentice Hall of India, 2003, ISBN 81 – 203 – 2962 – 7
- Computer Organization and Architecture by John P. Haynes.