

Computer Architecture 2023-24 (WBCS010-05)

Lecture 6: The LC-3

Reza Hassanpour r.zare.hassanpour@rug.nl



Instruction (Recap)

- > A computer **instruction** is a binary value that specifies one operation to be carried out by the hardware.
- > Instruction is the **fundamental unit of work**. Once an instruction begins, it will complete its job.
- > Two components of an instruction:
- opcode specifies the operation to be performed (for example: ADD)
- operands specify the data to be used during the operation
- > The set of instructions and their formats is called the **Instruction Set Architecture (ISA)** of a computer



LC-3 Instruction (Recap)

- LC-3 has a four-bit opcode, bits [15:12] -- up to 16 different operations
- LC-3 has eight CPU registers. Registers are used as operands for instructions -- each operand requires 3 bits to specify which register
- > **Example:** ADD instruction, opcode = 0001

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	AI	DD		I	Ost	-	S	rc	1	0	0	0	S	rc	2
4.5	a .a	4.0	4.0	4.4	4.0	_		_		_	4			4	
15	14	13	12	11	10	9_	8	7	6	5	4	3	2		
0	0	0	1	1	1	0	0	1	0	0	0	0	1	1	0

"Add the contents of R2 (010) to the contents of R6 (110), and store the result in R6 (110)."



Types of Instructions (Recap)

 Instructions are classified into different types, depending on what sort of operation is specified

Operate

- > Will perform some sort of data transformation
- > Examples: add, AND, NOT, multiply, shift, ...

> Data Movement

- > Move data from memory to a register in the CPU, or
- Move data from a register to a memory location

> Control

> Determine the next instruction to be executed



Control Instructions

- > Changes the PC to redirect program execution
- > Conditional Branch: BR
- > Unconditional Branch: JMP
- > Subroutines and System Calls:
 - JSR, JSRR, TRAP, RET, RTI (Discussed in Chapters 8 and 9)



Condition Codes

- > LC-3 has three condition code registers
 - N = negative (less than zero)
 - \rightarrow Z = zero
 - > P = positive (greater than zero)
- > Set by instructions that compute or load a value into a register
- > ADD, AND, NOT, LD, LDI, LDR
- Based on <u>result</u> of computation or load. Other instructions <u>do</u> <u>not</u> change the condition codes.
- > Exactly one of these will be set (1). Others will be zero.



Instruction Type 1 Operate Instructions



Operate Instructions

ADD

- > Add two integers and write the result to a register
- > Set condition codes

AND

- > Perform a bitwise AND operation on two integers, and write the result to a register
- > Set condition codes

NOT

- > Perform a bitwise NOT on an integer, and write the result to a register
- > Set condition codes

LEA

> Add an offset to the PC and write the result to a register



Addressing Modes

Register

- > First operand is always specified by a register
- > Second operand is a register if IR[5] = 0


Immediate

> **If IR[5] = 1**, the second operand is specified in the instruction IR[4:0] is a 5-bit 2's complement integer, sign-extended to 16 bits


Q: what are the min and max values that fit in IR[4:0]?



ADD/AND (Register mode) this zero means "register mode"




Sets condition codes





ADD/AND (Immediate mode) this one means "immediate mode"






NOT (Register mode)



Sets condition codes






Only ADD, AND, and NOT?


- > It might seem very limiting to only provide these three operations, but anything else can be built from these
- Negate -- Flip bits with NOT, then ADD +1
- Subtract -- Negate and ADD
- Multiply -- Repeated additions
- OR -- Use DeMorgan's Law (see Chapter 2)
- Clear -- AND with o to set register to zero
- Copy -- ADD o (zero) to copy from one register (src) to another (dst)
- Others: XOR, divide, shift left, increment, ...



LEA (not 100% operate)

 Computes an address by adding sign-extended IR[8:0] to PC, and write the result to a register (Does not set condition codes)







Instruction Type 2 Data Movement Instructions



Data Movement Instructions: Load and Store

- > Used to move data between memory and registers.
- LOAD = from memory to register (and sets condition codes)
- > STORE = from register to memory
- > Three variants of each, with different addressing modes:

PC-Relative	Compute address by adding an offset IR[8:0] to the PC
Indirect	Load an address from a memory location
Base+Offset	Compute address by adding an offset IR[5:0] to a register


PC-Relative Addressing Mode

- > Wants to specify address directly in the instruction.
- But an address is 16 bits, and so is an instruction!
- After subtracting 4 bits for opcode and 3 bits for register, we have <u>9 bits</u> available for address.
- > Solution: Use the 9 bits as a *signed offset* from the current PC.
- > Can form any address X, such that: $PC 256 \le X \le PC + 255$
- Remember that PC is incremented as part of the FETCH phase;
- > This is done <u>before</u> the EVALUATE ADDRESS stage.

So the range is -255 ... +256 locations relative to the LD/ST. Do you see it?




LD (PC-Relative mode)





ST (PC-Relative mode)






Indirect Addressing Mode

- > With PC-relative mode, can only address data within 256 words of the instruction. What about the rest of memory?
- Solution #1: Read address from a memory location, then load/store to that address
- (1) Compute PC + IR[8:0] (just like PC-Relative), put in MAR
- (2)Load from that address into MDR
- (3) Move data from MDR into MAR
- (4)Perform load/store




LDI (Indirect mode)





STI (Indirect mode)






Base + Offset Addressing Mode

- > With PC-relative mode, can only address data within 256 words of the instruction. What about the rest of memory?
- Solution #2: Use a register to generate a full 16-bit address
- 4 bits for opcode, 3 for src/dest register,
 3 bits for *base* register -- the one to be used as an address.
- Remaining 6 bits are used as a <u>signed offset</u>.
- Offset is *sign-extended* before adding to base register. Offset is often zero, but a non-zero offset can be useful at times.




LDR (Base + Offset mode)





STR (Base + Offset mode)





Example using Load/Store Addressing Modes

Address	Instruction													Comments					
x 30 F 6	1	1	1	0	0	0	1	1	1	1	1	1	1	1	0	1	$R1 \leftarrow PC - 3 = x30F4$	LEA	
x 30 F 7	0	0	0	1	0	1	0	0	0	1	1	0	1	1	1	0	R2 ← R1 + 14 = x3102	ADD	
x 30F8	0	0	1	1	0	1	0	1	1	1	1	1	1	0	1	1	$M[PC - 5] \leftarrow R2$ $M[x30F4] \leftarrow x3102$	ST	
x 30 F 9	0	1	0	1	0	1	0	0	1	0	1	0	0	0	0	0	R2 ← 0	AND	
x30FA	0	0	0	1	0	1	0	0	1	0	1	0	0	1	0	1	$R2 \leftarrow R2 + 5 = 5$	ADD	
x30FB	0	1	1	1	0	1	0	0	0	1	0	0	1	1	1	0	$M[R1+14] \leftarrow R2$ $M[x3102] \leftarrow 5$	STR	
x30FC	1	0	1	0	0	1	1	1	1	1	1	1	0	1	1	1	$R3 \leftarrow M[M[x30F4]]$ $R3 \leftarrow M[x3102]$ $R3 \leftarrow 5$	LDI	

opcode



Instruction Type 3 Control Instructions





Conditional Branch (BR)

- > BR specifies two things:
- Condition -if true, branch is taken (PC changed to target address)
 if false, branch is not taken (PC not changed)
- Target address
- Condition specifies which condition code bits are relevant for this branch
 If any specified bit is set, branch is taken.
 - Example: BRn = branch if N bit is set
 Example: BRnp = branch if N or P bit is set
- > Target is specified using PC-Relative mode



BR





Logic: (IR[11] and N) or (IR[10] and Z) or (IR[9] and P)



Example BR instruction

> Suppose the following instruction is fetched from address x4027

Copyright © McGraw-Hill Education. Permission required for reproduction or display.

- Condition: zBranch will be taken if Z bit is set
- \rightarrow Target: x4028 + x00D9 = x4101
- Current PC is x4028, because it was incremented when fetching
 If branch is taken PC will be x4101
 If branch is not taken PC will remain x4028




R3 <- R3 + R4

Increment R1
Decrement R2

Example: Loop with a Counter

Compute the sum of 12 integers stored in x3100 - x310B
 Instructions begin at address x3000




> R2 counts down from 12. Branch out of the loop when R2 becomes zero



Increment R1 R4 <- M[R1]

Example: Loop with Sentinel

> Compute the sum of integers starting at x3100, until a negative integer is found. Instructions start at x3000




> In this case, it's the data that tells when to exit the loop. When the value loaded into R4 is negative, take branch to x3008



Unconditional Branch (JMP)

- > We can create a branch that is always taken by setting n, z, and p to 1
- > However, the target address of BR is limited by the 9-bit PC offset
- > The JMP instruction provides an unconditional branch to any target location by using the contents of a register as the target address. It simply copies the register into the PC







Input/Output Instructions



TRAP: Invoke a System Service Routine

The TRAP instruction is used to give control to the operating system to perform a task that user code is not allowed to do. The details will be explained in Chapter 9

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TRAP	1	1	1	1	0	0	0	0		t:	raj	ρV∈	ect	:8		

For now, you just need to know that bits [7:0] hold a "trap vector"
 -- a unique code that specifies the service routine. The service routines used in this part of the course are:

trapvector	service routine
x23	Input a character from the keyboard
X21	Output a character to the monitor
x25	Halt the processor



Input / Output Service Routines

- > Getting character input from the keyboard
- TRAP x23 is used to invoke the keyboard input service routine.
- When the OS returns control to our program, the **ASCII code** for the key pressed by the user will be **in Ro**.

- Sending character output to the monitor
- TRAP x21 is used to invoke the monitor output service routine.
- Before invoking the routine, put the ASCII character to be output into Ro.



Example Program: Count Occurrences of a Character


- > We want to count the number of times a user-specified character appears in a text file, and then print the count to the monitor
- The text file is stored in memory as a sequence of ASCII characters
- The end of the file is denoted with the EOT* character (x04). NOTE: We do not know how many characters are in the file; EOT is the sentinel value that signals when we are done
- A pointer to the file will be stored at the end of the program. (A "pointer" is a memory address; it will be the address of the first character in the file)
- We will assume that the character will appear no more than 9 times
- Program instructions will start at x3000. The file data can be anywhere in memory

* End Of Transmission



Part 1: Initializing Registers






Copyright @ McGraw-Hill Education, Permission required for reproduction or display.

Co	pyrig	ght ©	McG	raw-	HIII E	duca	tior	1. P	erm	ISSI	on r	equ			rep	oroc	luction or display.
Address	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
x3000	0	1	0	1	0	1	0	0	1	0	1	0	0	0	0	0	R2 <- 0
x3001	0	0	1	0	0	1	1	0	0	0	0	1	0	0	0	0	R3 <- M[x3012]
x3002	1	1	1	1	0	0	0	0	0	0	1	0	0	0	1	1	TRAP x23
x3003	0	1	1	0	0	0	1	0	1	1	0	0	0	0	0	0	R1 <- M[R3]
x3004	0	0	0	1	1	0	0	0	0	1	1	1	1	1	0	0	R4 <- R1-4
x3005	0	0	0	0	0	1	0	0	0	0	0	0	1	0	0	0	BRz x300E
x3006	1	0	0	1	0	0	1	0	0	1	1	1	1	1	1	1	R1 <- NOT R1
x3007	0	0	0	1	0	0	1	0	0	1	1	0	0	0	0	1	R1 <- R1 + 1
x3008	0	0	0	1	0	0	1	0	0	1	0	0	0	0	0	0	R1 <- R1 + R0
x3009	0	0	0	0	1	0	1	0	0	0	0	0	0	0	0	1	BRnp x300B
x300A	0	0	0	1	0	1	0	0	1	0	1	0	0	0	0	1	R2 <- R2 + 1
x300B	0	0	0	1	0	1	1	0	1	1	1	0	0	0	0	1	R3 <- R3 + 1
x300C	0	1	1	0	0	0	1	0	1	1	0	0	0	0	0	0	R1 <- M[R3]
x300D	0	0	0	0	1	1	1	1	1	1	1	1	0	1	1	0	BRnzp x3004
x300E	0	0	1	0	0	0	0	0	0	0	0	0	0	1	0	0	RO <- M[x3013]
x300F	0	0	0	1	0	0	0	0	0	0	0	0	0	0	1	0	R0 <- R0 + R2
x3010	1	1	1	1	0	0	0	0	0	0	1	0	0	0	0	1	TRAP x21
x3011	1	1	1	1	0	0	0	0	0	0	1	0	0	1	0	1	TRAP x25
x3012					Start	ing	adc	lres	ss o	f fi	le						
x3013	0	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0	ASCII TEMPLATE

R2 is counter. R3 is address of first character to read from file. Ro is character from keyboard. R1 is first character from file.




Part 2: Read Characters and Count



Compare character to immediate xo4 (EOT in ASCII). If equal, exit loop. Otherwise, count if matches user input and read the next character.



Part 3: Output Count and HALT



When loop is finished, convert count (R2) to the corresponding ASCII character by adding 'o' (x30). Output the character and halt the program



Questions?