C335 Computer Structures

Introduction to MIPS Assembly Languages

Dr. Liqiang Zhang

Department of Computer and Information Sciences

Adapted from Morgan Kaufmann and others

Review: Instruction Set Architecture

- Basic job of a CPU: execute lots of *instructions*.
- Instructions are the primitive operations that the CPU may execute.
- □ Different CPUs implement different sets of instructions. The set of instructions a particular CPU implements is an *Instruction Set Architecture* (*ISA*).
 - Examples: Intel x86, Apple/IBM/Motorola PowerPC (Macintosh), ARM, MIPS, Intel IA64, ...

MIPS Architecture

 MIPS (Microprocessor without Interlocked Pipeline Stages) – semiconductor company that built one of the first commercial RISC architectures



- Why MIPS instead of Intel 80x86?
 - MIPS is simple, elegant. Don't want to get bogged down in gritty details.
 - MIPS widely used in embedded apps, x86 little used in embedded, and more embedded computers than PCs





Most HP LaserJet workgroup printers are driven by MIPS-based™ 64-bit processors.

India

Assembly Variables: Registers (1/4)



- Unlike HLL like C or Java, assembly cannot use variables
 - Why not?
 - Keep Hardware Simple
- Assembly Operands are <u>registers</u>
 - limited number of special locations built directly into the CPU hardware
 - Arithmetic/logical operations can only be performed on these!
- Benefit: Since registers are directly in CPU hardware, they are very fast (faster than 1 billionth of a second)

Assembly Variables: Registers (2/4)



- Drawback: Since registers are in CPU, there are a predetermined number of them
 - Solution: MIPS code must be very carefully put together to efficiently use registers
- 32 registers in MIPS, Why only 32?
 - Smaller is faster
- Each MIPS register is 32 bits wide
 - Groups of 32 bits called a word in MIPS

Assembly Variables: Registers (3/4)

- Registers are numbered from 0 to 31
- Each register can be referred to by number or name
- Number references:

```
$0, $1, $2, ... $30, $31
```

Assembly Variables: Registers (4/4)

- By convention, each register also has a name to make it easier to code
- □ For now:

(correspond to temporary variables)

Later will explain other 16 register names

□ In general, use names to make your code more readable

C variables vs. registers



- In C (and most High Level Languages) variables declared first and given a type
 - Example:

```
int fahr, celsius;
char a, b, c, d, e;
```

- Each variable can ONLY represent a value of the type it was declared as.
- In Assembly Language, the registers have no type; operation determines how register contents are treated

Comments in Assembly

- Another way to make your code more readable: comments!
- □ Hash (#) is used for MIPS comments
 - anything from hash mark to end of line is a comment and will be ignored
- Note: Different from C.
 - C comments have format

```
/* comment */
```

so they can span many lines

Assembly Instructions

- In assembly language, each statement (called an <u>Instruction</u>), executes exactly one of a short list of simple commands
- □ Unlike in C (and most other High Level Languages), each line of assembly code contains at most 1 instruction
- Instructions are related to operations (=, +, -, *, /) in C or Java
- Ok, enough already...gimme my MIPS!

MIPS Addition and Subtraction (1/4)



Syntax of Instructions:

1 2,3,4

where:

- 1) operation by name
- 2) operand getting result ("destination")
- 3) 1st operand for operation ("source1")
- 4) 2nd operand for operation ("source2")
- Syntax is rigid (Why?)
 - 1 operator, 3 operands,
 - Keep Hardware simple via regularity

Addition and Subtraction of Integers (2/4)



Addition in Assembly

Example: add \$s0,\$s1,\$s2 (in MIPS)

Equivalent to: a = b + c (in C)

where MIPS registers \$s0,\$s1,\$s2 are associated with C variables a, b, c

Subtraction in Assembly

• Example: sub \$s3,\$s4,\$s5 (in MIPS)

Equivalent to: d = e - f (in C)

where MIPS registers \$s3,\$s4,\$s5 are associated with C variables d, e, f

Addition and Subtraction of Integers (3/4)

■ How do we do for the following C statement?

$$a = b + c + d - e;$$

Addition and Subtraction of Integers (3/4)



How do we do for the following C statement?

$$a = b + c + d - e;$$

Break into multiple instructions

```
add $t0, $s1, $s2 # temp = b + c
add $t0, $t0, $s3 # temp = temp + d
sub $s0, $t0, $s4 # a = temp - e
```

- Notice: A single line of C may break up into several lines of MIPS.
- Notice: Everything after the hash mark on each line is ignored (comments)

Addition and Subtraction of Integers (4/4)

■ How do we do this?

$$f = (g + h) - (i + j);$$

Addition and Subtraction of Integers (4/4)



■ How do we do this?

$$f = (g + h) - (i + j);$$

Use intermediate temporary register

```
add $t0,$s1,$s2  # temp = g + h
add $t1,$s3,$s4  # temp = i + j
sub $s0,$t0,$t1  # f = (g+h) - (i+j)
```

Register Zero

- □ One particular immediate, the number zero (0), appears very often in code.
- □ So we define register zero (\$0 or \$zero) to always have the value 0; eg

```
add $s0,$s1,$zero (in MIPS)

f = g (in C)
where MIPS registers $s0,$s1 are associated with C
variables f, q
```

defined in hardware, so an instruction

```
add $zero,$zero,$s0
```

will not do anything!

Immediates

- Immediates are numerical constants.
- □ They appear often in code, so there are special instructions for them.
- Add Immediate:

```
addi $s0,$s1,10 (in MIPS)

f = g + 10 (in C)

where MIPS registers $s0,$s1 are associated with C
 variables f, g
```

Syntax similar to add instruction, except that last argument is a number instead of a register.

Immediates



- □ There is no Subtract Immediate in MIPS: Why?
- Limit types of operations that can be done to absolute minimum
 - if an operation can be decomposed into a simpler operation, don't include it
 - addi ..., -X = subi ..., X => so no subi
- addi \$s0,\$s1,-10 (in MIPS) f = g - 10 (in C)

where MIPS registers \$s0,\$s1 are associated with C variables f, q

Question

- A. Types are associated with declaration in C (normally), but are associated with instruction (operator) in MIPS.
- B. Since there are only 8 local (\$s) and 10 temp (\$t) variables, we can't write MIPS for C exprs that contain > 18 vars.
- c. If p (stored in \$s0) were a pointer to an array of ints, then p++; would be addi \$s0, \$s0, 1

```
ABC
1: FFF
2: FFT
3: FTF
4: FTT
5: TFF
6: TFT
7: TTF
8: TTT
```

"And in Conclusion..."

- In MIPS Assembly Language:
 - Registers replace C variables
 - One Instruction (simple operation) per line
 - Simpler is Better
 - Smaller is Faster
- New Instructions:

add, addi, sub

■ New Registers:

C Variables: \$s0 - \$s7

Temporary Variables: \$t0 - \$t9

Zero: \$zero