Lecture 7

CMPEN 331

Solving review questions

Procedure Calling

- Steps required
 - 1. Place parameters in registers
 - 2. Transfer control to procedure
 - 3. Acquire storage for procedure
 - 4. Perform procedure's operations
 - 5. Place result in register for caller
 - 6. Return to place of call

Register Usage

- \$a0 \$a3: arguments (reg's 4 7)
- \$v0, \$v1: result values (reg's 2 and 3)
- \$t0 \$t9: temporaries
 - Can be overwritten by callee (calling program)
- \$s0 \$s7: saved
 - Must be saved/restored by callee
- \$gp: global pointer for static data (reg 28)
- \$sp: stack pointer (reg 29)
- \$fp: frame pointer (reg 30)
- \$ra: return address (reg 31)

Register Specifications

- \$t0 \$t9: temporary register that are not preserved by the callee (called procedure) on a procedure call
- \$s0 \$s7: saved registers that must be preserved on a procedure call (if used, the callee saves and restore them)

Procedure Call Instructions

- Procedure call: jump and link
 jal ProcedureLabel
 - Address of following instruction put in \$ra
 - Jumps to target address
- Procedure return: jump registerjr \$ra
 - Copies \$ra to program counter
 - Can also be used for computed jumps
 - e.g., for case/switch statements

Leaf Procedure Example

 C code: (Leaf procedure: procedures that don't call others)

```
int leaf_example (int g, h, i, j)
{ int f;
    f = (g + h) - (i + j);
    return f;
}
```

- Arguments g, h, i, j in \$a0 \$a3
- f in \$s0 (hence, need to save \$s0 on stack)
- Result in \$v0



Leaf Procedure Example

MIPS code:

<pre>leaf_example:</pre>							
addi	\$sp,	\$sp,	-4				
SW	\$s0 ,						
add	\$t0,	\$a0,	\$a1				
add	\$t1,	\$a2,	\$a3				
sub	\$s0,	\$t0,	\$t1				
add	\$v0,	\$s0 ,	\$zero				
٦w	\$s0 ,	0(\$5	o)				
addi	\$sp,	\$sp,	4				
jr	\$ra						

Save \$s0 on stack

Procedure body

Result

Restore \$s0

Return back to calling routine

Lecture 8

CMPEN 331

Leaf Procedure Example

 C code: (Leaf procedure: procedures that don't call others)

```
int leaf_example (int g, h, i, j)
{ int f;
    f = (g + h) - (i + j);
    return f;
}
```

- Arguments g, h, i, j in \$a0 \$a3
- f in \$s0 (hence, need to save \$s0 on stack)
- Result in \$v0



Leaf Procedure Example

MIPS code:

<pre>leaf_example:</pre>							
addi	\$sp,	\$sp,	-4				
SW	\$s0 ,	0(\$sp	o)				
add	\$t0,	\$a0,	\$a1				
add	\$t1,	\$a2,	\$a3				
sub	\$s0 ,	\$t0,	\$t1				
add	\$v0 ,	\$s0 ,	\$zero				
٦w	\$s0,	0(\$sp	o)				
addi	\$sp,	\$sp,	4				
jr	\$ra						

Save \$s0 on stack

Procedure body

Result

Restore \$s0

Return back to calling routine

Non-Leaf Procedures

- Procedures that call other procedures
- For nested call, caller needs to save on the stack:
 - Its return address
 - Any arguments and temporaries needed after the call
- Restore from the stack after the call

Non-Leaf Procedure Example

C code:
 int fact (int n)
 {
 if (n < 1) return 1;
 else return n * fact(n - 1);
 }
 Argument n in \$a0
 Result in \$v0

Steps for Calling a Procedure


- Save necessary values onto stack
- Assign arguments if any
- jal call
- Restore values from stack

Non-Leaf Procedure Example

MIPS code:

```
fact:
   addi $sp, $sp, -8 # adjust stack for 2 items
   sw $ra, 4($sp)
                        # save return address
   sw $a0, 0($sp)
                        # save argument
   slti $t0, $a0, 1
                        # test for n < 1
   beq $t0, $zero, L1
                        # if so, result is 1
   addi $v0, $zero, 1
                        # pop 2 items from stack
   addi $sp, $sp, 8
   ir $ra
                        # and return
L1: addi $a0, $a0, -1
                        # else decrement n
   jal fact
                        # recursive call
   1w $a0, 0($sp)
                        # restore original n
   lw $ra, 4($sp)
                        # and return address
   addi $sp, $sp, 8
                        # pop 2 items from stack
                        # multiply to get result
   mul $v0, $a0, $v0
   jr
        $ra
                        # and return
```


Local Data on the Stack



- Local data allocated by callee
 - e.g., C automatic variables
- Procedure frame (activation record)
 - Used by some compilers to manage stack storage

Memory Layout

- Text: program code
- Static data: global variables
 - e.g., static variables in C, constant arrays and strings
 - \$gp initialized to address allowing ±offsets into this segment
- Dynamic data: heap
 - E.g., malloc in C, new in Java
- Stack: automatic storage



Byte Operations

- Could use bitwise operations
- MIPS byte load/store
- 1b:load a byte from memory, placing it in the rightmost 8 bits of a register

```
lb rt, offset(rs) # read byte from source
```

```
lbu rt, offset(rs)
```

sb rt, offset(rs)

String Copy Example

- C code:
 - Null-terminated string

```
void strcpy (char x[], char y[])
{ int i;
    i = 0;
    while ((x[i]=y[i])!='\0')
        i += 1;
}
```

- Addresses of x, y in \$a0, \$a1
- i in \$s0

String Copy Example

MIPS code:

```
strcpy:
   addi $sp, $sp, -4
                         # adjust stack for 1 item
   sw $s0, 0($sp)
                          # save $s0
   add $s0, $zero, $zero # i = 0
L1: add $t1, $s0, $a1
                         # addr of y[i] in $t1
   1bu $t2, 0($t1)
                          # t^2 = y[i]
   add $t3, $s0, $a0
                         # addr of x[i] in $t3
   sb $t2, 0($t3)
                          \# x[i] = y[i]
                          # exit loop if y[i] == 0
   beq $t2, $zero, L2
   addi $s0, $s0, 1
                          \# i = i + 1
        L1
                          # next iteration of loop
L2: 1w $s0, 0($sp)
                          # restore saved $s0
   addi $sp, $sp, 4
                          # pop 1 item from stack
        $ra
                          # and return
   ir
```

32-bit Constants

- Most constants are small
 - 16-bit immediate is sufficient
- For the occasional 32-bit constant
- lui: load upper immediate
 lui rt, constant
 - Copies 16-bit constant to left 16 bits of rt
 - Clears right 16 bits of rt to 0
- Load 32 bit constant into register \$s0

```
      0000 0000 0011 1101
      0000 1001 0000 0000

      61 in decimal
      2304 in decimal
```

lui \$s0, 61

ori \$s0, \$s0, 2304

0000 0000 0111 1101 0000 1001 0000 0000

Jump Addressing

- Jump (j and jal) targets could be anywhere in text segment
 - Encode full address in instruction

ор	address
6 bits	26 bits

Branch Addressing

- Branch instructions specify
 - Opcode, two registers, target address
- Most branch targets are near branch
 - Forward or backward

ор	rs	rt	constant or address
6 bits	5 bits	5 bits	16 bits

- PC (program counter)-relative addressing
 - Target address = PC + branch address

Target Addressing Example

- Loop code from earlier example
 - Assume Loop at location 80000

Loop:	sll	\$t1,	\$s3,	2	80000	0	0	19	9	2	0
	add	\$t1,	\$t1,	\$ s6	80004	0	9	22	9	0	32
	٦w	\$t0,	0(\$t1)		80008	35	9	8	0		
	bne	\$t0,	\$s5,	Exit	80012	5	8	21	, e e e e	2	
	addi	\$s3,	\$s3,	1	80016	8	19	19	*****	1	
	j	Loop			80020	2	******	20000			
Exit:					80024	Are					

Branching Far Away

- If branch target is too far to encode with 16-bit offset, assembler rewrites the code
- Example

```
beq $s0,$s1, L1

↓

bne $s0,$s1, L2

j L1

L2: ...
```