

# EE 531: ADVANCED VLSI DESIGN

---

## Introduction

Nishith N. Chakraborty

January, 2025


# OUTLINE

---

- Review of IC design basics
- Design partitioning and design approaches
- Introduction to semi-custom design approach
- Introduction to automated approach


# TYPES OF DIGITAL SYSTEMS

- ASIC: Application Specific Integrated Circuits
  - Usually fabricated in silicon, custom or synthesized
- Microprocessor
- FPGA: Field Programmable Gate Arrays
  - Reconfigurable logic blocks configured for use




# MOS INTEGRATED CIRCUITS

- 1970's processes usually had only nMOS transistors
  - Inexpensive, but consume power while idle
- 1980s-present: CMOS processes for low idle power




Intel 1101 256-bit SRAM



Intel 4004 4-bit  $\mu$ Proc

# MOORE'S LAW

- 1965: Gordon Moore plotted transistor on each chip
  - Fit straight line on semilog scale
  - Transistor counts have doubled every 26 months



## Integration Levels

<b>SSI:</b>	10 gates
<b>MSI:</b>	1000 gates
<b>LSI:</b>	10,000 gates
<b>VLSI:</b>	> 10k gates



# WHY SCALING?

---

- Technology shrinks by 0.7/generation
- Every generation can integrate 2x more functions per chip; chip cost does not increase significantly
- Cost of a function decreases by 2x
- But...
  - How to design chips with more and more functions?
  - Design engineering population does not double every two years...
- Hence, a need for more efficient design methods
- Exploit different levels of abstraction

# A MICROPROCESSOR EXAMPLE

- Intel Coffee Lake
  - Up to 6 cores (12 threads)
  - 2.9 to 4.8GHz clock (Core i9)
  - Still 14nm technology...
    - Cannon Lake (shrink) is 10nm
    - Moore's Law at an end?
  - Over 1 billion transistors 12MB SmartCache
  - Built-in GPU – a “system on chip”
  - Some custom (“neat” areas); many synthesized components (“messy” areas)




# DESIGNING A MICROPROCESSOR

---

- Requires a large team and a lot of time
- Some components can be synthesized
  - Design written in code (e.g. VHDL)
  - Synthesis tool generates netlist from code
- Other components must be custom designed
  - Blocks on critical path (i.e. critical to system performance)

## AN ASIC EXAMPLE: AVALON BITCOIN MINING ASIC

- Application very specific: device that mines bitcoins
- Bitcoin mining can be time consuming – ASIC works fast
- Almost entirely synthesized from standard cells
  - “messy” look of layout
  - Not as fast as full custom



# STRUCTURED DESIGN

---

Hierarchy: Divide and Conquer

- Recursively system into modules

Regularity

- Reuse modules wherever possible
- Ex: Standard cell library

Modularity: well-formed interfaces

- Allows modules to be treated as black boxes

Locality


- Physical and temporal

# DESIGN PARTITIONING

---

- Architecture: User's perspective, what does it do?
  - Instruction set, registers
  - MIPS, x86, Alpha, PIC, ARM, ...
- Microarchitecture
  - Single cycle, multi-cycle, pipelined ?
- Logic: how are functional blocks constructed
  - Ripple carry, carry lookahead, carry select adders
- Circuit: how are transistors used
  - Complementary CMOS, pass transistors, domino
- Physical: chip layout
  - Datapaths, memories, random logic

# DESIGN ABSTRACTION LEVELS



# PERFORMANCE METRICS

---

How do we evaluate performance of a digital circuit (gate, block, ...)?


- Cost
- Reliability
- Scalability
- Speed (delay, operating frequency)
- Power dissipation
- Energy to perform a function

# VLSI DESIGN APPROACHES

---

- **Custom:** A design that has been carefully crafted by the designer including manual layout.
- **Semi-custom:** Some custom crafted blocks including custom blocks using automation (i.e., SKILL) along with some fully automated blocks. Usually makes use of predefined, well optimized blocks that cannot be changed.
- **Automated:** The use of a hardware description language (VHDL, Verilog, SystemC, etc.) and CAD tools to synthesize a design from code to Silicon.

# A QUICK LOOK AT INTEL PENTIUM




# ASIC/SOC DESIGN FLOW

---

- SOC design should always start with a clear design flow
- An integrated circuit design flow shows the particular steps taken for each design stage and highlights CAD tools used

# ASIC/SOC DESIGN FLOW



# AUTOMATED DESIGN

---

- Typically, an application specific integrated circuit (ASIC) is designed using commercial tools
- A **standard cell library** is provided by a vendor (i.e., fab facility) which includes a set of basic gates
- The design is specified using an HDL (such as Verilog or VHDL) and synthesized to a gate-level netlist in terms of the gates in the library
- Finally, this netlist is used for floorplanning and place & route using another tool to produce layout
- Custom blocks can be included but much of the flow is automated starting with the HDL

# STANDARD CELL LIBRARY

---

- The standard cell library is usually provided a vendor
- A lot is required for a library:
  - Optimized schematic and layout for each gate
  - Timing files
  - Input/output pin definitions
- Typical standard cells: INV, AND2, AND3, OR2, OR3, XOR2, AOI21, AOI22, etc.

# HDLS


---

- Hardware Description Languages
  - Widely used in logic design
  - Verilog and VHDL
- Describe hardware using code
  - Document logic functions
  - Simulate logic before building
  - Synthesize code into gates and layout
    - Requires a library of standard cells

# VERILOG EXAMPLE

```
module fulladder(input a, b, c,
                  output s, cout);
    sum     s1(a, b, c, s);
    carry   c1(a, b, c, cout);
endmodule
```

```
module carry(input a, b, c,
              output cout)
    assign cout = (a&b) | (a&c) | (b&c);
endmodule
```




# CIRCUIT DESIGN

---

- How should logic be implemented?
  - NANDs and NORs vs. ANDs and ORs?
  - Fan-in and fan-out?
  - How wide should transistors be?
- These choices affect speed, area, power
- Logic synthesis makes these choices for you
  - Good enough for many applications
  - Hand-crafted circuits are still better

## EXAMPLE: CARRY LOGIC


```
assign cout = (a&b) | (a&c) | (b&c);
```



Transistors? Gate Delays?

## EXAMPLE: CARRY LOGIC

```
assign cout = (a&b) | (a&c) | (b&c);
```



Transistors? Gate Delays?


# GATE-LEVEL NETLIST

```
module carry(input a, b, c,
              output cout)

    wire x, y, z;


    and g1(x, a, b);
    and g2(y, a, c);
    and g3(z, b, c);
    or  g4(cout, x, y, z);

endmodule
```



# PLACE & ROUTE

- Floorplanning
- Placement
- Routing



# SUMMARY

---

- VLSI design occurs at several abstraction layers
- Can design manually (custom) or using automated CAD tools
- Most VLSI systems are in a “gray area” – some custom and some automation
- This class focuses mostly on top-down, automated approach
- We will study ASIC/SOC design in general and will use FPGAs as our primary platform for prototyping designs

Welcome... Let's have fun!