


SoundLink® on-ear Bluetooth® headphones

Quick Start Guide • Lynstartvejledning • Kurzanleitung • Beknopte handleiding • Guía de inicio rápido • Pikaopas • Guide de démarrage rapide • Guida rapida • Rövid üzembe helyezési útmutató



English | Dansk | Deutsch | Dutch | Español | Finnish | Français | Italiano | Magyar

Please read and follow this Quick Start Guide and the Important Safety Information and keep for future reference.

Pairing a mobile device

Slide the Power/Bluetooth® button (all the way up to the * symbol and hold until you hear, "Ready to pair" or you see the *Bluetooth* indicator blinking blue. D

On your mobile device, turn on *Bluetooth* functionality.

Select Bose OE SoundLink in your mobile device's Bluetooth list. You will hear, "Connected to <device name>" or you will see the Bluetooth indicator glow solid white.

Note: Visit owners.Bose.com/SoundLinkOE to see how-to videos (English only), or refer to your mobile device user guide to learn how it pairs/connects.

With the headphones on your head, press and hold

To change the voice prompt language

■ and + together for five seconds.

Press the volume buttons to scroll through the list of

available languages: When you hear the language you want, press and hold • ● •.

• For additional languages, check updates.Bose.com/SoundLinkOE • To turn voice prompts off or on, press and hold

Headphone controls (C)



Multi-function

Volume up

+ and - together.

To add another device

Triple press to track back.

Double press to track forward.

Press once to play/pause or answer/end

 Press and hold to ignore an incoming call. Volume down

The headphones can store eight devices in memory.

When powered on, the headphones will automatically connect to

Repeat Step 1 and Step 2 above for each new device.

the first two devices in memory, for example a tablet for audio, and a phone for calls. **Managing devices** Slide up and release to scroll through the list of devices

in memory. D Repeat until you hear the device you want to control.

Note: If a device is not within Bluetooth range, 33 ft. (10 m), scroll to the next device.

Indicators Blue blinking: Ready to pair





Charging

Green: Medium to full charge

Amber: Low charge

White solid: Connected

White blinking: Connecting

Plug the small end of the USB cable into the micro-USB connector on the right earcup. Plug the other end into

a USB wall charger or computer that is powered on.

Red blinking: Need to charge

Use the supplied back-up audio cable to connect a non-Bluetooth device, or if the headphones battery is

Using the back-up audio cable

Note: The headphones will not play while charging.

depleted. A Please refer to the Owner's Guide, available online, for more

information about your headphones, including advanced functions,

additional troubleshooting suggestions, and information on

of the complete Owner's Guide, please refer to the contact

accessories and replacement parts. To request a printed copy

Remove the headphones from the Bluetooth list on your mobile

Visit owners.Bose.com/SoundLinkOE to see how-to videos

information on this sheet.

- Make sure Bose OE SoundLink is removed from the Bluetooth list on your mobile device. Slide up and hold **(b)** until you hear "device list cleared". Then repeat steps 1-2 above.
- Make sure the headphones power is on and battery is charged. Make sure the volume is turned up on the headphones and on your mobile device (or music app). • Your mobile device may be connected to another Bluetooth

speaker or headset. Make sure that Bose OE SoundLink is

Poor sound quality • Move the mobile device closer to the headphones, and away from any interference.

Operating time: 15 hours

Technical Information

iPad, iPhone, iPod, iPod touch, and Retina are trademarks of Apple Inc., registered in the U.S. and other countries. iPad Air and iPad mini are trademarks of Apple Inc. The trademark "iPhone" is used with a license from Aiphone K.K.

"Made for iPod," "Made for iPhone," and "Made for iPad" mean that an electronic accessory

Bluetooth range: 33 ft. (10 m)

has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone or iPad may affect wireless performance.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

and any use of such marks by Bose Corporation is under license. ©2014 Bose Corporation. No part of this work may be reproduced, modified, distributed,

or otherwise used without prior written permission.

United States 888 757 9943

Troubleshooting Headphones do not connect with mobile device On your device, turn off and on the Bluetooth functionality. device. Then repeat steps 1-2 above.

(English only). • Clear the headphones memory:

No sound

selected in the Bluetooth device list.

Try pairing another mobile device.