

|                            |                                    |                   |                |
|----------------------------|------------------------------------|-------------------|----------------|
| <b>Process flow title:</b> | <b>Pt100 Thin-Film RTD Process</b> | <b>Revision:</b>  | <b>Rev 0.1</b> |
| Contact email:             | jephin@dtu.dk                      | Contact name:     | Jeppe Hinrichs |
| Contact phone:             | Not applicable                     |                   |                |
| LabManager group:          | Not applicable                     | Batch name:       | TBD            |
| Date of creation:          | 2025-09-29                         | Date of revision: | 2025-10-03     |

---

## Process Overview

A process flow for fabricating a Pt100 resistance temperature detector (RTD) on oxidized silicon, using Ti/Pt thin films patterned by lift-off.

### Key Specifications

- Substrate: n-type silicon wafer, <100>, with thermal oxide isolation
- Insulating layer: 500 nm thermal SiO<sub>2</sub>
- Adhesion layer: 10 nm Ti
- Sensing layer: 100 nm Pt, patterned in meander geometry
- Nominal resistance: 100 Ω at 0 °C (Pt100)

### Critical Safety

- **HF handling:** Apron + gloves, face shield, no lone working, no glass beakers!
- **Solvents:** Acetone, IPA, resist remover: Use fume hood and PPE.
- **Sputter/evaporation:** Pt/Ti target change requires care; follow target handling SOP
- **Anneal:** Use thermal gloves for > 300 °C operations

## 1 Starting Material

| Substrate | Specification                | Thickness      | Box Name | Qty |
|-----------|------------------------------|----------------|----------|-----|
| Silicon   | n-type <100>, 4", 0.025 Ω cm | 525 μm ± 20 μm | SN608    | 5   |

## 2 Critical Layers

| Layer                      | Material                 | Thickness            |
|----------------------------|--------------------------|----------------------|
| Insulating oxide           | Thermal SiO <sub>2</sub> | 500 nm               |
| Adhesion layer             | Ti                       | 10 nm                |
| Resistive element          | Pt                       | 100 nm               |
| Optional pad metallization | Ni/Au                    | 20 nm Ni + 200 nm Au |

## 3 Core Process Flow

Table 1: Pt100 RTD Process Flow

| Step     | Process                     | Equipment                      | Parameters  | Comment  |
|----------|-----------------------------|--------------------------------|---|--|
| <b>1</b> | <b>Wafer Prep and Oxide</b> |                                |   |  |
| 1.1      | Incoming inspection         | 4-point probe + thickness tool | Measure resistivity, bow, thickness   | Verify starting wafer specs.                             |
| 1.2      | Pre-oxidation clean         | RCA bench                      | Standard RCA clean  | Required prior to oxidation.                             |
| 1.3      | Thermal oxide growth        | Furnace: E1 oxidation          | Target: 500 nm<br>Recipe: WET1100<br>Oxidation time: 50 min<br>Anneal time: 20 min                        | Provides electrical isolation.                           |
| 1.4      | Inspection                  | Ellipsometer                   |   | Verify oxide thickness.                                  |
| <b>2</b> | <b>Lithography</b>          |                                |   |  |
| 2.1      | Resist coat                 | Spin Coater: Gamma UV          | Recipe: 3421 DCH 100mm<br>5214E 2.2 μm HMDS<br>Softbake: 100 °C, 60 s                                     |  |
| 2.2      | Pattern exposure            | Maskless Aligner: MLA2         | Mask: rtd_sulfiloger_wafer<br>Dose: 50 mJ/cm <sup>2</sup><br>Wavelength: 375 nm                           | Expose regions that should remain after lift-off.        |
| 2.3      | Image reversal bake         | TMAH lithography               | UV-<br>Recipe: 2001 DCH PEB<br>110 °C 60 s  | Crosslinks initially exposed resist (becomes insoluble). |
| 2.4      | Flood exposure              | Maskless Aligner: MLA2         | No mask, blanket exposure<br>Dose: 500 mJ/cm <sup>2</sup><br>Exposure time: 45 s at 11 mW/cm <sup>2</sup> | Reverses tone: unexposed areas become soluble.           |

Continued on next page

Table 1: Pt100 RTD Process Flow (Continued)

| Step                                | Process                    | Equipment                          | Parameters  | Comment                                |                                 |
|-------------------------------------|----------------------------|------------------------------------|---|--|---------------------------------|
| 2.5                                 | Develop                    | TMAH lithography                   | UV-<br>Recipe: 1002 DCH 100mm<br>SP 60 s<br>Developer: AZ 726 MIF<br>single puddle, 60 s<br>Rinse: DI water, 30 s | Creates undercut profile for lift-off. |                                 |
| <b>3 Metal Deposition</b>           |                            |                                    |   |  |                                 |
| 3.1                                 | Chamber prep               | E-beam evaporator (Temescal)       | Base pressure $\leq 1 \times 10^{-6}$ mbar  | Lift-off friendly.                     |                                 |
| 3.2                                 | Ti deposition              | E-beam evaporator (Temescal)       | 10 nm Ti @ 0.5 Å/s to 1 Å/s   | Adhesion layer.                        |                                 |
| 3.3                                 | Pt deposition              | E-beam evaporator (Temescal)       | 100 nm Pt @ 1 Å/s to 2 Å/s  | Resistive layer.                       |                                 |
| <b>4 Lift-off</b>                   |                            |                                    |   |  |                                 |
| 4.1                                 | Lift-off                   | Solvent bath (acetone)             | Soak + ultrasonic assist if needed  | Leaves Ti/Pt meander.                  |                                 |
| 4.2                                 | Rinse/Dry                  | IPA + N2 gun                       |   | Inspect for clean edges, no flakes.    |                                 |
| <b>5 Post-processing (optional)</b> |                            |                                    |   |  |                                 |
| 5.1                                 | Optional anneal            | C3 Furnace: N <sub>2</sub> ambient | 400 °C, 1 h   | Stabilizes Pt resistance.              |                                 |
| 5.2                                 | Optional pad metallization | Lithography evaporator             | + Ni/Au stack   | Improves bondability.                  |                                 |
| 5.3                                 | Final inspection           | Optical microscope + probe         | micro-<br>4-point   | Measure sheet R, continuity            | Target $R = 100\Omega$ at 0 °C. |

## 4 Critical Checks

| Step | QC Verification  |
|------|--|
| 1.3  | Oxide thickness: 500 nm $\pm$ 10 nm (ellipsometer)             |
| 2.2  | Lithography: line/space $\pm$ 1 µm (optical inspection)        |
| 3.3  | Pt thickness: 100 nm $\pm$ 5 nm (Dektak XTA stylus profiler)   |
| 4.1  | Lift-off complete, no bridging (microscope)                    |
| 5.1  | Sheet resistance stable within 1% after anneal (4-point probe) |

## **5 Process Flow Diagram**

Figure 1: Process flow diagram for Pt100 RTD fabrication.

## 6 Required Figures

Table 2: Cross-sectional illustrations of key process steps in the Pt100 RTD fabrication flow.

| ID | Step | Description                         |
|----|------|-------------------------------------|
| 1  | 1.3  | Thermal oxide isolation             |
| 2  | 2.2  | Lithography defines meander         |
| 3  | 3.3  | Ti/Pt deposition                    |
| 4  | 4.1  | Lift-off completed                  |
| 5  | 5.1  | Optional anneal / pad metallization |