
What's it all about?

- A signal is a waveform or measurement that represents some physical quantity
- A system is a set of operations that transforms input signals to output signals
- We've seen this kind of thing already in circuits (CMPE306)



Mathematical Description of Signals

- We want to be able to describe signals in three ways
 - Time domain
 - Frequency (or Fourier) Domain
 - Laplace Domain
- Each way emphasizes different qualities of the the signal
- Our method is to decompose complex signals into simpler signals
- In the process, we'll develop a dictionary of standard signals that will prove very useful.

UMBC CMPE323 Signals and Systems © EFCLaBerge, S. J. Kim 2014 All rights reserved Portions © Addison-Wesley Publishing, Inc

Key Mathematical Characteristic of Signals

- Periodicity
 - A signal is periodic if it repeats exactly, that is if

$$f(\alpha) = f(\alpha \pm nT)$$
 for any α and and n

T is called the *period*


• Sinusoids are periodic

$$x(t) = A\cos(\omega t + \phi), \quad T = \frac{2\pi}{\omega}$$

Pulse trains may be periodic

$$s(t) = \sum_{-\infty}^{\infty} p(t - kT)$$
 where $p(t)$ is a specified pulse waveform

UMBC CMPE323 Signals and Systems © EFCLaBerge, S. J. Kim 2014 All rights reserved Portions © Addison-Wesley Publishing, Inc



Sums and products of periodic waveforms

- The sum of two periodic waveforms with periods T_1 and T_2 will be periodic iff T_1 / T_2 = f_2 / f_1 = n_2 / n_1 ; $n_1, n_2 \in \mathbb{Z}$
- The period of the sum is $T = n_1 T_1 = n_2 T_2$


cos(5t) + cos(3t) is periodic

$$T_1 = \frac{2\pi}{5}, T_2 = \frac{2\pi}{3}, \frac{T_1}{T_2} = \frac{3}{5}, \text{ so } n_1 = 5, n_2 = 3$$

The common period is $T = n_1 T_1 = 2\pi = n_2 T_2$

• A similar rule holds for the product of periodic waveforms $(f_1+f_2)/(f_1-f_2)=n_2/n_1,\ n_1,n_2\in\mathbb{Z}$

UMBC CMPE323 Signals and Systems © EFCLaBerge, S. J. Kim 2014 All rights reserved Portions © Addison-Wesley Publishing, Inc



Elementary Functions



A unit step

$$u(t) = \begin{cases} 0 & t < 0 \\ 1 & t > 0 \end{cases}$$
, we'll leave the definition at $t = 0$ for later

A unit impulse

$$\delta(t) = \frac{du}{dt} \Longrightarrow \lim_{\varepsilon \to 0} \int_{-\varepsilon}^{+\varepsilon} \delta(t) dt = 1$$

- The unit impulse isn't a function is the traditional sense...
- ...but rather a limit of functions...
- ...and a number of different "shapes" can be used

UMBC CMPE323 Signals and Systems
© EFCLaBerge, S. J. Kim 2014 All rights reserved
Portions © Addison-Wesley Publishing, Inc

Totalis @ Addison Wesley Fabilishing, Inc

The unit impulse is very important

The sieving property

$$\int_{-\infty}^{\infty} f(t)\delta(t-t_0) dt = f(t_0)$$

Examples

$$\int_{-\infty}^{\infty} e^{-at} \delta(t - t_0) dt = e^{-at_0}, \text{ in fact } \int_{t_0 - \varepsilon}^{t_0 + \varepsilon} e^{-at} \delta(t - t_0) dt = e^{-at_0}$$

 $\int_{-\infty}^{\infty} e^{-at} (100\cos\omega t + 200\sin\omega t) \delta(t-\tau) dt = e^{-a\tau} (100\cos\omega\tau + 200\sin\omega\tau)$

UMBC CMPE323 Signals and Systems © EFCLaBerge, S. J. Kim 2014 All rights reserved Portions © Addison-Wesley Publishing, Inc

More elementary functions

Sinusoids

$$A\cos\omega t$$
, $A\sin(2\pi ft + \phi)$, etc., periodic with $T = \frac{2\pi}{\omega} = \frac{1}{f}$

Exponentials

$$a_0 e^{at}$$
 (growing), $b_0 e^{-\alpha t}$ (decaying)

Complex exponentials

$$Ae^{j\phi} = A\cos\phi + jA\sin\phi$$
$$Ae^{j(\omega t + \phi)} = A\cos(\omega t + \phi) + jA\sin(\omega t + \phi)$$

- The sinc function
 - Our text: $sinc(x) = \frac{\sin x}{x}$
 - Some other texts and MATLAB: $sinc(x) = \frac{sin \pi x}{\pi x}$

UMBC CMPE323 Signals and Systems
© EFCLaBerge, S. J. Kim 2014 All rights reserved
Portions © Addison-Wesley Publishing, Inc

_


Pulses and Windows

- Often, we want only a limited segment (in time) of one of the elementary functions.
- Such a segment is called a window
- Windows will be important later!
- We often create a window by multiplying two functions together...
- ...e.g. Rectified Cosine Window

$$w_{RC}(t;\tau) = \cos\left(\frac{\pi t}{\tau}\right) w_{RECT}(t - 0.5\tau;\tau)$$

UMBC CMPE323 Signals and Systems © EFCLaBerge, S. J. Kim 2014 All rights reserved Portions © Addison-Wesley Publishing, Inc

LO



Time Averages of Time Waveforms

- We are usually interested in the energy contained in a waveform or signal...
- ...as energy is the key to overcoming noise in the system.

$$\mathcal{E} = \int_{-\infty}^{\infty} x(t)x^{*}(t) dt = \int_{-\infty}^{\infty} |x(t)|^{2} dt = \int_{-\infty}^{\infty} x^{2}(t) dt$$
real valued valued signal

- If our signal has units of volts, then $\mathcal E$ has units of volt²-sec, which is not joules!
- When computing the mathematical energy (as above) we assume there is a $l\Omega$ resistor as a scale factor, giving volt²-sec/ohm = watt-sec = joules!
- Using this definition, the energy in a periodic signal is infinite!! (Why?)



$$\frac{\mathcal{E}}{T} = \frac{1}{T} \int_{\alpha}^{T+\alpha} x(t) x^{*}(t) dt = \frac{1}{T} \int_{\alpha}^{T+\alpha} |x(t)|^{2} dt = \frac{1}{T} \int_{0}^{T} x^{2}(t) dt$$

- Again using a 1Ω resistor as a scale factor, we wind up with volt²-sec/ohm-sec=watt-sec/sec=watt...
- ...so this is power!
- A signal with finite energy is called an energy signal
- A signal with meaningful power is called a power signal.
- Some signals are neither power or energy signals, but these are rare.

UMBC CMPE323 Signals and Systems © EFCLaBerge, S. J. Kim 2014 All rights reserved Portions © Addison-Wesley Publishing, Inc 4.5

Examples

Unit pulse


$$p(t) = \begin{cases} 1 & 0 \le t < 1 \\ 0 & \text{otherwise} \end{cases}$$

$$x(t) = 2p(t)$$

$$x^{2}(t) = \begin{cases} 4 & 0 \le t < 1\\ 0 & \text{otherwise} \end{cases}$$

$$\mathcal{E} = \int_{-\infty}^{\infty} x^2(t) dt = \int_{0}^{1} 4dt = 4 \text{ joules}$$

UMBC CMPE323 Signals and Systems © EFCLaBerge, S. J. Kim 2014 All rights reserved Portions © Addison-Wesley Publishing, Inc



Pulse train


$$p(t) = \begin{cases} 1 & 0 \le t < 1 \\ 0 & \text{otherwise} \end{cases}$$


$$x(t) = \sum_{-\infty}^{\infty} 0.5 p(t - 2n)$$

$$x^{2}(t) = \sum_{-\infty}^{\infty} 0.25 p(t - 2n)$$

$$P = \frac{1}{2} \int_{0}^{2} 0.25 dt = 0.125 \text{ watts}$$

UMBC CMPE323 Signals and Systems © EFCLaBerge, S. J. Kim 2014 All rights reserved Portions © Addison-Wesley Publishing, Inc





a(t) is an energy signal

$$\mathcal{E} = \int_{0}^{2} (e^{-0.5t})^{2} dt = \int_{0}^{2} (e^{-1t}) dt = 1 - e^{-2}$$

b(t) is periodic with period 4, therefore it is a power signal

$$P = \frac{1}{4} \int_{0}^{4} (b(t))^{2} dt = \frac{1}{4} \left(\int_{0}^{2} (e^{-0.5t})^{2} dt + \int_{2}^{4} (0)^{2} dt \right) = \frac{1 - e^{-2}}{4}$$

c(t) is periodic with period $\frac{2\pi}{120\pi} = \frac{1}{60}$. The phase does not affect

the period, c(t) is a power signal

Let
$$120\pi t_0 = \frac{\pi}{3} \Rightarrow t_0 = \frac{1}{360}$$
, $c(t) = 120\cos(120\pi(t + t_0))$

$$P = \left(\frac{1}{60}\right) 120^2 \int_{-1/360}^{1/360+1/60} \cos^2(120\pi(t+t_0)) dt = \left(\frac{1}{60}\right) 120^2 \int_{0}^{1/60} \cos^2(120\pi\tau) d\tau$$

$$= \left(\frac{1}{60}\right) 120^2 \int_0^{1/60} \left(\frac{1}{2} + \frac{1}{2}\cos 240\pi\tau\right) d\tau$$

$$=120^{2} \frac{\left((1/60)-0\right)}{2\times60} + 120^{2} \frac{\left(\sin\frac{240\pi}{60}-\sin 0\right)}{2\times60\times240\pi} = \frac{120^{2}}{2} = 7200 \text{ watts}$$

UMBC CMPE323 Signals and Systems
© EFCLaBerge, S. J. Kim 2014 All rights reserved
Portions © Addison-Wesley Publishing, Inc.