Microprocessor Systems Lab 1: IDE & ANSI Display

Nick Choi Samuel Deslandes

1 Introduction

The overall goal of this lab is to become familiar with utilizing the registers on the 8051 as well as performing fundamental I/O operations with it. This lab also served as an introduction to the VT100 Terminal and the utilization of he ANSI escape sequences it features.

This lab was divided into 3 parts. The first was an exercise in basic terminal I/O in which a C program was written to await a user keystroke and, if printable, output it on the terminal display. The second part was an enhancement of the first part but heavy usage of the ANSI escape codes to format text on the display. The ANSI escape codes are special sequences beginning with <ESC>(\033 in octal or \$1B in hex) which modify terminal behavior, adding features such as underlined text, background/foreground color changes, changing the cursor position, selectable scrolling, etc... The third part of the lab involved configuring ports on the 8051 to be either inputs or outputs. In this part of the lab hardware connected to the input port could be used to change the state of hardware connected to the output ports of the 8051.

2 Methods

2.1 Software

The code for parts 1, 2 and 3 can be found in Appendix A, B and C respectively. All code was uploaded and run on the 8051 through the programming/debugging USB port.

In the first section of the lab, a C program was written so that user input from a keyboard could be displayed in the ANSI terminal. The 8051 determined which keyboard character was pressed by utilizing the "getchar()" and "putchar()" functions defined in the "putget.h" header file. It should be noted that the "getchar()" function was modified from the original header file to not echo captured keystrokes. Whenever a printable character was input, it was printed to the terminal display with the following message: "The keyboard character is *." Unprintable characters were not displayed and the program would run in an infinite loop unless the <ESC>key was pressed. Pressing the <ESC>key both restarted the C program and cleared the terminal. In order to determine whether the input was printable or not, the captured character's ASCII was compared with the printable characters on the ASCII table, which range from 0x20 (space) through 0x7E (~).

The second part builds upon the C program written for the first so that it would incorporate escape sequences to achieve various text effects within the VT100 terminal. Table 1 below contains all of the ANSI escape sequences used for this lab. The first modification was to change the background color to blue and the foreground color to yellow. This was done using the codes "\033[1;43m" and "\033[1;33m" respectively. The first line of text contains program termination information similar to that of part 1; It is printed on line 2 of the terminal and is horizontally centered. This can be accomplished using the escape code for changing the cursor position "\033[{row};{col}H". In this case 2 and 30 were used for the row and column respectively. As was done in part 1, the keyboard response must also be displayed, this time on line 6 with the keyed in character printed in white. The same code above was used to jump the cursor to line 6, and "\033[1;37m" is used to change the text's color to white. If the keyed in character is not printable, the message "The keyboard character \$XX is 'not printable'." should appear starting halfway down the terminal (line 12 in our case) and work its way down the screen. This text should be blinking and make an audible 'BEL' noise when a non-printable character is keyed in. The terminal should be set such that only the bottom half of the screen scrolls. Although the escape code to change the position of the cursor could be used accomplish this, the codes to save and restore the cursors position were used instead so that we would not have to directly keep track of what line to jump to. In order to do this we had it so that before a non-printable is even keyed in the position of the next error message was already stored so that when it came time to print the error message all that had to be done was restore the cursor position, print the error message ending it with the ASCII newline escape sequence ('\n'), then save this position before returning to waiting for user input. The ANSI codes for saving and restoring the cursor's position are "\033[s" and "\033[u" respectively. To get the audible feedback portion the ASCII escape sequence '\a' was used. When writing the code block pertaining to printing the error message, it is important to remember to turn off the underscore and blinking once the desired text with these effects has been printed.

\033[2J	Clear screen and return cursor to home
\033[1;33m	Set text color to yellow
\033[1;43m	Set background color to blue
\033[1;37m	Set text color to white
\033[row;colH	Move cursor position to $({row},{col})$
$\sqrt{033}$ [start;stopr	Set scroll area from {start} to {stop}
\033[s	Save cursor position
\033[u	Restore cursor position
\033[5m	Turn blinking text on
\033[25m	Turn blinking text off
\033[4m	Underline text
\033[24m	Turn underline text off

Table 1: Quick reference table of ANSI escape sequences

Part 3 took the code in a very different direction and focused more on the hardware than the software. In terms of software, all of port 1 had to be configured to be in open-drain mode (input), and all of port 2 to push-pull mode (output). This was done by setting all of the bits of the P1MDOUT special function register (SFR) low, and all of those of P2MDOUT high. This should be done in the 'PORT_INIT()' function. In the main function, all that had to be done was read the value of port 1 into port 2. This could be done using the P1 and P2 port SFRs.

2.2 Hardware

Parts 1 and 2 of this lab did not require any hardware other than a serial-to-USB adapter in order to interface with the terminal.

In the third section of the lab, the pins on port 1 were connected to the input device, the potentiometer module, and pins on port 2 were connected to the output device, the LED module. Since there were only 4 potentiometers on the potentiometer module only the first 4 pins on each port were used (P1.0 - P1.3 and P2.0 - P2.3). These corresponded to pins 12, 13, 10, and 11 on the EVB for port 1, and 29, 30, 27, and 28 for port 2. A circuit diagram can be seen in figure 1 below.

The input pins of the module have inverters incorporated into them so that whenever a logic high is applied to an input pin, the signal is changed to be a logic low. This inversion allows the LED to illuminate because there will be a voltage difference across the anode and cathode of the LED. If a logic low is applied to the input pin, the signal is changed to be a logic high. This removes the voltage difference between the anode and cathode of the LED and thus prevents the LED from lighting up.




Figure 1: Circuit schematic for part 3

3 Results

By completing section one of the lab, a functioning C program was produced which read keyboard input and displayed it in an ANSI terminal. After completing section two, an improved version of the program from section one was produced. This version reacted to user input and manipulated the output of the ANSI terminal in several ways. The final deliverable was an LED module which was controlled by a potentiometer module.

4 Conclusion

5 Appendices

5.1 Modified putget.h

```
// putget.h
// Title:
                         Microcontroller Development: putchar() & getchar() fu
// Author:
                         Dan Burke
// Date Created:
                         03.25.2006
// Date Last Modified:
                         03.25.2006
                         http://chaokhun.kmitl.ac.th/~kswichit/easy1/easy1_3.h
// Description:
// Target:
                         C8051F120
// Tool Chain:
                         KEIL C51
// putchar()
void putchar(char c)
    while (!TI0);
    TI0=0;
    SBUF0 = c;
}
// getchar()
char getchar (void)
    char c;
```

```
while (!RIO);
    RI0 = 0;
    c = SBUF0;
// Echoing the get character back to the terminal is not normally part of get
      putchar(c); // echo to terminal
    return SBUF0;
5.2
     Part 1
     Part 2
5.3
// Hello.c
//8051 Test program to demonstrate serial port I/O. This program writes a mo
//the console using the printf() function, and reads characters using the get
//function. An ANSI escape sequence is used to clear the screen if a '2' is
//A '1' repeats the message and the program responds to other input character
//an appropriate message.
//Any valid keystroke turns on the green LED on the board; invalid entries tu
// Includes
\#include < c8051f120.h >
#include <stdio.h>
#include "putget.h"
// Global Constants
#define EXTCLK
                                         // External oscillator frequency in H
                    22118400
#define SYSCLK
                    49766400
                                         // Output of PLL derived from (EXTCLK
#define BAUDRATE
                    115200
                                         // UART baud rate in bps
// Function Prototypes
void main(void);
void SYSCLK_INIT(void);
void PORT_INIT(void);
void UART0_INIT(void);
```

```
// MAIN Routine
void main(void)
    char choice;
        //unsigned char row = 12;
    WDTCN = 0xDE;
                                            // Disable the watchdog timer
    WDTCN = 0xAD;
    PORT_INIT();
                                            // Initialize the Crossbar and GPIO
                                            // Initialize the oscillator
    SYSCLK_INIT();
    UARTO_INIT();
                                            // Initialize UARTO
    SFRPAGE = UARTO_PAGE;
                                            // Direct output to UARTO
    printf("\setminus 033[2J");
                                            // Erase screen & move cursor to home
                                                                      // Set the te
        printf (" \setminus 033[1;33m");
        printf (" \setminus 033[2;30H");
                                                             // Center text
        printf (" \setminus 033[12;25r");
                                                             // Set scroll area
        printf (" \setminus 033[12;1H");
                                     // Jump to line 12 and save position
        printf("\setminus 033[s]");
    while (1)
                 // Get the keyboard character and output it to the terminal
                 printf("\033[6;1H");
                                                             // Move cursor to row
                 printf("The keyboard character is ");
                 printf("\033[6;27H");
                                                                      // Move curso
                 choice = getchar();
                 if (choice = 0x1b){
                          return;
                                                                               //Che
                 else if (choice \Rightarrow 0x20 && choice \Leftarrow 0x7E){
                          printf (" \setminus 033[1;37m");
                          putchar(choice);
                          printf (" \setminus 033[1;33m.");
```

```
else {
                            printf("\setminus 033[u \setminus a");
                            printf("\setminus033[5m");
                            printf("The keyboard character $\%02x is ", choice);
                            printf("\setminus 033[4m' \text{ not printable '} \setminus 033[24m. \setminus n \setminus r");
                            printf("\033[s");
// Save cursor position
                            printf("\setminus 033[25m]");
                  }
    }
}
// SYSCLK_Init
//
// Initialize the system clock to use a 22.1184MHz crystal as its clock source
void SYSCLK_INIT(void)
    int i;
    char SFRPAGE_SAVE;
    SFRPAGE\_SAVE = SFRPAGE;
                                              // Save Current SFR page
    SFRPAGE = CONFIG_PAGE;
    OSCXCN = 0x67;
                                              // Start ext osc with 22.1184MHz crys
                                              // Wait for the oscillator to start u
    for (i=0; i < 256; i++);
    while (!(OSCXCN \& 0x80));
    CLKSEL = 0x01;
    OSCICN = 0x00;
    SFRPAGE = CONFIG_PAGE;
    PLL0CN = 0x04;
    SFRPAGE = LEGACY_PAGE;
    FLSCL
            = 0x10;
    SFRPAGE = CONFIG_PAGE;
    PLL0CN = 0 \times 01;
    PLL0DIV = 0x04;
    PLL0FLT = 0x01;
    PLLOMUL = 0x09;
    for (i=0; i < 256; i++);
    PLLOCN = 0x02;
```

```
while (!(PLL0CN & 0x10));
    CLKSEL = 0x02;
   SFRPAGE = SFRPAGE\_SAVE;
                                         // Restore SFR page
}
// PORT_Init
// Configure the Crossbar and GPIO ports
void PORT_INIT(void)
    char SFRPAGE_SAVE;
    SFRPAGE\_SAVE = SFRPAGE;
                                         // Save Current SFR page
    SFRPAGE = CONFIG_PAGE;
            = 0x04;
   XBR0
                                         // Enable UART0
    XBR1
             = 0x00;
   XBR2 = 0x40;
                                         // Enable Crossbar and weak pull-up
   POMDOUT \mid = 0 \times 01;
                                         // Set TX0 on P0.0 pin to push-pull
   P1MDOUT \mid = 0x40;
                                         // Set green LED output P1.6 to push-
   SFRPAGE = SFRPAGE\_SAVE;
                                         // Restore SFR page
}
// UART0_Init
// Configure the UARTO using Timer1, for <baudrate> and 8-N-1
void UART0_INIT(void)
    char SFRPAGE_SAVE;
                                         // Save Current SFR page
    SFRPAGE\_SAVE = SFRPAGE;
   SFRPAGE = TIMER01\_PAGE;
   TMOD &= ^{\circ}0xF0;
   TMOD
         = 0x20;
                                         // Timer1, Mode 2, 8-bit reload
   TH1 = -(SYSCLK/BAUDRATE/16); // Set Timer1 reload baudrate value T
                                         // Timer1 uses SYSCLK as time base
   CKCON = 0 \times 10;
```

```
TL1
            = TH1;
    TR1
                                          // Start Timer1
            = 1;
    SFRPAGE = UARTO_PAGE;
    SCON0
            = 0x50;
                                          // Mode 1, 8-bit UART, enable RX
    SSTA0
            = 0x10;
                                          // SMOD0 = 1
            = 1;
    TI0
                                          // Indicate TX0 ready
    SFRPAGE = SFRPAGE\_SAVE;
                                          // Restore SFR page
}
    Part 3
5.4
// Hello.c
//8051 Test program to demonstrate serial port I/O. This program writes a model of the serial port I/O.
//the console using the printf() function, and reads characters using the get
//function. An ANSI escape sequence is used to clear the screen if a '2' is
//A '1' repeats the message and the program responds to other input character
//an appropriate message.
//Any valid keystroke turns on the green LED on the board; invalid entries tu
// Includes
\#include < c8051f120.h >
#include <stdio.h>
#include "putget.h"
// Global Constants
#define EXTCLK
                     22118400
                                          // External oscillator frequency in H
#define SYSCLK
                     49766400
                                          // Output of PLL derived from (EXTCLE
#define BAUDRATE
                     115200
                                          // UART baud rate in bps
// Function Prototypes
void main(void);
void SYSCLK_INIT(void);
void PORT_INIT(void);
void UART0_INIT(void);
```

```
// MAIN Routine
void main (void)
    //char choice;
        unsigned char port1;
   WDTCN = 0xDE;
                                          // Disable the watchdog timer
   WDTCN = 0xAD;
    PORT_INIT();
                                          // Initialize the Crossbar and GPIO
                                          // Initialize the oscillator
    SYSCLK_INIT();
    UARTO_INIT();
                                          // Initialize UARTO
   SFRPAGE = UARTO_PAGE;
                                          // Direct output to UART0
        printf("\setminus 033[2J");
                                              // Clear screen and reset curosr
        P2 = 0xF0;
        printf ("Starting value P2 = 0x\%02x \n\r", P2);
                port1 = P1;
                P2 = port1;
        }
}
// SYSCLK_Init
// Initialize the system clock to use a 22.1184MHz crystal as its clock source
void SYSCLK_INIT(void)
    int i;
    char SFRPAGE_SAVE;
   SFRPAGE\_SAVE = SFRPAGE;
                                          // Save Current SFR page
   SFRPAGE = CONFIG_PAGE;
   OSCXCN = 0x67;
                                          // Start ext osc with 22.1184MHz crys
    for (i=0; i < 256; i++);
                                          // Wait for the oscillator to start u
    while (!(OSCXCN \& 0x80));
    CLKSEL = 0x01;
```

```
OSCICN = 0x00;
    SFRPAGE = CONFIG_PAGE;
    PLLOCN = 0x04;
    SFRPAGE = LEGACY_PAGE;
    FLSCL
          = 0x10;
    SFRPAGE = CONFIG_PAGE;
    PLLOCN = 0x01;
    PLL0DIV = 0x04;
    PLL0FLT = 0x01;
    PLL0MUL = 0x09;
    for (i=0; i < 256; i++);
    PLL0CN = 0x02;
    while (!(PLL0CN & 0x10));
    CLKSEL = 0x02;
   SFRPAGE = SFRPAGE\_SAVE;
                                        // Restore SFR page
}
// PORT_Init
// Configure the Crossbar and GPIO ports
void PORT_INIT(void)
    char SFRPAGE_SAVE;
    SFRPAGE\_SAVE = SFRPAGE;
                                          // Save Current SFR page
   SFRPAGE = CONFIG_PAGE;
    XBR0
                                          // Enable UART0
             = 0x04;
    XBR1
             = 0x00;
    XBR2
             = 0x40;
                                          // Enable Crossbar (XBARE) and weak p
   POMDOUT \mid = 0x01;
                                          // Set TX0 on P0.0 pin to push-pull
        P2MDOUT = 0xFF;
                                                                   // Set port 2
        P1MDOUT = 0 \times 00;
                                              // Set port 1 to open-drain
   SFRPAGE = SFRPAGE\_SAVE;
                                         // Restore SFR page
}
// UART0_Init
```

```
// Configure the UARTO using Timer1, for <baudrate> and 8-N-1
void UART0_INIT(void)
    char SFRPAGE_SAVE;
                                         // Save Current SFR page
    SFRPAGE\_SAVE = SFRPAGE;
   SFRPAGE = TIMER01\_PAGE;
   TMOD
           \&= ^{\circ}0xF0;
   TMOD
           = 0x20;
                                         // Timer1, Mode 2, 8-bit reload
           = -(SYSCLK/BAUDRATE/16);
   TH1
                                         // Set Timer1 reload baudrate value T
   CKCON
                                         // Timer1 uses SYSCLK as time base
          = 0x10;
    TL1
            = TH1;
    TR1
            = 1;
                                         // Start Timer1
   SFRPAGE = UARTO_PAGE;
    SCON0
           = 0x50;
                                         // Mode 1, 8-bit UART, enable RX
    SSTA0
            = 0x10;
                                         // SMOD0 = 1
    TI0
            = 1;
                                         // Indicate TX0 ready
   SFRPAGE = SFRPAGE\_SAVE;
                                         // Restore SFR page
}
```

6 References