WEEK 3 LESSON 2 CHAPTER 4 PART-2

BASIC ARITHMETIC INSTRUCTIONS

PREPARED BY

AHMED AL MAROUF

LECTURER

DEPT. OF CSE

DAFFODIL INTERNATIONAL UNIVERSITY



OUTLINE

- Few Basic Instructions (Revising)
- Arithmetic Instructions
- Translation of High-level Language to Assembly Language
- Related Exercises



FEW BASIC INSTRUCTIONS

MOV instruction:

The MOV instruction is used to transfer data between registers, between a register and a memory location, or to move a number directly into a register or memory location.

Syntax: MOV destination, source

Example:

MOV AX, WORD I; moving the value/content of word I into AX

MOV AX, BX ; moving the content of BX register into AX

MOV AX, 'A'; moving the ASCII value (41h) of character 'A'



SWAPPING/EXCHANGING CONTENTS OF TWO REGISTERS

- Lets say AX contains 1234h and BX contains 5678h. How we have to swap/exchange the values of AX and BX.
- Possible way to do this: Using another register (CX or DX) for temporary use

MOV CX,AX

MOV AX, BX


MOV BX, CX



XCHG INSTRUCTION

Syntax: XCHG destination, source

Example: XCHG AH, BL



To do the same task of the last swapping example,

we can simply write,

XCHG AX, BX



ARITHMETIC INSTRUCTIONS

- Basic arithmetic operations can be performed in 8086.
- For Addition, Subtraction, Increment, Decrement, Negation, in 8086 we have separate instructions.
- "ADD" instruction is used for adding two values/contents of registers.

Syntax:


ADD destination, source

 Content of destination is added with the content of source and the result is stored in destination operand.

Example: ADD WORD1, AX

Content of WORD1 is added with the content of AX and the result is stored in WORD1.

ADD WORD1, AX





ADDITION INSTRUCTION

Legal and illegal ADD instructions:

Case I:

```
ILLEGAL: ADD BYTE1, BYTE2

A solution is to move BYTE2 to a register before adding, thus

MOV AL, BYTE2

; AX gets BYTE2

; add it to BYTE1
```

Case 2:

ADD 5, AX; Illegal instruction

Reason: As the destination operand is not a register or memory location. It is an immediate value, which cannot store contents.



SUBTRACTION INSTRUCTION

SUB destination, source


The content of source operand is subtracted from the content of destination operand and the result is stored in the destination operand.

Example:

SUB AX, DX

This instruction will do AX-DX and the result will be stored in AX register.


SUB AX, DX






INCREMENT & DECREMENT INSTRUCTIONS

INC Word1



Just like i++ and i-- operations in C programming

DEC Byte1



NEGATION INSTRUCTION


- "NEG" is used to negate the contents of the destination,
- NEG does this by replacing the contents by its two's complement.

Syntax: NEG destination

The destination may be a register or memory

Example: NEG BX

This instruction will negate the content of BX.



TRANSLATION OF HIGH-LEVEL LANGUAGE TO ASSEMBLY LANGUAGE

- Statements given in high-level language (i.e. C, C++, JAVA) are to be converted into assembly language instruction.
- Using only MOV, XCHG, ADD, SUB, INC, DEC, NEG instructions.

Example 1:	Statement	Translation	
	B = A	MOV AX, A	;move A into AX
	,	MOV B, AX	; and then into B
Example 2:	A = 5 - A	MOV AX,5	;put 5 in AX
		- SUB AX, A	:AX contains 5 - A
		MOV A, AX	aput it in A

Alternate Solution:

NEG A.
ADD A, 5

A = -AA = 5 - A



DO EXERCISE

- Chapter 4 Exercise 6
 - 6. Using only MOV, ADD, SUB, INC, DEC, and NEG, translate the following high-level language assignment statements into assembly language. A, B, and C are word variables.
 - a. A = B A
 - b. A = -(A + 1)
 - c.- C = A + B
 - d. $B = 3 \times B + 7$
 - e. A = B A 1

THANK YOU

