## MiniSys 的 31 条指令

助记符							示例	示例含义	
BIT #	3126	2521	2016	1511	106	50	71 V3	7,1117	♪
R-类型	ор	rs	rt	rd	shamt	func			
	000000	rs	rt	rd	00000		add \$1,\$2,\$3	\$1=\$2+S3	(rd) ← (rs)+(rt); rs=\$2,rt=\$3,rd=\$1
addu	000000	rs	rt	rd	00000		addu \$1,\$2,\$3	\$1=\$2+S3	(rd)←(rs)+(rt); rs=\$2,rt=\$3,rd=\$1,无符号数
sub	000000	rs	rt	rd	00000	100010	sub \$1,\$2,\$3	\$1=\$2-S3	(rd)←(rs)-(rt); rs=\$2,rt=\$3,rd=\$1
subu	000000	rs	rt	rd	00000	100011	subu \$1,\$2,\$3	\$1=\$2-S3	(rd)←(rs)-(rt); rs=\$2,rt=\$3,rd=\$1,无符号数
and	000000	rs	rt	rd	00000	100100	and \$1,\$2,\$3	\$1=\$2&S3	(rd)←(rs)&(rt); rs=\$2,rt=\$3,rd=\$1
OF	000000	rs	rt	rd	00000	100101	or \$1,\$2,\$3	\$1=\$2 S3	(rd)←(rs)   (rt); rs=\$2,rt=\$3,rd=\$1
xor	000000	rs	rt	rd	00000	100110	xor \$1,\$2,\$3	\$1=\$2^S3	(rd) (rs)^(rt); rs=\$2,rt=\$3,rd=\$1
nov	000000	rs	rt	rd	00000	100111	nor \$1,\$2,\$3	\$1=~(\$2   S3)	(rd) ←~((rs)   (rt)); rs=\$2,rt=\$3,rd=\$1
slt	000000	rs	rt	rd	00000	101010	slt \$1,\$2,\$3	if(\$2<\$3) \$1=1 else \$1=0	if (rs< rt) rd=1 else rd=0;rs=\$2, rt=\$3, rd=\$1
sltu	000000	rs	rt	rd	00000	101011	sltu \$1,\$2,\$3	if(\$2<\$3) \$1=1 else \$1=0	if (rs< rt) rd=1 else rd=0;rs=\$2,rt=\$3, rd=\$1, 无符号数
sll 🗸	000000	00000	rt	rd	shamt	000000	sl1 \$1,\$2,10	\$1=\$2<<10	(rd)←(rt)< <shamt,rt=\$2,rd=\$1,shamt=10< td=""></shamt,rt=\$2,rd=\$1,shamt=10<>
srl	900000	00000	rt	rd	shamt	000010	srl \$1,\$2,10	\$1=\$2>>10	(rd) ← (rt)>>shamt, rt=\$2, rd=\$1, shamt=10, (逻辑右移) (rd) ← (rt)>>shamt, rt=\$2, rd=\$1, shamt=10,
sra	000000	00000	rt	rd	shamt	000011	sra \$1,\$2,10	\$1=\$2>>10	(算术右移,注意符号位保留)
sllv	000000	rs	rt	rd	00000	000100	sllv \$1,\$2,\$3	\$1=\$2<<\$3	(rd) (rt) << (rs), rs=\$3,rt=\$2,rd=\$1
srlv	000000	rs	rt	rd	00000	000110	srlv \$1,\$2,\$3	\$1=\$2>>\$3	(rd)←(rt)>>(rs), rs=\$3,rt=\$2,rd=\$1, (逻辑右移)
srav	000000	rs	rt	rd	00000	000111	srav \$1,\$2,\$3	\$1=\$2>>\$3	(rd)←(rt)>>(rs), rs=\$3,rt=\$2,rd=\$1, (算术右移, 注意符号位保留)
jr	000000	rs	00000	00000	00000	001000	jr \$31	goto \$31	(PC)←(rs)
I-类型	op	rs	rt immediate						
	001000	rs	rt	immediate		addi \$1,\$2,10	\$1=\$2+10	$(rt) \leftarrow (rs) + (sign-extend) immediate, rt = $1, rs = $2$	
addiu	901001	rs	rt	immediate		addiu \$1,\$2,10	\$1=\$2+10	$(rt) \leftarrow (rs) + (sign-extend) immediate, rt = \$1, rs = \$2$	
andi	001100	rs	rt		immediate		andi \$1,\$2,10	\$1=\$2&10	(rt)←(rs)&(zero-extend)immediate,rt=\$1,rs=\$2
ori	001101	rs	rt	immediate		ori \$1,\$2,10	\$1=\$2 10	$(rt) \leftarrow (rs)   (zero-extend) immediate, rt = $1, rs = $2$	
xori	001110	rs	rt	immediate		xori \$1,\$2,10	\$1=\$2^10	(rt)←(rs)^(zero-extend)immediate,rt=\$1,rs=\$2 (rt)←immediate<<16 & 0FFFF0000H,将 16 位	
lui	901111	00000	rt	immediate			lui \$1,10	\$1=10*65536	立即数放到目的寄存器高 16 位,目的寄存器的低 16 位填 0
lw	100011	rs	rt	offset			lw \$1,10(\$2)	\$1=Memory[ \$2+10]	(rt)←Memory[(rs)+(sign_extend)offset], rt=\$1,rs=\$2
sw	101011	rc	a-rt	offset			sw \$1,10(\$2)	Memory[ \$2+10] =\$1	Memory[(rs)+(sign_extend)offset] $\leftarrow$ (rt), rt=\$1,rs=\$2
	01011	rs	rt						
beq	000100	rs	rt		offset		beq \$1,\$2,40	if(\$1=\$2) goto PC+4+40	if ((rt)=(rs)) then (PC) $\leftarrow$ (PC)+4+( (Sign-Extend) offset<<2), rs= $\$1$ , rt= $\$2$
					offset offset		beq \$1,\$2,40 bne \$1,\$2,40	goto PC+4+40 if( $\$1 \neq \$2$ )	offset<<2), rs= $$1$ , rt= $$2$ if ((rt) $\neq$ (rs)) then (PC) $\leftarrow$ (PC)+4+(
	000100	rs	rt	i		e	•	goto PC+4+40 if( $\$1 \neq \$2$ )	offset<<2), rs=\$1, rt=\$2
bne	000100	rs	rt rt		offset		bne \$1,\$2,40	goto PC+4+40 if( $\$1 \neq \$2$ ) goto PC+4+40 if( $\$2 < 10$ ) \$1=1 else	offset<<2), rs=\$1, rt=\$2 if ((rt) $\neq$ (rs)) then (PC)+(PC)+4+( (Sign-Extend) offset<<2), rs=\$1, rt=\$2 if ((rs)<(Sign-Extend)immediate) then (rt)+1; else (rt)+0, rs=\$2, rt=\$1
bne slti	000100 000101 001010	rs rs	rt rt		offset		bne \$1,\$2,40 slti \$1,\$2,10	goto PC+4+40 if( $\$1 \neq \$2$ ) goto PC+4+40 if( $\$2 < 10$ ) \$1=1 else \$1=0 if( $\$2 < 10$ ) \$1=1 else	offset<<2), rs=\$1, rt=\$2 if ((rt) $\neq$ (rs)) then (PC)+(PC)+4+( (Sign-Extend) offset<<2), rs=\$1, rt=\$2 if ((rs)<(Sign-Extend)immediate) then (rt)+1; else (rt)+0, rs=\$2, rt=\$1 if ((rs)<(Zero-Extend)immediate) then (rt)+1;
bne slti	000100 000101 001010	rs rs	rt rt	i	offset		bne \$1,\$2,40 slti \$1,\$2,10	goto PC+4+40 if( $\$1 \neq \$2$ ) goto PC+4+40 if( $\$2 < 10$ ) \$1=1 else \$1=0 if( $\$2 < 10$ ) \$1=1 else	offset<<2), rs=\$1, rt=\$2 if ((rt) $\neq$ (rs)) then (PC)+(PC)+4+( (Sign-Extend) offset<<2), rs=\$1, rt=\$2 if ((rs)<(Sign-Extend)immediate) then (rt)+1; else (rt)+0, rs=\$2, rt=\$1 if ((rs)<(Zero-Extend)immediate) then (rt)+1;