

TECHNISCHE UNIVERSITÄT BERGAKADEMIE FREIBERG

PERSONAL PROGRAMMING PROJECT

Implementation of Iso-geometric Analysis (IGA) for Piezoelectric Material

Vikas Diddige 64041

Supervised by Dr. SERGII KOZINOV

Contents

1	\mathbf{Intr}	Introduction 3							
	1.1	Advantages of IGA over FEA	4						
2	B-Splines								
	2.1	Order	4						
	2.2	Knot vector	5						
	2.3	Control points	7						
	2.4	B-Spline basis functions	7						
		2.4.1 Properties	7						
		2.4.2 Derivatives	8						
	2.5	B-Spline curves	8						
	2.6	B-Spline surfaces	8						
		2.6.1 Derivatives	9						
3	Nor	Uniform Rational B-Splines	9						
•	3.1	NURBS basis functions	9						
	0.1		10						
	3.2	NURBS Curves	10						
	0.2		11						
	3.3	*	11						
	3.4		12						
4	Imp	elementation Procedure for IGA	12						
4	4.1	Pre-processing Stage of the Analysis	13						
	4.1		13						
			13						
		4.1.3 Boundary Conditions							
	4.2	Processing Stage of the Analysis							
	4.2	Post-processing Stage of the Analysis	16						
_	7. <i>(</i>		4 =						
5		chanical Case	17						
	5.1	0 1	17						
	5.2	Weak Formulation							
	5.3	IGA Formulation	18						
6	Piez	zoelectric Case	19						
	6.1	Governing Equations for Piezoelectric Materials	19						
	6.2	Weak Formulation	19						
	6.3	IGA Formulation	20						
7	Mod	delling and Results	21						
	7.1	2D Plate with linear elastic loading	21						
		7.1.1 Problem description	21						
		7.1.2 Parametric details for the plate with single element	21						
		7.1.3 Results and discussions	22						
		7.1.4 Conclusion	24						
	7.2	2D Plate with pure Electrical loading	24						
	1.4	7.2.1 Problem description	$\frac{24}{24}$						
		7.2.1 Parametric details for the plate with single element	$\frac{24}{25}$						
		7.2.3 Results and discussions	$\frac{25}{25}$						
		7.2.4 Conclusion	26						

R	efere	nces		34
8	Mile	estones	achieved	33
		7.3.6	Conclusion	33
			Results and discussions	
			elements in y direction	30
		7.3.4	Parametric details for the plate with 3 elements in x direction and 2	
		7.3.3	Conclusion	30
		7.3.2	Results and discussions	27
		7.3.1	Problem description	26
	7.3	2D Pie	zoelectric plate	26

1 Introduction

Among all the numerical methods Finite Element Methods (FEM) are more popularly used to find approximate solutions of partial differential equations. FEM approximates the Computer Aided Drawing (CAD) geometry by discretizing it into smaller geometries called elements. Such geometrical approximations may create numerical errors and seriously effect the accuracy of the solution. Isogeometric analysis (IGA) is a technique to generate geometry using CAD concept of Non Uniform Rational B-Splines (NURBS) and analyse using its basis functions. With the use of NURBS basis functions instead of Lagrangian basis functions the geometry is captured exactly for the analysis and rules out the possibility of the geometrical errors. Moreover, the time from design to analysis phase is greatly reduced saving the cost and time for the industry. The IGA technique is firstly pioneered by Tom Hughes and his group at The University of Texas at Austin.

The present programming project aims at writing a python code to implement IGA for piezoelectric materials which involves electro-mechanical coupling. The coding work involves writing functions for 2D NURBS geometry generation, analysis with different load conditions and post processing of the results using contour plots. The pure mechanical case, electrical case and electro-mechanical coupling has been analysed and results are verified using abaqus results. Comparing the IGA program generated results with abaqus elements output is justified because of the fact that IGA aims at reducing the approximation from traditional FEM proceduers.

1.1 Advantages of IGA over FEA

- The exact representation of the geometry for analysis rules out the possibility of geometrical approximations.
- A huge amount of time and effort involved in finite element modelling can be avoided.

2 B-Splines

In this section a brief description of B-Splines is discussed since NURBS is an extended version of B-Splines. A B-Spline basis function is defined by its order and knot vectors. A B-spline basis function along with control points defines a B-Spline curve. A surface or volume can be generated using a curve by tensor product between basis functions which will be discussed in detail in the future sections.




Figure 1: A B-Spline curve with six control points

2.1 Order

For a point on a B-Spline curve the order of the basis function speaks about the number of nearby control points influence the given point. The degree p of the basis function is one less than the order of the curve. The following figure shows a B-Spline curve with same number and position of control points but with different orders.




Figure 2: B-Spline curves with same control points but different order

2.2 Knot vector

A knot vector is an array with an ascending order of parameter values written as $\Xi = \{\xi_0, \xi_1, \xi_2, \dots, \xi_{n+p}\}$ (ξ_i is called *ith* knot), with n+1 basis functions which will be discussed in later sections. The number of knots in a knot vector is equal to the summation of degree of the curve and total number of control points defining the curve. B-Spline curves are defined in parametric space which is divided by knot spans. Knot vector should be an ascending order of knots. For example $\{0,0,1,1,2,3,3\}$ is valid but not $\{0,0,1,2,3,2,3\}$. There is no difference between $\Xi = \{0,0,0,1,2,3,4,4,4\}$ and $\Xi = \{0,0,0,1/4,2/4,3/4,1,1,1\}$ which can be seen from Fig.(3) because the latter can be obtained by dividing the former by 4.




Figure 3: B-Spline curves showing same trend with different Knot Vectors

The effect of the control points on a B-Spline curve is completely defined by knot vector parameter values as shown in Fig.(4)




Figure 4: B-Spline curves with same control points but with different Knot vectors

2.3 Control points

The co-ordinates and number of the control points determine the shape of the curve and the shape can be varied by altering the knot values in knot vector as discussed in section (2.2). A span on the B-Spline curve is controlled by p+1 number of points. The total number of control points is given by $n_{cp}(\xi) = \text{total number of knots in } [\Xi] - (p+1)$. For an pth degree curve at least p+1 control points have to be defined.

2.4 B-Spline basis functions

For a given Knot vector Ξ , the B-spline basis function for polynomial degree ≥ 1 is defined by a recursive function

$$N_{i,p}(\xi) = \frac{\xi - \xi_i}{\xi_{i+p} - \xi_i} N_{i,p-1}(\xi) + \frac{\xi_{i+p+1} - \xi}{\xi_{i+p+1} - \xi_{i+1}} N_{i+1,p-1}(\xi)$$
(1)

with

$$N_{i,0}(\xi) = \begin{cases} 1 & \text{if } \xi_i \le \xi < \xi_{i+1} \\ 0 & \text{otherwise} \end{cases}$$
 (2)

2.4.1 Properties

- 1. $N_{i,0}(\xi)$ is a step wise function with a value 1 over the half open interval $\xi \in [\xi_i \le \xi < \xi_{i+1})$ and zero on the rest.
- 2. Basis functions sum up to to unity $\sum_{i=0}^n N_{i,p}(\xi) = 1$
- 3. Basis functions are non-negative $N_{i,p}(\xi) \geq 0$ over the entire domain

4. ******** Write more********




Figure 5:

Second degree B-Spline functions with a uniform knot vector

2.4.2 Derivatives

The first derivative of a B-Spline basis function with its variable ξ is given by

$$\frac{d}{d\xi}N_{i,p}(\xi) = \frac{p}{\xi_{i+p} - \xi_i}N_{i,p-1}(\xi) - \frac{p}{\xi_{i+p+1} - \xi_{i+1}}N_{i+1,p-1}(\xi)$$
(3)

Higher order derivatives are not necessary for IGA formulation.

2.5 B-Spline curves

A pth-degree B-Spline curve with a set of control points P_i is given by

$$C(\xi) = \sum_{i=0}^{n} N_{i,p}(\xi) P_i \qquad \xi_0 \le \xi \le \xi_{n+p}$$
 (4)

defined on the knot vector $\Xi = \{\xi_0, \xi_1, \xi_2, \dots, \xi_{n+p}\}$

2.6 B-Spline surfaces

A B-Spline surface $S(\xi, \eta)$ is built by tensor product between B-Spline curves along each parametric direction (ξ, η) . It requires knot vectors $(\Xi = \{\xi_0, \xi_1, \xi_2, \dots, \xi_{n+p}\}, H = \{\eta_0, \eta_1, \eta_2, \dots, \eta_{m+q}\})$ along each parametric direction and control net $P_{i,j}$




Figure 6: A B-Spline surface with control points net

$$S(\xi, \eta) = \sum_{i=0}^{n} \sum_{j=0}^{m} N_{i,p}(\xi) N_{j,q}(\eta) P_{i,j}$$
(5)

where p,q are the degrees of the B-Spline basis functions along ξ, η respectively and n,m are number of control points along ξ, η respectively. Eq. (6) can be compactly written as

$$S(\xi, \eta) = \sum_{i=0}^{n} \sum_{j=0}^{m} N_{i,j}^{p,q}(\xi, \eta) P_{i,j}$$
(6)

2.6.1 Derivatives

The partial derivatives of bivariate B-Spline basis functions w.r.t parametric co-ordinates is given as

$$\frac{\partial N_{i,j}^{p,q}(\xi,\eta)}{\partial \xi} = \frac{d}{d\xi} \left(N_{i,p}(\xi) \right) N_{j,q}(\eta) \qquad \frac{\partial N_{i,j}^{p,q}(\xi,\eta)}{\partial \eta} = \frac{d}{d\eta} \left(N_{j,q}(\eta) \right) N_{i,p}(\xi) \tag{7}$$

3 Non Uniform Rational B-Splines

NURBS are very often used in computer-aided design(CAD), manufacturing (CAM) and engineering (CAE) due to its flexibility to represent complex geometries. NURBS curves and surfaces are considered as the generalization of B-Spline and Bezier curves and surfaces. A NURBS basis function is defined by its order and knot vector.

3.1 NURBS basis functions

NURBS basis functions $R_{i,p}(\xi)$ are defined as

$$R_{i,p}(\xi) = \frac{N_{i,p}(\xi)w_i}{\sum_{i=0}^{n} N_{i,p}(\xi)w_i}$$
(8)

where $N_{i,p}(\xi)$ is the *i*th B-Spline basis function with order p and w_i denotes weight of the *i*th control point (P_i) . ***** Explain weights with help of an example****. When $w_i = constant \quad \forall i$ the NURBS basis function reduces to B-Spline basis function.

The usage of weights can be illustrated in Fig.(7). The same circle can be drawn with different number of control points by altering their weights.




Figure 7: NURBS circle with different control points and weights

3.1.1 Derivatives

The first derivative of a NURBS basis function with its variable ξ is given by

$$\frac{d}{d\xi}R_{i,p}(\xi) = \frac{N'_{i,p}(\xi)W(\xi) - N_{i,p}(\xi)W'(\xi)}{W^{2}(\xi)}w_{i}$$
(9)

where $N'_{i,p}(\xi) = \frac{d}{d\xi} N_{i,p}(\xi)$

and
$$W'(\xi) = \sum_{i=0}^{n} N'_{i,p}(\xi) w_i$$

3.2 NURBS Curves

The p^{th} degree NURBS curve is given by

$$C(\xi) = \frac{\sum_{i=0}^{n} N_{i,p}(\xi)w_i P_i}{\sum_{i=0}^{n} N_{i,p}(\xi)w_i} \qquad \xi_0 \le \xi \le \xi_{n+p}$$
 (10)

in short form

$$C(\xi) = \sum_{i=0}^{n} R_{i,p}(\xi) P_i$$
(11)

****refer NURBS book and write more info*****

A NURBS curve with different weights on control points along with its basis function is shown in Fig.(8)




Figure 8: $\Xi = \{0,0,0,0,1,2,3,4,4,4,4\}, w = \{1,1,1,3,1,1,1\}$ (a) A third degree NURBS curve; (b) Associated NURBS basis functions

3.2.1 Properties

- 1. NURBS basis functions sum up to to unity $\sum_{i=0}^n R_{i,p}(\xi) = 1$
- 2. NURBS basis functions are non-negative $R_{i,p}(\xi) \geq 0$ over the entire domain
- 3. $R_{0,p}(0) = R_{n,p}(1) = 1$
- 4. For $w_i = 1$ for all i, NURBS basis functions $R_i(\xi)$ reduces B-Spline basis functions $N_i(\xi)$

3.3 NURBS Surfaces and solids

NURBS Surfaces and solids are generated by the tensor product between NURBS curve basis functions.

1. NURBS Surfaces:

A NURBS surface with degree p in ξ direction and degree q in η direction is defined as

$$S(\xi, \eta) = \sum_{i=0}^{n} \sum_{j=0}^{m} R_{i,j}^{p,q}(\xi, \eta) P_{i,j}$$
(12)

where the bivariate NURBS basis functions are given by

$$R_{i,j}^{p,q}(\xi,\eta) = \frac{N_{i,p}(\xi)N_{j,q}(\eta)w_{i,j}}{\sum_{i=0}^{n}\sum_{j=0}^{m}N_{i,p}(\xi)N_{j,q}(\eta)w_{i,j}}$$
(13)

2. NURBS Solids:

A NURBS solid with degree p, q, k in ξ, η, ζ directions respectively is defined as

$$S(\xi, \eta, \zeta) = \sum_{i=0}^{n} \sum_{j=0}^{m} \sum_{k=0}^{l} R_{i,j,k}^{p,q,r}(\xi, \eta, \zeta) P_{i,j,k}$$
(14)

where the $R_{i,j,k}^{p,q,r}(\xi,\eta,\zeta)$ is given by

$$R_{i,j,k}^{p,q,r}(\xi,\eta,\zeta) = \frac{N_{i,p}(\xi)N_{j,q}(\eta)N_{k,l}(\zeta)w_{i,j,k}}{\sum_{i=0}^{n}\sum_{j=0}^{m}\sum_{k=0}^{l}N_{i,p}(\xi)N_{j,q}(\eta)N_{k,r}(\zeta)w_{i,j,k}}$$
(15)

refer NURBS book and write more info

3.4 Derivatives of NURBS bivariate Basis Functions

The first partial derivatives of NURBS bivariate basis function are given by

$$\frac{\partial R_{i,j}^{p,q}}{\partial \xi} = \frac{N_{i,p}' N_{j,q} W - N_{i,p} N_{j,q} W_{\xi}'}{W^2} w_{i,j}$$
 (16)

$$\frac{\partial R_{i,j}^{p,q}}{\partial n} = \frac{N_{i,p} N_{j,q}' W - N_{i,p} N_{j,q} W_{\eta}'}{W^2} w_{i,j}$$
(17)

where

$$W = \sum_{i=0}^{n} \sum_{j=0}^{m} N_{i,p} N_{j,q} w_{i,j}$$
(18)

$$W'_{\xi} = \sum_{i=0}^{n} \sum_{j=0}^{m} N'_{i,p} N_{j,q} w_{i,j}$$
(19)

$$W'_{\eta} = \sum_{i=0}^{n} \sum_{j=0}^{m} N_{i,p} N'_{j,q} w_{i,j}$$
(20)

The first partial derivatives of the trivariate basis functions can be computed in a similar manner as bivariate basis functions using a chain rule.

4 Implementation Procedure for IGA

This section describes step-by-step implementation of the Isogeometric analysis. A modified FEM code structure can be used to implement IGA. Similar to FEM, IGA can be divided into pre-processing, processing and post-processing stages. The stages in an IGA analysis is shown with the help of an flow chart (Fig.9)




Figure 9: Flow chart describing Pre-processing Stage of IGA

4.1 Pre-processing Stage of the Analysis

This subsection mainly deals with NURBS based geometry creation, types of assembly arrays needed to assemble discretized geometries and how to deal with homogeneous and non-homogeneous boundary conditions on boundary defining control points due to their higher (C^{p-1}) continuity unlike C^0 continuity of FEM nodes.

4.1.1 Geometry Creation

As mentioned before in the section 3, the construction of NURBS discretized geometry requires parametric details such as control points, knot vectors and the order of the NURBS curve. Commercial softwares like "Rhino" can be used to extract parametric details of the complex NURBS geometry.

4.1.2 Assembly arrays

Assembly arrays are required to assemble local discretized geometries to global geometry. For IGA as knot vector and control points defines the geometry two assembly arrays (1) Control point assembly array and (2) Knot vector connectivity array are required.

1. Control point assembly array:

The degree of the NURBS curve determines the number of control points (n_{cp}^e) present in an IGA element. Considering a three-dimensional element (Ω^e)

$$n_{cp}^{e} = (p+1)(q+1)(r+1)$$

The details of the control points are stored row wise in assembly array. ***This can be illustrated with an example below

2. Knot vector connectivity array:

The knot vector connectivity matrix is a row wise matrix with each row corresponds to respective element's knot spans. The columns corresponds to span ranges along ξ, η and ζ directions. ***This can be illustrated with an example below

4.1.3 Boundary Conditions

A brief description on how to define boundary conditions (BCS) is described in this section. When the number of control points in each element in each direction equals the degree of the curve plus one in respective direction, a traditional way of defining homogeneous and inhomogeneous boundary conditions can be followed. In any other case a special treatment for defining BCS have to be followed which is not in the scope of this project. Procedures like least square minimization method are usually adopted for this purpose.

4.2 Processing Stage of the Analysis

In the processing stage of analysis it is required to compute global elemental stiffness matrix and global force vector and solve these for the solution field. To formulate these matrices it requires NURBS basis functions and their derivatives evaluation. Numerical integration scheme like Gauss-Legendre rule is employed to solve the volume and area integrals involved in forming the stiffness matrix and internal force vector. Numerical integration involves mapping elements from physical space to master space (which is also called unit domain). As NURBS basis functions are defined in parametric space as given in Eq. ()it requires an additional mapping from physical space to parametric space ($\Omega_e \to \widetilde{\Omega_e}$). Later parametric space can be mapped on to master space ($(\widetilde{\Omega_e} \to \overline{\Omega_e})$). This procedure is illustrated in Fig.(10).




Figure 10: Mapping IGA Physical element to Master element

1. Mapping from master space to parametric space:

Consider a discretized IGA surface which is defined in parametric space $\widetilde{\Omega}_e = [\xi_i, \xi_{i+1}] \otimes [\eta_i, \eta_{i+1}]$, Refer Fig.(). The NURBS basis functions and their derivatives are evaluated at ξ, η of the element $\widetilde{\Omega}_e$. These ξ, η co-ordinate values are calculated by a linear mapping as shown below

$$\xi = \frac{1}{2} [(\xi_{i+1} - \xi_i)\overline{\xi} + (\xi_{i+1} + \xi_i)]$$
(21)

$$\eta = \frac{1}{2} [(\eta_{i+1} - \eta_i)\overline{\eta} + (\eta_{i+1} + \eta_i)]$$
(22)

where $\bar{\xi}, \bar{\eta}$ are the integration points defined in master space \mathbf{J}_2 matrix is defined as

$$\mathbf{J}_2 = \frac{\partial \xi}{\partial \bar{\xi}} \frac{\partial \eta}{\partial \bar{\eta}} \tag{23}$$

Determinant of J_2 matrix is required in numerical integration scheme for linear mapping

2. Mapping from physical space to parametric space: The Jacobian matrix \mathbf{J}_1 used to map from physical space to parametric space $(\Omega_e \to \widetilde{\Omega_e})$ is computed as:

$$\mathbf{J}_1 = \begin{bmatrix} \frac{\partial x}{\partial \xi} & \frac{\partial x}{\partial \eta} \\ \frac{\partial y}{\partial \xi} & \frac{\partial y}{\partial \eta} \end{bmatrix} \tag{24}$$

The components of the J_1 matrix are calculated using Eq. (32).

$$\frac{\partial x}{\partial \xi} = \sum_{k=1}^{n_{cp}^e} \frac{\partial \mathbf{R}_k}{\partial \xi} x_i \qquad \frac{\partial x}{\partial \eta} = \sum_{k=1}^{n_{cp}^e} \frac{\partial \mathbf{R}_k}{\partial \eta} x_i \tag{25}$$

$$\frac{\partial y}{\partial \xi} = \sum_{k=1}^{n_{cp}^e} \frac{\partial \mathbf{R}_k}{\partial \xi} y_i \qquad \frac{\partial y}{\partial \eta} = \sum_{k=1}^{n_{cp}^e} \frac{\partial \mathbf{R}_k}{\partial \eta} y_i \tag{26}$$

The two different mappings described above can be illustrated with an example considering $\mathbf{F}(x,y)$ integrated over the physical space Ω

$$\begin{split} \int_{\Omega} \mathbf{F}(x,y) d\Omega &= \sum_{e=1}^{nel} \int_{\Omega_e} \mathbf{F}(x,y) d\Omega \\ &= \sum_{e=1}^{nel} \int_{\overline{\Omega_e}} \mathbf{F}(\xi,\eta) |\mathbf{J}_1| d\xi d\eta \\ &= \sum_{e=1}^{nel} \int_{\overline{\Omega_e}} \mathbf{F}(\overline{\xi},\overline{\eta}) |\mathbf{J}_1| |\mathbf{J}_2| d\overline{\xi} d\overline{\eta} \\ &= \sum_{e=1}^{nel} \int_{-1}^{1} \int_{-1}^{1} \mathbf{F}(\overline{\xi},\overline{\eta}) |\mathbf{J}_1| |\mathbf{J}_2| d\overline{\xi} d\overline{\eta} \\ &= \sum_{e=1}^{nel} \left[\sum_{i=1}^{n_{gp}^e} \mathbf{F}(\overline{\xi}_i,\overline{\eta}_i) gw_i |\mathbf{J}_1| |\mathbf{J}_2| d\overline{\xi} d\overline{\eta} \right] \end{split}$$

where nel is the total number of elements and n_{gp}^e , gw_i denotes the number of Gauss points and their respective Gauss weights.

The formulated global stiffness matrix and force vector are solved using numerical scheme like Newton-Raphson method for the solution field.

A flow chart describing processing stage flow is shown in Fig.(11)




Figure 11: Flow chart describing Processing Stage of IGA

4.3 Post-processing Stage of the Analysis

This section deals with visualization of the deformed geometry and how a displacement and solution dependent variables are plotted.

1. Visualization of the deformed NURBS geometry:

Visualization of the deformed geometry will be done in the same manner as the visualization of the initial geometry. After determining the displacement field at control points they are added to the initial control points co-ordinates [P].

$$[\mathbf{P}_{new}] = [\mathbf{P}] + [\mathbf{U}]$$

 $[\mathbf{P}^{new}]$ control points array is used to plot the deformed geometry.

2. Plotting of displacements and solution dependent variables:

A contour plot can be made using the displacement values (U) on deformed or undeformed geometry. Due to the higher continuity of the NURBS basis functions stress recovery techniques are not necessary to extract solution field on the deformed geometry.

Post-Processing Stage




Figure 12: Flow chart describing Post-processing Stage of IGA

5 Mechanical Case

5.1 Governing Equations

The governing equation for mechanical deformation is based on conservation of linear momentum which can be written as

$$\sigma_{ij,i} + b_j = 0 \tag{27}$$

where σ_{ij} and b_i is the Cauchy stress tensor and body force. Due to the static nature of the analysis the inertial term is not included in the eq().

Stress and strain are related by following constitutive equation

$$\sigma_{ij} = c_{ijkl}\epsilon_{kl} \tag{28}$$

The infinitesimal strain theory is adopted for the analysi in which displacements of the material particles are considered to be very small compared to the dimentions of the body under loading. Strain in a small strain setting can be written as

$$\epsilon_{ij} = \frac{1}{2} [u_{i,j} + u_{j,i}] \tag{29}$$

where u_i are the displacements in the body

5.2 Weak Formulation

Consider a domain Ω with Γ_u as prescribed displacements and Γ_t as traction boundary conditions. The domain boundary can be represented as $\Gamma = \Gamma_u \cup \Gamma_t$ and $\Gamma_u \cap \Gamma_t = \Phi$ By using the principle of virtual work the eq() can be written as

$$\delta W = \int_{\Omega} (\sigma_{ij,i} + b_j) \delta u_j dV = 0 \tag{30}$$

with, $u = u_o$ on Γ_u (essential boundary condition) and $\sigma_{ij}n_j = \bar{t}_j$ on Γ_t (natural boundary condition)

where δu_i is the virtual displacement field, n_i is unit normal to the surface

Applying integration by parts to the stress term under integral and by making using of conservation of angular momentum ($\sigma_{ij} = \sigma_{ji}$) and Gauss divergence theorm (converting volume integral to surface integral) we approach at the following equation

$$\delta W = \int_{\Omega} \sigma_{ij} \epsilon_{ij} d\Omega - \left[\int_{\Gamma} \bar{t}_j \delta u_j d\Gamma_t + \int_{\Omega} b_j \delta u_j d\Omega \right]$$
 (31)

as an additional requirement δu_j must be zero at essential boundary conditions (Γ_u) for a unique solution. ***Additional data regarding detailed explanation of steps to derive weak form can be included.

5.3 IGA Formulation

The advantage of IGA over FEM formulation lies in its basis functions incorporation and its ability to capture the exact geometry. While the FEM uses lagrangian basis functions, IGA uses NURBS basis functions which are used to generate the geometry itself. As discussed in the previous sections a multidimentional NURBS basis function is represented by $R_{i,j,k}^{p,q,r}(\xi,\eta,\zeta) \to R_i$. The isogeometric element is represented by basis function R_i and control points P_i as

$$\mathbf{x}^e = \sum_{i=1}^{n_{cp}^e} R_i P_i \tag{32}$$

By Galerkin approach, the displacements and virtual displacements are given by

$$\mathbf{u}^e = \sum_{i=1}^{n_{cp}^e} R_i \mathbf{u}_i \qquad \delta \mathbf{u}^e = \sum_{i=1}^{n_{cp}^e} R_i \delta \mathbf{u}_i$$
 (33)

where \mathbf{u}_i and $\delta \mathbf{u}_i$ are values at ith control point. The strain displacement matrix \mathbf{B} is given by

$$\mathbf{B} = \begin{bmatrix} R_{1,x} & 0 & 0 & R_{2,x} & 0 & 0 & \dots & R_{n_{cp}^e,x} & 0 & 0 \\ 0 & R_{1,y} & 0 & 0 & R_{2,y} & 0 & \dots & 0 & R_{n_{cp}^e,y} & 0 \\ 0 & 0 & R_{1,z} & 0 & 0 & R_{2,z} & \dots & 0 & 0 & R_{n_{cp}^e,z} \\ R_{1,y} & R_{1,x} & 0 & R_{2,y} & R_{2,x} & 0 & \dots & R_{n_{cp}^e,y} & R_{n_{cp}^e,x} & 0 \\ 0 & R_{1,z} & R_{1,y} & 0 & R_{2,z} & R_{2,y} & \dots & 0 & R_{n_{cp}^e,z} & R_{n_{cp}^e,y} \\ R_{1,z} & 0 & R_{1,x} & R_{2,z} & 0 & R_{2,x} & \dots & R_{n_{cp}^e,z} & 0 & R_{n_{cp}^e,x} \end{bmatrix}$$
(34)

By substituting Eqs. (33) and (34) in Eq. (31), the weak form in matrix terms can be written as

$$\sum_{e=1}^{nel} \left[\left(\int_{\Omega_e} \mathbf{B}^T \mathbf{C} \mathbf{B} d\Omega \right) \right] \mathbf{u} = \int_{\Gamma_t^e} \mathbf{R}^T \cdot \mathbf{t} d\Gamma + \int_{\Omega_t^e} \mathbf{R}^T \cdot \mathbf{f} d\Omega$$
 (35)

where R is defined as for the boundary Γ^e

$$\mathbf{R} = \begin{bmatrix} R_1(\xi, \eta) & 0 & R_2(\xi, \eta) & 0 & \dots & R_{n_{cp}^e}(\xi, \eta) & 0 \\ 0 & R_1(\xi, \eta) & 0 & R_2(\xi, \eta) & \dots & 0 & R_{n_{cp}^e}(\xi, \eta) \end{bmatrix}$$
(36)

for the domain Ω^e

$$\mathbf{R} = \begin{bmatrix} R_1(\xi, \eta, \zeta) & 0 & R_2(\xi, \eta, \zeta) & 0 & \dots & R_{n_{cp}^e}(\xi, \eta, \zeta) & 0 \\ 0 & R_1(\xi, \eta, \zeta) & 0 & R_2(\xi, \eta, \zeta) & \dots & 0 & R_{n_{cp}^e}(\xi, \eta, \zeta) \end{bmatrix}$$
(37)

Eq.(35) can be rewritten in a standard matrix form as

$$\sum_{e=1}^{nel} [\mathbf{K}^e \mathbf{U}^e = \mathbf{F}^e] \tag{38}$$

where \mathbf{K}^e is isogeometric element's stiffness matrix, \mathbf{U}^e is displacement vector and \mathbf{F}^e force vector

6 Piezoelectric Case

6.1 Governing Equations for Piezoelectric Materials

The coupled electro-mechanical interactions are governed by conservation of momentum and Gauss's law as:

$$\sigma_{ii,j} + f_i = 0 \tag{39}$$

$$D_{i,i} - q = 0 \tag{40}$$

Where, f_i is body force, q is electrical charge, σ_{ij} is Cauchy stress tensor and D_i is electrical displacement vector. The constitutive equations for electromechanical coupling are defined as

$$\sigma_{ij} = C_{ijkl}\varepsilon_{kl} - e_{kij}E_k \tag{41}$$

$$D_i = e_{ikl}\varepsilon_{kl} + \kappa_{ik}E_k \tag{42}$$

Where, C_{ijkl} , e_{ikj} and ε_{ij} are elastic, piezoelectric and dielectric material constants respectively. The Cauchy stain tensor is defined as:

$$\varepsilon_{ij} = \frac{1}{2}(u_{i,j} + u_{j,i}) \tag{43}$$

and electric field vector as:

$$E_i = -\phi_i \tag{44}$$

6.2 Weak Formulation

Applying the principle of virtual work to the Eq. (39) and Eq. (40) we can write

$$\int_{\Omega} (\sigma_{ij,j} + f_i) \delta u_i d\Omega = 0 \tag{45}$$

$$\int_{\Omega} (D_{i,i} - q)\delta\phi d\Omega = 0 \tag{46}$$

with,

essential boundary conditions: $u = u_o$ on Γ_u and $\Phi = \Phi_0$ on Γ_{Φ} natural boundary condition: $\sigma_{ij}n_j = \bar{t}_j$ on Γ_t and $D_in_i = q_0$ on Γ_q

where δu_i and $\delta \phi$ are virtual or arbitrary displacement and potential fields.

Integrating Eq. (45) and Eq. (46) by parts and later applying Guass divergence theorm and boundary conditions we approach at weak form

$$\int_{\Omega} \sigma_{ij} \delta \epsilon_{ij} d\Omega - \left[\int_{\Gamma} \bar{t}_i \delta u_i d\Gamma + \int_{\Omega} f_i \delta u_i d\Omega \right] = 0$$
(47)

$$\int_{\Omega} D_i \delta E_i d\Omega - \left[\int_{\Gamma} Q \delta \phi d\Gamma + \int_{\Omega} q \delta \phi d\Omega \right] = 0 \tag{48}$$

6.3 IGA Formulation

By Galerkin approach, displacements, potentials and their virtual values are given by below equations

$$\mathbf{u}^e = \sum_{i=1}^{n_{cp}^e} R_i \mathbf{u}_i \qquad \delta \mathbf{u}^e = \sum_{i=1}^{n_{cp}^e} R_i \delta \mathbf{u}_i$$
 (49)

$$\Phi^e = \sum_{i=1}^{n_{cp}^e} R_i \Phi_i \qquad \delta \Phi^e = \sum_{i=1}^{n_{cp}^e} R_i \delta \Phi_i$$
 (50)

where \mathbf{u}_i , $\delta \mathbf{u}_i$, $\delta \Phi_i$ and Φ_i are values at ith control point.

By substituting Eqs, (49) and (50) in Eq.(47) and Eq.(48) the weak form in matrix notation can be written as

$$\begin{bmatrix} K_{MM} & K_{ME} \\ K_{EM} & K_{EE} \end{bmatrix} \begin{bmatrix} \mathbf{u} \\ \phi \end{bmatrix} = \begin{bmatrix} F_M \\ F_E \end{bmatrix}$$
 (51)

Where,

$$K_{MM} = \int_{\Omega} \mathbf{B}_{u}^{T} \mathbf{C} \mathbf{B}_{u} d\Omega \tag{52}$$

$$K_{ME} = \int_{\Omega} \mathbf{B}_{u}^{T} \mathbf{e} \mathbf{B}_{e} d\Omega \tag{53}$$

$$K_{EM} = \int_{\Omega} \mathbf{B}_e^T \mathbf{e}^T \mathbf{B}_u d\Omega \tag{54}$$

$$K_{EE} = -\int_{\Omega} \mathbf{B}_e^T \kappa \mathbf{B}_e d\Omega \tag{55}$$

$$F_M = \int_{\Omega} \mathbf{R}_u^T \mathbf{f} d\Omega + \int_{\Gamma} \mathbf{R}_u^T \mathbf{t} d\Gamma$$
 (56)

$$F_E = \int_{\Omega} \mathbf{R}_e^T q d\Omega + \int_{\Gamma} \mathbf{R}_e^T Q d\Gamma$$
 (57)

where R is defined as for the boundary Γ

$$\mathbf{R}_{u} = \begin{bmatrix} R_{1}(\xi, \eta) & 0 & R_{2}(\xi, \eta) & 0 & \dots & R_{n_{cp}^{e}}(\xi, \eta) & 0 \\ 0 & R_{1}(\xi, \eta) & 0 & R_{2}(\xi, \eta) & \dots & 0 & R_{n_{cp}^{e}}(\xi, \eta) \end{bmatrix}$$
(58)

$$\mathbf{R}_e = \begin{bmatrix} R_1(\xi, \eta) & R_2(\xi, \eta) & \dots & R_{n_{cp}^e}(\xi, \eta) \end{bmatrix}$$
(59)

for the domain Ω

$$\mathbf{R}_{u} = \begin{bmatrix} R_{1}(\xi, \eta, \zeta) & 0 & R_{2}(\xi, \eta, \zeta) & 0 & \dots & R_{n_{cp}^{e}}(\xi, \eta, \zeta) & 0 \\ 0 & R_{1}(\xi, \eta, \zeta) & 0 & R_{2}(\xi, \eta, \zeta) & \dots & 0 & R_{n_{cp}^{e}}(\xi, \eta, \zeta) \end{bmatrix}$$
(60)

$$\mathbf{R}_e = \begin{bmatrix} R_1(\xi, \eta, \zeta) & R_2(\xi, \eta, \zeta) & \dots & R_{n_{cp}^e}(\xi, \eta, \zeta) \end{bmatrix}$$
(61)

B matix is given as

$$\mathbf{B}_{u} = \begin{bmatrix} R_{1,x} & 0 & 0 & R_{2,x} & 0 & 0 & \dots & R_{n_{cp},x} & 0 & 0 \\ 0 & R_{1,y} & 0 & 0 & R_{2,y} & 0 & \dots & 0 & R_{n_{cp},y} & 0 \\ 0 & 0 & R_{1,z} & 0 & 0 & R_{2,z} & \dots & 0 & 0 & R_{n_{cp},z} \\ R_{1,y} & R_{1,x} & 0 & R_{2,y} & R_{2,x} & 0 & \dots & R_{n_{cp},y} & R_{n_{cp},x} & 0 \\ 0 & R_{1,z} & R_{1,y} & 0 & R_{2,z} & R_{2,y} & \dots & 0 & R_{n_{cp},z} & R_{n_{cp},y} \\ R_{1,z} & 0 & R_{1,x} & R_{2,z} & 0 & R_{2,x} & \dots & R_{n_{cp},z} & 0 & R_{n_{cp},x} \end{bmatrix}$$

$$\mathbf{B}_{e} = \begin{bmatrix} R_{1,x} & R_{2,x} & \dots & R_{n_{cp},x} \\ R_{1,y} & R_{2,y} & \dots & R_{n_{cp},y} \\ R_{1,z} & R_{2,z} & \dots & R_{n_{cp},z} \end{bmatrix}$$

$$(62)$$

$$\mathbf{B}_{e} = \begin{bmatrix} R_{1,x} & R_{2,x} & \dots & R_{n_{cp}^{e},x} \\ R_{1,y} & R_{2,y} & \dots & R_{n_{cp}^{e},y} \\ R_{1,z} & R_{2,z} & \dots & R_{n_{cp}^{e},z} \end{bmatrix}$$
(63)

$$\varepsilon = \mathbf{B}_u.\mathbf{u} \tag{64}$$

$$\mathbf{E} = -\mathbf{B}_e.\Phi \tag{65}$$

Eq. (51) can be solved using numerical methods like Newton Raphson scheme for displacements and potential solution field.

7 Modelling and Results

7.1 2D Plate with linear elastic loading

Problem description 7.1.1

A 2D plate is subjected to mechanical loading as shown in Figure (??). The properties of the material are, Young's modulus E = 210GPa and Poisson's ratio $\nu = 0.3$. The movement of bottom edge is fixed in y direction and left edge in x direction. A displacement of 0.1 mm on right edge and 0.2 mm on top edge in x and y directions are given respectively.




Figure 14: 2D Plate with loading

Parametric details for the plate with single element

The 2nd order NURBS curve is used in both ξ and η directions.

1. Physical details for the geometry:

L = 10 # Length of the plate in mm H = 10 # Height of the plate in mm

2. Parametric details of the geometry:

```
\Xi = [0,0,1,1] # Knot vector in xi direction

H = [0,0,1,1] # Knot vector in eta direction
```

Degree of the curve

```
p=1 # Degree of the curve in \xi direction
q=1 # Degree of the curve in \eta direction
```

Number of control points in each direction

$$n_{cp}^{\xi} = \text{len}(\Xi)$$
 - (p+1) #No.of control points in ξ direction (4-(1+1) = 2) #No.of control points in η direction (4-(1+1) = 2)

3. Total number of control points for the geometry

$$n_{cp} = n_{cp}^{\xi} * n_{cp}^{\eta} = 2*2 = 4$$

The control points are given by

i	$P_{i,0}$	$P_{i,1}$
0	(0,0,0,1)	(0, 10, 0, 1)
1	(10,0,0,1)	(10, 10, 0, 1)

with fourth value in the paranthesis being weights of respective control points. As this is the case of single element there is no need for the control point assembly array and knot vector connectivity matrix.

7.1.3 Results and discussions

Abaqus plane strain full integration element (**CPE4**) is used for analysis (CPE4 element is used to verify Program generated IGA results).

The below figures shows the values of displacements (U) and reaction forces (RF) for both abaqus and IGA element.

**A similar contour is used for the program generated results and abaqus results for an easy comparison.

Figure (15) and Figure (16) shows the displacement (U1) values of the single CPE4 element and single IGA element at 100 % loading in x direction respectively.




Figure 15: CPE4 Element:U1 Abaqus generated result

Figure 16: IGA Element:U1 Program generated result

Figure(17) and Figure(18) shows the displacement (U2) values of the single CPE4 element and single IGA element at 100 % loading in y direction respectively.




Figure 17: CPE4 Element:U2

Figure 18: IGA Element:U2

Figure (19) and Figure (20) shows the Reaction force values (RF1) of the single CPE4 element and single IGA element at 100 % loading in x direction respectively.




Figure 19: CPE4 Element:RF1

Figure 20: IGA Element:RF1

Figure(21) and Figure(22) shows the Reaction force values (RF2) of the single CPE4 element and single IGA element at 100 % loading in y direction respectively.




Figure 21: CPE4 Element:RF2

Figure 22: IGA Element:RF2

7.1.4 Conclusion

As shown in figures above the values generated by IGA code are inline with the results of Abaqus element. So it can be concluded that IGA code written works fine for 2D one element case.


7.2 2D Plate with pure Electrical loading

7.2.1 Problem description

A 2D plate is subjected to Electrical loading as shown in Figure (24). The properties of the material are, Young's modulus E=210GPa and Poisson's ratio $\nu=0.3$. The dielectric constants for the material are

$$\varepsilon = \begin{bmatrix} 6.752E - 12 & 0 & 0 \\ 0 & 5.872E - 12 & 0 \\ 0 & 0 & 6.752E - 12 \end{bmatrix} C/(Vmm)$$

The movement of bottom edge is fixed in y direction and left edge in x direction. An electrical potential V of 1000 volts (***Check units) is applied at one node as shown in Fig.(24)






Figure 23: 2D Plate

Figure 24: 2D Plate with pure electrical loading

7.2.2 Parametric details for the plate with single element

The parametric details for the geometry are the same as in section 7.1.2

7.2.3 Results and discussions

Abaqus plane strain full integration element (**CPE4**) is used for analysis (CPE4 element is used to verify Program generated IGA results).

The below figures shows the values of Electrical potentials (EPOT) and reactive electrical nodal charge (RCHG) for both abaqus and IGA element.

**A similar contour is used for the program generated results and abaqus results for an easy comparison.

Figure(25) and Figure(26) shows the Electrical potential (EPOT) values of the single CPE4 element and single IGA element at 100~% loading respectively.




Figure 25: CPE4 Element:U1 Abaqus generated result




Figure 26: IGA Element:U1 Program generated result

Figure (27) and Figure (28) shows the reactive nodal charge (RCHG) values of the single CPE4 element and single IGA element at 100 % loading respectively.




Figure 27: CPE4 Element:U2

Figure 28: IGA Element:U2

7.2.4 Conclusion

As shown in figures above the values generated by IGA code are inline with the results of Abaqus element. So it can be concluded that IGA code written works fine for 2D one element case.

7.3 2D Piezoelectric plate

7.3.1 Problem description

A 2D piezoelectric plate subjected to mechanical displacements and electrical loading is considered as shown in Figure (29). The material used is PZT4 and material properties are as follows


$$C = \begin{bmatrix} 139000 & 74280 & 77840 & 0 & 0 & 0 \\ 47280 & 115400 & 74280 & 0 & 0 & 0 \\ 77840 & 74280 & 139000 & 0 & 0 & 0 \\ 0 & 0 & 0 & 25640 & 0 & 0 \\ 0 & 0 & 0 & 0 & 25640 & 0 \\ 0 & 0 & 0 & 0 & 0 & 25640 \end{bmatrix} MPa$$

$$e = \begin{bmatrix} 0 & -5.20710E - 6 & 0 \\ 0 & 15.08E - 6 & 0 \\ 0 & -5.207E - 6 & 0 \\ 12.710E - 6 & 0 & 0 \\ 0 & 0 & 12.710E - 6 \end{bmatrix} C/mm^{\circ}2$$

$$\varepsilon = \begin{bmatrix} 6.752E - 12 & 0 & 0 \\ 0 & 5.872E - 12 & 0 \\ 0 & 0 & 6.752E - 12 \end{bmatrix} C/(Vmm)$$

where

C is Elastic constants, e is Piezoelectric constants and ε being dielectric constants. The material is polarized in Y-direction.






Figure 29: 2D Piezoelectric Plate

Figure 30: 2D Piezoelectric Plate with loading

The movement of the bottom edge and left edge of 2D piezoelectric plate is fixed in y direction and x direction respectively as shown in figure (30). The left edge is grounded (Electric potential $\Phi=0$) and a displacement load of 0.1 mm and 0.2 mm is applied on the right edge and top edge respectively. The results for single element case and multiple elements is discussed in the below sections.

The results generated by IGA code is compared with inbuilt Abaqus piezoelectric element.

7.3.2 Results and discussions

Abaqus plane strain full integration piezoelectric element (**CPE4E**) is used for analysis. The below figures shows the values of displacements (U), electrical potentials (EPOT) and reaction forces (RF) for both abaqus and IGA element.

Figure(31) and Figure(32) shows the displacement (U1) values of the single CPE4E element and single IGA element at 100 % loading in x direction respectively.




Figure 31: CPE4E Element:U1

Figure 32: IGA Piezoelectric Element:U1

Figure(33) and Figure(34) shows the displacement (U2) values of the single CPE4E element and single IGA element at 100 % loading in y direction respectively.




Figure 33: CPE4E Element:U2

Figure 34: IGA Piezoelectric Element:U2

Figure (35) and Figure (36) shows the Reaction force values (RF1) of the single CPE4E element and single IGA element at 100 % loading in x direction respectively.




Figure 35: CPE4E Element:RF1

Figure 36: IGA Piezoelectric Element:RF1

Figure(37) and Figure(38) shows the Reaction force values (RF2) of the single CPE4E element and single IGA element at 100 % loading in y direction respectively.





Figure 37: CPE4E Element:RF2

Figure 38: IGA Piezoelectric Element:RF2

Figure(39) and Figure(40) shows the Electrical potential values (EPOT) of the single CPE4E element and single IGA element at 100~% loading respectively.



EPOT

247550

165033

82517

-0

-82517

-165033

-247550

Figure 39: CPE4E Element:EPOT

Figure 40: IGA Piezoelectric Element:EPOT

7.3.3 Conclusion

As shown in figures above the values generated by IGA code are inline with the results of Abaqus element. So it can be concluded that IGA code written works fine for 2D one element case.

7.3.4 Parametric details for the plate with 3 elements in x direction and 2 elements in y direction

The 2nd order NURBS curve is used in both ξ and η directions.

1. Physical details for the geometry:

L = 10 # Length of the plate in mm H = 10 # Height of the plate in mm

2. Parametric details of the geometry:

```
\Xi = [0,0,1,2,2] # Knot vector in xi direction

H = [0,0,1,2,3,3] # Knot vector in eta direction
```

Degree of the curve

p=1 # Degree of the curve in ξ direction q=1 # Degree of the curve in η direction

Number of control points in each direction

$$n_{cp}^{\xi} = \text{len}(\Xi)$$
 - (p+1) #No.of control points in ξ direction (5-(1+1) = 3) #No.of control points in η direction (6-(1+1) = 4)

3. Total number of control points for the geometry

$$n_{cp} = n_{cp}^{\xi} * n_{cp}^{\eta} = 3*4 = 12$$

The control points are given by

i	$P_{i,0}$	$P_{i,1}$	$P_{i,2}$
0	(0,0,0,1)	(0, 5, 0, 1)	(0, 10, 0, 1)
1	(3.33, 0, 0, 1)	(3.33, 5, 0, 1)	(3.33, 10, 0, 1)
2	(6.67, 0, 0, 1)	(6.67, 5, 0, 1)	(6.67, 10, 0, 1)
3	(10,0,0,1)	(10, 5, 0, 1)	(10, 10, 0, 1)

with fourth value in the paranthesis being weights of respective control points. A control point assembly array and knot vector connectivity matrix are used to connect the elements.

7.3.5 Results and discussions

Abaqus plane strain full integration piezoelectric element (**CPE4E**) is used for analysis. For the comparision between abaqus and IGA elements 2 elements, along x direction and 3 elements along y direction are used. A different number of elements are used along each direction in order to verify if the code generates proper results in unsymmetric conditions aswell w.r.t number of elements in each direction.

The below figures shows the values of displacements (U), electrical potentials (EPOT) and reaction forces (RF) for both abaqus and IGA elements.

Figure (41) and Figure (42) shows the displacement (U1) values of the CPE4E elements and IGA elements at 100 % loading in x direction respectively.




Figure 41: CPE4E Element:U1

Figure 42: IGA Piezoelectric Element:U1

Figure (43) and Figure (44) shows the displacement (U2) values of the CPE4E elements and single IGA elements at 100 % loading in y direction respectively.




Figure 43: CPE4E Element:U2

Figure 44: IGA Piezoelectric Element:U2

Figure (45) and Figure (46) shows the Reaction force values (RF1) of the CPE4E elements and IGA elements at 100 % loading in x direction respectively.




Figure 45: CPE4E Element:RF1

Figure 46: IGA Piezoelectric Element:RF1

Figure (47) and Figure (48) shows the Reaction force values (RF2) of the CPE4E elements and IGA elements at 100 % loading in y direction respectively.




Figure 47: CPE4E Element:RF2

Figure 48: IGA Piezoelectric Element:RF2

Figure (49) and Figure (50) shows the Electrical potential values (EPOT) of the CPE4E elements and IGA elements at 100 % loading respectively.




Figure 49: CPE4E Element:EPOT

Figure 50: IGA Piezoelectric Element:EPOT

7.3.6 Conclusion

As shown in figures above the values generated by IGA code are inline with the results of Abaqus elements.

8 Milestones achieved

The following table describes the proposed coding activities and achieved activities.

Proposed Activities	Achieved
Implementation of Isogeometric Analysis	yes
IGA implementation for a Single element 2D case	yes
Coupling between mechanical and electrical Dof's	yes
Verification of results with abaqus inbuilt piezoelectric element	yes
Extra Activities	Achieved
Implementation of Knot and Control point assembly arrays	yes
Code extension to multiple elements	yes

References