Lab 2

Part 1

I first updated the start-up script, linker script, and header file to the correct files for the STM32F411VE MCU—startup_stm32f411xe.s, stm32f411xe.h, STM32F411VETx_FLASH.ld respectively. I also updated the per-project makefiles and the armf4 makefile to reference the relevant updated files. After that, I used the generic header file in my .c files and uncommented the relevant section in the generic header file to include stm32f411xe.h. One of the struggles I had during this phase of Part 1 was getting the correct .s file for my compilation configuration. I was accidentally trying to use one for a custom arm configuration at first, before seeking help in office hours and then selecting the correct .s file for my gcc set up.

After doing this, I was able to make and run the "timer" example by commenting out "set_sysclk_to_168", but the timing of the led blinks did not match what it said it should be in the code. This was because my timer was assuming that the system clock was running at 168 Mhz, when it was not. I then updated the system_stm32f4xx.h to define new PLL_M, PLL_Q, PLL_P, and PLL_N based on the recommendations found in this source to set the clock to 100 Mhz, which the board can handle. I then changed the name of the "set_sysclk_to_168" to "set sysclk to 100" to more accurately reflect its functioning.

After these changes were made I combined the code from the timer and external projects from the sample repo given. I enabled both the rising and falling edge trigger on the button so that the interrupt handler would be called both when it was pressed and being let go. In the actual interrupt handler, I checked if the interrupt was coming from the correct line, cleared the interrupt and waited for another trigger. This allowed the falling edge trigger to initially trigger the interrupt, and then it would hang and wait for the rising edge trigger, which paused the led blinking given the high priority level of the interrupt handler. Once the falling edge trigger was detected, the handler reset the led sequence to start at green again, and returned.

The functions of the files mentioned in the lab handout are detailed below. startup stm32f411xe.s:

Since C files assume that there is a call stack when they run, some code not written in C has to set up the stack before the C code can be executed. At a high level, this code, which is

written in assembly, sets up the call stack and other basics so that a C program will run. This program first defines the reset handler, which sets the stack pointer to _estack. __estack is defined in the linker script as the highest address in RAM. Then, using the section headers and footers defined in the linker script, it copies the data from flash to RAM, and fills the bss section with zeros. Then it initializes the clock, calls static constructors and then calls main. This script also sets the vector table entries for the interrupt handlers and creates aliases for these handlers that can be overwritten by user code. Also, the script sets the program counter to the reset handler, so it is the first instruction run when the program starts.

It is very important that this script and the linker script used the same variable names, as this script used the data segment addresses (like the start and end of the bss section, for example) in the startup code. This was one of the problems I ran into when updating the files.

stm32f411xe.h

This file defines nice macros that the C program can use to access and set peripheral registers without having to directly use addresses. First, this file defines structs that can be used to access registers nicely. Then all the base pointers for the major peripherals are defined. Finally, the file casts the base addresses to struct pointers and defines them as with names that correspond to the reference manual.

STM32F411VETx FLASH.ld

The linker first sets the program entry point to be the reset handler. This means that the first thing that will be executed in the code is the reset handler. Then, it sets the location of the stack pointer, the minimum heap size, and the minimum stack size. It then also sets parameters like flash and RAM sizes, their start values, and their permissions. This is a very important section of the linker script because it specifies the memory layout that the board has. Then the script dictates the layout of the ELF file to be generated. The startup code is put first, then the standard text section and rodata sections. After that, there is a "ARM extab" section defined, which according to this stackoverflow post, contains unwiding information. Unwinding, per this source, is how to get rid of local variables and call destructors on a stack when a function call ends. Apparently this information is mostly useful for dealing with exceptions being thrown. After this section, "pre init array", "init array", and "fini array" are mentioned. From the stackoverflow post mentioned earlier, these sections are referring to the constructor and destructor C methods that are called before and after main(). After that, the standard data and bss

sections are described, and global symbols are created at the beginning and end of these sections for use in the startup script. Towards the end of the file, there is some memory reserved for the user heap/stack. The last bit deletes any sections that were not specified in the above script (source).

Makefile

At a high level, the initial per-project makefile defines some variables used in the overall makefile (armf4) and then calls the overall makefile. Some of these variables that were important to change were the TARGET and SRC variables, which are responsible for the name of the files generated and the files that need to be compiled, respectively. The linker script was also assigned to a variable as well as the processor type, for further use in the armf4 makefile.

When "make" is called, it calls three sub commands, clean, build, and size. Clean is pretty self explanatory, as it removes all files/folders generated from a previous call to make. Build is more complicated, as it generates a .elf, .bin, and .lst file with the name specified by the TARGET variable, in a sub folder named by the variable OBJDIR. This command first generates the .elf file. First, all the relevant .c and .s files are compiled into .o files. All the .o file names with their corresponding file paths in OBJDIR are stored in the variable OBJS. So, the makefile compiles all the corresponding .c and .s files for the .o filenames in OBJS with the specified CFLAGS and included libraries necessary (in the case of the .c files). Then these .o files are linked together to create the .elf file based on the linker flags, one of which is the linker script mentioned earlier. Once this .elf file is created in the OBJDIR directory, then the .bin and .lst files can be created by calling "arm-none-eabi-objcopy" and "arm-none-eabi-objdump" on the .elf file created earlier with the correct flags. The "size" command then reads the elf file and prints the sizes of all the text, data, bss, sections as well as other information to the screen after you are done generating all the necessary files. "make burn" then writes the .bin file to address 0x8000000 using the st-flash command with the "write" option from the stlink-tools library. 0x8000000 looks like the standard address to write .bin files to on an STM32 board.

Source code for part1

I got my <u>startup stm32f411xe.s</u>, <u>STM32F411VETx FLASH.ld</u>, and <u>stm32f411xe.h</u> from the STM23CubeF4 repository of the STMicroelectronics github. I did not change any of these files.

From the <u>sample repo</u> given, I used the contents of the libs folder (the CMSIS_5 repo), and the stm32f4xx.h file without making any major changes to them.

The makefile in the Part1 folder was taken from the "blinky" project from the sample repo. I changed the name of the TARGET and SRC variables to be Part1 and Part1.c respectively. I changed the processor CDEF to -DSTM32F411xE from -DSTM32F407xx and changed the address of the linker script to point to the updated linker script: STM32F411VETx FLASH.ld.

I also used the overall makefile (armf4). I changed the path to the startup script and to point to the updated script mentioned above. I also changed the paths to the CMSIS library and the system stm32f4xx.c to reflect their new location in my repository.

I also used the system_stm32f4xx.c from the sample repo. I changed the name of the "set sysclk to 168" function to "set sysclk to 100" to more accurately reflect its functioning.

I also used the system_stm32f4xx.h file, but changed the PLL_M, PLL_Q, PLL_P, and PLL_N values to better fit with the STM32F411VE MCU. I also changed the name of the function declaration of the old "set_sysclk_to_168" function to "set_sysclk_to_100".

My Part1.c was a combination of the "external.c" and the "timer.c" files from the external and timer projects in the example repo.

I combined the main functions from external.c and timer.c to create my main function. I then deleted any repeated parts (like setting up the LEDs) and called set_sysclk_to_100 instead of set_sysclk_to_168. Since the board I was using had a different clock speed, I updated the prescaler (TIM2->PSC) from 8399 to 4999 based on the formula listed in the comment on lines 69-75 in timer.c. I also changed the auto reload time from 10000 to 5000 to trigger the switching of the LEDs every 0.5s instead of every 1s.

I based my EXTIO_IRQHandler on the one found in external.c. I used the function definition, if statement used to check if the interrupt was coming from EXTIO, and line 50, which was used to clear the interrupt status. I deleted everything else in that function and replaced it with my solution, which was described above.

I used the TIM2_IRQHandler from timer.c in my code. The only changes I made were declaring "i"—the variable used in timer.c's TIM2_IRQHandler—as a global variable and changing the variable name from i to ledVal.

At first, I tried the first method for implementing a touch sensor recommended in the lab handout. However, I struggled to measure the time that the capacitor took to discharge reliably. I had a difficult time effectively prioritizing my interrupt handlers. The "time keeping" handler kept getting interrupted by other handlers, but couldn't be prioritized or it would have affected the LED blink pattern. Therefore, I switched to the second method, which proved to be easier to implement.

To implement the touch sensor, I first configured PC7 to be a "floating" pin and then periodically refreshed the charge on the pin. When my finger touches the pin, the pin's charge drops, causing a falling edge trigger, which triggers the configured interrupt handler to either pause or restart the sequence from the green LED.

In order to do this, I first enabled the GPIOC clock and configured pin 7 on GPIOC as an input using this video, looking at the LED code from part 1, and reading the reference manual. Then I configured the SYSCFG->EXTICR2 register bits 12-15 to map EXTI7 to PC7. I had one issue with this initially. At first, I was accidentally trying to access the second EXTICR register using SYSCFG->EXTICR[2] instead of SYSCFG->EXTICR[1]. Then, I had to enable the falling edge trigger on EXTI7, and enable interrupts on line 7 as well. I also had to set the priority and enable the EXTI9_5_IRQHandler. The issue I had with this was I initially thought since I was mapping PC7 to an EXTI handler using the second EXTICR register, that I was mapping PC7 to the EXTI2 handler. Once I figured out that was wrong, things got a lot easier.

In my EXTI9_5_IRQHandler, I toggled a global variable "blinking", which dictated if the LED blinking was paused or not. If blinking was being set to 1 (not paused), then I set the global variable ledVal to 1, which restarted the blinking sequence at green.

Then I created my second timer interrupt (TIM3), which refreshed the charge on PC7 approximately every 0.3 seconds. I followed the method I used to set up TIM2 in part from (from timer.c) and enabled the TIM3 clock, set the prescaler to 4999, set the auto refill value to be 3000 (0.3 seconds), enabled interrupts from TIM3, and enabled the TIM3 module. Then I gave my TIM3 handler 3rd priority, and enabled it. This went pretty smoothly as all I had to do was copy the method used to set up TIM2.

In my TIM3 handler, I used the method from TIM2 to clear the interrupt and then added code to charge the pin.

Lastly, I slightly edited my TIM2 code from Part1, and added a line to prevent changing the LED values unless the "blinking" global variable was set to 1.

After this, I also had an issue where one touch would trigger the interrupt handler multiple times. In office hours, Zhiyao helped me with this by suggesting an decrease in the rate I was refreshing the charge on the PC7. This helped to reduce some of the instances of this error.

Source code for part 2

I used my Part1 as source code for Part2. See <u>Source code for part 1</u>, for details on the source code for Part1.

I used all the same files mentioned in <u>Source code for part 1</u> in part 2 unchanged except the per-project makefile and Part1.c. I changed the TARGET and SRC variable in the per-project makefile (the makefile in the Part2 folder) to Part2 and Part2.c respectively.

In regards to the changes I made to Part1.c to make it Part2.c, I added and enabled the TIM3 handler, configured the PC7 pin instead of the user button, replaced the EXTI0 handler with the EXTI9_5 handler, connected the EXTI9_5 handler to PC7 instead of connecting the EXTI0 handler to the user button, and configured EXTI7 instead of EXTI0. I also changed the TIM2 handler to depend on a new global variable "blinking". My interrupt handler now also toggled "blinking" to pause the LED blinking instead of hanging and waiting for a second trigger inside the handler like my EXTI0 handler did in part 1.

Part 3

This part was greatly simplified once I found the i2s-beep sample code mentioned on Ed. I used the example code's methods for setting up the i2s and the cs43122 audio chip, as well as their i2c write method to communicate with specific registers on the cs43122. Then, I looked up the registers used in lines 362-371 of the example code on the audio chip datasheet to figure out how these lines played the notes in the "nem" array. Once I did that, I found the table of frequencies on page 48, which caused me to start my scale on C5 instead of C4, since the beep generator had more support for that scale. After switching the notes in "nem" for the notes of the C5 scale, I needed to fix the volume that the sounds were playing at. With the settings in the example code, the notes were playing too loud through my headphones. Using the

"CS43L22_REG_BEEP_VOL_OFF_TIME" register, I set the beeps to the minimum volume. I also lowered the headphone volume using the "CS43L22_REG_HEADPHONE_A_VOL" register. Once I fixed the volume, I used the TIM2 interrupt to play my scale on repeat by disabling the beep, changing the frequency of the beep, and then re-enabling it each time the interrupt was called.

After I was able to successfully play the scale starting at C5 on a loop at a reasonable volume, I moved on to crafting the state machine to differentiate between a single click or double click. I started by configuring the EXTIO handler to be connected to PAO, as was done in Part1, and have a rising edge trigger. My first attempt at this was similar to how the touch sensor worked in PC7. I had a global variable "click" which I set to 0 every 0.3 seconds, and every time EXTIO was triggered, it incremented the click variable. Then, if "click" was 0, i.e. it was the first click that had been registered by the handler, the scale was paused. If "click" was 1, the scale was restarted. This had the unfortunate side effect of causing the scale to pause for a second before the next click of a double click triggered an interrupt. Therefore, after visiting office hours. I decided to create a state machine and use timers to differentiate between a single click and a double click. Now, when the first click triggers an interrupt, I start 2 timers, one for debouncing and one to differentiate between a single and double click. The debouncing timer makes sure that the state machine does not take into account clicks that happen less than 10 ms after the first one. When the second timer triggers (after 0.3 seconds), it checks the state of the program. If the program state is FIRST PRESS DEBOUNCE, i.e. a second rising edge trigger has not been detected, then it assumes that it was a single click and pauses the scale. If a second click triggers the interrupt before 0.3s have elapsed, the state of the program will be changed back to its initial state (NO PRESS) and the scale will restart.

Rule of Representation:

There were two major places in my code where I utilized the rule of representation: the state machine and the "scale" array.

In the state machine, I chose to create an enum that detailed all possible program states and use one "myState" variable to store the current program state. I did this instead of having separate variables that stored different pieces of information. For example, I could have had one variable to determine how many times the button interrupt had been triggered and another to

determine the state of the debouncing timer. This could have allowed me to have fewer states, but would have made the procedural logic that switches between states more complicated. Right now, my "if" statements changing the state of the system consist of " if (myState == State_x), then myState = State_y". This allows for readable code and easier debugging than if each state depended on many different variables.

For the scale array, I choose to use #define to store each note using its letter and number code instead of its actual value (ie C6 instead of 0x80). This way, when I was creating the scale array, it looks more readable and is more easily interpreted. Additionally, since each note in the scale array differs from the previous one by 0x10, I could have simply incremented a variable by 0x10 to get the next note and just reset the value back to 0x10 (the value of C5) once the variable had gotten to the last note on the scale. This however, would have been harder to follow and less simple than traversing an array.

Source code for part 3

I used the files in the "include", "lib", and "flash" folders as well as the armf4 makefile during part 3. See <u>Source code for part 1</u> for details on the files in these three folders and the armf4 makefile.

During this part, I did add one file to the "include" folder, cs43122.h, which mainly assigned names to the different registers on the cs43122 audio chip. I got this from the example repo's "include" folder and did not change it.

The makefile in my Part3 folder was copied from the one in my Part2 folder, and is identical except I changed the TARGET and SRC variables to Part3 and Part3.c respectively. Please see Source code for part 2 for more details on the source of the makefile.

I used <u>i2s-beep.c</u> from the example repo given to create my Part3.c. I used the init_i2s_pll, init_i2s3, init_cs43l22, start_cs43l22, I2C1_ER_IRQHandler, i2c_start, i2c_stop, i2c_read, and i2c_write methods created in i2s-beep.c in my Part3.c without making any changes. I also used lines 281-356 of the i2s-beep.c main function in my Part3.c main function with no changes. I used lines 359 and 360 of the i2s-beep.c main function with small changes. I set my volume to 7, while the i2s-beep.c main function volume was set to 16. I did not use lines 363-371 in my main function, but they did help me create the contents of my TIM2_IRQHandler.

To the source code I got from i2s-beep.c, I added code to initialize the user button, tie PA0 to EXTIO, and initialize timer 2, 3, and 4. I used source code from part 1 to set up the user button and tie PA0 to EXTIO. Specifically, I used lines 82-84 (PA0 configuration), 114-127 (EXTIO set up). I also used source code from part 2 to help me set up the timers (lines 128-130). I modified the timer code from part 2 based on the different settings I wanted my timer to have. For example, I changed the timer 3 mode from recurring to one pulse, and the timer refill value from 0.5s to 0.3 seconds. I also added code for the EXTIO, TIM2, TIM3, and TIM4 interrupt handlers, which used the same method for clearing the interrupts as was used in Part 2, but perform different functions. Lastly, I added #defines for each of the notes I was using, the array of notes the TIM2 handler steps through, an enum "processState" that lists all potential states for the system, and various global variables used to pause and play the scale.