



2K15X Installation Manual XPON ONT 2GE 1POTS with Wi-Fi Dual-Band



1.1 Product Description

Thanks for choosing the 1LAN Home Gateway Unit. All PPC terminal devices are designed for fulfilling FTTH and triple play service demand of fixed network operators or cable operators. These boxes are based on the mature GPON and Gigabit EPON technology, which have high ratio of performance to price, they are highly reliable and easy to maintain, with guaranteed QoS for different service. And they are fully compliant with GPON and EPON technical regulations such as ITU-T G.984.x, IEEE802.3ah and technical requirement of EPON Equipment. Dual mode PPC ONT can detect and exchange PON mode automatically.

1.2 Application Chart




Fig 1: Network Architecture





Fig 2 : **2K15X**

1.3 Technical Parameters

Technical items	2K15X(2GE 1POTS with Wi-Fi Dual-Band) PPC ONT			
PON interface	1 GPON/EPON interface, SC single-mode/single-fiber.			
	GPON: uplink 1.25Gbps, downlink 2.5Gbps; EPON: symmetric 1.25Gbps.			
Wavelength	Tx 1310nm, Rx 1490nm			
Optical interface	SC/APC			
LAN interface	2x 10/100/1000Mbps auto adaptive Ethernet interfaces.10/100M Full/Half, 1000M			
	Full Duplex, RJ45 connector.			
POTS	1 RJ11 port			
LED	10, For Status of POWER, PON, LOS, INT, LAN1, LAN2, TEL, 2.4G, 5G, USB			
Operating condition	Temperature: -5°C~55°C			
	Humidity: 10%~90% (non-condensing)			
Storing condition	Temperature :-30°C~60°C			
	Humidity :10%~90% (non-condensing)			
Power supply	DC 12V/1A			
Power consumption	≤6W			
Dimension	160mmx139.5mmx28.5mm(L×W×H)			
Net weight	0.24Kg			

1.4 Package Contents

Contents	Quantity	
PPC ONT	1 pcs	
Power Adapter	1 pcs	
User manual	1 pcs	
Cat 5E cable	1 pcs	





2.1 Installation Requirements

Installation Environment Requirements

PPC ONT equipment must be installed in the interior, and to ensure the following conditions:

- Confirmation at the PPC ONT installation at sufficient space to facilitate cooling machine.
- PPC ONT suitable operating temperature of -5°C ~ 55°C, humidity 10% to 90%.
- Device workplace should avoid radio transmitters, radar stations and high-frequency interference from power equipment.

Equipment Installation

- Installed on the desktop
 - Place the machine on a clean bench, this installation is relatively simple, you can observe the following operation:
 - Ensure the smooth workbench
 - Around the device enough space for heat dissipation.
- 2 Mounted on the wall.
 - Observation PPC ONT equipment chassis two cruciform recess, in accordance with the position of the groove, installed two screws in the wall.
 - The original selected two mounting screws gently snap into recesses aligned.
 - Slowly let go,so that the device under the support the screw hanging on the wall



2.2 LED Indications

LED	Panel Marking	Status	Description
Power	POWER	On	The device is powered up.
		Off	The device is powered down.
Optical signal	LOS	Blink	Device does not receive optical signals.
loss		Off	Device has received optical signal.
Registration		On	The device is registered to PON system
	PON	Off	Device is not registered to PON system
		Blink	Device registeration is incorrect
Internet	INT	On	The routed WAN Internet access is normal
		Off	The routed WAN Internet access is abnormal
Interface	LAN	On	Port is connected properly (LINK).
		Off	Port connection exception or not connected.
		Blink	Port is sending or/and receiving data (ACT).
	2.4G & 5G	On	Wi-Fi is enabled
		Off	Wi-Fi is disabled
	TEL	On	The connection between the TEL Port and Voice Server has
			been set.
		Blinking	The voice service of the TEL port is established.
		Off	The connection between the TEL Port and Voice Server is not
			set up.
USB	USB	On	USB Connection is normal
		Off	USB Connection is not set up



Fig 4 : ONT Back Panel

Name	Function	
PON	Connect to OLT by SC type fiber connector, single mode optical fiber cable.	
LAN	Connect PC or other devices with Ethernet port by Cat5 cable, RJ-45 connector.	
POWER	Connect with power adapter. DC 12V, 1A.	
TEL	Connect to Telephone with FXS port by telephone wire	



Web Management

2LAN 1POTS with Wi-Fi dual mode PPC ONT provides simple Web management function.

3.1 Default Configuration

The following is the default device configuration information.

- · Local (LAN access) Username: admin , Password: admin
- LAN port management IP address: 192.168.1.1/24

3.2 Basic Configuration



Fig 5 : Login Interface

Web login default username: admin Password: admin





Fig 6: Status



Fig 7: WAN Connections

WAN connections will provide access to create/ delete/ modify the connections. From WAN connection list we can create a new WAN connection as per the requirements of the customer. All the details required for creating wan connection will be provided on the above web interface





Fig 8: LAN setting

IP Address and Subnet Mask: LAN port IP address and Mask.

DHCP option: Enable or disable DHCP server and configure IP address pool, DNS, etc.

Note: DHCP server changes take effect after the device is restarted.



Fig 9: WLAN Configuration

WLAN Basic Configuration helps us to select the wireless band (2.4 GHz & 5GHz) and also can change the parameters as per the requirement.





Fig 10: WLAN Security Setting

WLAN Security Settings helps us to configure the Wi-Fi key encryption and authentication mode of the selected SSID.



Fig 11: Firmware Upgradation

The above web page will helps us to do upgrade the software/firmware of ONT



For Reference

Warranty term & conditions:

https://www.ppc-online.com/hubfs/Legal Policies/actives-product-warranty.pdf

End of life policy:

https://www.ppc-online.com/hubfs/Legal Policies/actives-end-of-life-policy.pdf

Service level agreement:

https://www.ppc-online.com/hubfs/Legal Policies/actives-service-level-agreement.pdf