
ECE249: Unit-4

PN junction diode and its applications


Basic Diode Concepts


* Energy Diagrams – *Insulator, Semiconductor, and Conductor* the energy diagram for the three types of solids



Intrinsic Semiconductors

* Intrinsic (pure) *Si* Semiconductor:






When equilibrium between excitation and recombination is reached:

electrondensity = hole density $n_i = p_i = 1.5 \times 10^{10} \text{ cm}^{-3}$ for intrinsic Si crystal at 300 K (Note: Si crystal atom density is ~ $5 \times 10^{22} \text{ cm}^{-3}$)

Intrinsic Semiconductors

*Apply a voltage across a piece of *Si*:

electron current and hole current




Valence electron moves (5) Valence electron moves 1) Free electron into 2nd hole and leaves into 4th hole and leaves leaves hole in a 3rd hole. a 5th hole. valence shell. (2) Valence electron moves (4) Valence electron moves (6) Valence electron moves into 1st hole and leaves into 3rd hole and leaves into 5th hole and leaves a 2nd hole.a 4th hole. a 6th hole. Si Si

When a valence electron moves left to right to fill a hole while leaving another hole behind, a hole has effectively moved from right to left. Gray arrows indicate effective movement of a hole.

N- and P- Type Semiconductors

- * *Doping*: adding of impurities (i.e., dopants) to the intrinsic semiconductor material.
- * *N-type*: adding Group V dopant (or donor) such as As, P, Sb,...



 $n \cdot p = constant for a semiconductor$ For Si at 300K

$$n \cdot p = n_i^2 = p_i^2 = (1.5 \times 10^{10})^2$$

In n-typematerial

 $n \cong N_d$ the donor conceration


$$n = N_d >> n_i, p << p_i$$

We call

electronthe major chargecarrier holethe minor cahagecarrier

N- and P- Type Semiconductors

- * *Doping*: adding of impurities (i.e., dopants) to the intrinsic semiconductor material.
- * *P-type*: adding Group III dopant (or acceptor) such as Al, B, Ga,...



$$n \cdot p = constant for a semiconductor$$

For Si at 300K

$$n \cdot p = n_i^2 = p_i^2 = (1.5 \times 10^{10})^2$$

In p -typematerial

 $p \cong N_a$ the acceptor concertaion

 $p = N_a >> p_i$, $n << n_i$

We call


holethe major charge carrier electronthe minor cahage carrier

The PN-Junction


* The interface in-between p-type and n-type material is called a *pn-junction*.

The barrier potential $V_B \cong 0.6 - 0.7V$ for Si and 0.3V for Ge

at 300K: as $T \uparrow, V_B \downarrow$.



(a) At the instant of junction formation, free electrons in the n region near the pn junction begin to diffuse across the junction and fall into holes near the junction in the p region.




(b) For every electron that diffuses across the junction and combines with a hole, a positive charge is left in the n region and a negative charge is created in the p region, forming a barrier potential. This action continues until the voltage of the barrier repels further diffusion.

Biasing the PN-Junction


- * There is no movement of charge through a PN-junction at equilibrium.
- * The PN-junction form a *diode*which allows current in only one
 direction and prevent the current
 in the other direction as
 determined by the *bias*.

The arrow in the circuit symbol for the diode indicates the direction of current flow when the diode is forward-biased.




Biasing the PN-Junction


***Forward Bias**: dc voltage positive terminal connected to the p region and negative to the n region. It is the condition that permits current through the pn-junction of a diode.




Biasing the PN-Junction

*Forward Bias:





*Reverse Bias: dc voltage negative terminal connected to the p region and positive to the n region. Depletion region widens until its potential difference equals the bias voltage, majority-carrier current ceases.





2. Diodes – Basic Diode Concepts

*Reverse Bias:

majority-carrier current ceases.

* However, there is still a very small current produced by minority carriers.






(b) Majority current ceases when barrier potential equals bias voltage. There is an extremely small reverse current due to minority carriers.

2. Diodes – Basic Diode Concepts

Biasing the PN-Junction

* Reverse Breakdown: As reverse voltage reach certain value, avalanche occurs and generates large current.

Diode Characteristic I-V Curve



Shockley Equation

* The Shockley equation is a theoretical result under certain simplification:

$$i_D = I_s \left[exp \left(\frac{v_D}{nV_T} \right) - 1 \right]$$


where $I_s \cong 10^{-14}$ A at 300K is the (reverse) saturation current, $n \cong 1$ to 2 is the emission coefficient,

$$V_T = \frac{kT}{q} \cong 0.026 V at 300 K is the thermal voltage$$


k is the Boltzman's constant, $q = 1.60 \times 10^{-19} C$

when
$$v_D \ge 0.1 V$$
, $i_D \cong I_s exp\left(\frac{v_D}{nV_T}\right)$

This equation is not applicable when $v_D < 0$



Diode Testing



Ideal-Diode Model

- * We may apply "Ideal-Diode Model" to simplify the analysis:
- (1) in forward direction: short-circuit assumption, zero voltage drop;
- (2) in reverse direction: open-circuit assumption.
- * The ideal-diode model can be used when the forward voltage drop and reverse currents are negligible.





Figure 10.15 Ideal-diode volt–ampere characteristic.

2. Piecewise-Linear Diode Models Modified Ideal-Diode Model



* This modified ideal-diode model is usually accurate enough in most of the circuit analysis.

Application

Rectifier Circuits

* *Rectifiers* convert ac power to dc power.

* Rectifiers form the basis for electronic power suppliers and battery charging

circuits.

Half-Wave Rectifier







Figure 10.24 Half-wave rectifier with resistive load.






Center-Tapped Full wave rectifiers

 A center-tapped transformer is used with two diodes that conduct on alternating half-cycles.




During the positive half-cycle, the upper diode is forward-biased and the lower diode is reverse-biased. During the negative half-cycle, the lower diode is forward-biased and the upper diode is reverse-biased.




Bridge Full-wave rectifiers

* The Bridge Full-Wave rectifier uses four diodes connected across the entire secondary as shown.



Conduction path for the negative half-cycle.

Conduction path for the positive half-cycle.



MCQ

The forward voltage drop across a silicon diode is about ...

- (a) o.3 V
- (b) 3 V
- (C) 7 V (d) 0.7 V

MCQ

The leakage current in a crystal diode is due to

•••••

- (a) minority carriers
- (b) majority carriers
- (C)junction capacitance
- (d) none of the above