

WRIST BLASTER SCHEMATIC V1.0

*** WIRES COLORS ARE FOR REFERENCE ONLY ***
 YOUR WIRES/JUMPERS MAY HAVE DIFFERENT COLORS
 AND/OR DIFFERENT COLORS ORDER. IT IS MORE
 IMPORTANT TO RESPECT THE 2 POINTS CONNECTED :
 GND TO GND, 5V+ TO 5V+, SIGNAL TO SIGNAL, ETC.


FOR REFERENCE ON THIS SCHEMATIC :

BLACK -> GROUND
 RED -> VCC / V+
 OTHERS -> SIGNALS, AUDIO, ETC.

SELECT THE RIGHT BAR METER PCBs

COMMON CATHODE SK

BAR METER DRIVER PCB : SBK BarDrive SK28
 LEDs DRIVER : MAX7221
 BAR METER HOLDER PCB : SBK BarMeter 28
 BAR METER : BL28Z-3005SK04Y



COMMON ANODE SA

BAR METER DRIVER PCB : SBK BarDrive SA28
 LEDs DRIVER : MAX7221
 BAR METER HOLDER PCB : SBK BarMeter 28
 BAR METER : BL28Z-3005SA04Y

