

### **Radio Engineering**

Lecture 4: Wideband channels

Florian Kaltenberger

#### Last lecture



- Statistical description of fading
  - Equivalent baseband representation
  - Small scale fading without a dominat component
  - Small scale fading with a dominat component
  - Doppler spectra
  - Temporal dependence of fading
  - Large-scale fading

### Repetition: Path loss



Path loss is the attenuation of the signal between transmitter and receiver.

$$egin{aligned} P_{\mathsf{RX}} &= rac{P_{\mathsf{TX}}}{PL} \ P_{\mathsf{RX}}|_{\mathsf{dB}} &= P_{\mathsf{TX}}|_{\mathsf{dB}} - PL|_{\mathsf{dB}} \end{aligned}$$

It contains the following factors

$$\begin{aligned} \mathsf{PL} &= \mathsf{PL}(\textit{d}) \times \mathsf{SF} \times \mathsf{SSF} \\ \mathsf{PL}|_{\mathsf{dB}} &= \mathsf{PL}(\textit{d})|_{\mathsf{dB}} + \mathsf{SF}|_{\mathsf{dB}} + \mathsf{SSF}|_{\mathsf{dB}} \end{aligned}$$

PL(d) deterministic path loss

SF large-scale (shadow) fading

SSF small scale fading

#### **Deterministic Path Loss**



$$PL(d) = \left(\frac{4\pi d}{\lambda}\right)^2 \quad 0 \le d \le d_{\text{break}}$$
  $PL(d) = PL(d_{\text{break}}) \left(\frac{d}{d_{\text{break}}}\right)^n \quad d > d_{\text{break}}$ 

- distance dependent loss in signal energy
- proportional to  $d^n$ , where d is the distance and n is the path loss exponent
- typicall values  $n \in [1.5, 6]$ , depending on terrain and foilage

### Large Scale fading



- Deviation of average received signal energy from deterministic path loss
- Averaging done over a small area (a few wavelengths)
- Is usually attributed to multiple interactions of the signal with the environment
- A large number of these interactions results in a log-normal distribution

$$pdf(L|_{dB}) = \frac{1}{\sqrt{2\pi}\sigma_F|_{dB}} \exp\left(-\frac{L^2|_{dB}}{2\sigma_F^2|_{dB}}\right)$$
(1)

• This distribution matches measurements very well with  $\sigma_F|_{dB}\approx 4\dots 10$  dB.


### Small Scale Fading



- Small scale fading results from constructive and destructive combination of multipaths
- No dominant component ⇒ Rayleigh Fading

$$pdf(r) = \frac{r}{\sigma^2} \exp\left(-\frac{r^2}{2\sigma^2}\right), \quad 0 \le r < \infty$$

$$cdf(r) = 1 - \exp\left(-\frac{r^2}{2\sigma^2}\right)$$



### Small Scale Fading




Dominant component (LOS) ⇒ Ricean fading

$$ext{pdf}(r) = rac{r}{\sigma^2} \exp\left(-rac{r^2 + A^2}{2\sigma^2}\right) I_0\left(rac{rA}{\sigma^2}\right), \quad 0 \leq r < \infty$$

$$ext{cdf}(r) = 1 - Q_M\left(rac{A}{\sigma}, rac{r}{\sigma}\right)$$


- The ratio of the power in the LOS component and the diffuse component  $K = \frac{A^2}{2\sigma^2}$  is called the Ricean factor
- $Q_M$  is Marcum's Q function and  $I_n$  is the modified Bessel function of the first kind, order n.



### Example: Ricean Fading Margin



Compute the fading margin for a Rice distribution with  $K_r = 0.3, 3$ , and 20 dB so that the outage probability is less than 5%.



**Figure 5.21** The Rice power 
$$cdf$$
,  $\sigma = 1$ .

$$M = \frac{r_{\text{rms}}^2}{r_{\text{min}}^2} = \frac{2\sigma^2(1 + K_r)}{r_{\text{min}}^2}$$
  
= 11.5, 9.7, 1.1dB

### Example: Outage probablity



Assume that, at a certain distance, we have a deterministic propagation loss of  $L_0=127$  dB and larg-scale fading, which is log-normal distributed with  $\sigma_F=7$  dB.

- How large is the outage probability  $P_{\text{out}} = \Pr\{L_0 + L \ge L_{\text{max}}\}$  (due to large-scale fading) if our system is designed to handle a maximum propagation loss of  $L_{\text{max}} = 135 \text{ dB}$ ?
- Which of the following methods can be used to lower the outage probability? Why (not)?
  - (a) Increase the transmit power
  - (b) Decrease the deterministc path loss
  - (c) Change the antennas
  - (d) Lower  $\sigma_F$
  - (e) Build a better receiver

#### This lecture



- Wideband channels
  - Wideband vs narrowband channels
  - System theoretic description of wideband channels
  - WSSUS model
  - Condesed parameters
  - Direction channel description

#### Wideband channels: definition




- So far we only looked at narrowband systems:
  - The symbol duration  $T_s$  is *larger* than the maximum delay in the channel  $\Delta \tau$
  - ⇒ Receiver cannot distinguish different echos
- A communication system is wide-band if
  - The symbol duration  $T_s$  is *smaller* than the maximum delay in the channel  $\Delta \tau$
  - ⇒ One transmitted symbol can spread over more than one symbol at the receiver


## Chapter 6

## Wideband channels


# Delay (time) dispersion A simple case




# Delay (time) dispersion One reflection/path, many paths



# Narrow- versus wide-band Channel impulse response



# Narrow- versus wide-band Channel frequency response



## System functions (1)

- Time-variant impulse response  $h(t,\tau)$ 
  - Due to movement, impulse response changes with time
  - Input-output relationship:

$$y(t) = \int_{-\infty}^{\infty} x(t-\tau)h(t,\tau)d\tau$$

- Time-variant transfer function H(t,f)
  - Perform Fourier transformation with respect to  $\tau$


$$H(t,f) = \int_{-\infty}^{\infty} h(t,\tau) \exp(-j2\pi f \tau) d\tau$$

Input-output relationship

$$Y(\widetilde{f}) = \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} X(f)H(t,f)\exp(j2\pi ft)\exp(-j2\pi \widetilde{f}t)dfdt$$

becomes Y(f)=X(f)H(f) only in slowly time-varying channels

## Transfer function, Typical urban




## System functions (2)

- Further equivalent system functions:
  - Since impulse response depends on two variables, Fourier transformation can be done w.r.t. each of them
  - -> four equivalent system descriptions are possible:
    - Impulse response
    - Time-variant transfer function
    - Spreading function

$$S(v,\tau) = \int_{-\infty}^{\infty} h(t,\tau) \exp(-j2\pi vt) dt$$

Doppler-variant spreading function  $B(v,f) = \int_{-\infty}^{\infty} S(v,\tau) \exp(-j2\pi f\tau) d\tau$ 

$$B(v,f) = \int_{-\infty}^{\infty} S(v,\tau) \exp(-j2\pi f\tau) d\tau$$



## Stochastic system functions

autocorrelation function (second-order statistics)

$$R_h(t,t',\tau,\tau') = E\{h^*(t,\tau)h(t',\tau')\}$$

Input-output relationship:

$$R_{yy}(t,t') = \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} R_{xx}(t-\tau,t'-\tau') R_h(t,t',\tau,\tau') d\tau d\tau'$$

## The WSSUS model: mathematics

- If WSSUS is valid, ACF depends only on two variables (instead of four)
- ACF of impulse response becomes

$$R_h(t, t + \Delta t, \tau, \tau') = \delta(\tau - \tau') P_h(\Delta t, \tau)$$

 $P_h(\Delta t, \tau)$ ...Delay cross power spectral density

ACF of transfer function

$$R_H(t + \Delta t, f + \Delta f) = R_H(\Delta t, \Delta f)$$

ACF of spreading function


$$R_s(v,v',\tau,\tau') = \delta(v-v')\delta(\tau-\tau')P_s(v,\tau)$$

 $P_s(v,\tau)$ .....Scattering function


## Condensed parameters

- Correlation functions depend on two variables
- For concise characterization of channel, we desire
  - A function depending on one variable or
  - A single (scalar) parameter
- Most common condensed parameters
  - Power delay profile
  - Rms delay spread
  - Coherence bandwidth
  - Doppler spread
  - Coherence time

## Channel measures



## Channel measures



# Condensed parameters Power-delay profile

One interesting channel property is the **power-delay profile** (PDP), which is the expected value of the received power at a certain delay:

$$P(\tau) = \mathbf{E}_t \left[ \left| h(t, \tau) \right|^2 \right]$$
E<sub>t</sub> denotes expectation over time.

For our tapped-delay line we get: 
$$P(\tau) = \mathbf{E}_t \left[ \left| \sum_{i=1}^N \alpha_i(t) \exp\left(j\theta_i(t)\right) \delta\left(\tau - \tau_i\right) \right|^2 \right]$$
 
$$= \sum_{i=1}^N \mathbf{E}_t \left[ \alpha_i^2(t) \right] \delta\left(\tau - \tau_i\right) = \sum_{i=1}^N 2\sigma_i^2 \delta\left(\tau - \tau_i\right)$$
 Average power of tap i.

# Condensed parameters Power-delay profile (cont.)

We can "reduce" the PDP into more compact descriptions of the channel:

Total power (time integrated):

$$P_{m} = \int_{-\infty}^{\infty} P(\tau) d\tau$$

Average mean delay:

$$T_{m} = \frac{\int_{-\infty}^{\infty} \tau P(\tau) d\tau}{P_{m}}$$

Average rms delay spread:

$$S = \sqrt{\frac{\int_{-\infty}^{\infty} \tau^2 P(\tau) d\tau}{P_m} - T_m^2}$$

For our tapped-delay line channel: N

channel: 
$$P_m = \sum_{i=1}^{N} 2\sigma_i^2$$

$$T_m = \frac{\sum_{i=1}^{N} \tau_i 2\sigma_i^2}{P_m}$$

$$S = \sqrt{\frac{\sum_{i=1}^{N} \tau_{i}^{2} 2\sigma_{i}^{2}}{P_{m}} - T_{m}^{2}}$$

# Condensed parameters Frequency correlation

A property closely related to the power-delay profile (PDP) is the **frequency correlation** of the channel. It is in fact the Fourier transform of the PDP:


$$\rho_f(\Delta f) = \int_{-\infty}^{\infty} P(\tau) \exp(-j2\pi \Delta f \tau) d\tau$$

For our tapped delay-line channel we get:


$$\rho_{f}(\Delta f) = \int_{-\infty}^{\infty} \left( \sum_{i=1}^{N} 2\sigma_{i}^{2} \delta(\tau - \tau_{i}) \right) \exp(-j2\pi \Delta f \tau) d\tau$$

$$= \sum_{i=1}^{N} 2\sigma_{i}^{2} \exp(-j2\pi \Delta f \tau_{i})$$

# Condensed parameters Coherence bandwidth



## Channel measures



# Condensed parameters The Doppler spectrum

Given the scattering function  $P_s$  (doppler spectrum as function of delay) we can calculate a total **Doppler spectrum** of the channel as:

$$P_{B}(v) = \int P_{S}(v,\tau) d\tau$$

For our tapped delay-line channel, we have:  $P_{S}(v,\tau) = \frac{2\sigma_{i}^{2}}{\pi\sqrt{v_{i,\max}^{2}-v^{2}}} \delta(\tau-\tau_{i})$  Doppler spectrum of tap *i*.  $P_{B}(v) = \int_{-\infty}^{\infty} \frac{2\sigma_{i}^{2}}{\pi\sqrt{v_{i,\max}^{2}-v^{2}}} \delta(\tau-\tau_{i}) d\tau$   $= \sum_{i=1}^{N} \frac{2\sigma_{i}^{2}}{\pi\sqrt{v_{i,\max}^{2}-v^{2}}}$ 

# Condensed parameters The Doppler spectrum (cont.)

We can "reduce" the Doppler spectrum into more compact descriptions of the channel:

Total power (frequency integrated):

$$P_{B,m} = \int_{-\infty}^{\infty} P_B(v) dv$$

Average mean Doppler shift:

$$T_{B,m} = \frac{\int_{-\infty}^{\infty} v P_B(v) dv}{P_{B,m}}$$

Average rms Doppler spread:

$$S_{B} = \sqrt{\frac{\int_{-\infty}^{\infty} v^{2} P(v) dv}{P_{B,m}}} - T_{B,m}^{2}$$


For our tapped-delay line channel: N

channel: 
$$P_{B,m} = \sum_{i=1}^{N} 2\sigma_i^2$$

$$T_{B,m}=0$$


$$S_B = \sqrt{\frac{\sum_{i=1}^{N} \sigma_i^2 v_{i,\text{max}}^2}{P_{B,m}}}$$

## Channel measures



# Condensed parameters Coherence time

Given the time correlation of a channel, we can define the coherence time  $T_C$ :



## Condensed parameters The time correlation

A property closely related to the Doppler spectrun is the time correlation of the channel. It is in fact the inverse Fourier transform of the Doppler spectrum:

$$\rho_{t}(\Delta t) = \int_{-\infty}^{\infty} P_{B}(v) \exp(j2\pi v \Delta t) dv$$


For our tapped-delay line channel we get 
$$\rho_t\left(\Delta t\right) = \int_{-\infty}^{\infty} \sum_{i=1}^{N} \frac{2\sigma_i^2}{\pi \sqrt{v_{i,\max}^2 - v^2}} \exp\left(j2\pi v \Delta t\right) dv$$

$$= \sum_{i=1}^{N} \int_{-\infty}^{\infty} \frac{2\sigma_i^2}{\pi \sqrt{v_{i,\max}^2 - v^2}} \exp\left(j2\pi v \Delta t\right) dv$$

$$= \sum_{i=1}^{N} 2\sigma_i^2 J_0\left(2\pi v_{i,\max} \Delta t\right)$$
Sum of time correlations for each tap.

each tap.

# It's much more complicated than what we have discussed!



Copyright: Shaker

#### **Properties of Wideband Channels**




- In wideband communication systems, multipath propagation results in inter-symbol interference (ISI)
- Wideband channels fade also in frequency, causing frequency-selective fading
- Wideband channels can be mathematically described as linear time-variant systems (LTV)
- Wideband channels are wide-sense stationary (WSS) with uncorrelated scattering (US) iff
  - their second order statistics (autocorrelation function) do not change over time
  - contributions with different delays are uncorrelated

#### WSS-US channels: discussion




- The WSSUS assumption greatly simplifies many calculations, and is thus very popular
- However, it should be used with great care and applicability should always be checked
- It assumes that channels are ergodic (i.e., ensemble average can be interchanged with time average)
- Real channels are never wide-sense stationary

## Double directional impulse response



# Physical interpretation




### **Directional models**

 The double directional delay power spectrum is sometimes factorized w.r.t. DoD, DoA and delay.


$$DDDPS(\Omega, \Psi, \tau) = APS^{BS}(\Omega)APS^{MS}(\Psi)PDP(\tau)$$

Often in reality there are groups of scatterers with similar DoD and DoA



## Angular spread

$$E\{s^*(\Omega, \Psi, \tau, \nu)s(\Omega', \Psi', \tau', \nu')\} = P_s(\Omega, \Psi, \tau, \nu)\delta(\Omega - \Omega')\delta(\Psi - \Psi')\delta(\tau - \tau')\delta(\nu - \nu')$$



double directional delay power spectrum  $DDDPS(\Omega, \Psi, \tau) = \int P_s(\Psi, \Omega, \tau, \nu) d\nu$ 

angular delay power spectrum  $ADPS(\Omega,\tau) = \int DDDPS(\Psi,\Omega,\tau)G_{\rm MS}(\Psi)d\Psi$ 

angular power spectrum  $APS(\Omega) = \int APDS(\Omega, \tau) d\tau$ 

power 
$$P = \int APS(\Omega)d\Omega$$

#### References





P. Bello.

"Characterization of randomly time-variant linear channels," *Communications Systems, IEEE Transactions on*, vol. 11, no. 4, pp. 360 –393, 1963.