

# **EK-TM4C1294XL-BOOSTXL-BATTPACK**Firmware Development Package

**USER'S GUIDE** 

## Copyright

Copyright © 2013-2015 Texas Instruments Incorporated. All rights reserved. Tiva and TivaWare are trademarks of Texas Instruments Instruments. ARM and Thumb are registered trademarks and Cortex is a trademark of ARM Limited. Other names and brands may be claimed as the property of others.

APlease be aware that an important notice concerning availability, standard warranty, and use in critical applications of Texas Instruments semiconductor products and disclaimers thereto appears at the end of this document.

Texas Instruments 108 Wild Basin, Suite 350 Austin, TX 78746 www.ti.com/tiva-c







#### **Revision Information**

This is version 2.1.1.71 of this document, last updated on May 07, 2015.

## **Table of Contents**

Cop	yright	2
Rev	ision Information	2
1	Introduction	5
2	Example Applications	7
2.1	Fuel Tank BoosterPack Measurement Example Application (boostxl_battpack)	7
IMP	ORTANT NOTICE	8

#### 1 Introduction

The Texas Instruments® Tiva™ EK-TM4C1294XL-BOOSTXL-BATTPACK evaluation board (Tiva C Series TM4C1294 Connected LaunchPad) is a low cost platform that can be used for software development and prototyping a hardware design. A variety of BoosterPacks are available to quickly extend the LaunchPad's features.

The EK-TM4C1294XL-BOOSTXL-BATTPACK includes a Tiva ARM® Cortex<sup>™</sup>-M4-based microcontroller and the following features:

- Tiva<sup>TM</sup> TM4C1294NCPDT microcontroller
- Ethernet connector
- USB OTG connector
- 2 user buttons
- 4 User LEDs
- 2 booster pack connectors
- On-board In-Circuit Debug Interface (ICDI)
- Power supply option from USB ICDI connection, USB OTG connection or external power connection
- Shunt jumper for microcontroller current consumption measurement

This document describes the example applications that are provided for the EK-TM4C1294XL when paired with the BOOSTXL-BATTPACK BoosterPack. This BoosterPack provides a lithium polymer battery that can power the LaunchPad for several hours. The BoosterPack features multiple Texas Instruments devices including two TP6300 series buck-boost converters, a BQ24210 battery charger and a BQ27510 battery gas gauge.

#### 2 Example Applications

The example applications show how to utilize features of the EK-TM4C1294XL development board. Examples are included to show how to use many of the general features of the Tiva microcontroller, as well as the feature that are unique to this development board.

A number of drivers are provided to make it easier to use the features of the EK-TM4C1294XL. These drivers also contain low-level code that make use of the TivaWare peripheral driver library and utilities.

There is an IAR workspace file (ek-tm4c1294x1-boostx1-battpack.eww) that contains the peripheral driver library project, along with all of the board example projects, in a single, easy-to-use workspace for use with Embedded Workbench

There is a Keil multi-project workspace file (ek-tm4c1294x1-boostx1-battpack.mpw) that contains the peripheral driver library project, along with all of the board example projects, in a single, easy-to-use workspace for use with uVision.

All of these examples reside in the examples/boards/ek-tm4c1294xl-boostxl-battpack subdirectory of the firmware development package source distribution.

# 2.1 Fuel Tank BoosterPack Measurement Example Application (boostxl\_battpack)

This example demonstrates the basic use of the Sensor Library, TM4C1294XL LaunchPad and the Fuel Tank BoosterPack to obtain state-of-charge, battery voltage, temperature, and several other supported measurements via the BQ27510G3 gas gauge sensor on the Fuel tank boosterpack.

The LEDs on the LaunchPad will blink while the application is running.

The Fuel Tank BoosterPack (BOOSTXL-BATTPACK) defaults to be installed on the BoosterPack 2 interface headers.

Instructions for use of Fuel Tank on BoosterPack 1 headers are in the code comments.

If you would like to observe how the application affects the voltage or current readings from the battery, please ensure the POWER\_SELECT (JP1) jumper on the EK-TM4C1294XL LaunchPad is configured for "BoosterPack".

Connect a serial terminal program to the LaunchPad's ICDI virtual serial port at 115,200 baud. Use eight bits per byte, no parity and one stop bit. The raw sensor measurements are printed to the terminal.

#### IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have not been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

"So long and thanks for all the fish." - Douglas Adams

Prod	ucts
------	------

Audio Amplifiers **Data Converters DLP® Products** DSP

Clocks and Timers Interface Logic Power Mgmt Microcontrollers

**OMAP Applications Processors** 

Wireless Connectivity

www.ti.com/audio amplifier.ti.com dataconverter.ti.com www.dlp.com dsp.ti.com www.ti.com/clocks interface.ti.com logic.ti.com power.ti.com microcontroller.ti.com www.ti-rfid.com

www.ti.com/omap www.ti.com/wirelessconnectivity

#### **Applications**

Automotive and Transportation Communications and Telecom Computers and Peripherals Consumer Electronics Energy and Lighting Industrial Medical Security Space, Avionics and Defense

Video and Imaging

TI E2E Community

www.ti.com/automotive

www.ti.com/communications www.ti.com/computers www.ti.com/consumer-apps

www.ti.com/energy www.ti.com/industrial www.ti.com/medical www.ti.com/security

www.ti.com/space-avionics-defense

www.ti.com/video

e2e.ti.com

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2013-2015, Texas Instruments Incorporated