Network Working Group Request for Comments: 1512

Updates: 1285

J. Case
The University of Tennesse and
SNMP Research, Incorporated
A. Rijsinghani
Digital Equipment Corporation
September 1993

FDDI Management Information Base

Status of this Memo

This RFC specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in TCP/IP-based internets. In particular, it defines objects for managing devices which implement the FDDI based on the ANSI FDDI SMT 7.3 draft standard [8], which has been forwarded for publication by the X3T9.5 committee.

Table of Contents

1. The Network Management Framework	. 2
1.1 Object Definitions	. 2
1.2 Format of Definitions	. 2
2. Overview	
2.1 Textual Conventions	. 3
3. Changes from RFC 1285	. 3
4. Object Definitions	. 4
4.1 The SMT Group	. 6
4.2 The MAC Group	. 17
4.3 The Enhanced MAC Counters Group	. 29
4.4 The PATH Group	. 32
4.5 The PORT Group	. 38
5. Acknowledgements	. 48
6. References	. 50
7. Security Considerations	. 51
8. Authors Addresses	. 51

1. The Network Management Framework

The Internet-standard Network Management Framework consists of three components. They are:

- o STD 16, RFC 1155 which defines the SMI, the mechanisms used for describing and naming objects for the purpose of management. STD 16, RFC 1212 defines a more concise description mechanism, which is wholly consistent with the SMI.
- o STD 17, RFC 1213 defines MIB-II, the core set of managed objects for the Internet suite of protocols.
- o STD 15, RFC 1157 which defines the SNMP, the protocol used for network access to managed objects.

The Framework permits new objects to be defined for the purpose of experimentation and evaluation.

1.1. Object Definitions

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the subset of Abstract Syntax Notation One (ASN.1) defined in the SMI. In particular, each object object type is named by an OBJECT IDENTIFIER, an administratively assigned name. The object type together with an object instance serves to uniquely identify a specific instantiation of the object. For human convenience, we often use a textual string, termed the descriptor, to refer to the object type.

1.2. Format of Definitions

Section 4 contains contains the specification of all object types contained in this MIB module. The object types are defined using the conventions defined in the SMI, as amended by the extensions specified in [7].

2. Overview

This document defines the managed objects for FDDI devices which are to be accessible via the Simple Network Management Protocol (SNMP). At present, this applies to these values of the ifType variable in the Internet-standard MIB:

fddi(15)

For these interfaces, the value of the ifSpecific variable in the

MIB-II [4] has the OBJECT IDENTIFIER value:

fddimib OBJECT IDENTIFIER ::= { fddi 73 }

The definitions of the objects presented here draws heavily from related work in the ANSI X3T9.5 committee and the SMT subcommittee of that committee [8]. In fact, the definitions of the managed objects in this document are, to the maximum extent possible, identical to those identified by the ANSI committee. The semantics of each managed object should be the same with syntactic changes made as necessary to recast the objects in terms of the Internet-standard SMI and MIB so as to be compatible with the SNMP. Examples of these syntactic changes include remapping booleans to enumerated integers, remapping bit strings to octet strings, and the like. In addition, the naming of the objects was changed to achieve compatibility.

These minimal syntactic changes with no semantic changes should allow implementations of SNMP manageable FDDI systems to share instrumentation with other network management schemes and thereby minimize implementation cost. In addition, the translation of information conveyed by managed objects from one network management scheme to another is eased by these shared definitions.

Only the essential variables, as indicated by their mandatory status in the ANSI specification, were retained in this document. The importance of variables which have an optional status in the ANSI specification were perceived as being less widely accepted.

2.1. Textual Conventions

Several new datatypes are introduced as a textual convention in this MIB document. These textual conventions enhance the readability of the document and ease comparisons with its ANSI counterpart. It should be noted that the introduction of these textual conventions has no effect on either the syntax or the semantics of any managed objects. The use of these is merely an artifact of the explanatory method used. Objects defined in terms of one of these methods are always encoded by means of the rules that define the primitive type. Hence, no changes to the SMI or the SNMP are necessary to accommodate these textual conventions which are adopted merely for the convenience of readers and writers in pursuit of the elusive goal of clear, concise, and unambiguous MIB documents.

3. Changes from RFC 1285

The changes from RFC 1285 [2] to this document, based on changes from ANSI SMT 6.2 to SMT 7.3, were so numerous that the objects in this MIB module are located on a different branch of the MIB tree. No

assumptions should be made about compatibility with RFC 1285.

4. Object Definitions

```
FDDI-SMT73-MIB DEFINITIONS ::= BEGIN
IMPORTS
        Counter
             FROM RFC1155-SMI
        OBJECT-TYPE
             FROM RFC-1212;
    This MIB module uses the extended OBJECT-TYPE macro as
    defined in [7].
-- this is the FDDI MIB module
fddi
        OBJECT IDENTIFIER ::= { transmission 15 }
fddimib
          OBJECT IDENTIFIER ::= { fddi 73 }
-- textual conventions
FddiTimeNano ::= INTEGER (0..2147483647)
-- This data type specifies 1 nanosecond units as
-- an integer value.
-- NOTE: The encoding is normal integer representation, not
-- two's complement. Since this type is used for variables
-- which are encoded as TimerTwosComplement in the ANSI
-- specification, two operations need to be performed on such
-- variables to convert from ANSI form to SNMP form:
-- 1) Convert from two's complement to normal integer
      representation
-- 2) Multiply by 80 to convert from 80 nsec to 1 nsec units
-- No resolution is lost. Moreover, the objects for which
-- this data type is used effectively do not lose any range
-- due to the lower maximum value since they do not require
-- the full range.
-- Example: If fddimibMACTReq had a value of 8 ms, it would
-- be stored in ANSI TimerTwosComplement format as 0xFFFE7960
-- [8 ms is 100000 in 80 nsec units, which is then converted -- to two's complement] but be reported as 8000000 in SNMP -- since it is encoded here as FddiTimeNano.
```

```
FddiTimeMilli ::= INTEGER (0..2147483647)
-- This data type is used for some FDDI timers. It specifies
-- time in 1 millisecond units, in normal integer
-- representation.
FddiResourceId ::= INTEGER (0..65535)
-- This data type is used to refer to an instance of a MAC, -- PORT, or PATH Resource ID. Indexing begins
-- at 1. Zero is used to indicate the absence of a resource.
FddiSMTStationIdType ::= OCTET STRING (SIZE (8))
-- The unique identifier for the FDDI station.
                                                             This is a
-- string of 8 octets, represented as X' yy yy xx xx xx xx -- xx xx' with the low order 6 octet (xx) from a unique IEEE -- assigned address. The high order two bits of the IEEE -- address, the group address bit and the administration bit
-- (Universal/Local) bit should both be zero. The first two
-- octets, the yy octets, are implementor-defined.
-- The representation of the address portion of the station id -- is in the IEEE (ANSI/IEEE P802.1A) canonical notation for
-- 48 bit addresses. The canonical form is a 6-octet string
-- where the first octet contains the first 8 bits of the
-- address, with the I/G(Individual/Group) address bit as the
-- least significant bit and the U/L (Universal/Local) bit
-- as the next more significant bit, and so on. Note that
-- addresses in the ANSI FDDI standard SMT frames are
-- represented in FDDI MAC order.
FddiMACLongAddressType ::= OCTET STRING (SIZE (6))
-- The representation of long MAC addresses as management
-- values is in the IEEE (ANSI/IEEE P802.1A) canonical
-- notation for 48 bit addresses. The canonical form is a
-- 6-octet string where the first octet contains the first 8
-- bits of the address, with the I/G (Individual/Group)
-- address bit as the least significant bit and the U/L
-- (Universal/Local) bit as the next more significant bit,
-- and so on. Note that the addresses in the SMT frames are
-- represented in FDDI MAC order.
-- groups in the FDDI MIB module
fddimibSMT
                          OBJECT IDENTIFIER ::= { fddimib 1 }
fddimibMAC
                          OBJECT IDENTIFIER ::= { fddimib 2 }
fddimibMACCounters
                         OBJECT IDENTIFIER ::= { fddimib 3 }
```

```
fddimibPATH
                    OBJECT IDENTIFIER ::= { fddimib 4 }
fddimibPORT
                    OBJECT IDENTIFIER ::= { fddimib 5 }
-- the SMT group
-- Implementation of the SMT group is mandatory for all
-- systems which implement manageable FDDI subsystems.
fddimibSMTNumber OBJECT-TYPE
            INTEGER (0..65535)
    SYNTAX
            read-only
    ACCESS
    STATUS
            mandatory
    DESCRIPTION
            "The number of SMT implementations (regardless of
            their current state) on this network management
            application entity. The value for this variable
            must remain constant at least from one re-
            initialization of the entity's network management
    system to the next re-initialization."
::= { fddimibSMT 1 }
-- the SMT table
fddimibSMTTable OBJECT-TYPE
            SEQUENCE OF FddimibSMTEntry
    SYNTAX
    ACCESS
            not-accessible
    STATUS
            mandatory
    DESCRIPTION
            "A list of SMT entries. The number of entries
            shall not exceed the value of fddimibSMTNumber."
    ::= { fddimibSMT 2 }
fddimibSMTEntry OBJECT-TYPE
    SYNTAX FddimibSMTEntry
    ACCESS
            not-accessible
    STATUS
            mandatorv
    DESCRIPTION
            "An SMT entry containing information common to a
            given SMT."
            { fddimibSMTIndex }
    INDEX
    ::= { fddimibSMTTable 1 }
FddimibSMTEntry ::=
    SEQUENCE 4
        fddimibSMTIndex
            INTEGER,
```

fddimibSMTStationId FddiSMTStationIdType, fddimibSMT0pVersionId INTEGER. fddimibSMTHiVersionId INTEGER,
fddimibSMTLoVersionId INTEGER, fddimibSMTUserData OCTET STRING, fddimibSMTMIBVersionId INTEGER, **fddimibSMTMACCts** INTEGER, fddimibSMTNonMasterCts INTEGER, fddimibSMTMasterCts INTEGER, fddimibSMTAvailablePaths INTEGER, **fddimibSMTConfigCapabilities** INTEGER, **fddimibSMTConfigPolicy** INTEGER. fddimibSMTConnectionPolicv INTEGER, fddimibSMTTNotify INTEGER, **fddimibSMTStatRptPolicy** INTEGER, **fddimibSMTTraceMaxExpiration** FddiTimeMilli, fddimibSMTBypassPresent INTEGER fddimibSMTECMState INTEGER, **fddimibSMTCFState INTEGER,** fddimibSMTRemoteDisconnectFlag INTEGER fddimibSMTStationStatus INTEGER, **fddimibSMTPeerWrapFlag** INTEGER, fddimibSMTTimeStamp FddiTimeMilli, fddimibSMTTransitionTimeStamp FddiTimeMilli,

```
fddimibSMTStationAction
            INTEGER
    }
fddimibSMTIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
            read-only
    ACCESS
    STATUS
            mandatory
    DESCRIPTION
            "A unique value for each SMT. The value for each
            SMT must remain constant at least from one re-
            initialization of the entity's network management
            system to the next re-initialization."
    ::= { fddimibSMTEntry 1 }
fddimibSMTStationId OBJECT-TYPE
           FddiSMTStationIdType -- OCTET STRING (SIZE (8))
    SYNTAX
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "Used to uniquely identify an FDDI station."
    REFERENCE
            "ANSI { fddiSMT 11 }"
    ::= { fddimibSMTEntry 2 }
fddimibSMTOpVersionId OBJECT-TYPE
            INTEGER (1..65535)
    SYNTAX
            read-only
    ACCESS
    STATUS
            mandatory
    DESCRIPTION
            "The version that this station is using for its
            operation (refer to ANSI 7.1.2.2). The value of
            this variable is 2 for this SMT revision."
    REFERENCE
             ANSI { fddiSMT 13 }"
    ::= { fddimibSMTEntry 3 }
fddimibSMTHiVersionId OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "The highest version of SMT that this station
            supports (refer to ANSI 7.1.2.2)."
    REFERENCE
            "ANSI { fddiSMT 14 }"
    ::= { fddimibSMTEntry 4 }
```

```
fddimibSMTLoVersionId OBJECT-TYPE
    SYNTAX
           INTEGER (1..65535)
   ACCESS
            read-only
    STATUS
           mandatory
   DESCRIPTION
            "The lowest version of SMT that this station
            supports (refer to ANSI 7.1.2.2)."
   REFERENCE
            ::= { fddimibSMTEntry 5 }
fddimibSMTUserData OBJECT-TYPE
    SYNTAX OCTET STRING (SIZE (32))
   ACCESS
           read-write
    STATUS
           mandatory
    DESCRIPTION
            "This variable contains 32 octets of user defined
            information. The information shall be an ASCII
            string."
   REFERENCE
            "ANSI { fddiSMT 17 }"
    ::= { fddimibSMTEntry 6 }
fddimibSMTMIBVersionId OBJECT-TYPE
    SYNTAX INTEGER (0..65535)
   ACCESS
            read-only
    STATUS
           mandatory
    DESCRIPTION
            "The version of the FDDI MIB of this station.
                                                           The
            value of this variable is 1 for this SMT
            revision."
   REFERENCE
            "ANSI { fddiSMT 18 }"
    ::= { fddimibSMTEntry 7 }
fddimibSMTMACCts OBJECT-TYPE
    SYNTAX INTEGER (0..255)
   ACCESS
            read-only
   STATUS
           mandatory
   DESCRIPTION
            "The number of MACs in this station or
            concentrator."
   REFERENCE
            "ANSI { fddiSMT 21 }"
    ::= { fddimibSMTEntry 8 }
fddimibSMTNonMasterCts OBJECT-TYPE
   SYNTAX INTEGER (0..2)
```

```
ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The value of this variable is the number of A, B,
             and S ports in this station or concentrator."
    REFERENCE
    "ANSI { fddiSMT 22 }"
::= { fddimibSMTEntry 9 }
fddimibSMTMasterCts OBJECT-TYPE
    SYNTAX INTEGER (0..255)
             read-only
    ACCESS
    STATUS
             mandatory
    DESCRIPTION
             "The number of M Ports in a node. If the node is
             not a concentrator, the value of the variable is
             zero."
    REFERENCE
             "ANSI { fddiSMT 23 }"
    ::= { fddimibSMTEntry 10 }
fddimibSMTAvailablePaths OBJECT-TYPE
    SYNTAX INTEGER (0..7)
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "A value that indicates the PATH types available
             in the station.
             The value is a sum. This value initially takes
             the value zero, then for each type of PATH that
             this node has available, 2 raised to a power is
             added to the sum. The powers are according to the
             following table:
                              Power
                       Path
                   Primary
                                0
                 Secondary
                                 1
                      Local
                                 2
             For example, a station having Primary and Local PATHs available would have a value of 5 (2**0 +
             2**2).'
    REFERENCE
             "ANSI { fddiSMT 24 }"
    ::= { fddimibSMTEntry 11 }
```

fddimibSMTConfigCapabilities OBJECT-TYPE

SYNTAX INTEGER (0..3) ACCESS read-only STATUS mandatory DESCRIPTION

"A value that indicates the configuration capabilities of a node. The 'Hold Available' bit indicates the support of the optional Hold Function, which is controlled by fddiSMTConfigPolicy. The 'CF-Wrap-AB' bit indicates that the station has the capability of performing a wrap_ab (refer to ANSI SMT 9.7.2.2).

The value is a sum. This value initially takes the value zero, then for each of the configuration policies currently enforced on the node, 2 raised to a power is added to the sum. The powers are according to the following table:

Policy Power holdAvailable 0 CF-Wrap-AB 1 "

REFERENCE

"ANSI { fddiSMT 25 }"
::= { fddimibSMTEntry 12 }

fddimibSMTConfigPolicy OBJECT-TYPE

SYNTAX INTEGER (0..1)
ACCESS read-write
STATUS mandatory
DESCRIPTION

"A value that indicates the configuration policies currently desired in a node. 'Hold' is one of the terms used for the Hold Flag, an optional ECM flag used to enable the optional Hold policy.

The value is a sum. This value initially takes the value zero, then for each of the configuration policies currently enforced on the node, 2 raised to a power is added to the sum. The powers are according to the following table:

Policy Power configurationhold 0 "

REFERENCE

"ANSI { fddiSMT 26 }"
::= { fddimibSMTEntry 13 }

fddimibSMTConnectionPolicy OBJECT-TYPE

```
SYNTAX INTEGER (32768..65535)
ACCESS read-write
STATUS mandatory
DESCRIPTION
```

"A value representing the connection policies in effect in a node. A station sets the corresponding bit for each of the connection types that it rejects. The letter designations, X and Y, in the 'rejectX-Y' names have the following significance: X represents the PC-Type of the local PORT and Y represents the PC_Type of the adjacent PORT (PC_Neighbor). The evaluation of Connection-Policy (PC-Type, PC-Neighbor) is done to determine the setting of T- Val(3) in the PC-Signalling sequence (refer to ANSI 9.6.3). Note that Bit 15, (rejectM-M), is always set and cannot be cleared.

The value is a sum. This value initially takes the value zero, then for each of the connection policies currently enforced on the node, 2 raised to a power is added to the sum. The powers are according to the following table:

```
Power
   Policy
rejectA-A
                0
                1
rejectA-B
                2
3
4
5
6
rejectA-S
rejectA-M
rejectB-A
rejectB-B
rejectB-S
                7
8
rejectB-M
rejectS-A
                9
reiectS-B
rejectS-S
                10
rejectS-M
                11
                12
rejectM-A
                13
rejectM-B
rejectM-S
                14
rejectM-M
                15
```

REFERENCE

```
"ANSI { fddiSMT 27 }"
::= { fddimibSMTEntry 14 }
```

```
fddimibSMTTNotify OBJECT-TYPE
SYNTAX INTEGER (2..30)
ACCESS read-write
STATUS mandatory
```

```
DESCRIPTION
            "The timer, expressed in seconds, used in the
            Neighbor Notification protocol. It has a range of
            2 seconds to 30 seconds, and its default value is
            30 seconds (refer to ANSI SMT 8.2)."
    REFERENCE
    "ANSI { fddiSMT 29 }"
::= { fddimibSMTEntry 15 }
fddimibSMTStatRptPolicy OBJECT-TYPE
            INTEGER { true(1), false(2) }
    SYNTAX
    ACCESS
            read-write
    STATUS
            mandatory
    DESCRIPTION
            "If true, indicates that the node will generate
            Status Reporting Frames for its implemented events
            and conditions. It has an initial value of true.
            This variable determines the value of the
            SR_Enable Flag (refer to ANSI SMT 8.3.2.1)."
    REFERENCE
            "ANSI { fddiSMT 30 }"
    ::= { fddimibSMTEntry 16 }
fddimibSMTTraceMaxExpiration OBJECT-TYPE
    SYNTAX FddiTimeMilli
    ACCESS
            read-write
    STATUS
            mandatory
    DESCRIPTION
            "Reference Trace_Max (refer to ANSI SMT
            9.4.4.2.2)."
    REFERENCE
            ::= { fddimibSMTEntry 17 }
fddimibSMTBypassPresent OBJECT-TYPE
    SYNTAX INTEGER { true(1), false(2) }
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "A flag indicating if the station has a bypass on
            its AB port pair.
    REFERENCE
            "ANSI { fddiSMT 34 }"
    ::= { fddimibSMTEntry 18 }
fddimibSMTECMState OBJECT-TYPE
   SYNTAX INTEGER {
ec0(1), -- Out
```

```
ec1(2), -- In
ec2(3), -- Trace
                 ec3(4), -- Leave
                 ec4(5), -- Path_Test
ec5(6), -- Insert
                 ec6(7), -- Check
                 ec7(8) -- Deinsert
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "Indicates the current state of the ECM state
            machine (refer to ANSI SMT 9.5.2)."
    REFERENCE
             "ANSI { fddiSMT 41 }"
    ::= { fddimibSMTEntry 19 }
fddimibSMTCFState OBJECT-TYPE
    SYNTAX INTEGER {
                 cf0(1),
                            -- isolated
                           -- local_a
                 cf1(2),
                           -- local_b
                 cf2(3),
                 cf3(4),
                           -- local ab
                 cf4(5),
                            -- local s
                 cf5(6),
                            -- wrap a
                 cf6(7),
                            -- wrap_b
                 cf7(8),
                            -- wrap_ab
                 cf8(9),
                            -- wrap_s
                 cf9(10),
                            -- c_wrap_a
                 cf10(11), -- c_wrap_b
                 cf11(12), -- c_wrap_s
cf12(13) -- thru
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
             "The attachment configuration for the station or
             concentrator (refer to ANSI SMT 9.7.2.2)."
    REFERENCE
             "ANSI { fddiSMT 42 }"
    ::= { fddimibSMTEntry 20 }
fddimibSMTRemoteDisconnectFlag OBJECT-TYPE
    SYNTAX
            INTEGER { true(1), false(2) }
    ACCESS
             read-only
            mandatory
    STATUS
    DESCRIPTION
             "A flag indicating that the station was remotely
```

```
disconnected from the network as a result of
            receiving an fddiSMTAction, disconnect (refer to
            ANSI SMT 6.4.5.3) in a Parameter Management Frame.
            A station requires a Connect Action to rejoin and
            clear the flag (refer to ANSI SMT 6.4.5.2)."
    REFERENCE
            "ANSI { fddiSMT 44 }"
    ::= { fddimibSMTEntry 21 }
fddimibSMTStationStatus OBJECT-TYPE
            INTEGER { concatenated(1), separated(2), thru(3) }
    SYNTAX
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "The current status of the primary and secondary
            paths within this station.
    REFERENCE
            "ANSI { fddiSMT 45 }"
    ::= { fddimibSMTEntry 22 }
fddimibSMTPeerWrapFlag OBJECT-TYPE
    SYNTAX
            INTEGER { true(1), false(2) }
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "This variable assumes the value of the
            PeerWrapFlag in CFM (refer to ANSI SMT
            9.7.2.4.4).
    REFERENCE
            "ANSI { fddiSMT 46 }"
    ::= { fddimibSMTEntry 23 }
fddimibSMTTimeStamp OBJECT-TYPE
    SYNTAX FddiTimeMilli
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "This variable assumes the value of TimeStamp
            (refer to ANSI SMT 8.3.2.1)."
    REFERENCE
            "ANSI { fddiSMT 51 }"
    ::= { fddimibSMTEntry 24 }
fddimibSMTTransitionTimeStamp OBJECT-TYPE
           FddiTimeMilli
    SYNTAX
            read-only
    ACCESS
    STATUS mandatory
    DESCRIPTION
```

```
"This variable assumes the value of
             TransitionTimeStamp (refer to ANSI SMT 8.3.2.1)."
    REFERENCE
             "ANSI { fddiSMT 52 }"
    ::= { fddimibSMTEntry 25 }
fddimibSMTStationAction OBJECT-TYPE
    SYNTAX INTEGER {
                 other(1), connect(2)
                                             -- none of the following
                  disconnect(3),
                  path-Test(4),
                  self-Test(5),
                  disable-a(6),
                  disable-b(7),
                  disable-m(8)
    ACCESS
             read-write
             mandatory
    STATUS
    DESCRIPTION
             "This object, when read, always returns a value of
             other(1). The behavior of setting this variable
             to each of the acceptable values is as follows:
                   other(1): Results in an appropriate error.
                   connect(2): Generates a Connect signal to ECM
                        to begin a connection sequence. See ANSI
                        Ref 9.4.2.
                   disconnect(3): Generates a Disconnect signal
                        to ECM. see ANSI Ref 9.4.2.
                   path-Test(4): Initiates a station Path_Test.
    The Path_Test variable (see ANSI Ref_
                        9.4.1) i\bar{s} set to 'Testing'. The results
                        of this action are not specified in this
                        standard.
                   self-Test(5): Initiates a station Self_Test.
                        The results of this action are not
                        specified in this standard.
                   disable-a(6): Causes a PC_Disable on the A
    port if the A port mode is peer.
                   disable-b(7): Causes a PC_Disable on the B
    port if the B port mode is peer.
                   disable-m(8): Causes a PC Disable on all M
                        ports.
             Attempts to set this object to all other values
             results in an appropriate error. The result of
             setting this variable to path-Test(4) or self-
```

```
Test(5) is implementation-specific."
    REFERENCE
            "ANSI { fddiSMT 60 }"
    ::= { fddimibSMTEntry 26 }
-- the MAC group
-- Implementation of the MAC Group is mandatory for all
-- systems which implement manageable FDDI subsystems.
fddimibMACNumber OBJECT-TYPE
    SYNTAX
            INTEGER (0..65535)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "The total number of MAC implementations (across
            all SMTs) on this network management application
                    The value for this variable must remain
            constant at least from one re-initialization of
            the entity's network management system to the next re-initialization."
    ::= { fddimibMAC 1 }
-- the MAC table
fddimibMACTable OBJECT-TYPE
    SYNTAX SEQUENCE OF FddimibMACEntry
    ACCESS
            not-accessible
    STATUS
            mandatory
    DESCRIPTION
            "A list of MAC entries. The number of entries
            shall not exceed the value of fddimibMACNumber."
    ::= { fddimibMAC 2 }
fddimibMACEntry OBJECT-TYPE
    SYNTAX FddimibMACEntry
    ACCESS
            not-accessible
    STATUS
            mandatory
    DESCRIPTION
            "A MAC entry containing information common to a
            given MAC.'
            { fddimibMACSMTIndex, fddimibMACIndex }
    INDEX
    ::= { fddimibMACTable 1 }
FddimibMACEntry ::=
    SEQUENCE { fddimibMACSMTIndex
```

```
INTEGER,
fddimibMACIndex
        INTEGER.
fddimibMACIfIndex
INTEGER, fddimibMACFrameStatusFunctions
        INTEGER,
fddimibMACTMaxCapability
FddiTimeNano, fddimibMACTVXCapability
        FddiTimeNano,
fddimibMACAvailablePaths
        INTEGER,
fddimibMACCurrentPath
        INTEGER,
fddimibMACUpstreamNbr
        FddiMACLongAddressType,
fddimibMACDownstreamNbr
        FddiMACLongAddressType,
fddimibMACOldUpstreamNbr
        FddiMACLongAddressType,
fddimibMACOldDownstreamNbr
        FddiMACLongAddressType,
fddimibMACDupAddressTest
        INTEGER,
fddimibMACRequestedPaths
        INTEGER,
fddimibMACDownstreamPORTType
        INTEGER,
fddimibMACSMTAddress
        FddiMACLongAddressType,
fddimibMACTReq
        FddiTimeNano,
fddimibMACTNea
        FddiTimeNano,
fddimibMACTMax
        FddiTimeNano,
fddimibMACTvxValue
        FddiTimeNano,
fddimibMACFrameCts
        Counter,
fddimibMACCopiedCts
        Counter,
fddimibMACTransmitCts
        Counter,
fddimibMACErrorCts
Counter, fddimibMACLostCts
```

```
Counter,
        fddimibMACFrameErrorThreshold
                INTEGER,
        fddimibMACFrameÉrrorRatio
                INTEGER,
        fddimibMACRMTState
                INTEGER.
        fddimibMACDaFlag
                INTEGER,
        fddimibMACUnaDaFlag
                INTEGER.
        fddimibMACFrameErrorFlag
                INTEGER,
        fddimibMACMAUnitdataAvailable
                INTEGER,
        fddimibMACHardwarePresent
                INTEGER,
        fddimibMACMAUnitdataEnable
                INTEGER
    }
fddimibMACSMTIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
   ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "The value of the SMT index associated with this
            MAC.
    ::= { fddimibMACEntry 1 }
fddimibMACIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "Index variable for uniquely identifying the MAC
            object instances, which is the same as the
            corresponding resource index in SMT."
    REFERENCE
            "ANSI { fddiMAC 34 }"
    ::= { fddimibMACEntry 2 }
fddimibMACIfIndex OBJECT-TYPE
            INTEGER (1..65535)
    SYNTAX
    ACCESS
            read-only
    STATUS mandatory
    DESCRIPTION
```

```
"The value of the MIB-II ifIndex corresponding to
            this MAC. If none is applicable, 0 is returned.'
   REFERENCE
            "MIB-II"
    ::= { fddimibMACEntry 3 }
fddimibMACFrameStatusFunctions OBJECT-TYPE
    SYNTAX
           INTEGER (0..7)
   ACCESS
            read-only
    STATUS
           mandatory
   DESCRIPTION
            "Indicates the MAC's optional Frame Status
            processing functions.
            The value is a sum. This value initially takes
            the value zero, then for each function present, 2
            raised to a power is added to the sum. The powers
            are according to the following table:
                 function
                            Power
             fs-repeating
                              0
               fs-setting
                              1
              fs-clearing
   REFERENCE
            'ANSI { fddiMAC 11 }"
    ::= { fddimibMACEntry 4 }
fddimibMACTMaxCapability OBJECT-TYPE
    SYNTAX
           FddiTimeNano
    ACCESS
            read-only
    STATUS
           mandatory
   DESCRIPTION
            "Indicates the maximum time value of fddiMACTMax
            that this MAC can support."
   REFERENCE
            ::= { fddimibMACEntry 5 }
fddimibMACTVXCapability OBJECT-TYPE
    SYNTAX FddiTimeNano
    ACCESS
            read-only
    STATUS
           mandatory
    DESCRIPTION
            "Indicates the maximum time value of
            fddiMACTvxValue that this MAC can support."
   REFERENCE
            "ANSI { fddiMAC 14 }"
    ::= { fddimibMACEntry 6 }
```

fddimibMACAvailablePaths OBJECT-TYPE

```
SYNTAX
            INTEGER (0..7)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "Indicates the paths available for this MAC (refer
            to ANSI SMT 9.7.7).
            The value is a sum. This value initially takes
            the value zero, then for each type of PATH that
            this MAC has available, 2 raised to a power is
            added to the sum. The powers are according to the
            following table:
                      Path
                             Power
                  Primary
                               0
                Secondary
                     Local
    REFERENCE
    "ANSI { fddiMAC 22 }"
::= { fddimibMACEntry 7 }
fddimibMACCurrentPath OBJECT-TYPE
    SYNTAX INTEGER {
                isolated(1),
                local(2),
                secondary(3),
                primary(4),
                concatenated(5),
                thru(6)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "Indicates the Path into which this MAC is
            currently inserted (refer to ANSI 9.7.7)."
    REFERENCE
            "ANSI { fddiMAC 23 }"
    ::= { fddimibMACEntry 8 }
fddimibMACUpstreamNbr OBJECT-TYPE
    SYNTAX
            FddiMACLongAddressType -- OCTET STRING (SIZE (6))
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "The MAC's upstream neighbor's long individual MAC
            address. It has an initial value of the SMT-
            Unknown-MAC Address and is only modified as
```

```
specified by the Neighbor Information Frame
             protocol (refer to ANSI SMT 7.2.1 and 8.2)."
    REFERENCE
             "ANSI { fddiMAC 24 }"
    ::= { fddimibMACEntry 9 }
fddimibMACDownstreamNbr OBJECT-TYPE
             FddiMACLongAddressType -- OCTET STRING (SIZE (6))
    SYNTAX
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The MAC's downstream neighbor's long individual
             MAC address. It has an initial value of the SMT-
             Unknown-MAC Address and is only modified as specified by the Neighbor Information Frame
             protocol (refer to ANSI SMT 7.2.1 and 8.2)."
    REFERENCE
             "ANSI { fddiMAC 25 }"
    ::= { fddimibMACEntry 10 }
fddimibMACOldUpstreamNbr OBJECT-TYPE
    SYNTAX
             FddiMACLongAddressType -- OCTET STRING (SIZE (6))
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The previous value of the MAC's upstream
             neighbor's long individual MAC address. It has an initial value of the SMT-Unknown- MAC Address and
             is only modified as specified by the Neighbor
             Information Frame protocol (refer to ANSI SMT
             7.2.1 and 8.2)."
    REFERENCE
             "ANSI { fddiMAC 26 }"
    ::= { fddimibMACEntry 11 }
fddimibMACOldDownstreamNbr OBJECT-TYPE
            FddiMACLongAddressType -- OCTET STRING (SIZE (6))
    SYNTAX
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The previous value of the MAC's downstream neighbor's long individual MAC address. It has an
             initial value of the SMT- Unknown-MAC Address and
             is only modified as specified by the Neighbor
             Information Frame protocol (refer to ANSI SMT
             7.2.1 and 8.2)."
    REFERENCE
             "ANSI { fddiMAC 27 }"
```

INTEGER { none(1), pass(2), fail(3) }

::= { fddimibMACEntry 12 }

SYNTAX

fddimibMACDupAddressTest OBJECT-TYPE

```
ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            'The Duplicate Address Test flag, Dup_Addr_Test
            (refer to ANSI 8.2)."
    REFERENCE
            ::= { fddimibMACEntry 13 }
fddimibMACRequestedPaths OBJECT-TYPE
    SYNTAX
            INTEGER (0..255)
    ACCESS
            read-write
    STATUS
            mandatory
    DESCRIPTION
            "List of permitted Paths which specifies the
            Path(s) into which the MAC may be inserted (refer
            to ansi SMT 9.7).
            The value is a sum which represents the individual
            paths that are desired. This value initially
            takes the value zero, then for each type of PATH
            that this node is, 2 raised to a power is added to
            the sum. The powers are according to the
            following table:
                               Path
                                      Power
                              local
                                        0
                                        1
                secondary-alternate
                                        2
                  primary-alternate
             concatenated-alternate
                                        3
                secondary-preferred
                                        5
                  primary-preferred
             concatenated-preferred
                                          - 11
    REFERENCE
            "ANSI { fddiMAC 32 }"
    ::= { fddimibMACEntry 14 }
fddimibMACDownstreamPORTType OBJECT-TYPE
            INTEGER { a(1), b(2), s(3), m(4), none(5) }
    SYNTAX
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "Indicates the PC-Type of the first port that is
```

```
downstream of this MAC (the exit port)."
   REFERENCE
            "ANSI { fddiMAC 33 }"
    ::= { fddimibMACEntry 15 }
fddimibMACSMTAddress OBJECT-TYPE
    SYNTAX
           FddiMACLongAddressType -- OCTET STRING (SIZE (6))
   ACCESS
            read-only
    STATUS
           mandatory
   DESCRIPTION
            "The 48-bit individual address of the MAC used for
            SMT frames."
   REFERENCE
            "ANSI { fddiMAC 41 }"
    ::= { fddimibMACEntry 16 }
fddimibMACTReg OBJECT-TYPE
           FddiTimeNano
    SYNTAX
   ACCESS
            read-only
    STATUS
           mandatory
   DESCRIPTION
            "This variable is the T_Req_value passed to the
           MAC. Without having detected a duplicate, the
            time value of this variable shall assume the
            maximum supported time value which is less than or
            equal to the time value of fddiPATHMaxT-Req. When
            a MAC has an address detected as a duplicate, it
            may use a time value for this variable greater
            than the time value of fddiPATHTMaxLowerBound.
            station shall cause claim when the new T Req may
            cause the value of T_Neg to change in the claim
            process, (i.e., time value new T_Req < T_Neg, or
            old T Réq = T Neg)."
   REFERENCE
            ::= { fddimibMACEntry 17 }
fddimibMACTNea OBJECT-TYPE
    SYNTAX FddiTimeNano
   ACCESS
           read-only
    STATUS
           mandatory
    DESCRIPTION
            "It is reported as a FddiTimeNano number."
   REFERENCE
            "ANSI { fddiMAC 52 }"
    ::= { fddimibMACEntry 18 }
fddimibMACTMax OBJECT-TYPE
```

```
SYNTAX
            FddiTimeNano
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "This variable is the T Max value passed to the
            MAC. The time value of this variable shall assume
            the minimum suported time value which is greater
            than or equal to the time value of fddiPATHT-
            MaxLowerBound'
    REFERENCE
             ::= { fddimibMACEntry 19 }
fddimibMACTvxValue OBJECT-TYPE
    SYNTAX FddiTimeNano
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "This variable is the TVX_value passed to the MAC.
            The time value of this variable shall assume the minimum suported time value which is greater than
            or equal to the time value of
            fddiPATHTVXLowerBound.'
    REFERENCE
             "ANSI { fddiMAC 54 }"
    ::= { fddimibMACEntry 20 }
fddimibMACFrameCts OBJECT-TYPE
    SYNTAX
            Counter
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "A count of the number of frames received by this
            MAC (refer to ANSI MAC 7.5.1)."
    REFERENCE
             ::= { fddimibMACEntry 21 }
fddimibMACCopiedCts OBJECT-TYPE
    SYNTAX
            Counter
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "A count that should as closely as possible match
            the number of frames addressed to (A bit set) and
            successfully copied into the station's receive buffers (C bit set) by this MAC (refer to ANSI MAC
            7.5). Note that this count does not include MAC
```

```
frames."
    REFERENCE
             "ANSI { fddiMAC 72 }"
    ::= { fddimibMACEntry 22 }
fddimibMACTransmitCts OBJECT-TYPE
    SYNTAX Counter
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "A count that should as closely as possible match
the number of frames transmitted by this MAC
             (refer to ANSI MAC 7.5). Note that this count
            does not include MAC frames."
    REFERENCE
             "ANSI { fddiMAC 73 }"
    ::= { fddimibMACEntry 23 }
fddimibMACErrorCts OBJECT-TYPE
    SYNTAX Counter
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "A count of the number of frames that were
            detected in error by this MAC that had not been
            detected in error by another MAC (refer to ANSI
            MAC 7.5.2)."
    REFERENCE
            "ANSI { fddiMAC 81 }"
    ::= { fddimibMACEntry 24 }
fddimibMACLostCts OBJECT-TYPE
    SYNTAX Counter
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "A count of the number of instances that this MAC
            detected a format error during frame reception
            such that the frame was stripped (refer to ANSI
            MAC 7.5.3)."
    REFERENCE
             "ANSI { fddiMAC 82 }"
    ::= { fddimibMACEntry 25 }
fddimibMACFrameErrorThreshold OBJECT-TYPE
    SYNTAX
            INTEGER (0..65535)
            read-write
    ACCESS
    STATUS
            mandatory
```

```
DESCRIPTION
             "A threshold for determining when a MAC Condition report (see ANSI 8.3.1.1) shall be generated.
             Stations not supporting variable thresholds shall
             have a value of 0 and a range of (0..0)."
    REFERENCE
             "ANSI { fddiMAC 95 }"
    ::= { fddimibMACEntry 26 }
fddimibMACFrameErrorRatio OBJECT-TYPE
    SYNTAX INTEGER (0..65535)
    ACCESS
            read-only
    STATUS
             mandatory
    DESCRIPTION
             "This variable is the value of the ratio,
              ((delta fddiMACLostCts + delta fddiMACErrorCts) /
              (delta fddiMACFrameCts + delta fddiMACLostCts ))
              * 2**16 "
    REFERENCE
              ANSI { fddiMAC 96 }"
    ::= { fddimibMACEntry 27 }
fddimibMACRMTState OBJECT-TYPE
    SYNTAX INTEGER {
                 rm0(1), -- Isolated
                 rm1(2), -- Non_Op
                 rm2(3), -- Ring_Op
                 rm3(4), -- Detect
                 rm4(5), -- Non_Op_Dup
                 rm5(6), -- Ring_Op_Dup
rm6(7), -- Directed
rm7(8) -- Trace
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "Indicates the current state of the RMT State
             Machine (refer to ANSI 10.3.2)."
    REFERENCE
             "ANSI { fddiMAC 111 }"
    ::= { fddimibMACEntry 28 }
fddimibMACDaFlag OBJECT-TYPE
             INTEGER { true(1), false(2) }
    SYNTAX
    ACCESS
             read-only
    STATUS mandatory
    DESCRIPTION
```

```
"The RMT flag Duplicate Address Flag, DA_Flag
             (refer to ANSI 10.2.1.2)."
    REFERENCE
             "ANSI { fddiMAC 112 }"
    ::= { fddimibMACEntry 29 }
fddimibMACUnaDaFlag OBJECT-TYPE
    SYNTAX INTEGER { true(1), false(2) }
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "A flag, UNDA_Flag (refer to ANSI 8.2.2.1), set
            when the upstream neighbor reports a duplicate
            address condition. Cleared when the condition clears."
    REFERENCE
             "ANSI { fddiMAC 113 }"
    ::= { fddimibMACEntry 30 }
fddimibMACFrameErrorFlag OBJECT-TYPE
            INTEGER { true(1), false(2) }
    SYNTAX
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "Indicates the MAC Frame Error Condition is
            present when set. Cleared when the condition
            clears and on station initialization."
    REFERENCE
            "ANSI { fddiMAC 1<u>1</u>4 }"
    ::= { fddimibMACEntry 31 }
fddimibMACMAUnitdataAvailable OBJECT-TYPE
    SYNTAX
            INTEGER { true(1), false(2) }
    ACCESS
            read-only
            mandatory
    STATUS
    DESCRIPTION
             "This variable shall take on the value of the
            MAC Avail flag defined in RMT."
    REFERENCE
             "ANSI { fddiMAC 116 }"
    ::= { fddimibMACEntry 32 }
fddimibMACHardwarePresent OBJECT-TYPE
    SYNTAX
            INTEGER { true(1), false(2) }
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "This variable indicates the presence of
```

```
underlying hardware support for this MAC object. If the value of this object is false(2), the
             reporting of the objects in this entry may be
             handled in an implementation-specific manner."
    REFERENCE
             "ANSI { fddiMAC 117 }"
    ::= { fddimibMACEntry 33 }
fddimibMACMAUnitdataEnable OBJECT-TYPE
             INTEGER { true(1), false(2) }
    SYNTAX
    ACCESS
             read-write
    STATUS
             mandatory
    DESCRIPTION
             "This variable determines the value of the
             MA_UNITDATA_Enable flag in RMT. The default and
             initial value of this flag is true(1).'
    REFERENCE
             "ANSI { fddiMAC 118 }"
    ::= { fddimibMACEntry 34 }
-- the Enhanced MAC Counters group
-- Implementation of this Group is optional, but systems
-- claiming support must implement all variables in this
-- aroup
-- the MAC Counters table
fddimibMACCountersTable OBJECT-TYPE
             SEQUENCE OF FddimibMACCountersEntry
    SYNTAX
    ACCESS
             not-accessible
    STATUS
             mandatory
    DESCRIPTION
             "A list of MAC Counters entries. The number of
             entries shall not exceed the value of
             fddimibMACNumber.
    ::= { fddimibMACCounters
fddimibMACCountersEntry OBJECT-TYPE
    SYNTAX FddimibMACCountersEntry
    ACCESS
             not-accessible
    STATUS
             mandatory
    DESCRIPTION
             "A MAC Counters entry containing information common to a given MAC."
    INDEX { fddimibMACSMTIndex, fddimibMACIndex }
::= { fddimibMACCountersTable 1 }
    INDEX
```

```
FddimibMACCountersEntry ::=
    SEQUENCE {
        fddimibMACTokenCts
                 Counter,
        fddimibMACTvxExpiredCts
                 Counter,
        fddimibMACNotCopiedCts
                 Counter,
        fddimibMACLateCts
                 Counter,
        fddimibMACRingOpCts
                 Counter,
        fddimibMACNotCopiedRatio
                 INTEGER,
        fddimibMACNotCopiedFlag
                 INTEGER,
        fddimibMACNotCopiedThreshold
                 INTEGER
    }
fddimibMACTokenCts OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
    STATUS
            mandatory
    DESCRIPTION
             "A count that should as closely as possible match
             the number of times the station has received a
             token (total of non-restricted and restricted) on this MAC (see ANSI MAC 7.4). This count is
             valuable for determination of network load."
    REFERENCE
             "ANSI { fddiMAC 74 }"
    ::= { fddimibMACCountersEntry 1 }
fddimibMACTvxExpiredCts OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
            mandatory
    STATUS
    DESCRIPTION
             "A count that should as closely as possible match
             the number of times that TVX has expired.'
    REFERENCE
             "ANSI { fddiMAC 83 }"
    ::= { fddimibMACCountersEntry 2 }
fddimibMACNotCopiedCts OBJECT-TYPE
            Counter
    SYNTAX
    ACCESS
             read-only
```

```
STATUS mandatory
     DESCRIPTION
               "A count that should as closely as possible match
               the number of frames that were addressed to this
               MAC but were not copied into its receive buffers
               (see ANSI MAC 7.5). For example, this might occur due to local buffer congestion. Because of implementation considerations, this count may not
               match the actual number of frames not copied. It
               is not a requirement that this count be exact.
               Note that this count does not include MAC frames."
     REFERENCE
               "ANSI { fddiMAC 84 }"
     ::= { fddimibMACCountersEntry 3 }
fddimibMACLateCts OBJECT-TYPE
     SYNTAX
               Counter
     ACCESS
               read-only
     STATUS
               mandatory
     DESCRIPTION
               "A count that should as closely as possible match
the number of TRT expirations since this MAC was
               reset or a token was received (refer to ANSI MAC
               7.4.5)."
     REFERENCE
               "ANSI { fddiMAC 85 }"
     ::= { fddimibMACCountersEntry 4 }
fddimibMACRingOpCts OBJECT-TYPE
     SYNTAX
               Counter
               read-only
     ACCESS
     STATUS
               mandatory
     DESCRIPTION
               "The count of the number of times the ring has entered the 'Ring_Operational' state from the 'Ring Not Operational' state. This count is
               updated when a SM MA STATUS. Indication of a change
               in the Ring_Operational status occurs (refer to
               ANSI 6.1.4). Because of implementation
               considerations, this count may be less than the actual RingOp_Ct. It is not a requirement that this count be exact."
     REFERENCE
               "ANSI { fddiMAC 86 }"
     ::= { fddimibMACCountersEntry 5 }
fddimibMACNotCopiedRatio OBJECT-TYPE
     SYNTAX INTEGER (0..65535)
```

```
ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "This variable is the value of the ratio:
             (delta fddiMACNotCopiedCts /
             (delta fddiMACCopiedCts +
               delta fddiMACNotCopiedCts )) * 2**16 "
    REFERENCE
            'ANSI { fddiMAC 105 }"
    ::= { fddimibMACCountersEntry 6 }
fddimibMACNotCopiedFlag OBJECT-TYPE
            INTEGER { true(1), false(2) }
    SYNTAX
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "Indicates that the Not Copied condition is
            present when read as true(1). Set to false(2)
            when the condition clears and on station
            initialization."
    REFERENCE
            "ANSI { fddiMAC 115 }"
    ::= { fddimibMACCountersEntry 7 }
fddimibMACNotCopiedThreshold OBJECT-TYPE
            INTEGER (0..65535)
    SYNTAX
            read-write
    ACCESS
    STATUS
            mandatory
    DESCRIPTION
            "A threshold for determining when a MAC condition
            report shall be generated. Stations not
            supporting variable thresholds shall have a value
            of 0 and a range of (0..0)."
    REFERENCE
            'ANSI { fddiMAC 103 }"
    ::= { fddimibMACCountersEntry 8 }
-- the PATH group
-- Implementation of the PATH group is mandatory for all
-- systems which implement manageable FDDI subsystems.
fddimibPATHNumber OBJECT-TYPE
            INTEGER (0..65535)
    SYNTAX
            read-only
    ACCESS
    STATUS mandatory
    DESCRIPTION
```

```
"The total number of PATHs possible (across all
            SMTs) on this network management application
            entity. The value for this variable must remain
            constant at least from one re-initialization of
            the entity's network management system to the next
            re-initialization."
    ::= { fddimibPATH 1 }
-- the PATH table
fddimibPATHTable OBJECT-TYPE
    SYNTAX
            SEQUENCE OF FddimibPATHEntry
    ACCESS
            not-accessible
    STATUS
            mandatory
    DESCRIPTION
            "A list of PATH entries. The number of entries
            shall not exceed the value of fddimibPATHNumber."
    ::= { fddimibPATH 2 }
fddimibPATHEntry OBJECT-TYPE
    SYNTAX FddimibPATHEntry
    ACCESS
            not-accessible
    STATUS
            mandatorv
    DESCRIPTION
            "A PATH entry containing information common to a
            given PATH."
            { fddimibPATHSMTIndex, fddimibPATHIndex }
    INDEX
    ::= { fddimibPATHTable 1 }
FddimibPATHEntry ::=
    SEQUENCE {
        fddimibPATHSMTIndex
                INTEGER.
        fddimibPATHIndex
                INTEGER,
        fddimibPATHTVXLowerBound
                FddiTimeNano.
        fddimibPATHTMaxLowerBound
                FddiTimeNano,
        fddimibPATHMaxTReq
                FddiTimeNano
    }
fddimibPATHSMTIndex OBJECT-TYPE
    SYNTAX
            INTEGER (1..65535)
    ACCESS
            read-only
    STATUS
            mandatory
```

```
DESCRIPTION
            "The value of the SMT index associated with this
            PATH."
    ::= { fddimibPATHEntry 1 }
fddimibPATHIndex OBJECT-TYPE
    SYNTAX
            INTEGER (0..65535)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "Index variable for uniquely identifying the
            primary, secondary and local PATH object
            instancés. Local PATH object instancés are
            represented with integer values 3 to 255.
    REFERENCE
            "ANSI { fddiPATH 11 }"
    ::= { fddimibPATHEntry 2 }
fddimibPATHTVXLowerBound OBJECT-TYPE
    SYNTAX FddiTimeNano
    ACCESS
            read-write
    STATUS
            mandatory
    DESCRIPTION
            "Specifies the minimum time value of
            fddiMACTvxValue that shall be used by any MAC that
            is configured in this path. The operational value of fddiMACTvxValue is managed by settting this
            variable. This variable has the time value range
            of:
            0 < fddimibPATHTVXLowerBound < fddimibPATHMaxTReq</p>
            Changes to this variable shall either satisfy the
            time value relationship:
            fddimibPATHTVXLowerBound <=
            fddimibMACTVXCapability
            of each of the MACs currently on the path, or be
            considered out of range. The initial value of
            fddimibPATHTVXLowerBound shall be 2500 nsec (2.5
            ms)."
    REFERENCE
            "ANSI { fddiPATH 21 }"
    ::= { fddimibPATHEntry 3 }
fddimibPATHTMaxLowerBound OBJECT-TYPE
    SYNTAX FddiTimeNano
```

```
ACCESS read-write
STATUS mandatory
DESCRIPTION
```

"Specifies the minimum time value of fddiMACTMax that shall be used by any MAC that is configured in this path. The operational value of fddiMACTMax is managed by setting this variable. This variable has the time value range of:

fddimibPATHMaxTReq <= fddimibPATHTMaxLowerBound</pre>

and an absolute time value range of:

10000nsec (10 msec) <= fddimibPATHTMaxLowerBound

Changes to this variable shall either satisfy the time value relationship:

fddimibPATHTMaxLowerBound <
fddimibMACTMaxCapability</pre>

of each of the MACs currently on the path, or be considered out of range. The initial value of fddimibPATHTMaxLowerBound shall be 165000 nsec (165 msec)."

REFERENCE

"ANSI { fddiPATH 22 }"
::= { fddimibPATHEntry 4 }

fddimibPATHMaxTReq OBJECT-TYPE

SYNTAX FddiTimeNano ACCESS read-write STATUS mandatory DESCRIPTION

"Specifies the maximum time value of fddiMACT-Req that shall be used by any MAC that is configured in this path. The operational value of fddiMACT-Req is managed by setting this variable. This variable has the time value range of:

The default value of fddimibPATHMaxTReq is 165000 nsec (165 msec)."

REFERENCE

"ANSI { fddiPATH 23 }"
::= { fddimibPATHEntry 5 }

```
-- the PATH Configuration table
fddimibPATHConfigTable OBJECT-TYPE
    SYNTAX SEQUENCE OF FddimibPATHConfigEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
             "A table of Path configuration entries. This
             table lists all the resources that may be in this
             Path."
    REFERENCE
             "ANSI { fddiPATH 18 }"
    ::= { fddimibPATH 3 }
fddimibPATHConfigEntry OBJECT-TYPE
    SYNTAX FddimibPATHConfigEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
    "A collection of objects containing information
for a given PATH Configuration entry."
INDEX { fddimibPATHConfigSMTIndex,
             fddimibPATHConfigPATHIndex,
             fddimibPATHConfigTokenOrder }
    ::= { fddimibPATHConfigTable 1 }
FddimibPATHConfigEntry ::=
    SEQUENCE {
        fddimibPATHConfigSMTIndex
             INTEGER.
        fddimibPATHConfigPATHIndex
             INTEGER.
        fddimibPATHConfigTokenOrder
        INTEGER, fddimibPATHConfigResourceType
             INTEGER,
        fddimibPATHConfigResourceIndex
             INTEGER.
        fddimibPATHConfigCurrentPath
             INTEGER
    }
fddimibPATHConfigSMTIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
             "The value of the SMT index associated with this
```

```
configuration entry."
    ::= { fddimibPATHConfigEntry 1 }
fddimibPATHConfiqPATHIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
             "The value of the PATH resource index associated
            with this configuration entry.
    ::= { fddimibPATHConfigEntry 2 }
fddimibPATHConfigTokenOrder OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only STATUS mandatory
    DESCRIPTION
             "An object associated with Token order for this
            entry. Thus if the token passes resources a, b, c and d, in that order, then the value of this
             object for these resources would be 1, 2, 3 and 4
             respectively.
    ::= { fddimibPATHConfigEntry 3 }
fddimibPATHConfiaResourceType OBJECT-TYPE
    SYNTAX INTEGER { mac(2), port(4) }
    ACCESS read-only
STATUS mandatory
    DESCRIPTION
             "The type of resource associated with this
             configuration entry."
    ::= { fddimibPATHConfigEntry 4 }
fddimibPATHConfiaResourceIndex OBJECT-TYPE
    SYNTAX INTEGÉR (1..65535)
    ACCESS read-only
    STATUS mandatorv
    DESCRIPTION
             "The value of the SMT resource index used to refer
             to the instance of this MAC or Port resource."
    ::= { fddimibPATHConfigEntry 5 }
fddimibPATHConfigCurrentPath OBJECT-TYPE
    SYNTAX INTEGER {
              isolated(1), local(2), secondary(3), primary(4),
              concatenated(5), thru(6)
    ACCESS read-only
```

```
STATUS mandatory
    DESCRIPTION
             "The current insertion status for this resource on
             this Path.'
    ::= { fddimibPATHConfigEntry 6 }
-- the PORT group
-- Implementation of the PORT group is mandatory for all
-- systems which implement manageable FDDI subsystems.
fddimibPORTNumber OBJECT-TYPE
            INTEGER (0..65535)
    SYNTAX
    ACCESS
             read-only
    STATUS
            mandatory
    DESCRIPTION
             "The total number of PORT implementations (across
             all SMTs) on this network management application
             entity. The value for this variable must remain constant at least from one re-initialization of
            the entity's network management system to the next re-initialization."
    ::= { fddimibPORT 1 }
-- the PORT table
fddimibPORTTable OBJECT-TYPE
            SEQUENCE OF FddimibPORTEntry
    SYNTAX
    ACCESS
            not-accessible
    STATUS
            mandatory
    DESCRIPTION
             "A list of PORT entries. The number of entries
             shall not exceed the value of fddimibPORTNumber."
    ::= { fddimibPORT 2 }
fddimibPORTEntry OBJECT-TYPE
    SYNTAX
            FddimibPORTEntry
    ACCESS
            not-accessible
    STATUS
            mandatory
    DESCRIPTION
             "A PORT entry containing information common to a
             given PORT."
             fddimibPORTSMTIndex, fddimibPORTIndex }
    INDEX
    ::= { fddimibPORTTable 1 }
FddimibPORTEntry ::=
    SEQUENCE {
```

fddimibPORTSMTIndex INTEGER, fddimibPORTIndex INTEGER, fddimibPORTMyType INTEĞER, fddimibPORTNeighborType INTEGER, **fddimibPORTConnectionPolicies** INTEGER, **fddimibPORTMACIndicated** INTEGER, fddimibPORTCurrentPath INTEGER, fddimibPORTRequestedPaths OCTET STRING, **fddimibPORTMACPlacement** FddiResourceId, fddimibPORTAvailablePaths INTEGER. fddimibPORTPMDClass INTEGER, **fddimibPORTConnectionCapabilities** INTEGER. fddimibPORTBSFlag INTEGER, fddimibPORTLCTFailCts Counter, **fddimibPORTLerEstimate** INTEGER, **fddimibPORTLemRejectCts** Counter. **fddimibPORTLemCts** Counter, fddimibPORTLerCutoff INTEGER, fddimibPORTLerAlarm INTEGER, **fddimibPORTConnectState** INTEGER **fddimibPORTPCMState** INTEGER. fddimibPORTPCWithhold INTEGER,

fddimibPORTLerFlag

INTEGER, fddimibPORTHardwarePresent INTEGER,

```
fddimibPORTAction
                  INTEGER
    }
fddimibPORTSMTIndex OBJECT-TYPE
    SYNTAX
             INTEGER (1..65535)
    ACCESS
              read-only
    STATUS
             mandatory
    DESCRIPTION
              "The value of the SMT index associated with this
    ::= { fddimibPORTEntry 1 }
fddimibPORTIndex OBJECT-TYPE
    SYNTAX
             INTEGER (1..65535)
    ACCESS
              read-only
    STATUS
             mandatory
    DESCRIPTION
              "A unique value for each PORT within a given SMT,
             which is the same as the corresponding resource index in SMT. The value for each PORT must remain constant at least from one re-initialization of
              the entity's network management system to the next
              re-initialization."
    REFERENCE
              "ANSI { fddiPORT 29 }"
    ::= { fddimibPORTEntry 2 }
fddimibPORTMyType OBJECT-TYPE
    SYNTAX
             INTEGER \{ a(1), b(2), s(3), m(4), none(5) \}
    ACCESS
              read-only
    STATUS
             mandatory
    DESCRIPTION
              "The value of the PORT's PC_Type (refer to ANSI
              9.4.1, and 9.6.3.2)."
    REFERENCE
              ::= { fddimibPORTEntry 3 }
fddimibPORTNeighborType OBJECT-TYPE
              INTEGER \{a(1), b(2), s(3), m(4), none(5)\}
    SYNTAX
    ACCESS
              read-only
    STATUS
             mandatory
    DESCRIPTION
              "The type of the remote PORT as determined in PCM.
             This variable has an initial value of none, and is only modified in PC_RCode(3)_Actions (refer to ANSI SMT 9.6.3.2)."
```

```
REFERENCE
           "ANSI { fddiPORT 13 }"
    ::= { fddimibPORTEntry 4 }
fddimibPORTConnectionPolicies OBJECT-TYPE
   SYNTAX
           INTEGER (0..3)
   ACCESS
           read-write
   STATUS
           mandatorv
   DESCRIPTION
           "A value representing the PORT's connection
           policies desired in the node. The value of pc-
           mac-lct is a term used in the PC_MAC_LCT Flag (see
           9.4.3.2). The value of pc-mac-loop is a term used
           in the PC MAC Loop Flag.
           The value is a sum. This value initially takes
           the value zero, then for each PORT policy, 2
           raised to a power is added to the sum. The powers
           are according to the following table:
                                  Power
                         Policy
                     pc-mac-lct
                    pc-mac-loop
   REFERENCE
            ::= { fddimibPORTEntry 5 }
fddimibPORTMACIndicated OBJECT-TYPE
   SYNTAX INTEGER {
               tVal9FalseRVal9False(1),
               tVal9FalseRVal9True(2),
               tVal9TrueRVal9False(3),
               tVal9TrueRVal9True(4)
   ACCESS
           read-only
   STATUS
           mandatory
   DESCRIPTION
           "The indications (T_Val(9), R_Val(9)) in PC-
           Signalling, of the intent to place a MAC in the
           output token path to a PORT (refer to ANSI SMT
           9.6.3.2.)."
   REFERENCE
           "ANSI { fddiPORT 15 }"
    ::= { fddimibPORTEntry 6 }
fddimibPORTCurrentPath OBJECT-TYPE
```

```
ce1(2), -- local
                  ce2(3), -- secondary
                  ce3(4), -- primary
ce4(5), -- concatenated
ce5(6) -- thru
    ACCESS
             read-only
    STATUS mandatory
    DESCRIPTION
              "Indicates the Path(s) into which this PORT is
             currently inserted.'
    REFERENCE
              "ANSI { fddiPORT 16 }"
    ::= { fddimibPORTEntry 7 }
fddimibPORTRequestedPaths OBJECT-TYPE
    SYNTAX
            OCTET STRING (SIZE (3))
    ACCESS
             read-write
    STATUS
             mandatory
    DESCRIPTION
             "This variable is a list of permitted Paths where
             each list element defines the Port's permitted
             Paths. The first octet corresponds to 'none', the
             second octet to 'tree', and the third octet to
              'peer'."
    REFERENCE
              "ANSI { fddiPORT 17 }"
    ::= { fddimibPORTEntry 8 }
fddimibPORTMACPlacement OBJECT-TYPE
             FddiResourceId -- INTEGER (0..65535)
    SYNTAX
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "Indicates the MAC, if any, whose transmit path exits the station via this PORT. The value shall be zero if there is no MAC associated with the
             PORT. Otherwise, the MACIndex of the MAC will be
              the value of the variable."
    REFERENCE
              "ANSI { fddiPORT 18 }"
    ::= { fddimibPORTEntry 9 }
fddimibPORTAvailablePaths OBJECT-TYPE
    SYNTAX
             INTEGER (0..7)
    ACCESS
             read-only
    STATUS mandatory
    DESCRIPTION
```

"Indicates the Paths which are available to this Port. In the absence of faults, the A and B Ports will always have both the Primary and Secondary Paths available.

The value is a sum. This value initially takes the value zero, then for each type of PATH that this port has available, 2 raised to a power is added to the sum. The powers are according to the following table:

```
Path
                               Power
                    Primary
                                 0
                 Secondary
                                 1
                      Local
    REFERENCE
             "ANSI { fddiPORT 19 }"
    ::= { fddimibPORTEntry 10 }
fddimibPORTPMDClass OBJECT-TYPE
    SYNTAX INTEGER {
                      multimode(1),
single-mode1(2),
                      single-mode2(3),
                      sonet(4),
                      low-cost-fiber(5),
                      twisted-pair(6),
unknown(7),
                      unspecified(8)
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "This variable indicates the type of PMD entity
             associated with this port."
    REFERENCE
             ::= { fddimibPORTEntry 11 }
fddimibPORTConnectionCapabilities OBJECT-TYPE
    SYNTAX
             INTEGER (0..3)
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "A value that indicates the connection
             capabilities of the port. The pc-mac-lct bit
             indicates that the station has the capability of setting the PC_MAC_LCT Flag. The pc-mac-loop bit
```

```
indicates that the station has the capability of setting the PC_MAC_Loop Flag (refer to ANSI 9.4.3.2).
```

The value is a sum. This value initially takes the value zero, then for each capability that this port has, 2 raised to a power is added to the sum. The powers are according to the following table:

```
capability
                             Power
                pc-mac-lct
               pc-mac-loop
    REFERENCE
             "ANSI { fddiPORT 23 }"
    ::= { fddimibPORTEntry 12 }
fddimibPORTBSFlag OBJECT-TYPE
    SYNTAX
            INTEGER { true(1), false(2) }
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "This variable assumes the value of the BS_Flag
             (refer to ANSI SMT 9.4.3.3)."
    REFERENCE
             "ANSI { fddiPORT 33 }"
    ::= { fddimibPORTEntry 13 }
fddimibPORTLCTFailCts OBJECT-TYPE
    SYNTAX
            Counter
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "The count of the consecutive times the link
            confidence test (LCT) has failed during connection management (refer to ANSI 9.4.1)."
    REFERENCE
             ::= { fddimibPORTEntry 14 }
fddimibPORTLerEstimate OBJECT-TYPE
    SYNTAX
            INTEGER (4..15)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "A long term average link error rate. It ranges
            from 10**-4 to 10**-15 and is reported as the
            absolute value of the base 10 logarithm (refer to ANSI SMT 9.4.7.5.)."
```

```
REFERENCE
             "ANSI { fddiPORT 51 }"
    ::= { fddimibPORTEntry 15 }
fddimibPORTLemRejectCts OBJECT-TYPE
    SYNTAX
            Counter
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "A link error monitoring count of the times that a
            link has been rejected.
    REFERENCE
            "ANSI { fddiPORT 52 }"
    ::= { fddimibPORTEntry 16 }
fddimibPORTLemCts OBJECT-TYPE
    SYNTAX
           Counter
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "The aggregate link error monitor error count, set
            to zero only on station initialization.'
    REFERENCE
             "ANSI { fddiPORT 53 }"
    ::= { fddimibPORTEntry 17 }
fddimibPORTLerCutoff OBJECT-TYPE
    SYNTAX INTEGER (4..15)
    ACCESS
            read-write
    STATUS
            mandatory
    DESCRIPTION
              "The link error rate estimate at which a link
            connection will be broken. It ranges from 10**-4
            to 10**-15 and is reported as the absolute value of the base 10 logarithm (default of 7)."
    REFERENCE
             "ANSI { fddiPORT 58 }"
    ::= { fddimibPORTEntry 18 }
fddimibPORTLerAlarm OBJECT-TYPE
            INTEGER (4..15)
    SYNTAX
    ACCESS
            read-write
    STATUS
            mandatory
    DESCRIPTION
             "The link error rate estimate at which a link
            connection will generate an alarm. It ranges from
            10**-4 to 10**-15 and is reported as the absolute
            value of the base 10 logarithm of the estimate
```

```
(default of 8)."
    REFERENCE
             "ANSI { fddiPORT 59 }"
    ::= { fddimibPORTEntry 19 }
fddimibPORTConnectState OBJECT-TYPE
    SYNTAX INTEGER {
                 disabled(1)
                 connecting(2),
                 standby(3),
                 active(4)
             }
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "An indication of the connect state of this PORT
            and is equal to the value of Connect State (refer
            to ANSI 9.4.1)"
    REFERENCE
            "ANSI { fddiPORT 61 }"
    ::= { fddimibPORTEntry 20 }
fddimibPORTPCMState OBJECT-TYPE
    SYNTAX INTEGER {
                 pc0(1), -- Off
                 pc1(2), -- Break
                 pc2(3), -- Trace
                 pc3(4), -- Connect
                 pc4(5), -- Next
                 pc5(6), -- Signal
                 pc6(7), -- Join
                 pc7(8), -- Verify
pc8(9), -- Active
pc9(10) -- Maint
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "The state of this Port's PCM state machine refer
            to ANSI SMT 9.6.2)."
    REFERENCE
             "ANSI { fddiPORT 62 }"
    ::= { fddimibPORTEntry 21 }
fddimibPORTPCWithhold OBJECT-TYPE
    SYNTAX INTEGER {
                  none(1),
                  m-m(2),
```

```
otherincompatible(3),
                  pathnotavailable(4)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "The value of PC_Withhold (refer to ANSI SMT
            9.4.1)."
    REFERENCE
             "ANSI { fddiPORT 63 }"
    ::= { fddimibPORTEntry 22 }
fddimibPORTLerFlag OBJECT-TYPE
            INTEGER { true(1), false(2) }
    SYNTAX
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "The condition becomes active when the value of
            fddiPORTLerEstimate is less than or equal to
            fddiPORTLerAlarm. This will be reported with the
            Status Report Frames (SRF) (refer to ANSI SMT
             7.2.7 and 8.3)."
    REFERENCE
             'ANSI { fddiPORT 64 }"
    ::= { fddimibPORTEntry 23 }
fddimibPORTHardwarePresent OBJECT-TYPE
            INTEGER { true(1), false(2) }
    SYNTAX
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
             "This variable indicates the presence of
            underlying hardware support for this Port object.
            If the value of this object is false(2), the reporting of the objects in this entry may be
            handled in an implementation-specific manner."
    REFERENCE
             "ANSI { fddiPORT 65 }"
    ::= { fddimibPORTEntry 24 }
fddimibPORTAction OBJECT-TYPE
            INTEGER {
    SYNTAX
                                  -- none of the following
            other(1)
            maintPORT(2).
            enablePORT(3)
            disablePORT(4),
            startPORT(5),
            stopPORT(6)
```

END

5. Acknowledgements

This document was produced by the IETF FDDI MIB working group:

Hossein Alaee, 3Com Corporation Haggar Alsaleh, Bell Northern Research William Anderson, Mitre Corporation Alan Apt, Addison-Wesley Mary Artibee, Silicon Graphics Karén Auerbach, Epilogue Technologies Doug Bagnall, Apollo/Hewlett Packard Chet Birger, Coral Network Corporation Pablo Brenner, Fibronics
Howard Brown, Cabletron
Jack Brown, US Army Computer Engineering Center **Eric Brunner** Jeff Case, The University of Tennessee Tammy Chan, Fibercom Asheem Chandna, AT&T Cho Y. Chang, Apollo/Hewlett Packard Chris Chiotasso, Fibronics Paul Ciarfella, Digital Equipment Corporation John Cook, Chipcom Don Coolidge, Silicon Graphics Burt Cyr, Unisys James Ř. Davin, Massachusetts Institute of Technology Nabil Damouny Nadya El-Afandi, Network Systems Corporation Hunaid Engineer, Cray Research Jeff Fitzgerald, Fibercom Richard Fox, Synoptics Stan Froyd, ACC

Debbie Futcher, U.S. Naval Surface Warfare Center Joseph Golio, Cray Research Jeremy Greene, Coral
Peter Hayden, Digital Equipment Corporation
Scott Hiles, U.S. Naval Surface Warfare Center
Greg Jones, Data General
Satish Joshi, SynOptics Communications
Jayant Kadambi, AT&T Bell Labs Joanna Karwowska, Data General Frank Kastenholz, Interlan Jim Kinder, Fibercom Christopher Kolb, PSI Cheryl Krupczak, NCR Peter Lin, Vitalink Then Liu John R. LoVerso, Concurrent Computer Corporation Ron Mackey, Distributed Systems International, Inc. Gary Malkin, Proteon Bruce McClure, Synernetics Keith McCloghrie, Hughes Lan Systems Donna McMaster, SynOptics John O'Hara, Massachusetts Institute of Technology Luc Pariseau, Digital Equipment Corporation Dave Perkins, SynOptics Communications James E. Reeves, SynOptics Communications Jim Reinstedler, Ungermann-Bass Radhi Renous, Fibronics Sal Ricci, AT&T/NCR Anil Rijsinghani, Digital Equipment Corporation Bob Rolla, Synernetics Nelson Ronkin, Synernetics Marshall T. Rose, Performance Systems International, Inc. Milt Roselinsky, CMC Jon Saperia, Digital Equipment Corporation Greg Satz, cisco Systems Steven Senum, Network Systems Corporation Jim Sheridan, IBM Corporation Jeffrey Schiller, MIT Dror Shindelman, Fibronics Mark Sleeper, Sparta Lou Steinberg, IBM Corporation Larry Stefani, Digital Equipment Corporation Mary Jane Strohl, Apollo/Hewlett Packard Sally Tarquinio, Mitre Corporation Kaj Tesink, Bellcore Ian Thomas, Chipcom Dean Throop, Data General Bill Townsend, Xylogics

September 1993

Ahmet H. Tuncay, SynOptics Communications
Mike Turico, Motorola
Chris VandenBerg, ACC
Sudhanshu Verma, Hewlett Packard
Joe Vermeulen, UNISYS
David Waiteman, BBN
Bert Williams, Synernetics
Mark Wood, Distributed Systems International, Inc.
Y. C. Yang
Denis Yaro, Sun Microsystems
Jeff Young, Cray Research

The author gratefully acknowledges the labors of Judi Talley and David Reid of SNMP Research, Inc. for their editorial assistance in the preparation of this document.

6. References

- [1] Rose M., and K. McCloghrie, "Structure and Identification of Management Information for TCP/IP-based internets", STD 16, RFC 1155, Performance Systems International, Hughes LAN Systems, May 1990.
- [2] Case, J., "FDDI Management Information Base", RFC 1285, SNMP Research, Incorporated, January 1992.
- [3] Case, J., Fedor, M., Schoffstall, M., and J. Davin, "Simple Network Management Protocol", STD 15, RFC 1157, SNMP Research, Performance Systems International, Performance Systems International, MIT Laboratory for Computer Science, May 1990.
- [4] McCloghrie K., and M. Rose, Editors, "Management Information Base for Network Management of TCP/IP-based internets", STD 17, RFC 1213, Performance Systems International, March 1991.
- [5] Information processing systems Open Systems Interconnection Specification of Abstract Syntax Notation One (ASN.1), International Organization for Standardization. International Standard 8824, (December, 1987).
- [6] Information processing systems Open Systems Interconnection Specification of Basic Encoding Rules for Abstract Notation One (ASN.1), International Organization for Standardization. International Standard 8825, (December, 1987).
- [7] Rose, M., and K. McCloghrie, Editors, "Concise MIB Definitions", STD 16, RFC 1212, Performance Systems International, Hughes LAN Systems, March 1991.

[8] American National Standards Institute, FDDI Station Management (SMT), Draft Proposed American National Standard, American National Standards Institute, X3T9.5/84-49 REV 7.3.

7. Security Considerations

Security issues are not discussed in this memo.

8. Authors' Addresses

Jeffrey D. Case The University of Tennessee Department of Computer Science 107 Ayres Hall Knoxville, Tennessee 37996

and

SNMP Research, Incorporated 3001 Kimberlin Heights Road Knoxville, Tennessee 37920

Phone: (615) 974-5067 or (615) 573-1434

EMail: case@CS.UTK.EDU

Anil Rijsinghani Digital Equipment Corporation 295 Foster Street Littleton, MA 01460-1123

Phone: (508) 952-3520

EMail: anil@levers.enet.dec.com