

scikit-rf Documentation Release dev

Alex Arsenovic

CONTENTS

1	Tutor	rials	3	
	1.1	Installation	3	
	1.2	Introduction	4	
	1.3	Networks	11	
	1.4	Plotting	20	
	1.5	NetworkSet	30	
	1.6	Virtual Instruments	35	
	1.7	Calibration	36	
	1.8	Media	40	
2	Exan		47	
	2.1	Visualizing a Single Stub Matching Network	47	
	2.2	One-Port Calibration	51	
3 Reference				
	3.1	<pre>frequency (skrf.frequency)</pre>	53	
	3.2	network (skrf.network)		
	3.3	networkSet(skrf.networkSet)		
	3.4	plotting (skrf.plotting)		
	3.5	mathFunctions (skrf.mathFunctions)		
	3.6	tlineFunctions (skrf.tlineFunctions)		
	3.7	constants (skrf.constants)		
	3.8	util (skrf.util)		
	3.9	io (skrf.io)		
	3.10	calibration (skrf.calibration)		
	3.11	media (skrf.media)		
	3.11	vi (skrf.vi)		
	3.12	Indices and tables		
	3.13	indices and tables	207	
Рy	thon N	Module Index	269	
In	dev		271	

This documentation is also available in pdf form: scikit-rf.pdf

CONTENTS 1

2 CONTENTS

CHAPTER

ONE

TUTORIALS

1.1 Installation

Contents

- Installation
 - Introduction
 - skrf Installation
 - Testing Installation
 - Requirements
 - * Debian-Based Linux
 - * Necessary
 - * Optional

1.1.1 Introduction

The requirements to run **skrf** are basically a Python environment setup to do numerical/scientific computing. If you are new to development, you may want to install a pre-built scientific python IDE like pythonxy or the enthought python distribution. Either of these *ditributions* will install all requirements, as well as provide a nice environment to get started in. If you dont want use pythonxy or enthought see Requirements.

Note: If you want to use **skrf** for instrument control you will need to install pyvisa as well as the NI-GPIB drivers. You may also be interested in Pythics, which provides a simple way to build graphical interfaces to virtual instruments.

1.1.2 skrf Installation

Once the requirements are installed, there are two choices for installing skrf:

- windows installer
- python source package

These can be found at http://scikit-rf.org/download.html

If you dont know how to install a python module and dont care to learn how, you want the windows installer.

The current version can be accessed through github. This is mainly of interest for developers.

1.1.3 Testing Installation

If import **skrf** and dont recieve an error, then installation was succesful.

```
In [1]: import skrf as rf
```

If instead you get an error like this,

Then installation was unsuccesful. If you need help post to the mailing list.

1.1.4 Requirements

Debian-Based Linux

For debian-based linux users who dont want to install pythonxy, here is a one-shot line to install all requirements,

```
sudo apt-get install python-pyvisa python-numpy python-scipy python-matplotlib ipython python python-
```

Once *setuptools* is installed you can install skrf through easy_install

```
easy_install scikit-rf
```

Necessary

- python (>=2.6) http://www.python.org/
- matplotlib (aka pylab) http://matplotlib.sourceforge.net/
- numpy http://numpy.scipy.org/
- scipy http://www.scipy.org/ (provides tons of good stuff, check it out)

Optional

- ipython http://ipython.scipy.org/moin/ for interactive shell
- pyvisa http://pyvisa.sourceforge.net/pyvisa/ for instrument control
- Pythics http://code.google.com/p/pythics instrument control and gui creation

1.2 Introduction

Contents

- Introduction
 - Introduction
 - Networks
 - * Linear Operations
 - * Cascading and De-embedding
 - Plotting
 - NetworkSet
 - * Statistical Properties
 - * Plotting Uncertainty Bounds
 - Virtual Instruments
 - Calibration
 - * One Port Calibration
 - Media
 - * Media Types
 - * Network Compoents

1.2.1 Introduction

This is a brief introduction to **skrf** which highlights a range of features without going into detail on any single one. At the end of each section there are links to other tutorials, that provide more information about a given feature. The intended audience are those who have a working python stack, and are somewhat familiar with python. If you are unfamiliar with python, please see scipy's Getting Started.

Although not essential, these tutorials are most easily followed by using the ipython shell with the --pylab flag.

```
> ipython --pylab
In [1]:
```

Using ipython with the pylab flag imports several commonly used functions, and turns on interactive plotting mode which causes plots to display immediately.

Throughout this tutorial, and the rest of the scikit-rf documentation, it is assumed that **skrf** has been imported as rf. Whether or not you follow this convention in your own code is up to you.

```
In [8]: import skrf as rf
```

If this produces an error, please see *Installation*.

Note: The example code in these tutorials make use of files that are distributed with the source package. The working directory for these code snippets is scikit-rf/doc/, hence all data files are referenced relative to that directory. If you do not have the source package, then you may access these files through the skrf.data module (ie from skrf.data import ring_slot)

1.2.2 Networks

The Network object represents a N-port microwave Network. A Network can be created in a number of ways. One way is from data stored in a touchstone file.

```
In [9]: ring_slot = rf.Network('../skrf/data/ring slot.s2p')
```

1.2. Introduction 5

A short description of the network will be printed out if entered onto the command line

```
In [10]: ring_slot
Out[10]: 2-Port Network: 'ring slot', 75-110 GHz, 201 pts, z0=[ 50.+0.j 50.+0.j]
```

he basic attributes of a microwave Network are provided by the following properties:

- Network.s: Scattering Parameter matrix.
- Network.z0: Port Characterisic Impedance matrix.
- Network.frequency: Frequency Object.

All of the network parameters are complex numpy.ndarray 's of shape FxNxN, where F is the number of frequency points and N is the number of ports. The Network object has numerous other properties and methods which can found in the Network docstring. If you are using IPython, then these properties and methods can be 'tabbed' out on the command line.

Linear Operations

Element-wise mathematical operations on the scattering parameter matrices are accessible through overloaded operators. To illustrate their usage, load a couple Networks stored in the data module.

```
In [12]: short = rf.data.wr2p2_short
In [13]: delayshort = rf.data.wr2p2_delayshort
In [14]: short - delayshort
Out[14]: 1-Port Network: 'wr2p2, short', 330-500 GHz, 201 pts, z0=[ 50.+0.j]
In [15]: short + delayshort
Out[15]: 1-Port Network: 'wr2p2, short', 330-500 GHz, 201 pts, z0=[ 50.+0.j]
```

Cascading and De-embedding

Cascading and de-embeding 2-port Networks can also be done though operators. The cascade() function can be called through the power operator, **. To calculate a new network which is the cascaded connection of the two individual Networks line and short.

```
In [16]: short = rf.data.wr2p2_short
In [17]: line = rf.data.wr2p2_line
In [18]: delayshort = line ** short
```

De-embedding can be accomplished by cascading the *inverse* of a network. The inverse of a network is accessed through the property Network.inv. To de-embed the short from delay_short,

```
In [19]: short = line.inv ** delayshort
```

For more information on the functionality provided by the Network object, such as interpolation, stitching, n-port connections, and IO support see the *Networks* tutorial.


1.2.3 Plotting

Amongst other things, the methods of the Network class provide convenient ways to plot components of the network parameters,

- Network.plot_s_db(): plot magnitude of s-parameters in log scale
- Network.plot_s_deg(): plot phase of s-parameters in degrees
- Network.plot_s_smith(): plot complex s-parameters on Smith Chart
- ..

To plot all four s-parameters of the ring_slot on the Smith Chart.

```
In [20]: ring_slot.plot_s_smith();
```



For more detailed information about plotting see the *Plotting* tutorial

1.2.4 NetworkSet

The NetworkSet object represents an unordered set of networks and provides methods for calculating statistical quantities and displaying uncertainty bounds.

A NetworkSet is created from a list or dict of Network's. This can be done quickly with read_all(), which loads all skrf-readable objects in a directory. The argument contains is used to load only files which match a given substring.

```
In [21]: rf.read_all('../skrf/data/', contains='ro')
Out[21]:
{'ro,1': 1-Port Network: 'ro,1', 500-750 GHz, 201 pts, z0=[ 50.+0.j],
    'ro,2': 1-Port Network: 'ro,2', 500-750 GHz, 201 pts, z0=[ 50.+0.j],
    'ro,3': 1-Port Network: 'ro,3', 500-750 GHz, 201 pts, z0=[ 50.+0.j]}
```

This can be passed directly to the NetworkSet constructor,

```
In [22]: ro_dict = rf.read_all('../skrf/data/', contains='ro')
In [23]: ro_ns = rf.NetworkSet(ro_dict, name='ro set') #name is optional
```

1.2. Introduction 7

```
In [24]: ro_ns
Out[24]: A NetworkSet of length 3
```

Statistical Properties

Statistical quantities can be calculated by accessing properties of the NetworkSet. For example, to calculate the complex average of the set, access the mean_s property


```
In [25]: ro_ns.mean_s
Out[25]: 1-Port Network: 'ro set', 500-750 GHz, 201 pts, z0=[ 50.+0.j]
```

Similarly, to calculate the complex standard deviation of the set,

```
In [26]: ro_ns.std_s
Out[26]: 1-Port Network: 'ro set', 500-750 GHz, 201 pts, z0=[ 50.+0.j]
```

These methods return a Network object, so the results can be saved or plotted in the same way as you would with a Network. To plot the magnitude of the standard deviation of the set,


```
In [27]: figure();
In [28]: ro_ns.std_s.plot_s_re(y_label='Standard Deviations')
```



Plotting Uncertainty Bounds

Uncertainty bounds on any network parameter can be plotted through the methods

```
In [29]: figure();
In [30]: ro_ns.plot_uncertainty_bounds_s_db()
```



See the NetworkSet tutorial for more information.

1.2.5 Virtual Instruments

Warning: The vi module is not well written or tested at this point.

The vi module holds classes for GPIB/VISA instruments that are intricately related to skrf, ie mostly VNA's. The VNA classes were created for the sole purpose of retrieving data so that calibration and measurements could be carried out offline by skrf, control of most other VNA capabilities is neglected.

Note: To use the virtual instrument classes you must have pyvisa installed.

A list of VNA's that have been are partially supported.

- HP8510C
- HP8720
- PNAX
- ZVA40

An example usage of the $\mathtt{HP8510C}$ class to retrieve some s-parameter data

```
In [31]: from skrf.vi import vna
In [32]: my_vna = vna.HP8510C(address =16)
#if an error is thrown at this point there is most likely a problem with your visa setup
In [33]: dut_1 = my_vna.s11
In [34]: dut_2 = my_vna.s21
In [35]: dut_3 = my_vna.two_port
```

Unfortunately, the syntax is different for every VNA class, so the above example wont directly translate to other VNA's. Re-writing all of the VNA classes to follow the same convention is on the TODO list

1.2. Introduction 9

1.2.6 Calibration

skrf has support for one and two-port calibration. **skrf** sdefault calibration algorithms are generic in that they will work with any set of standards. If you supply more calibration standards than is needed, skrf will implement a simple least-squares solution. **skrf** does not currently support TRL.

Calibrations are performed through a Calibration class. Creating a Calibration object requires at least two pieces of information:

- a list of measured Network's
- a list of ideal Network's

The Network elements in each list must all be similar (same #ports, frequency info, etc) and must be aligned to each other, meaning the first element of ideals list must correspond to the first element of measured list.

Optionally, other information can be provided when relevent such as,

- · calibration algorithm
- enforce eciprocity of embedding networks
- etc

When this information is not provided skrf will determine it through inspection, or use a default value.

Below is an example script illustrating how to create a Calibration . See the *Calibration* tutorial for more details and examples.

One Port Calibration

This example is the same as the first except more concise.

```
import skrf as rf

my_ideals = rf.read_all('ideals/')
my_measured = rf.read_all('measured/')
duts = rf.read_all('measured/')

## create a Calibration instance
cal = rf.Calibration(\\
        ideals = [my_ideals[k] for k in ['short','open','load']],
        measured = [my_measured[k] for k in ['short','open','load']],
    )

caled_duts = [cal.apply_cal(dut) for dut in duts.values()]
```

1.2.7 **Media**

skrf supports the microwave network synthesis based on transmission line models. Network creation is accomplished through methods of the Media class, which represents a transmission line object for a given medium. Once constructed, a Media object contains the necessary properties such as propagation constant and characteristic impedance, that are needed to generate microwave circuits.

The basic usage looks something like this,

```
In [36]: import skrf as rf
In [37]: freq = rf.Frequency(75,110,101,'ghz')
```

```
In [38]: cpw = rf.media.CPW(freq, w=10e-6, s=5e-6, ep_r=10.6)
In [39]: cpw.line(100*1e-6, name = '100um line')
Out[39]: 2-Port Network: '100um line', 75-110 GHz, 101 pts, z0=[ 50.06074662+0.j 50.06074662+0.j]
```

Warning: The network creation and connection syntax of **skrf** are cumbersome if you need to doing complex circuit design. For a this type of application, you may be interested in using QUCS instead. **skrf**'s synthesis cabilities lend themselves more to scripted applications such as *Design Optimization* or batch processing.

Media Types

Specific instances of Media objects can be created from relevant physical and electrical properties. Below is a list of mediums types supported by skrf,

- CPW
- RectangularWaveguide
- Freespace
- DistributedCircuit
- Media

Network Compoents

Here is a brief list of some generic network components skrf supports,

```
• match()
```

- short()
- open()
- load()
- line()
- thru()
- tee()
- delay_short()
- shunt_delay_open()

Usage of these methods can is demonstrated below.

To create a 1-port network for a coplanar waveguide short (this neglects dicontinuity effects),

```
In [40]: cpw.short(name = 'short')
Out[40]: 1-Port Network: 'short', 75-110 GHz, 101 pts, z0=[ 50.06074662+0.j]
```

Or to create a 90° section of cpw line,

```
In [41]: cpw.line(d=90,unit='deg', name='line')
Out[41]: 2-Port Network: 'line', 75-110 GHz, 101 pts, z0=[ 50.06074662+0.j 50.06074662+0.j]
```

See *Media* for more information about the Media object and network creation.

1.3 Networks

1.3. Networks

Contents

- Networks
 - Introduction
 - Creating Networks
 - Network Basics
 - Network Operators
 - * Linear Operations
 - * Cascading and De-embedding
 - Connecting Multi-ports
 - Interpolation and Stitching
 - Reading and Writing
 - Impedance and Admittance Parameters
 - Creating Networks 'From Scratch'
 - Sub-Networks
 - References

1.3.1 Introduction

For this tutorial, and the rest of the scikit-rf documentation, it is assumed that **skrf** has been imported as rf. Whether or not you follow this convention in your own code is up to you.

```
In [1]: import skrf as rf
```

If this produces an error, please see *Installation*. The code in this tutorial assumes that you are in the directory scikit-rf/doc.

1.3.2 Creating Networks

skrf provides an object for a N-port microwave Network. A Network can be created in a number of ways. One way is from data stored in a touchstone file.

```
In [1]: ring_slot = rf.Network('../skrf/data/ring slot.s2p')
```

A short description of the network will be printed out if entered onto the command line

```
In [1]: ring_slot
Out[1]: 2-Port Network: 'ring slot', 75-110 GHz, 201 pts, z0=[ 50.+0.j 50.+0.j]
```

Networks can also be created from a pickled Network (written by Network.write()),

```
In [1]: ring_slot = rf.Network('../skrf/data/ring slot.ntwk')
```

or from directly passing values for the frequency, s-paramters and z0.

```
In [1]: custom_ntwk = rf.Network(f = [1,2,3], s= [-1, 1j, 0], z0=50)
```

Seen Network.__init__() for more information on network creation.

1.3.3 Network Basics

The basic attributes of a microwave Network are provided by the following properties:

• Network.s: Scattering Parameter matrix.

- Network.z0: Port Characteristic Impedance matrix.
- Network.frequency: Frequency Object.

All of the network parameters are represented internally as complex numpy.ndarray 's of shape FxNxN, where F is the number of frequency points and N is the number of ports.

```
In [1]: shape(ring_slot.s)
Out[1]: (201, 2, 2)
```

Note that the indexing starts at 0, so the first 10 values of S_{11} can be accessed with

The Network object has numerous other properties and methods which can found in the Network docstring. If you are using IPython, then these properties and methods can be 'tabbed' out on the command line.

Note: Although this tutorial focuses on s-parametes, other network representations such as Impedance (Network.z) and Admittance Parameters (Network.y) are available as well, see Impedance and Admittance Parameters.

Amongst other things, the methods of the Network class provide convenient ways to plot components of the network parameters,


- Network.plot_s_db(): plot magnitude of s-parameters in log scale
- Network.plot_s_deg(): plot phase of s-parameters in degrees
- Network.plot_s_smith(): plot complex s-parameters on Smith Chart

• ...

To plot all four s-parameters of the ring slot on the Smith Chart.


```
In [1]: ring_slot.plot_s_smith();
```

1.3. Networks



Or plot a pair of s-parameters individually, in log magnitude

```
In [1]: figure();
In [2]: ring_slot.plot_s_db(m=1, n=0); # s21
In [3]: ring_slot.plot_s_db(m=0, n=0); # s11
```



For more detailed information about plotting see *Plotting*.

1.3.4 Network Operators


Linear Operations

Element-wise mathematical operations on the scattering parameter matrices are accessible through overloaded operators. To illustrate their usage, load a couple Networks stored in the data module.

```
In [1]: short = rf.data.wr2p2_short
In [2]: delayshort = rf.data.wr2p2_delayshort
In [3]: short - delayshort
Out[3]: 1-Port Network: 'wr2p2,short', 330-500 GHz, 201 pts, z0=[ 50.+0.j]
In [4]: short + delayshort
Out[4]: 1-Port Network: 'wr2p2,short', 330-500 GHz, 201 pts, z0=[ 50.+0.j]
In [5]: short * delayshort
Out[5]: 1-Port Network: 'wr2p2,short', 330-500 GHz, 201 pts, z0=[ 50.+0.j]
In [6]: short / delayshort
Out[6]: 1-Port Network: 'wr2p2,short', 330-500 GHz, 201 pts, z0=[ 50.+0.j]
In [7]: short / delayshort
Out[7]: 1-Port Network: 'wr2p2,short', 330-500 GHz, 201 pts, z0=[ 50.+0.j]
```

All of these operations return Network types, so the methods and properties of a Network are available on the result. For example, to plot the complex difference between short and delay_short,


```
In [1]: figure();
In [2]: difference = (short- delayshort)
In [3]: difference.plot_s_mag()
```



Another common application is calculating the phase difference using the division operator,

```
In [1]: figure();
In [2]: (delayshort/short).plot_s_deg()
```

1.3. Networks 15



Linear operators can also be used with scalars or an numpy.ndarray that ais the same length as the Network.

Note that if you multiply a Network by an numpy . ndarray be sure to place the array on right side.

Cascading and De-embedding

Cascading and de-embeding 2-port Networks can also be done though operators. The cascade() function can be called through the power operator, **. To calculate a new network which is the cascaded connection of the two individual Networks line and short,

```
In [1]: short = rf.data.wr2p2_short
In [2]: line = rf.data.wr2p2_line
In [3]: delayshort = line ** short
```

De-embedding can be accomplished by cascading the *inverse* of a network. The inverse of a network is accessed through the property Network.inv. To de-embed the short from delay_short,

```
In [1]: short = line.inv ** delayshort
```

1.3.5 Connecting Multi-ports

skrf supports the connection of arbitrary ports of N-port networks. It accomplishes this using an algorithm called sub-network growth ¹, available through the function connect(). Terminating one port of an ideal 3-way splitter can be done like so,

```
In [1]: tee = rf.Network('../skrf/data/tee.s3p')
```

To connect port 1 of the tee, to port 0 of the delay short,

```
In [1]: terminated_tee = rf.connect(tee,1,delayshort,0)
```

Note that this function takes into account port impedances, and if connecting ports have different port impedances an appropriate impedance mismatch is inserted.

1.3.6 Interpolation and Stitching

A common need is to change the number of frequency points of a Network. For instance, to use the operators and cascading functions the networks involved must have matching frequencies. If two networks have different frequency information, then an error will be raised,

```
In [1]: line = rf.data.wr2p2_line.copy()
In [2]: line1 = rf.data.wr2p2_line1.copy()
In [3]: line1
Out[3]: 2-Port Network: 'wr2p2,line1', 330-500 GHz, 101 pts, z0=[ 50.+0.j 50.+0.j]
In [4]: line
Out[4]: 2-Port Network: 'wr2p2,line', 330-500 GHz, 201 pts, z0=[50.+0.j 50.+0.j]
In [5]: line1+line
IndexError
                                          Traceback (most recent call last)
<ipython-input-5-82040f7eab08> in <module>()
----> 1 line1+line
/home/alex/data/docs/code/path/skrf/network.pyc in __add__(self, other)
    438
    439
                if isinstance(other, Network):
--> 440
                   self.__compatable_for_scalar_operation_test(other)
                    result.s = self.s + other.s
    441
    442
                else:
/home/alex/data/docs/code/path/skrf/network.pyc in __compatable_for_scalar_operation_test(self, other
    564
    565
                if other.frequency != self.frequency:
                    raise IndexError('Networks must have same frequency. See 'Network.interpolate')
--> 566
    567
    568
               if other.s.shape != self.s.shape:
```

1.3. Networks

¹ Compton, R.C.; , "Perspectives in microwave circuit analysis," Circuits and Systems, 1989., Proceedings of the 32nd Midwest Symposium on , vol., no., pp.716-718 vol.2, 14-16 Aug 1989. URL: http://ieeexplore.ieee.org/stamp/stamp.jsp?tp=&arnumber=101955&isnumber=3167

```
IndexError: Networks must have same frequency. See 'Network.interpolate'
```

This problem can be solved by interpolating one of Networks, using Network.resample().

```
In [1]: line1
Out[1]: 2-Port Network: 'wr2p2,line1', 330-500 GHz, 101 pts, z0=[ 50.+0.j 50.+0.j]
In [2]: line1.resample(201)
In [3]: line1
Out[3]: 2-Port Network: 'wr2p2,line1', 330-500 GHz, 201 pts, z0=[ 50.+0.j 50.+0.j]
In [4]: line1+line
Out[4]: 2-Port Network: 'wr2p2,line1', 330-500 GHz, 201 pts, z0=[ 50.+0.j 50.+0.j]
```

A related application is the need to combine Networks which cover different frequency ranges. Two Networks can be stitched together using stitch(), which concatenates their s-parameter matrices along their frequency axis. To combine a WR-2.2 Network with a WR-1.5 Network,

```
In [1]: from skrf.data import wr2p2_line, wr1p5_line
In [2]: line = rf.stitch(wr2p2_line, wr1p5_line)
In [3]: line
Out[3]: 2-Port Network: 'wr2p2,line', 330-750 GHz, 402 pts, z0=[ 50.+0.j 50.+0.j]
```

1.3.7 Reading and Writing

While **skrf** supports reading and writing the touchstone file format, it also provides native IO capabilities for any skrf object through the functions read() and write(). These functions can also be called through the Network methods Network.read() and Network.write(). The Network constructor (Network.__init__()) calls read() implicitly if a skrf file is passed.

```
In [1]: line = rf.Network('../skrf/data/line.s2p')
In [2]: line.write() # write out Network using native IO
line.ntwk
In [3]: rf.Netwrok('line.ntwk') # read Network using native IO
```

Frequently there is an entire directory of files that need to be analyzed. The function read_all() is used to create objects from all files in a directory quickly. Given a directory of skrf-readable files, read_all() returns a dict with keys equal to the filenames, and values equal to objects. To load all **skrf** files in the skrf/data/ directory which contain the string \'wr2p2\'.


```
In [1]: dict_o_ntwks = rf.read_all('../skrf/data/', contains = 'wr2p2')
In [2]: dict_o_ntwks
Out[2]:
{'wr2p2,delayshort': 1-Port Network: 'wr2p2,delayshort', 330-500 GHz, 201 pts, z0=[ 50.+0.j],
    'wr2p2,line': 2-Port Network: 'wr2p2,line', 330-500 GHz, 201 pts, z0=[ 50.+0.j 50.+0.j],
    'wr2p2,line1': 2-Port Network: 'wr2p2,line1', 330-500 GHz, 101 pts, z0=[ 50.+0.j 50.+0.j],
    'wr2p2,short': 1-Port Network: 'wr2p2,short', 330-500 GHz, 201 pts, z0=[ 50.+0.j]}
```

read_all() has a companion function, write_all() which takes a dictionary of **skrf** objects, and writes each object to an individual file.

A similar function <code>save_sesh()</code>, can be used to save all **skrf** objects in the current namespace.

1.3.8 Impedance and Admittance Parameters

This tutorial focuses on s-parameters, but other network representations are available as well. Impedance and Admittance Parameters can be accessed through the parameters <code>Network.z</code> and <code>Network.y</code>, respectively. Scalar components of complex parameters, such as <code>Network.z_re</code>, <code>Network.z_im</code> and plotting methods like <code>Network.plot_z_mag()</code> are available as well.



1.3. Networks

1.3.9 Creating Networks 'From Scratch'

A Network can be created from scratch by passing values of relevant properties as keyword arguments to the constructor,

```
In [1]: frequency = rf.Frequency(75,110,101,'ghz')
In [2]: s = -1*ones(101)
In [3]: wr10_short = rf.Network(frequency = frequency, s = s, z0 = 50 )
```

For more information creating Networks representing transmission line and lumped components, see the media module.

1.3.10 Sub-Networks

Frequently, the one-port s-parameters of a multiport network's are of interest. These can be accessed by the subnetwork properties, which return one-port Network objects,

```
In [1]: port1_return = line.s11
In [2]: port1_return
Out[2]: 1-Port Network: 'line', 75-110 GHz, 201 pts, z0=[ 50.+0.j]
```

1.3.11 References

1.4 Plotting

Contents

- Plotting
 - Plotting Methods
 - Complex Plots
 - * Smith Chart
 - * Complex Plane
 - Rectangular Plots
 - * Log-Magnitude
 - * Phase
 - * Impedance, Admittance
 - Customizing Plots
 - Saving Plots
 - Misc
 - * Adding Markers to Lines
 - * Formating Plots

1.4.1 Plotting Methods

Network plotting abilities are implemented as methods of the Network class. Some of the plotting functions of network s-parameters are,

```
• Network.plot_s_re()
```

```
Network.plot_s_im()
Network.plot_s_mag()
Network.plot_s_db()
Network.plot_s_deg()
Network.plot_s_deg_unwrap()
Network.plot_s_rad()
Network.plot_s_rad_unwrap()
Network.plot_s_smith()
Network.plot_s_complex()
```

Similar methods exist for Impedance (Network.z) and Admittance Parameters (Network.y),

```
Network.plot_z_re()Network.plot_z_im()...Network.plot_y_re()Network.plot_z_im()...
```


Step-by-step examples of how to create and customize plots are given below.

1.4.2 Complex Plots

Smith Chart

As a first example, load a Network from the data module, and plot all four s-parameters on the Smith chart.

```
In [1]: import skrf as rf
In [2]: from skrf.data import ring_slot
In [3]: ring_slot
Out[3]: 2-Port Network: 'ring slot', 75-110 GHz, 501 pts, z0=[ 50.+0.j 50.+0.j]
In [4]: ring_slot.plot_s_smith()
```




1.4. Plotting 21

Note: If you dont see any plots after issuing these commands, then you may not have started ipython with the --pylab flag. Try from pylab import * to import the matplotlib commands and ion () to turn on interactive plotting. See this page, for more info on ipython's *pylab* mode.

Note: Why do my plots look different? See Formating Plots


The smith chart can be drawn with some impedance values labeled through the draw_labels argument.

```
In [1]: figure();
In [2]: ring_slot.plot_s_smith(draw_labels=True)
```



Another common option is to draw addmitance contours, instead of impedance. This is controlled through the chart_type argument.

```
In [1]: figure();
In [2]: ring_slot.plot_s_smith(chart_type='y')
```




See smith () for more info on customizing the Smith Chart.

Note: If more than one plot_s_smith() command is issued on a single figure, you may need to call draw() to refresh the chart.

Complex Plane

Network parameters can also be plotted in the complex plane without a Smith Chart through $\texttt{Network.plot_s_complex()}$.

```
In [1]: figure();
In [2]: ring_slot.plot_s_complex();
```




1.4. Plotting 23

1.4.3 Rectangular Plots

Log-Magnitude


Scalar components of the complex network parameters can be plotted vs frequency as well. To plot the log-magnitude of the s-parameters vs. frequency,

```
In [1]: figure();
In [2]: ring_slot.plot_s_db()
```



When no arguments are passed to the plotting methods, all parameters are plotted. Single parameters can be plotted by passing indecies m and n to the plotting commands (indexing start from 0). Comparing the simulated reflection coefficient off the ring slot to a measurement,

```
In [1]: from skrf.data import ring_slot_meas
In [2]: figure();
In [3]: ring_slot.plot_s_db(m=0,n=0) # s11
In [4]: ring_slot_meas.plot_s_db(m=0,n=0) # s11
```




See Customizing Plots for more information on customization.

Phase

Plot phase,


```
In [1]: figure();
In [2]: ring_slot.plot_s_deg()
```



Or unwrapped phase,

```
In [1]: figure();
In [2]: ring_slot.plot_s_deg_unwrap()
```


1.4. Plotting 25



Impedance, Admittance


The components the Impendanc and Admittance parameters can be plotted similarly,

```
In [1]: figure();
```



```
In [1]: figure();
```


```
In [2]: ring_slot.plot_y_re()
```



1.4.4 Customizing Plots

The legend entries are automatically filled in with the Network's name. The entry can be overidden by passing the label argument to the plot method.

```
In [1]: figure();
In [2]: ring_slot.plot_s_db(m=0,n=0, label = 'Simulation')
In [3]: ring_slot_meas.plot_s_db(m=0,n=0, label = 'Measured')
```




The frequency unit used on the x-axis is automatically filled in from the Networks frequency attribute. To change the label, change the frequency's unit.

```
In [1]: ring_slot.frequency.unit = 'mhz'
```

Other key word arguments given to the plotting methods are passed through to the matplotlib plot () function.


1.4. Plotting 27

```
In [1]: figure();
In [2]: ring_slot.plot_s_db(m=0,n=0, linewidth = 3, linestyle = '--', label = 'Simulation')
In [3]: ring_slot_meas.plot_s_db(m=0,n=0, marker = 'x', markevery = 10, label = 'Measured')
```



All components of the plots can be customized through matplotlib functions.

```
In [1]: figure();
In [2]: ring_slot.plot_s_smith()
In [3]: xlabel('Real Part');
In [4]: ylabel('Imaginary Part');
In [5]: title('Smith Chart');
In [6]: draw();
```



1.4.5 Saving Plots

Plots can be saved in various file formats using the GUI provided by the matplotlib. However, skrf provides a convenience function, called <code>save_all_figs()</code>, that allows all open figures to be saved to disk in multiple file formats, with filenames pulled from each figure's title:

```
>>> rf.save_all_figs('.', format=['eps','pdf'])
./WR-10 Ringslot Array Simulated vs Measured.eps
./WR-10 Ringslot Array Simulated vs Measured.pdf
```


1.4.6 Misc

Adding Markers to Lines

A common need is to make a color plot, interpretable in greyscale print. There is a convenient function, add_markers_to_lines(), which adds markers each line in a plots *after* the plot has been made. In this way, adding markers to an already written set of plotting commands is easy.

```
In [1]: figure();
In [2]: ring_slot.plot_s_db(m=0,n=0)
In [3]: ring_slot_meas.plot_s_db(m=0,n=0)
In [4]: rf.add_markers_to_lines()
```

1.4. Plotting 29



Formating Plots

It is likely that your plots dont look exactly like the ones in this tutorial. This is because matplotlib supports a vast amount of customization. Formating options can be customized *on-the-fly* by modifying values of the rcParams dictionary. Once these are set to your liking they can be saved to your .matplotlibrc file.

Here are some relevant parameters which should get your plots looking close to the ones in this tutorial:

```
my_params = {
'figure.dpi': 120,
'figure.figsize': [4,3],
'figure.subplot.left' : 0.15,
'figure.subplot.right'
                        : 0.9,
'figure.subplot.bottom'
                          : 0.12,
'axes.titlesize' : 'medium',
                   : 10 ,
'axes.labelsize'
'ytick.labelsize'
                  :'small',
'xtick.labelsize'
                    :'small',
'legend.fontsize'
                    : 8 #small,
'legend.loc'
                        : 'best',
'font.size'
                    : 10.0,
'font.family'
                   : 'serif',
'text.usetex' : True,
                         # if you have latex
rcParams.update(my_params)
```

The project mpltools provides a way to switch between pre-defined *styles*, and contains other useful plotting-related features.

1.5 NetworkSet

Contents

- NetworkSet
 - Creating a NetworkSet
 - Accesing Network Methods
 - Statistical Properties
 - Plotting Uncertainty Bounds
 - Reading and Writing

The NetworkSet object represents an unordered set of networks and provides methods for calculating statistical quantities and displaying uncertainty bounds.

1.5.1 Creating a NetworkSet

For this example, assume that numerous measurements of a single network are made. These measurements have been retrieved from a VNA and are in the form of touchstone files. A set of example data can be found in scikit-rf/skrf/data/, with naming convention ro, *.slp,

```
In [1]: import skrf as rf
In [2]: ls ../skrf/data/ro*
../skrf/data/ro,1.slp ../skrf/data/ro,2.slp ../skrf/data/ro,3.slp
```

The files ro, 1.slp, ro, 2.slp, ... are redundant measurements on which we would like to calculate statistics using the NetworkSet class.

A NetworkSet is created from a list or dict of Network's. So first we need to load all of the touchstone files. This can be done quickly with read_all(), which loads all skrf-readable objects in a directory. The argument contains is used to load only files which match a given substring.

```
In [1]: rf.read_all('../skrf/data/', contains='ro')
Out[1]:
{'ro,1': 1-Port Network: 'ro,1', 500-750 GHz, 201 pts, z0=[ 50.+0.j],
    'ro,2': 1-Port Network: 'ro,2', 500-750 GHz, 201 pts, z0=[ 50.+0.j],
    'ro,3': 1-Port Network: 'ro,3', 500-750 GHz, 201 pts, z0=[ 50.+0.j]}
```

This can be passed directly to the NetworkSet constructor,

```
In [1]: ro_dict = rf.read_all('../skrf/data/', contains='ro')
In [2]: ro_ns = rf.NetworkSet(ro_dict, name='ro set') #name is optional
In [3]: ro_ns
Out[3]: A NetworkSet of length 3
```

A NetworkSet can also be constructed from zipfile of touchstones through the class method $\texttt{NetworkSet.from_zip()}$

1.5.2 Accesing Network Methods


The Network elements in a NetworkSet can be accessed like the elements of list,

```
In [1]: ro_ns[0]
Out[1]: 1-Port Network: 'ro,1', 500-750 GHz, 201 pts, z0=[ 50.+0.j]
```

1.5. NetworkSet 31

Most Network methods are also methods of NetworkSet. These methods are called on each Network element individually. For example to plot the log-magnitude of the s-parameters of each Network, (see *Plotting* for details on Network ploting methods).

```
In [1]: ro_ns.plot_s_db(label='Mean Response')
Out[1]: [None, None, None]
```



1.5.3 Statistical Properties


Statistical quantities can be calculated by accessing properties of the NetworkSet. For example, to calculate the complex average of the set, access the mean_s property

```
In [1]: ro_ns.mean_s
Out[1]: 1-Port Network: 'ro set', 500-750 GHz, 201 pts, z0=[ 50.+0.j]
```

Note: Because the statistical operator methods are generated upon initialization they are not explicitly documented in this manual.


The naming convention of the statistical operator properties are *NetworkSet.function_parameter*, where *function* is the name of the statistical function, and *parameter* is the Network parameter to operate on. These methods return a Network object, so they can be saved or plotted in the same way as you would with a Network. To plot the log-magnitude of the complex mean response

```
In [1]: figure();
In [2]: ro_ns.mean_s.plot_s_db(label='ro')
```



Or to plot the standard deviation of the complex s-parameters,


```
In [1]: figure();
```



Using these properties it is possible to calculate statistical quantities on the scalar components of the complex network parameters. To calculate the mean of the phase component,

```
In [1]: figure();
In [2]: ro_ns.mean_s_deg.plot_s_re()
```

1.5. NetworkSet 33



1.5.4 Plotting Uncertainty Bounds


Uncertainty bounds can be plotted through the methods

```
In [1]: figure();
```


In [2]: ro_ns.plot_uncertainty_bounds_s_db()

In [3]: figure();

In [4]: ro_ns.plot_uncertainty_bounds_s_deg()



34 Chapter 1. Tutorials



1.5.5 Reading and Writing

NetworkSets can be saved to disk using skrf's native IO capabilities. This can be ccomplished through the NetworkSet.write() method.

```
In [1]: ro_set.write()
In [2]: ls
ro set.ns
```

Note: Note that if the NetworkSet's name attribute is not assigned, then you must provide a filename to NetworkSet.write().

Alternatively, you can write the Network set by directly calling the write () function. In either case, the resultant file can be read back into memory using read ().

```
In [1]: ro_ns = rf.read('ro set.ns')
```

1.6 Virtual Instruments

Contents

• Virtual Instruments

Warning: The vi module is not well written or tested at this point.

The vi module holds classes for GPIB/VISA instruments that are intricately related to skrf. Most of the classes were created for the sole purpose of retrieving data so that calibration and measurements could be carried out offline with skrf, therefore most other instrument capabilities are neglected.

Note: To use the virtual instrument classes you must have pyvisa installed, and a working VISA installation.

A list of VNA's that have been are partially supported.

- HP8510C
- HP8720
- PNAX
- ZVA40

An example usage of the HP8510C class to retrieve some s-parameter data

```
In [1]: from skrf.vi import vna
In [2]: my_vna = vna.HP8510C(address =16)
#if an error is thrown at this point there is most likely a problem with your visa setup
In [3]: dut_1 = my_vna.s11
In [4]: dut_2 = my_vna.s21
In [5]: dut_3 = my_vna.two_port
```

Unfortunately, the syntax is different for every VNA class, so the above example wont directly translate to other VNA's. Re-writing all of the VNA classes to follow the same convention is on the TODO list

1.7 Calibration

Contents

- Calibration
 - Intro
 - Creating a Calibration
 - Saving and Recalling a Calibration
 - One-Port
 - Concise One-port
 - Two-port
 - * Switch-terms
 - Example
 - * Using one-port ideals in two-port Calibration

1.7.1 Intro

This tutorial illustrates how to use **skrf** to calibrate data taken from a VNA. The explanation of calibration theory and calibration kit design is beyond the scope of this tutorial. Instead, this tutorial describes how to calibrate a device under test (DUT), assuming you have measured an acceptable set of standards, and have a coresponding set ideal responses.

skrf's default calibration algorithms are generic in that they will work with any set of standards. If you supply more calibration standards than is needed, skrf will implement a simple least-squares solution.

1.7.2 Creating a Calibration

Calibrations are performed through a Calibration class. Creating a Calibration object requires at least two pieces of information:

- a list of measured Network's
- a list of ideal Network's

The Network elements in each list must all be similar (same #ports, frequency info, etc) and must be aligned to each other, meaning the first element of ideals list must correspond to the first element of measured list.

Optionally, other information can be provided when relevent such as,

- · calibration algorithm
- enforce eciprocity of embedding networks
- etc

When this information is not provided skrf will determine it through inspection, or use a default value.

1.7.3 Saving and Recalling a Calibration

Like other **skrf** objects, Calibration's can be written-to and read-from disk. Writing can be accomplished by using Calibration.write(), or rf.write(), and reading is done with rf.read().

1.7.4 One-Port

This example is written to be instructive, not concise.

```
import skrf as rf
## created necessary data for Calibration class
# a list of Network types, holding 'ideal' responses
my\_ideals = [\
        rf.Network('ideal/short.s1p'),
        rf.Network('ideal/open.slp'),
        rf.Network('ideal/load.s1p'),
# a list of Network types, holding 'measured' responses
my_measured = [\]
        rf.Network('measured/short.slp'),
        rf.Network('measured/open.s1p'),
        rf.Network('measured/load.s1p'),
## create a Calibration instance
cal = rf.Calibration(\
        ideals = my_ideals,
        measured = my_measured,
## run, and apply calibration to a DUT
```

1.7. Calibration 37

```
# run calibration algorithm
cal.run()

# apply it to a dut
dut = rf.Network('my_dut.slp')
dut_caled = cal.apply_cal(dut)

# plot results
dut_caled.plot_s_db()
# save results
dut_caled.write_touchstone()
```

1.7.5 Concise One-port

This example is the same as the first except more concise.

```
import skrf as rf

my_ideals = rf.load_all_touchstones_in_dir('ideals/')
my_measured = rf.load_all_touchstones_in_dir('measured/')

## create a Calibration instance
cal = rf.Calibration(\
    ideals = [my_ideals[k] for k in ['short','open','load']],
    measured = [my_measured[k] for k in ['short','open','load']],
    )

## what you do with 'cal' may may be similar to above example
```

1.7.6 Two-port

Two-port calibration is more involved than one-port. skrf supports two-port calibration using a 8-term error model based on the algorithm described in ², by R.A. Speciale.

Like the one-port algorithm, the two-port calibration can handle any number of standards, providing that some fundamental constraints are met. In short, you need three two-port standards; one must be transmissive, and one must provide a known impedance and be reflective.

One draw-back of using the 8-term error model formulation (which is the same formulation used in TRL) is that switch-terms may need to be measured in order to achieve a high quality calibration (this was pointed out to me by Dylan Williams).

Switch-terms

Originally described by Roger Marks ³, switch-terms account for the fact that the error networks change slightly depending on which port is being excited. This is due to the internal switch within the VNA.

² Speciale, R.A.; "A Generalization of the TSD Network-Analyzer Calibration Procedure, Covering n-Port Scattering-Parameter Measurements, Affected by Leakage Errors," Microwave Theory and Techniques, IEEE Transactions on , vol.25, no.12, pp. 1100-1115, Dec 1977. URL: http://ieeexplore.ieee.org/stamp/stamp.jsp?tp=&arnumber=1129282&isnumber=25047

³ Marks, Roger B.; , "Formulations of the Basic Vector Network Analyzer Error Model including Switch-Terms," ARFTG Conference Digest-Fall, 50th , vol.32, no., pp.115-126, Dec. 1997. URL: http://ieeexplore.ieee.org/stamp/stamp.jsp?tp=&arnumber=4119948&isnumber=4119931

Switch terms can be measured with a custom measurement configuration on the VNA itself. **skrf** has support for switch terms for the HP8510C class, which you can use or extend to different VNA. Without switch-term measurements, your calibration quality will vary depending on properties of you VNA.

1.7.7 Example

Two-port calibration is accomplished in an identical way to one-port, except all the standards are two-port networks. This is even true of reflective standards (S21=S12=0). So if you measure reflective standards you must measure two of them simultaneously, and store information in a two-port. For example, connect a short to port-1 and a load to port-2, and save a two-port measurement as 'short,load.s2p' or similar:

```
import skrf as rf
## created necessary data for Calibration class
# a list of Network types, holding 'ideal' responses
my\_ideals = [\
        rf.Network('ideal/thru.s2p'),
        rf.Network('ideal/line.s2p'),
        rf.Network('ideal/short, short.s2p'),
# a list of Network types, holding 'measured' responses
my_measured = [\]
        rf.Network('measured/thru.s2p'),
        rf.Network('measured/line.s2p'),
        rf.Network('measured/short, short.s2p'),
## create a Calibration instance
cal = rf.Calibration(\
        ideals = my_ideals,
        measured = my_measured,
        )
## run, and apply calibration to a DUT
# run calibration algorithm
cal.run()
# apply it to a dut
dut = rf.Network('my_dut.s2p')
dut_caled = cal.apply_cal(dut)
# plot results
dut_caled.plot_s_db()
# save results
dut_caled.write_touchstone()
```

Using one-port ideals in two-port Calibration

Commonly, you have data for ideal data for reflective standards in the form of one-port touchstone files (ie s1p). To use this with skrf's two-port calibration method you need to create a two-port network that is a composite of the two

1.7. Calibration 39

networks. There is a function in the WorkingBand Class which will do this for you, called two_port_reflect.:

```
short = rf.Network('ideals/short.s1p')
load = rf.Network('ideals/load.s1p')
short_load = rf.two_port_reflect(short, load)
```

Bibliography

1.8 Media

Contents

- Media
 - Introduction
 - * Media's Supported by skrf
 - Creating Media Objects
 - * Coplanar Waveguide
 - * Freespace
 - * Rectangular Waveguide
 - Working with Media's
 - Network Synthesis
 - Building Cicuits
 - Design Optimization
 - References

1.8.1 Introduction

skrf supports the microwave network synthesis based on transmission line models. Network creation is accomplished through methods of the Media class, which represents a transmission line object for a given medium. Once constructed, a Media object contains the necessary properties such as propagation constant and characteristic impedance, that are needed to generate microwave circuits.

This tutorial illustrates how created Networks using several different Media objects. The basic usage is,

```
In [1]: import skrf as rf
In [2]: freq = rf.Frequency(75,110,101,'ghz')
In [3]: cpw = rf.media.CPW(freq, w=10e-6, s=5e-6, ep_r=10.6)
In [4]: cpw.line(100*1e-6, name = '100um line')
Out[4]: 2-Port Network: '100um line', 75-110 GHz, 101 pts, z0=[ 50.06074662+0.j 50.06074662+0.j]
```

More detailed examples illustrating how to create various kinds of Media objects are given below.

Warning: The network creation and connection syntax of **skrf** are cumbersome if you need to doing complex circuit design. For a this type of application, you may be interested in using QUCS instead. **skrf**'s synthesis cabilities lend themselves more to scripted applications such as Design Optimization or batch processing.

Media's Supported by skrf

The base-class, Media, is constructed directly from values of propagation constant and characteristic impedance. Specific instances of Media objects can be created from relevant physical and electrical properties. Below is a list of mediums types supported by skrf,

- CPW
- RectangularWaveguide
- Freespace
- DistributedCircuit
- Media

1.8.2 Creating Media Objects

Typically, network analysis is done within a given frequency band. When a Media object is created, it must be given a Frequency object. This prevent having to repitously provide frequency information for each new network created.

Coplanar Waveguide

Here is an example of how to initialize a coplanar waveguide ⁴ media. The instance has a 10um center conductor, gap of 5um, and substrate with relative permativity of 10.6,

```
In [1]: import skrf as rf
In [2]: freq = rf.Frequency(75,110,101,'ghz')
In [3]: cpw = rf.media.CPW(freq, w=10e-6, s=5e-6, ep_r=10.6)
In [4]: cpw
Out[4]:
Coplanar Waveguide Media. 75-110 GHz. 101 points
W= 1.00e-05m, S= 5.00e-06m
```

See CPW for details on that class.

Freespace

Here is another example, this time constructing a plane-wave in freespace from 10-20GHz

```
In [1]: freq = rf.Frequency(10,20,101,'ghz')
In [2]: fs = rf.media.Freespace(freq)
In [3]: fs
Out[3]: Freespace Media. 10-20 GHz. 101 points
```

See Freespace for details.

1.8. Media 41

⁴ http://www.microwaves101.com/encyclopedia/coplanarwaveguide.cfm

Rectangular Waveguide

or a WR-10 Rectangular Waveguide

```
In [1]: freq = rf.Frequency(75,110,101,'ghz')
In [2]: wg = rf.media.RectangularWaveguide(freq, a=100*rf.mil,z0=50) # see note below about z0
In [3]: wg
Out[3]:
Rectangular Waveguide Media. 75-110 GHz. 101 points
a= 2.54e-03m, b= 1.27e-03m
```


See Rectangular Waveguide for details.

Note: The z0 argument in the Rectangular Waveguide constructor is used to force a specific port impedance. This is commonly used to match the port impedance to what a VNA stores in a touchstone file. See media.Media.__init__() for more information.


1.8.3 Working with Media's

Once constructed, the pertinent wave quantities of the media such as propagation constant and characteristic impedance can be accessed through the properties propagation_constant and characteristic_impedance. These properties return complex numpy.ndarray's,

In [3]: ylabel('Propagation Constant [rad/m]');



Because the wave quantities are dynamic they change when the attributes of the cpw line change. To illustrate this, plot the propagation constant of the cpw for various values of substrated permativity,



1.8. Media 43

1.8.4 Network Synthesis

Networks are created through methods of a Media object. Here is a brief list of some generic network components skrf supports,

```
• match()
```

- short()
- open()
- load()
- line()
- thru()
- tee()
- delay_short()
- shunt_delay_open()

Usage of these methods can is demonstrated below.

To create a 1-port network for a rectangular waveguide short,

```
In [1]: wg.short(name = 'short')
Out[1]: 1-Port Network: 'short', 75-110 GHz, 101 pts, z0=[ 50.+0.j]
```

Or to create a 90° section of cpw line,

```
In [1]: cpw.line(d=90,unit='deg', name='line')
Out[1]: 2-Port Network: 'line', 75-110 GHz, 101 pts, z0=[ 50.06074662+0.j 50.06074662+0.j]
```

Note: Simple circuits like short () and open () are ideal short and opens with $\Gamma=-1$ and $\Gamma=1$, i.e. they dont take into account sophisticated effects of the discontinuities. Effects of discontinuities are implemented as methods specific to a given Media, like CPW.cpw_short.

1.8.5 Building Cicuits

By connecting a series of simple circuits, more complex circuits can be made. To build a the 90° delay short, in the rectangular waveguide media defined above.

```
In [1]: delay_short = wg.line(d=90,unit='deg') ** wg.short()
In [2]: delay_short.name = 'delay short'
In [3]: delay_short
Out[3]: 1-Port Network: 'delay short', 75-110 GHz, 101 pts, z0=[ 50.+0.j]
```

When Networks with more than 2 ports need to be connected together, use rf.connect(). To create a two-port network for a shunted delayed open, you can create an ideal 3-way splitter (a 'tee') and conect the delayed open to one of its ports,

```
In [1]: tee = cpw.tee()
In [2]: delay_open = cpw.delay_open(40,'deg')
In [3]: shunt_open = rf.connect(tee,1,delay_open,0)
```

If a specific circuit is created frequenctly, it may make sense to use a function to create the circuit. This can be done most quickly using lamba

```
In [1]: delay_short = lambda d: wg.line(d,'deg')**wg.short()
In [2]: delay_short(90)
Out[2]: 1-Port Network: '', 75-110 GHz, 101 pts, z0=[ 50.+0.j]
```

This is how many of **skrf**'s network creation methods are made internally.

A more useful example may be to create a function for a shunt-stub tuner, that will work for any media object

1.8.6 Design Optimization

The abilities of scipy's optimizers can be used to automate network design. In this example, skrf is used to automate the single stub design. First, we create a 'cost' function which returns somthing we want to minimize, such as the reflection coefficient magnitude at band center. Then, one of scipy's minimization algorithms is used to determine the optimal parameters of the stub lengths to minimize this cost.

```
In [1]: from scipy.optimize import fmin
# the load we are trying to match
In [2]: load = cpw.load(rf.zl_2_Gamma0(z0=50,zl=100))
# single stub circuit generator function
In [3]: def shunt_stub(med, d0, d1):
           return med.line(d0,'deg')**med.shunt_delay_open(d1,'deg')
   . . . :
   . . . :
# define the cost function we want to minimize (this uses sloppy namespace)
In [4]: def cost(d):
             return (shunt_stub(cpw,d[0],d[1]) ** load)[100].s_mag.squeeze()
   . . . :
   . . . :
# initial guess of optimal delay lengths in degrees
In [5]: d0 = 120,40 # initial guess
#determine the optimal delays
In [6]: d_opt = fmin(cost, (120, 40))
Optimization terminated successfully.
         Current function value: 0.333333
         Iterations: 65
         Function evaluations: 140
In [7]: d_opt
Out[7]: array([ 1.74945025e+02, -9.55405994e-08])
```

1.8.7 References

· Development

1.8. Media 45

46 Chapter 1. Tutorials

EXAMPLES

2.1 Visualizing a Single Stub Matching Network

2.1.1 Introduction

This example illustrates a way to visualize the design space for a single stub matching network. The matching Network consists of a shunt and series stub arranged as shown below, (image taken from R.M. Weikle's Notes).

A single stub matching network can be designed to produce maximum power transfer to the load, Z_L at a single frequency. The matching network has two design parameters:

- · length of series tline
- · length of shunt tline

This script illustrates how to create a plot of reflection coefficient magnitude, vs series and shunt line lengths. The optimal designs are then seen as the minima of a 2D surface.

2.1.2 Script

```
import skrf as rf
from pylab import *
# Inputs
wg = rf.wr10 # The Media class
f0 = 90 # Design Frequency in GHz
d_start, d_stop = 0,180 # span of tline lengths [degrees]
n = 21
                    # number of points
Gamma0 = .5
                   # the reflection coefficient off the load we are matching
# change wg.frequency so we only simulat at f0
wg.frequency = rf.Frequency(f0,f0,1,'ghz')
# create load network
load = wg.load(.5)
# the vector of possible line-lengths to simulate at
d_range = linspace(d_start,d_stop,n)
def single_stub(wg, d):
    function to return series-shunt stub matching network, given a
```

48






Figure 2.1: Single stub matching Network

```
WorkingBand and the electrical lengths of the stubs
   return wg.shunt_delay_open(d[1],'deg') ** wg.line(d[0],'deg')
# loop through all line-lengths for series and shunt tlines, and store
# reflection coefficient magnitude in array
for d0 in d_range] for d1 in d_range] )
### Plots
# show the resultant return loss for the parameters space in 2D
figure()
title('Series-Shunt Stub Matching Network Design Space (2D)')
imshow(output)
xlabel('Series T-line [deg]')
ylabel('Shunt T-line [deg]')
xticks(range(0, n+1, n/5), d_range[0::n/5])
yticks(range(0,n+1,n/5),d_range[0::n/5])
cbar = colorbar()
cbar.set_label('Return Loss Magnitude')
grid(False)
# show the resultant return loss for the parameters space in 3D
from mpl_toolkits.mplot3d import Axes3D
fig=figure()
ax = Axes3D(fig)
x,y = meshgrid(d_range, d_range)
ax.plot_surface(x,y,output, rstride=1, cstride=1,cmap=cm.jet)
ax.set_xlabel('Series T-line [deg]')
ax.set_ylabel('Shunt T-line[deg]')
ax.set_zlabel('Return Loss Magnitude')
ax.set_title(r'Series-Shunt Stub Matching Network Design Space (3D)')
show()
```





2.2 One-Port Calibration

2.2.1 Instructive

This example is written to be instructive, not concise.:

2.2.2 Concise

This example is meant to be the same as the first except more concise:

```
import skrf as rf

my_ideals = rf.load_all_touchstones_in_dir('ideals/')
my_measured = rf.load_all_touchstones_in_dir('measured/')

## create a Calibration instance
cal = rf.Calibration(\
    ideals = [my_ideals[k] for k in ['short','open','load']],
    measured = [my_measured[k] for k in ['short','open','load']],
    )

## what you do with 'cal' may may be similar to above example
```

REFERENCE

3.1 frequency (skrf.frequency)

Provides a frequency object and related functions.

Most of the functionality is provided as methods and properties of the Frequency Class.

3.1.1 Frequency Class

Frequency([start, stop, npoints, unit, ...]) A frequency band.

skrf.frequency.Frequency

The frequency object provides a convenient way to work with and access a frequency band. It contains a fruequency vector as well as a frequency unit. This allows a frequency vector in a given unit to be available (f_scaled), as well as an absolute frquency axis in 'Hz' (f).

A Frequency object can be created from either (start, stop, npoints) using the default constructor, __init__ (). Or, it can be created from an arbitrary frequency vector by using the class method from_f().

Internally, the frequency information is stored in the f property combined with the *unit* property. All other properties, $start\ stop$, etc are generated from these.

Attributes

center	Center frequency.
f	Frequency vector in Hz
f_scaled	Frequency vector in units of unit
multiplier	Multiplier for formating axis
multiplier_dict	
npoints	starting frequency in Hz
span	the frequency span
start	starting frequency in Hz
step	the inter-frequency step size
	Continued on next page

Table 3.2 – continued from previous page

stop	starting frequency in Hz
unit	Unit of this frequency band.
unit_dict	
W	Frequency vector in radians/s

skrf.frequency.Frequency.center

 ${\tt Frequency.center}$

Center frequency.

Returns center: number

the exact center frequency in units of unit

skrf.frequency.Frequency.f

Frequency.f

Frequency vector in Hz

Returns f: numpy.ndarray

The frequency vector in Hz

See Also:

f_scaled frequency vector in units of unit

w angular frequency vector in rad/s

skrf.frequency.Frequency.f_scaled

Frequency.f_scaled

Frequency vector in units of unit

Returns f_scaled: numpy.ndarray

A frequency vector in units of unit

See Also:

- f frequency vector in Hz
- w frequency vector in rad/s

skrf.frequency.Frequency.multiplier

Frequency.multiplier

Multiplier for formating axis

This accesses the internal dictionary *multiplier_dict* using the value of unit

Returns multiplier: number

multiplier for this Frequencies unit

skrf.frequency.Frequency.multiplier_dict

Frequency.multiplier_dict = {'hz': 1, 'khz': 1000.0, 'mhz': 1000000.0, 'thz': 100000000000.0, 'ghz': 10000000000.0}

skrf.frequency.Frequency.npoints

Frequency.npoints starting frequency in Hz

skrf.frequency.Frequency.span

Frequency.span the frequency span

skrf.frequency.Frequency.start

Frequency.start
starting frequency in Hz

skrf.frequency.Frequency.step

Frequency.step
the inter-frequency step size

skrf.frequency.Frequency.stop

Frequency.stop starting frequency in Hz

skrf.frequency.Frequency.unit

Frequency.unit

Unit of this frequency band.

Possible strings for this attribute are: 'hz', 'khz', 'mhz', 'ghz', 'thz'

Setting this attribute is not case sensitive.

Returns unit: string

lower-case string representing the frequency units

skrf.frequency.Frequency.unit_dict

Frequency.unit_dict = {'hz': 'Hz', 'khz': 'KHz', 'mhz': 'MHz', 'thz': 'THz', 'ghz': 'GHz'}

skrf.frequency.Frequency.w

```
Frequency.w
```

Frequency vector in radians/s

The frequency vector in rad/s

Returns w:numpy.ndarray

The frequency vector in rad/s

See Also:

f_scaled frequency vector in units of unit

f frequency vector in Hz

Methods

init	Frequency initializer.
сору	returns a new copy of this frequency
from_f	Alternative constructor of a Frequency object from a frequency
labelXAxis	Label the x-axis of a plot.

skrf.frequency.Frequency.__init__

```
Frequency.__init__ (start=0, stop=0, npoints=0, unit='ghz', sweep_type='lin')
Frequency initializer.
```

Creates a Frequency object from start/stop/npoints and a unit. Alternatively, the class method $from_f()$ can be used to create a Frequency object from a frequency vector instead.

Parameters start: number

start frequency in units of unit

stop: number

stop frequency in units of unit

npoints: int

number of points in the band.

unit : ['hz','khz','mhz','ghz']

frequency unit of the band. This is used to create the attribute f_scaled. It is also used by the Network class for plots vs. frequency.

See Also:

from_f constructs a Frequency object from a frequency vector instead of start/stop/npoints.

Notes

The attribute unit sets the property freqMultiplier, which is used to scale the frequency when f_scaled is referenced.

Examples

```
>>> wrlp5band = Frequency(500,750,401, 'ghz')
skrf.frequency.Frequency.copy
Frequency.copy()
     returns a new copy of this frequency
skrf.frequency.Frequency.from_f
classmethod Frequency.from_f (f, *args, **kwargs)
     Alternative constructor of a Frequency object from a frequency vector, the unit of which is set by kwarg 'unit'
          Parameters f: array-like
                  frequency vector
              *args, **kwargs: arguments, keyword arguments
                  passed on to ___init___().
          Returns myfrequency: Frequency object
                  the Frequency object
     Examples
     \rightarrow \rightarrow f = np.linspace(75,100,101)
     >>> rf.Frequency.from_f(f, unit='ghz')
skrf.frequency.Frequency.labelXAxis
Frequency.labelXAxis(ax=None)
     Label the x-axis of a plot.
```

Sets the labels of a plot using matplotlib.x_label() with string containing the frequency unit.

Parameters ax: matplotlib. Axes, optional

Axes on which to label the plot, defaults what is returned by matplotlib.gca()

3.2 network (skrf.network)

Provides a n-port network class and associated functions.

Most of the functionality in this module is provided as methods and properties of the Network Class.

3.2.1 Network Class

Network([file, name, comments]) A n-port electrical network [#]_.

skrf.network.Network

class skrf.network.Network (file=None, name=None, comments=None, **kwargs)
 A n-port electrical network 1.

For instructions on how to create Network see __init__().

A n-port network may be defined by three quantities,

- network parameter matrix (s, z, or y-matrix)
- port characteristic impedance matrix
- · frequency information

The Network class stores these data structures internally in the form of complex numpy.ndarray's. These arrays are not interfaced directly but instead through the use of the properties:

Property	Meaning
S	scattering parameter matrix
z0	characteristic impedance matrix
f	frequency vector

Although these docs focus on s-parameters, other equivalent network representations such as z and y are available. Scalar projections of the complex network parameters are accesable through properties as well. These also return numpy.ndarray's.

Property	Meaning
s_re	real part of the s-matrix
s_im	imaginary part of the s-matrix
s_mag	magnitude of the s-matrix
s_db	magnitude in log scale of the s-matrix
s_deg	phase of the s-matrix in degrees

The following operations act on the networks s-matrix.

Operator	Function
+	element-wise addition of the s-matrix
-	element-wise difference of the s-matrix
*	element-wise multiplication of the s-matrix
/	element-wise division of the s-matrix
**	cascading (only for 2-ports)
//	de-embedding (for 2-ports, see inv)

Different components of the Network can be visualized through various plotting methods. These methods can be used to plot individual elements of the s-matrix or all at once. For more info about plotting see the *Plotting* tutorial

¹ http://en.wikipedia.org/wiki/Two-port_network

Method	Meaning
plot_s_smith()	plot complex s-parameters on smith chart
plot_s_re()	plot real part of s-parameters vs frequency
plot_s_im()	plot imaginary part of s-parameters vs frequency
plot_s_mag()	plot magnitude of s-parameters vs frequency
plot_s_db()	plot magnitude (in dB) of s-parameters vs frequency
plot_s_deg()	plot phase of s-parameters (in degrees) vs frequency
<pre>plot_s_deg_unwrap()</pre>	plot phase of s-parameters (in unwrapped degrees) vs frequency

Network objects can be created from a touchstone or pickle file (see __init__()), by a Media object, or manually by assigning the network properties directly. Network objects can be saved to disk in the form of touchstone files with the write_touchstone() method.

An exhaustive list of Network Methods and Properties (Attributes) are given below

References

Attributes

a	Active scattering parameter matrix.
a_arcl	The arcl component of the a-matrix
a_arcl_unwrap	The arcl_unwrap component of the a-matrix
a_db	The db component of the a-matrix
a_deg	The deg component of the a-matrix
a_deg_unwrap	The deg_unwrap component of the a-matrix
a_im	The im component of the a-matrix
a_mag	The mag component of the a-matrix
a_rad	The rad component of the a-matrix
a_rad_unwrap	The rad_unwrap component of the a-matrix
a_re	The re component of the a-matrix
f	the frequency vector for the network, in Hz.
frequency	frequency information for the network.
inv	a Network object with 'inverse' s-parameters.
nports	the number of ports the network has.
number_of_ports	the number of ports the network has.
passivity	passivity metric for a multi-port network.
S	Scattering parameter matrix.
s11	one-port sub-network.
s12	one-port sub-network.
s21	one-port sub-network.
s22	one-port sub-network.
s_arcl	The arcl component of the s-matrix
s_arcl_unwrap	The arcl_unwrap component of the s-matrix
s_db	The db component of the s-matrix
s_deg	The deg component of the s-matrix
s_deg_unwrap	The deg_unwrap component of the s-matrix
s_im	The im component of the s-matrix
s_mag	The mag component of the s-matrix
s_rad	The rad component of the s-matrix
s_rad_unwrap	The rad_unwrap component of the s-matrix
s_re	The re component of the s-matrix
	Continued on next page

Table 3.5 – continued from previous page

t	Scattering transfer parameters
У	Admittance parameter matrix.
y_arcl	The arcl component of the y-matrix
y_arcl_unwrap	The arcl_unwrap component of the y-matrix
y_db	The db component of the y-matrix
y_deg	The deg component of the y-matrix
y_deg_unwrap	The deg_unwrap component of the y-matrix
y_im	The im component of the y-matrix
y_mag	The mag component of the y-matrix
y_rad	The rad component of the y-matrix
y_rad_unwrap	The rad_unwrap component of the y-matrix
y_re	The re component of the y-matrix
Z	Impedance parameter matrix.
z0	Characteristic impedance[s] of the network ports.
z_arcl	The arcl component of the z-matrix
z_arcl z_arcl_unwrap	The arcl component of the z-matrix The arcl_unwrap component of the z-matrix
	The arcl component of the z-matrix The arcl_unwrap component of the z-matrix The db component of the z-matrix
z_arcl_unwrap	The arcl component of the z-matrix The arcl_unwrap component of the z-matrix The db component of the z-matrix The deg component of the z-matrix
z_arcl_unwrap z_db	The arcl component of the z-matrix The arcl_unwrap component of the z-matrix The db component of the z-matrix The deg component of the z-matrix The deg_unwrap component of the z-matrix
z_arcl_unwrap z_db z_deg	The arcl component of the z-matrix The arcl_unwrap component of the z-matrix The db component of the z-matrix The deg component of the z-matrix The deg_unwrap component of the z-matrix The im component of the z-matrix
z_arcl_unwrap z_db z_deg z_deg_unwrap	The arcl component of the z-matrix The arcl_unwrap component of the z-matrix The db component of the z-matrix The deg component of the z-matrix The deg_unwrap component of the z-matrix The im component of the z-matrix The mag component of the z-matrix
z_arcl_unwrap z_db z_deg z_deg_unwrap z_im	The arcl component of the z-matrix The arcl_unwrap component of the z-matrix The db component of the z-matrix The deg component of the z-matrix The deg_unwrap component of the z-matrix The im component of the z-matrix The mag component of the z-matrix The rad component of the z-matrix
z_arcl_unwrap z_db z_deg z_deg_unwrap z_im z_mag	The arcl component of the z-matrix The arcl_unwrap component of the z-matrix The db component of the z-matrix The deg component of the z-matrix The deg_unwrap component of the z-matrix The im component of the z-matrix The mag component of the z-matrix The rad component of the z-matrix The rad_unwrap component of the z-matrix
z_arcl_unwrap z_db z_deg z_deg_unwrap z_im z_mag z_rad	The arcl component of the z-matrix The arcl_unwrap component of the z-matrix The db component of the z-matrix The deg component of the z-matrix The deg_unwrap component of the z-matrix The im component of the z-matrix The mag component of the z-matrix The rad component of the z-matrix

skrf.network.Network.a

Network.a

Active scattering parameter matrix.

Active scattering parameters are simply inverted s-parameters, defined as a = 1/s. Useful in analysis of active networks. The a-matrix is a 3-dimensional numpy.ndarray which has shape fxnxn, where f is frequency axis and n is number of ports. Note that indexing starts at 0, so all can be accessed by taking the slice a[:,0,0].

Returns a: complex numpy.ndarray of shape fxnxn

the active scattering parameter matrix.

See Also:

s, y, z, t, a

skrf.network.Network.a arcl

Network.a_arcl

The arcl component of the a-matrix

See Also:

а

skrf.network.Network.a_arcl_unwrap

Network.a_arcl_unwrap

The arcl_unwrap component of the a-matrix

See Also:

а

skrf.network.Network.a_db

Network.a_db

The db component of the a-matrix

See Also:

а

skrf.network.Network.a_deg

Network.a_deg

The deg component of the a-matrix

See Also:

а

skrf.network.Network.a_deg_unwrap

Network.a_deg_unwrap

The deg_unwrap component of the a-matrix

See Also:

а

$skrf.network. Network. a_im$

Network.a_im

The im component of the a-matrix

See Also:

а

skrf.network.Network.a_mag

Network.a_mag

The mag component of the a-matrix

See Also:

а

skrf.network.Network.a rad Network.a_rad The rad component of the a-matrix See Also: а skrf.network.Network.a_rad_unwrap Network.a_rad_unwrap The rad_unwrap component of the a-matrix See Also: а skrf.network.Network.a_re Network.a_re The re component of the a-matrix See Also: а skrf.network.Network.f Network.f the frequency vector for the network, in Hz. **Returns** f: numpy.ndarrayfrequency vector in Hz See Also: frequency frequency property that holds all frequency information skrf.network.Network.frequency Network.frequency frequency information for the network. This property is a Frequency object. It holds the frequency vector, as well frequency unit, and provides other properties related to frequency information, such as start, stop, etc. Returns frequency: Frequency object frequency information for the network. See Also: f property holding frequency vector in Hz change_frequency updates frequency property, and interpolates s-parameters if needed

62

interpolate interpolate function based on new frequency info

skrf.network.Network.inv

Network.inv

a Network object with 'inverse' s-parameters.

This is used for de-embeding. It is defined so that the inverse of a Network cascaded with itself is unity.

Returns inv: a Network object

a Network object with 'inverse' s-parameters.

See Also:

inv function which implements the inverse s-matrix

skrf.network.Network.nports

Network.nports

the number of ports the network has.

Returns number_of_ports : number

the number of ports the network has.

skrf.network.Network.number of ports

Network.number_of_ports

the number of ports the network has.

Returns number_of_ports : number

the number of ports the network has.

skrf.network.Network.passivity

Network.passivity

passivity metric for a multi-port network.

This returns a matrix who's diagonals are equal to the total power received at all ports, normalized to the power at a single excitement port.

mathmatically, this is a test for unitary-ness of the s-parameter matrix ².

for two port this is

$$(|S_{11}|^2 + |S_{21}|^2, |S_{22}|^2 + |S_{12}|^2)$$

in general it is

$$S^H \cdot S$$

where H is conjugate transpose of S, and \cdot is dot product.

Returns passivity: numpy.ndarray of shape fxnxn

² http://en.wikipedia.org/wiki/Scattering_parameters#Lossless_networks

References

skrf.network.Network.s

Network.s

Scattering parameter matrix.

The s-matrix[#]_ is a 3-dimensional numpy.ndarray which has shape fxnxn, where f is frequency axis and n is number of ports. Note that indexing starts at 0, so s11 can be accessed by taking the slice s[:,0,0].

Returns s: complex numpy.ndarray of shape fxnxn

the scattering parameter matrix.

See Also:

s, y, z, t, a

References

skrf.network.Network.s11

```
Network.s11 one-port sub-network.
```

skrf.network.Network.s12

```
Network.s12 one-port sub-network.
```

skrf.network.Network.s21

```
Network.s21 one-port sub-network.
```

skrf.network.Network.s22

```
Network.s22 one-port sub-network.
```

skrf.network.Network.s_arcl

```
Network.s_arcl
```

The arcl component of the s-matrix

See Also:

S

64

skrf.network.Network.s arcl unwrap Network.s_arcl_unwrap The arcl_unwrap component of the s-matrix See Also: S skrf.network.Network.s_db Network.s_db The db component of the s-matrix See Also: skrf.network.Network.s_deg Network.s_deg The deg component of the s-matrix See Also: skrf.network.Network.s_deg_unwrap Network.s_deg_unwrap The deg_unwrap component of the s-matrix See Also: skrf.network.Network.s_im Network.s_im The im component of the s-matrix See Also: skrf.network.Network.s_mag Network.s_mag

See Also:

S

The mag component of the s-matrix

skrf.network.Network.s rad

```
Network.s_rad
```

The rad component of the s-matrix

See Also:

S

skrf.network.Network.s_rad_unwrap

```
Network.s_rad_unwrap
```

The rad_unwrap component of the s-matrix

See Also:

S

skrf.network.Network.s_re

```
Network.s_re
```

The re component of the s-matrix

See Also:

S

skrf.network.Network.t

Network.t

Scattering transfer parameters

The t-matrix 3 is a 3-dimensional numpy.ndarray which has shape fx2x2, where f is frequency axis. Note that indexing starts at 0, so t11 can be accessed by taking the slice t[:,0,0].

The t-matrix, also known as the wave cascading matrix, is only defined for a 2-port Network.

Returns \mathbf{t} : complex numpy.ndarry of shape fx2x2

t-parameters, aka scattering transfer parameters

See Also:

s, y, z, t, a

References

skrf.network.Network.y

Network.y

Admittance parameter matrix.

The y-matrix 4 is a 3-dimensional numpy . ndarray which has shape fxnxn, where f is frequency axis and n is number of ports. Note that indexing starts at 0, so y11 can be accessed by taking the slice y[:,0,0].

 $^{^3\} http://en.wikipedia.org/wiki/Scattering_parameters\#Scattering_transfer_parameters$

⁴ http://en.wikipedia.org/wiki/Admittance_parameters

```
Returns y: complex numpy.ndarray of shape fxnxn
                 the admittance parameter matrix.
     See Also:
     s, y, z, t, a
     References
skrf.network.Network.y_arcl
Network.y_arcl
     The arcl component of the y-matrix
     See Also:
skrf.network.Network.y_arcl_unwrap
Network.y_arcl_unwrap
     The arcl_unwrap component of the y-matrix
     See Also:
skrf.network.Network.y db
Network.y_db
     The db component of the y-matrix
     See Also:
skrf.network.Network.y_deg
Network.y_deg
     The deg component of the y-matrix
     See Also:
     У
skrf.network.Network.y_deg_unwrap
Network.y_deg_unwrap
     The deg_unwrap component of the y-matrix
     See Also:
```

У

skrf.network.Network.y_im Network.y_im The im component of the y-matrix See Also: У skrf.network.Network.y_mag Network.y_mag The mag component of the y-matrix See Also: У skrf.network.Network.y_rad Network.y_rad The rad component of the y-matrix See Also: У skrf.network.Network.y rad unwrap Network.y_rad_unwrap The rad_unwrap component of the y-matrix See Also: У skrf.network.Network.y_re Network.y_re The re component of the y-matrix

skrf.network.Network.z

See Also:

Network.z

У

Impedance parameter matrix.

The z-matrix 5 is a 3-dimensional numpy . ndarray which has shape fxnxn, where f is frequency axis and n is number of ports. Note that indexing starts at 0, so z11 can be accessed by taking the slice z[:,0,0].

Returns z: complex numpy.ndarray of shape fxnxn

⁵ http://en.wikipedia.org/wiki/impedance_parameters

the Impedance parameter matrix.

See Also:

s, y, z, t, a

References

skrf.network.Network.z0

Network.z0

Characteristic impedance[s] of the network ports.

This property stores the characteristic impedance of each port of the network. Because it is possible that each port has a different characteristic impedance each varying with frequency, z0 is stored internally as a fxn array.

However because z0 is frequently simple (like 50ohm), it can be set with just number as well.

Returns z0: numpy.ndarray of shape fxn

characteristic impedance for network

skrf.network.Network.z arcl

```
Network.z_arcl
```

The arcl component of the z-matrix

See Also:

Z

skrf.network.Network.z_arcl_unwrap

```
Network.z_arcl_unwrap
```

The arcl_unwrap component of the z-matrix

See Also:

7.

skrf.network.Network.z_db

```
Network.z_db
```

The db component of the z-matrix

See Also:

Z

skrf.network.Network.z deg

```
Network.z_deg
```

The deg component of the z-matrix

See Also:

Z skrf.network.Network.z_deg_unwrap Network.z_deg_unwrap The deg_unwrap component of the z-matrix See Also: skrf.network.Network.z_im Network.z_im The im component of the z-matrix See Also: skrf.network.Network.z_mag Network.z_mag The mag component of the z-matrix See Also: skrf.network.Network.z_rad Network.z_rad The rad component of the z-matrix See Also: skrf.network.Network.z_rad_unwrap ${\tt Network.z_rad_unwrap}$ The rad_unwrap component of the z-matrix See Also:

skrf.network.Network.z_re

 ${\tt Network.z_re}$

The re component of the z-matrix

See Also:

Z

70

Methods

init	Network constructor.
add_noise_polar	adds a complex zero-mean gaussian white-noise.
add_noise_polar_flatband	adds a flatband complex zero-mean gaussian white-noise signal of
сору	Returns a copy of this Network
copy_from	Copies the contents of another Network into self
flip	swaps the ports of a two port Network
interpolate	Return an interpolated network, from a new :class:'~skrf.frequency.Frequency'.
interpolate_from_f	Interpolates s-parameters from a frequency vector.
interpolate_self	Interpolates s-parameters given a new
interpolate_self_npoints	Interpolate network based on a new number of frequency points
multiply_noise	multiplys a complex bivariate gaussian white-noise signal
nudge	Perturb s-parameters by small amount.
plot_a_arcl	plot the Network attribute a_arcl vs frequency.
plot_a_arcl_unwrap	plot the Network attribute a_arcl_unwrap vs frequency.
plot_a_complex	plot the Network attribute a vs frequency.
plot_a_db	plot the Network attribute a_db vs frequency.
plot_a_deg	plot the Network attribute a_deg vs frequency.
plot_a_deg_unwrap	plot the Network attribute a_deg_unwrap vs frequency.
plot_a_im	plot the Network attribute a_im vs frequency.
plot_a_mag	plot the Network attribute a_mag vs frequency.
plot_a_polar	plot the Network attribute a vs frequency.
plot_a_rad	plot the Network attribute a_rad vs frequency.
plot_a_rad_unwrap	plot the Network attribute a_rad_unwrap vs frequency.
plot_a_re	plot the Network attribute a_re vs frequency.
plot_it_all	plot the retwork attribute a_re vs frequency.
plot_passivity	plots the passivity of a network, possibly for a specific port.
plot_s_arcl	plot the Network attribute s_arcl vs frequency.
plot_s_arcl_unwrap	plot the Network attribute s_arcl_unwrap vs frequency.
plot_s_complex	plot the Network attribute s vs frequency.
plot_s_db	plot the Network attribute s_db vs frequency.
plot_s_deg	plot the Network attribute s_deg vs frequency.
plot_s_deg_unwrap	plot the Network attribute s_deg_unwrap vs frequency.
plot_s_im	plot the Network attribute s_im vs frequency.
plot_s_mag	plot the Network attribute s_mag vs frequency.
plot_s_mag plot_s_polar	plot the Network attribute s vs frequency.
	plot the Network attribute s_rad vs frequency.
plot_s_rad	plot the Network attribute s_rad_unwrap vs frequency.
plot_s_rad_unwrap	plot the Network attribute s_rad_unwrap vs frequency. plot the Network attribute s_re vs frequency.
plot_s_re	<u> </u>
plot_s_smith	plots the scattering parameter on a smith chart
plot_y_arcl	plot the Network attribute y_arcl vs frequency.
plot_y_arcl_unwrap	plot the Network attribute y_arcl_unwrap vs frequency.
plot_y_complex	plot the Network attribute y vs frequency.
plot_y_db	plot the Network attribute y_db vs frequency.
plot_y_deg	plot the Network attribute y_deg vs frequency.
plot_y_deg_unwrap	plot the Network attribute y_deg_unwrap vs frequency.
plot_y_im	plot the Network attribute y_im vs frequency.
plot_y_mag	plot the Network attribute y_mag vs frequency.
plot_y_polar	plot the Network attribute y vs frequency.
	Continued on next page

TO 11 0 (4. 10	•
Table 3.6 -	continued tro	m previous page

plot_y_rad	plot the Network attribute y_rad vs frequency.
plot_y_rad_unwrap	plot the Network attribute y_rad_unwrap vs frequency.
plot_y_re	plot the Network attribute y_re vs frequency.
plot_z_arcl	plot the Network attribute z_arcl vs frequency.
plot_z_arcl_unwrap	plot the Network attribute z_arcl_unwrap vs frequency.
plot_z_complex	plot the Network attribute z vs frequency.
plot_z_db	plot the Network attribute z_db vs frequency.
plot_z_deg	plot the Network attribute z_deg vs frequency.
plot_z_deg_unwrap	plot the Network attribute z_deg_unwrap vs frequency.
plot_z_im	plot the Network attribute z_im vs frequency.
plot_z_mag	plot the Network attribute z_mag vs frequency.
plot_z_polar	plot the Network attribute z vs frequency.
plot_z_rad	plot the Network attribute z_rad vs frequency.
plot_z_rad_unwrap	plot the Network attribute z_rad_unwrap vs frequency.
plot_z_re	plot the Network attribute z_re vs frequency.
read	Read a Network from a 'ntwk' file
read_touchstone	loads values from a touchstone file.
renumber	renumbers some ports of a two port Network
resample	Interpolate network based on a new number of frequency points
write	Write the Network to disk using the pickle module.
write_touchstone	write a contents of the Network to a touchstone file.

skrf.network.Network.__init__

Network.__init__ (file=None, name=None, comments=None, **kwargs)
Network constructor.

Creates an n-port microwave network from a *file* or directly from data. If no file or data is given, then an empty Network is created.

Parameters file: str or file-object

file to load information from. supported formats are:

- touchstone file (.s?p)
- pickled Network (.ntwk, .p) see write()

name: str

Name of this Network. if None will try to use file, if its a str

comments : str

Comments associated with the Network

**kwargs::

key word arguments can be used to assign properties of the Network, such as s, f and z0.

See Also:

read read a network from a file
write write a network to a file, using pickle

write_touchstone write a network to a touchstone file

```
From a touchstone
     >>> n = rf.Network('ntwk1.s2p')
     From a pickle file
     >>> n = rf.Network('ntwk1.ntwk')
     Create a blank network, then fill in values
     >>> n = rf.Network()
     >>> n.f, n.s, n.z0 = [1,2,3], [1,2,3], [1,2,3]
     Directly from values
     >>> n = rf.Network(f=[1,2,3],s=[1,2,3],z0=[1,2,3])
skrf.network.Network.add noise polar
Network.add_noise_polar (mag_dev, phase_dev, **kwargs)
     adds a complex zero-mean gaussian white-noise.
     adds a complex zero-mean gaussian white-noise of a given standard deviation for magnitude and phase
          Parameters mag_dev : number
                  standard deviation of magnitude
              phase_dev : number
                  standard deviation of phase [in degrees]
skrf.network.Network.add_noise_polar_flatband
Network.add_noise_polar_flatband(mag_dev, phase_dev, **kwargs)
     adds a flatband complex zero-mean gaussian white-noise signal of given standard deviations for magnitude and
     phase
          Parameters mag_dev : number
                  standard deviation of magnitude
              phase_dev : number
                  standard deviation of phase [in degrees]
skrf.network.Network.copy
Network.copy()
     Returns a copy of this Network
     Needed to allow pass-by-value for a Network instead of pass-by-reference
```

skrf.network.Network.copy_from

```
Network.copy_from(other)
```

Copies the contents of another Network into self

Uses copy, so that the data is passed-by-value, not reference

Parameters other: Network

the network to copy the contents of

Examples

```
>>> a = rf.N()
>>> b = rf.N('my_file.s2p')
>>> a.copy_from (b)
```

skrf.network.Network.flip

```
Network.flip()
```

swaps the ports of a two port Network

skrf.network.Network.interpolate

```
Network.interpolate(new frequency, **kwargs)
```

Return an interpolated network, from a new :class:'~skrf.frequency.Frequency'.

Interpolate the networks s-parameters linearly in real and imaginary components. Other interpolation types can be used by passing appropriate **kwargs. This function returns an interpolated Network. Alternatively interpolate_self() will interpolate self.

```
Parameters new_frequency: Frequency
```

frequency information to interpolate

**kwargs: keyword arguments

passed to scipy.interpolate.interpld() initializer.

Returns result: Network

an interpolated Network

See Also:

```
resample, interpolate_self, interpolate_from_f
```

Notes

```
See scipy.interpolate.interpolate.interp1d() for useful kwargs. For example
```

kind [str or int] Specifies the kind of interpolation as a string ('linear', 'nearest', 'zero', 'slinear', 'quadratic, 'cubic') or as an integer specifying the order of the spline interpolator to use.

Examples

```
In [2]: n = rf.data.ring_slot
In [3]: n
Out[3]: 2-Port Network: 'ring slot', 75-110 GHz, 201 pts, z0=[ 50.+0.j 50.+0.j]
In [4]: new_freq = rf.Frequency(75,110,501,'ghz')
In [5]: n.interpolate(new_freq, kind = 'cubic')
Out[5]: 2-Port Network: 'ring slot', 75-110 GHz, 501 pts, z0=[ 50.+0.j 50.+0.j]
```

skrf.network.Network.interpolate_from_f

```
Network.interpolate_from_f (f, interp_kwargs={}, **kwargs)
```

Interpolates s-parameters from a frequency vector.

Given a frequency vector, and optionally a *unit* (see **kwargs), interpolate the networks s-parameters linearly in real and imaginary components.

See interpolate() for more information.

Parameters new_frequency: Frequency

frequency information to interpolate at

interp_kwargs::

```
dictionary of kwargs to be passed through to
scipy.interpolate.interpolate.interpld()
```

**kwargs::

passed to scipy.interpolate.interpld() initializer.

See Also:

```
resample, interpolate, interpolate_self
```

Notes

This creates a new Frequency, object using the method from_f(), and then calls interpolate_self().

skrf.network.Network.interpolate self

```
Network.interpolate_self (new_frequency, **kwargs)
```

Interpolates s-parameters given a new :class:'~skrf.frequency.Frequency' object.

See ${\tt interpolate}$ () for more information.

Parameters new_frequency: Frequency

frequency information to interpolate at

```
**kwargs : keyword arguments
```

passed to scipy.interpolate.interpld() initializer.

See Also:

```
resample, interpolate, interpolate_from_f
```

skrf.network.Network.interpolate self npoints

```
Network.interpolate_self_npoints (npoints, **kwargs)
```

Interpolate network based on a new number of frequency points

```
Parameters npoints: int
```

number of frequency points

**kwargs : keyword arguments

passed to scipy.interpolate.interpld() initializer.

See Also:

interpolate_self same functionality but takes a Frequency object

interpolate same functionality but takes a Frequency object and returns a new Network, instead of updating itself.

Notes

The function resample () is an alias for interpolate_self_npoints().

Examples

```
In [2]: n = rf.data.ring_slot

In [3]: n
Out[3]: 2-Port Network: 'ring slot', 75-110 GHz, 201 pts, z0=[ 50.+0.j 50.+0.j]

In [4]: n.resample(501) # resample is an alias

In [5]: n
Out[5]: 2-Port Network: 'ring slot', 75-110 GHz, 501 pts, z0=[ 50.+0.j 50.+0.j]
```

skrf.network.Network.multiply noise

```
Network.multiply_noise(mag_dev, phase_dev, **kwargs)
```

multiplys a complex bivariate gaussian white-noise signal of given standard deviations for magnitude and phase. magnitude mean is 1, phase mean is 0

takes: mag_dev: standard deviation of magnitude phase_dev: standard deviation of phase [in degrees] n_ports: number of ports. defualt to 1

returns: nothing

skrf.network.Network.nudge

```
Network.nudge(amount=1e-12)
     Perturb s-parameters by small amount.
     This is useful to work-around numerical bugs.
          Parameters amount: number,
                  amount to add to s parameters
     Notes
     This function is self.s = self.s + 1e-12
skrf.network.Network.plot_a_arcl
Network.plot_a_arcl(m=None,
                                      n=None,
                                                  ax=None,
                                                              show_legend=True,
                                                                                   attribute='a arcl',
                           y_label='Arc Length', *args, **kwargs)
     plot the Network attribute a_arcl vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show_legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args, **kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_a_arcl(m=1, n=0, color='r')
```

```
skrf.network.Network.plot a arcl unwrap
```

```
ax=None,
                                                                             show_legend=True,
Network.plot_a_arcl_unwrap(m=None,
                                                  n=None,
                                                                                                    at-
                                     tribute='a_arcl_unwrap', y_label='Arc Length', *args, **kwargs)
     plot the Network attribute a_arcl_unwrap vs frequency.
           Parameters m: int, optional
                   first index of s-parameter matrix, if None will use all
               n: int, optional
                   secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
               show legend: Boolean
                   draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                   the y-axis label
               *args,**kwargs: arguments, keyword arguments
                   passed to matplotlib.plot()
```

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_a_arcl_unwrap(m=1,n=0,color='r')
```

An existing Axes object to plot on

skrf.network.Network.plot_a_complex

```
Network.plot_a_complex (m=None, n=None, ax=None, show_legend=True, prop_name='a', *args, **kwargs)

plot the Network attribute a vs frequency.

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib.Axes object, optional
```

```
draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                   the y-axis label
               *args, **kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_a (m=1, n=0, color='r')
skrf.network.Network.plot a db
Network.plot_a_db (m=None,
                                                 ax=None,
                                                               show_legend=True,
                                                                                     attribute='a db',
                                     n=None,
                        y label='Magnitude (dB)', *args, **kwargs)
     plot the Network attribute a db vs frequency.
          Parameters m: int, optional
                   first index of s-parameter matrix, if None will use all
               n: int, optional
                   secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
               show_legend : Boolean
                  draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                   the y-axis label
               *args,**kwargs: arguments, keyword arguments
                   passed to matplotlib.plot()
```

show_legend: Boolean

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_a_db(m=1,n=0,color='r')
```

skrf.network.Network.plot_a_deg

```
Network.plot_a_deg (m=None, n=None, ax=None, show_legend=True, attribute='a_deg', y_label='Phase(deg)', *args, **kwargs) plot the Network attribute a_deg vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib. Axes object, optional

An existing Axes object to plot on

show_legend : Boolean

draw legend or not

attribute: string

Network attribute to plot

y_label: string, optional

the y-axis label

*args,**kwargs: arguments, keyword arguments

```
passed to matplotlib.plot()
```

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

```
>>> myntwk.plot_a_deg(m=1, n=0, color='r')
```

skrf.network.Network.plot a deg unwrap

```
n=None,
                                                                           show_legend=True,
Network.plot_a_deg_unwrap(m=None,
                                                             ax=None,
                                                                                                   at-
                                   tribute='a_deg_unwrap', y_label='Phase (deg)', *args, **kwargs)
     plot the Network attribute a_deg_unwrap vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_a_deq_unwrap(m=1, n=0, color='r')
skrf.network.Network.plot_a_im
Network.plot_a_im(m=None, n=None, ax=None, show_legend=True, attribute='a_im', y_label='Imag
                        Part', *args, **kwargs)
     plot the Network attribute a_im vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
```

show_legend: Boolean

```
draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_a_im(m=1, n=0, color='r')
skrf.network.Network.plot a mag
Network.plot_a_mag(m=None,
                                                 ax=None,
                                                             show_legend=True,
                                                                                   attribute='a mag',
                                     n=None,
                          y label='Magnitude', *args, **kwargs)
     plot the Network attribute a_mag vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show_legend : Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
```

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_a_mag(m=1, n=0, color='r')
```

skrf.network.Network.plot a polar

```
Network.plot_a_polar (m=None, n=None, ax=None, show_legend=True, prop_name='a', *args, **kwargs)

plot the Network attribute a vs frequency.

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib.Axes object, optional

An existing Axes object to plot on

show_legend: Boolean

draw legend or not

attribute: string
```

Network attribute to plot

y_label : string, optional

the y-axis label

*args, **kwargs: arguments, keyword arguments

```
passed to matplotlib.plot()
```

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

```
>>> myntwk.plot_a (m=1, n=0, color='r')
```

```
skrf.network.Network.plot a rad
Network.plot_a_rad(m=None,
                                      n=None,
                                                 ax=None,
                                                              show_legend=True,
                                                                                    attribute='a_rad',
                          v label='Phase (rad)', *args, **kwargs)
     plot the Network attribute a_rad vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_a_rad(m=1, n=0, color='r')
skrf.network.Network.plot_a_rad_unwrap
Network.plot_a_rad_unwrap(m=None,
                                                n=None,
                                                             ax=None,
                                                                           show_legend=True,
                                                                                                  at-
                                   tribute='a_rad_unwrap', y_label='Phase (rad)', *args, **kwargs)
     plot the Network attribute a_rad_unwrap vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
```

An existing Axes object to plot on

```
draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_a_rad_unwrap(m=1,n=0,color='r')
skrf.network.Network.plot a re
Network.plot_a_re (m=None, n=None, ax=None, show_legend=True, attribute='a_re', y_label='Real
                        Part', *args, **kwargs)
     plot the Network attribute a_re vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show_legend : Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
```

show_legend: Boolean

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_a_re(m=1, n=0, color='r')
```

skrf.network.Network.plot_it_all

```
Network.plot_it_all(*args, **kwargs)
```

skrf.network.Network.plot passivity

Network.**plot_passivity** (*port=None*, *ax=None*, *show_legend=True*, *args, **kwargs) plots the passivity of a network, possibly for a specific port.

Parameters port: int:

calculate passivity of a given port

ax: matplotlib.Axes object, optional

axes to plot on. in case you want to update an existing plot.

show_legend: boolean, optional

to turn legend show legend of not, optional

*args: arguments, optional

passed to the matplotlib.plot command

**kwargs: keyword arguments, optional

passed to the matplotlib.plot command

See Also:

```
plot_vs_frequency_generic, passivity
```

Examples

```
>>> myntwk.plot_s_rad()
>>> myntwk.plot_s_rad(m=0,n=1,color='b', marker='x')
```

skrf.network.Network.plot_s_arcl

```
Network.plot_s_arcl (m=None, n=None, ax=None, show_legend=True, attribute='s_arcl', y_label='Arc Length', *args, **kwargs)
plot the Network attribute s_arcl vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

```
n: int, optional
                  secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
               show legend: Boolean
                   draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                   the y-axis label
               *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_s_arcl(m=1, n=0, color='r')
skrf.network.Network.plot s arcl unwrap
                                                                            show legend=True,
Network.plot_s_arcl_unwrap(m=None,
                                                  n=None,
                                                               ax=None.
                                                                                                   at-
                                     tribute='s_arcl_unwrap', y_label='Arc Length', *args, **kwargs)
     plot the Network attribute s_arcl_unwrap vs frequency.
          Parameters m: int, optional
                   first index of s-parameter matrix, if None will use all
               n: int, optional
                  secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
               show_legend: Boolean
                  draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                   the y-axis label
```

```
*args,**kwargs: arguments, keyword arguments
passed to matplotlib.plot()
```

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_s_arcl_unwrap(m=1,n=0,color='r')
```

skrf.network.Network.plot_s_complex

```
Network.plot_s_complex(m=None, n=None, ax=None, show_legend=True, prop_name='s', *args, **kwargs)

plot the Network attribute s vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

 \mathbf{n} : int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib. Axes object, optional

An existing Axes object to plot on

show_legend: Boolean

draw legend or not

attribute: string

Network attribute to plot

y_label: string, optional

the y-axis label

*args,**kwargs: arguments, keyword arguments

passed to matplotlib.plot()

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

```
>>> myntwk.plot_s (m=1, n=0, color='r')
```

skrf.network.Network.plot s db

```
Network.plot_s_db(m=None,
                                     n=None,
                                                 ax=None,
                                                              show_legend=True,
                                                                                    attribute='s_db',
                        y_label='Magnitude (dB)', *args, **kwargs)
     plot the Network attribute s_db vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_s_db (m=1, n=0, color='r')
skrf.network.Network.plot_s_deg
Network.plot_s_deg(m=None,
                                     n=None,
                                                 ax=None,
                                                              show_legend=True,
                                                                                   attribute='s_deg',
                         y_label='Phase (deg)', *args, **kwargs)
     plot the Network attribute s_deg vs frequency.
          Parameters m: int, optional
```

first index of s-parameter matrix, if None will use all

ax : matplotlib.Axes object, optional
An existing Axes object to plot on

secon index of the s-parameter matrix, if None will use all

n: int, optional

show_legend: Boolean

```
draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_s_deg(m=1,n=0,color='r')
skrf.network.Network.plot s deg unwrap
Network.plot_s_deg_unwrap(m=None,
                                                             ax=None,
                                                                           show_legend=True,
                                                n=None,
                                                                                                  at-
                                   tribute='s_deg_unwrap', y_label='Phase (deg)', *args, **kwargs)
     plot the Network attribute s_deg_unwrap vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show_legend : Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
```

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_s_deg_unwrap(m=1, n=0, color='r')
```

skrf.network.Network.plot s im

```
Network.plot_s_im(m=None, n=None, ax=None, show_legend=True, attribute='s_im', y_label='Imag Part', *args, **kwargs')
plot the Network attribute s_im vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib. Axes object, optional

An existing Axes object to plot on

show_legend : Boolean

draw legend or not

attribute: string

Network attribute to plot

y_label: string, optional

the y-axis label

*args,**kwargs: arguments, keyword arguments

```
passed to matplotlib.plot()
```

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

```
>>> myntwk.plot_s_im (m=1, n=0, color='r')
```

```
skrf.network.Network.plot s mag
Network.plot_s_mag(m=None,
                                                             show_legend=True,
                                     n=None,
                                                                                   attribute='s_mag',
                                                 ax=None,
                          y_label='Magnitude', *args, **kwargs)
     plot the Network attribute s_mag vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_s_mag(m=1, n=0, color='r')
skrf.network.Network.plot_s_polar
Network.plot_s_polar(m=None, n=None, ax=None, show_legend=True, prop_name='s', *args,
                            **kwargs)
     plot the Network attribute s vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax : matplotlib.Axes object, optional
```

An existing Axes object to plot on

```
draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                   the y-axis label
               *args, **kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_s (m=1, n=0, color='r')
skrf.network.Network.plot s rad
Network.plot_s_rad(m=None,
                                                  ax=None,
                                                               show_legend=True,
                                                                                    attribute='s rad',
                                      n=None,
                          y label='Phase (rad)', *args, **kwargs)
     plot the Network attribute s_rad vs frequency.
          Parameters m: int, optional
                   first index of s-parameter matrix, if None will use all
               n: int, optional
                  secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
               show_legend : Boolean
                  draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                   the y-axis label
               *args,**kwargs: arguments, keyword arguments
                   passed to matplotlib.plot()
```

show_legend: Boolean

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_s_rad(m=1, n=0, color='r')
```

skrf.network.Network.plot s rad unwrap

```
Network.plot_s_rad_unwrap (m=None, n=None, ax=None, show_legend=True, at-tribute='s_rad_unwrap', y_label='Phase (rad)', *args, **kwargs) plot the Network attribute s_rad_unwrap vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib. Axes object, optional

An existing Axes object to plot on

show_legend : Boolean

draw legend or not

attribute: string

Network attribute to plot

y_label: string, optional

the y-axis label

*args,**kwargs: arguments, keyword arguments

```
passed to matplotlib.plot()
```

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

```
>>> myntwk.plot_s_rad_unwrap(m=1, n=0, color='r')
```

skrf.network.Network.plot s re

```
Network.plot_s_re(m=None, n=None, ax=None, show_legend=True, attribute='s_re', y_label='Real
                         Part', *args, **kwargs)
     plot the Network attribute s_re vs frequency.
           Parameters m: int, optional
                   first index of s-parameter matrix, if None will use all
               n: int, optional
                   secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
               show legend: Boolean
                   draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                   the y-axis label
               *args,**kwargs: arguments, keyword arguments
                   passed to matplotlib.plot()
```

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_s_re(m=1, n=0, color='r')
```

skrf.network.Network.plot_s_smith

```
Network.plot_s_smith (m=None, n=None, r=1, ax=None, show_legend=True, chart_type='z', draw_labels=False, label_axes=False, *args, **kwargs)
plots the scattering parameter on a smith chart
plots indices m, n, where m and n can be integers or lists of integers.
```

Parameters m: int, optional

```
first index

n: int, optional
second index

ax: matplotlib.Axes object, optional
```

```
axes to plot on. in case you want to update an existing plot.
               show_legend : boolean, optional
                   to turn legend show legend of not, optional
               chart_type : ['z','y']
                   draw impedance or addmitance contours
               draw_labels : Boolean
                   annotate chart with impedance values
               label_axes: Boolean
                   Label axis with titles Real and Imaginary
               border: Boolean
                   draw rectangular border around image with ticks
               *args: arguments, optional
                   passed to the matplotlib.plot command
               **kwargs: keyword arguments, optional
                   passed to the matplotlib.plot command
     See Also:
     plot_vs_frequency_generic, smith
     Examples
     >>> myntwk.plot_s_smith()
     >>> myntwk.plot_s_smith(m=0,n=1,color='b', marker='x')
skrf.network.Network.plot_y_arcl
Network.plot_y_arcl(m=None,
                                       n=None,
                                                   ax=None,
                                                               show_legend=True,
                                                                                     attribute='y_arcl',
                           y_label='Arc Length', *args, **kwargs)
     plot the Network attribute y_arcl vs frequency.
          Parameters m: int, optional
                   first index of s-parameter matrix, if None will use all
               n: int, optional
                   secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
               show legend: Boolean
                   draw legend or not
               attribute: string
                   Network attribute to plot
```

```
y_label: string, optional
    the y-axis label
*args,**kwargs: arguments, keyword arguments
    passed to matplotlib.plot()
```

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_y_arcl(m=1,n=0,color='r')
```

skrf.network.Network.plot_y_arcl_unwrap

```
Network.plot_y_arcl_unwrap (m=None, n=None, ax=None, show_legend=True, at-tribute='y_arcl_unwrap', y_label='Arc Length', *args, **kwargs)
plot the Network attribute y_arcl_unwrap vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib. Axes object, optional

An existing Axes object to plot on

show_legend: Boolean

draw legend or not

attribute: string

Network attribute to plot

y_label: string, optional

the y-axis label

*args,**kwargs: arguments, keyword arguments

passed to matplotlib.plot()

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

```
>>> myntwk.plot_y_arcl_unwrap(m=1, n=0, color='r')
skrf.network.Network.plot_y_complex
Network.plot_y_complex (m=None, n=None, ax=None, show_legend=True, prop_name='y', *args,
                               **kwargs)
     plot the Network attribute y vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show_legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args, **kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_y (m=1, n=0, color='r')
skrf.network.Network.plot_y_db
Network.plot_y_db (m=None,
                                     n=None,
                                                 ax=None,
                                                              show_legend=True,
                                                                                    attribute = 'y_db',
                        y_label='Magnitude (dB)', *args, **kwargs)
     plot the Network attribute y_db vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
```

```
ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
               show_legend: Boolean
                  draw legend or not
               attribute: string
                  Network attribute to plot
               y_label: string, optional
                   the y-axis label
               *args,**kwargs: arguments, keyword arguments
                   passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_y_db (m=1, n=0, color='r')
skrf.network.Network.plot_y_deg
Network.plot_y_deg(m=None,
                                      n=None,
                                                  ax=None,
                                                               show_legend=True,
                                                                                     attribute='y_deg',
                          y label='Phase (deg)', *args, **kwargs)
     plot the Network attribute y_deg vs frequency.
          Parameters m: int, optional
                   first index of s-parameter matrix, if None will use all
               n: int, optional
                   secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
               show_legend: Boolean
                   draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                  the y-axis label
               *args, **kwargs: arguments, keyword arguments
```

secon index of the s-parameter matrix, if None will use all

```
passed to matplotlib.plot()
```

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_y_deg(m=1, n=0, color='r')
```

skrf.network.Network.plot_y_deg_unwrap

```
Network.plot_y_deg_unwrap (m=None, n=None, ax=None, show_legend=True, at-
tribute='y_deg_unwrap', y_label='Phase (deg)', *args, **kwargs)
plot the Network attribute y_deg_unwrap vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib. Axes object, optional

An existing Axes object to plot on

show_legend : Boolean

draw legend or not

attribute: string

Network attribute to plot

y_label: string, optional

the y-axis label

*args,**kwargs: arguments, keyword arguments

passed to matplotlib.plot()

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

```
>>> myntwk.plot_y_deg_unwrap(m=1,n=0,color='r')
```

skrf.network.Network.plot y_im

```
Network.plot_y_im(m=None, n=None, ax=None, show_legend=True, attribute='y_im', y_label='Imag
                        Part', *args, **kwargs)
     plot the Network attribute y_im vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_y_im (m=1, n=0, color='r')
skrf.network.Network.plot_y_mag
Network.plot_y_mag(m=None,
                                    n=None,
                                                 ax=None,
                                                              show_legend=True,
                                                                                    attribute='y_mag',
                          y_label='Magnitude', *args, **kwargs)
     plot the Network attribute y_mag vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
```

show_legend: Boolean

```
draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_y_mag(m=1,n=0,color='r')
skrf.network.Network.plot y polar
Network.plot_y_polar (m=None, n=None, ax=None, show_legend=True, prop_name='y', *args,
                            **kwargs)
     plot the Network attribute y vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show_legend : Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
```

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_y (m=1, n=0, color='r')
```

skrf.network.Network.plot y rad

```
Network.plot_y_rad (m=None, n=None, ax=None, show_legend=True, attribute='y_rad', y_label='Phase (rad)', *args, **kwargs) plot the Network attribute y_rad vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib. Axes object, optional

An existing Axes object to plot on

show_legend: Boolean

draw legend or not

attribute: string

Network attribute to plot

y_label: string, optional

the y-axis label

*args,**kwargs: arguments, keyword arguments

```
passed to matplotlib.plot()
```

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

```
>>> myntwk.plot_y_rad(m=1, n=0, color='r')
```

```
skrf.network.Network.plot_y_rad_unwrap
```

```
ax=None,
Network.plot_y_rad_unwrap(m=None,
                                                 n=None,
                                                                           show_legend=True,
                                                                                                   at-
                                   tribute='y_rad_unwrap', y_label='Phase (rad)', *args, **kwargs)
     plot the Network attribute y_rad_unwrap vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_y_rad_unwrap(m=1, n=0, color='r')
skrf.network.Network.plot_y_re
Network.plot_y_re(m=None, n=None, ax=None, show_legend=True, attribute='y_re', y_label='Real
                        Part', *args, **kwargs)
     plot the Network attribute y_re vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
```

```
draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_y_re(m=1,n=0,color='r')
skrf.network.Network.plot z arcl
Network.plot_z_arcl(m=None, n=None,
                                                  ax=None,
                                                              show_legend=True, attribute='z_arcl',
                          y_label='Arc Length', *args, **kwargs)
     plot the Network attribute z_arcl vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show_legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
```

show_legend : Boolean

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_z_arcl(m=1, n=0, color='r')
```

skrf.network.Network.plot z arcl unwrap

```
Network.plot_z_arcl_unwrap (m=None, n=None, ax=None, show_legend=True, at-
tribute='z_arcl_unwrap', y_label='Arc Length', *args, **kwargs)
plot the Network attribute z_arcl_unwrap vs frequency.

Parameters m: int, optional
first index of s-parameter matrix, if None will use all

n: int, optional
secon index of the s-parameter matrix, if None will use all
```

 ${f ax}$: matplotlib.Axes object, optional

An existing Axes object to plot on

show_legend : Boolean
draw legend or not

attribute: string

Network attribute to plot

y_label : string, optional
 the y-axis label

*args, **kwargs: arguments, keyword arguments

passed to matplotlib.plot()

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_z_arcl_unwrap(m=1,n=0,color='r')
```

skrf.network.Network.plot z complex

```
Network.plot_z_complex(m=None, n=None, ax=None, show_legend=True, prop_name='z', *args,
                               **kwargs)
     plot the Network attribute z vs frequency.
          Parameters m: int, optional
                   first index of s-parameter matrix, if None will use all
               n: int, optional
                   secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
               show legend: Boolean
                  draw legend or not
               attribute: string
                   Network attribute to plot
               y_label: string, optional
                   the y-axis label
               *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_z (m=1, n=0, color='r')
skrf.network.Network.plot_z_db
Network.plot_z_db (m=None,
                                     n=None,
                                                  ax=None,
                                                               show_legend=True,
                                                                                     attribute='z_db',
                        y_label='Magnitude (dB)', *args, **kwargs)
     plot the Network attribute z_db vs frequency.
          Parameters m: int, optional
                   first index of s-parameter matrix, if None will use all
               n: int, optional
                   secon index of the s-parameter matrix, if None will use all
               ax: matplotlib. Axes object, optional
                   An existing Axes object to plot on
```

show_legend: Boolean

```
draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_z_db (m=1, n=0, color='r')
skrf.network.Network.plot z deg
Network.plot_z_deg(m=None,
                                                 ax=None,
                                                               show_legend=True,
                                                                                    attribute='z_deg',
                                      n=None,
                          y label='Phase (deg)', *args, **kwargs)
     plot the Network attribute z_deg vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show_legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
```

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_z_deg(m=1, n=0, color='r')
```

skrf.network.Network.plot z deg unwrap

```
Network.plot_z_deg_unwrap (m=None, n=None, ax=None, show_legend=True, at-
tribute='z_deg_unwrap', y_label='Phase (deg)', *args, **kwargs)
plot the Network attribute z_deg_unwrap vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib. Axes object, optional

An existing Axes object to plot on

show_legend: Boolean

draw legend or not

attribute: string

Network attribute to plot

y_label: string, optional

the y-axis label

*args, **kwargs: arguments, keyword arguments

passed to matplotlib.plot()

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_z_deg_unwrap(m=1, n=0, color='r')
```

```
skrf.network.Network.plot z im
Network.plot_z_im(m=None, n=None, ax=None, show_legend=True, attribute='z_im', y_label='Imag
                        Part', *args, **kwargs)
     plot the Network attribute z_im vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_z_im (m=1, n=0, color='r')
skrf.network.Network.plot_z_mag
Network.plot_z_mag(m=None,
                                     n=None,
                                                 ax=None,
                                                              show_legend=True,
                                                                                   attribute='z_mag',
                          y_label='Magnitude', *args, **kwargs)
     plot the Network attribute z_mag vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
```

secon index of the s-parameter matrix, if None will use all

ax : matplotlib.Axes object, optional
An existing Axes object to plot on

```
draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args, **kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_z_mag(m=1, n=0, color='r')
skrf.network.Network.plot z polar
Network.plot_z_polar (m=None, n=None, ax=None, show_legend=True, prop_name='z', *args,
                            **kwargs)
     plot the Network attribute z vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show_legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
```

show_legend: Boolean

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_z (m=1, n=0, color='r')
```

skrf.network.Network.plot_z_rad

```
Network.plot_z_rad (m=None, n=None, ax=None, show\_legend=True, attribute='z\_rad', y\_label='Phase (rad)', *args, **kwargs) plot the Network attribute z\_rad vs frequency.
```

Parameters m: int, optional

first index of s-parameter matrix, if None will use all

n: int, optional

secon index of the s-parameter matrix, if None will use all

ax: matplotlib. Axes object, optional

An existing Axes object to plot on

show_legend : Boolean

draw legend or not

attribute: string

Network attribute to plot

y_label: string, optional

the y-axis label

*args,**kwargs: arguments, keyword arguments

```
passed to matplotlib.plot()
```

Notes

This function is dynamically generated upon Network initialization. This is accomplished by calling plot_vs_frequency_generic()

Examples

```
>>> myntwk.plot_z_rad(m=1, n=0, color='r')
```

skrf.network.Network.plot z rad unwrap

```
Network.plot_z_rad_unwrap(m=None,
                                                 n=None,
                                                              ax=None,
                                                                            show_legend=True,
                                                                                                   at-
                                   tribute='z_rad_unwrap', y_label='Phase (rad)', *args, **kwargs)
     plot the Network attribute z_rad_unwrap vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
              show legend: Boolean
                  draw legend or not
              attribute: string
                  Network attribute to plot
              y_label: string, optional
                  the y-axis label
              *args,**kwargs: arguments, keyword arguments
                  passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_z_rad_unwrap(m=1, n=0, color='r')
skrf.network.Network.plot_z_re
Network.plot_z_re(m=None, n=None, ax=None, show_legend=True, attribute='z_re', y_label='Real
                        Part', *args, **kwargs)
     plot the Network attribute z_re vs frequency.
          Parameters m: int, optional
                  first index of s-parameter matrix, if None will use all
              n: int, optional
                  secon index of the s-parameter matrix, if None will use all
              ax: matplotlib. Axes object, optional
                  An existing Axes object to plot on
```

show_legend: Boolean

```
draw legend or not
              attribute: string
                 Network attribute to plot
              y_label: string, optional
                 the y-axis label
              *args,**kwargs: arguments, keyword arguments
                 passed to matplotlib.plot()
     Notes
     This function is dynamically generated upon Network initialization. This is accomplished by calling
     plot_vs_frequency_generic()
     Examples
     >>> myntwk.plot_z_re(m=1, n=0, color='r')
skrf.network.Network.read
Network.read(*args, **kwargs)
     Read a Network from a 'ntwk' file
     A ntwk file is written with write (). It is just a pickled file.
          Parameters *args, **kwargs : args and kwargs
                 passed to skrf.io.general.write()
     See Also:
     write, skrf.io.general.write, skrf.io.general.read
     Notes
     This function calls skrf.io.general.read().
     Examples
     >>> rf.read('myfile.ntwk')
     >>> rf.read('myfile.p')
```

skrf.network.Network.read_touchstone

```
{\tt Network.read\_touchstone}~(\mathit{filename})
```

loads values from a touchstone file.

The work of this function is done through the touchstone class.

Parameters filename: str or file-object

touchstone file name.

Notes

only the scattering parameters format is supported at the moment

skrf.network.Network.renumber

```
Network.renumber (from_ports, to_ports)
renumbers some ports of a two port Network

Parameters from_ports: list-like

to_ports: list-like:
```

Examples

```
To flip the ports of a 2-port network 'foo': >>> foo.renumber( [0,1], [1,0] )
```

To rotate the ports of a 3-port network 'bar' so that port 0 becomes port 1: >> bar.renumber([0,1,2], [1,2,0])

To swap the first and last ports of a network 'duck': >>> duck.renumber([0,-1], [-1,0])

skrf.network.Network.resample

```
Network.resample (npoints, **kwargs)
```

Interpolate network based on a new number of frequency points

```
Parameters npoints: int
```

number of frequency points

**kwargs: keyword arguments

passed to scipy.interpolate.interpld() initializer.

See Also:

interpolate_self same functionality but takes a Frequency object

interpolate same functionality but takes a Frequency object and returns a new Network, instead of updating itself.

Notes

The function resample () is an alias for interpolate_self_npoints().

Examples

```
In [2]: n = rf.data.ring_slot
In [3]: n
Out[3]: 2-Port Network: 'ring slot', 75-110 GHz, 501 pts, z0=[ 50.+0.j 50.+0.j]
In [4]: n.resample(501) # resample is an alias
In [5]: n
Out[5]: 2-Port Network: 'ring slot', 75-110 GHz, 501 pts, z0=[ 50.+0.j 50.+0.j]
```

skrf.network.Network.write

```
Network.write(file=None, *args, **kwargs)
```

Write the Network to disk using the pickle module.

The resultant file can be read either by using the Networks constructor, __init__() , the read method read(), or the general read function skrf.io.general.read()

Parameters file: str or file-object

filename or a file-object. If left as None then the filename will be set to Network.name, if its not None. If both are None, ValueError is raised.

```
*args, **kwargs : :
    passed through to write()
```

See Also:

```
skrf.io.general.write write any skrf object
skrf.io.general.read read any skrf object
```

Notes

If the self.name is not None and file is can left as None and the resultant file will have the .ntwk extension appended to the filename.

Examples

```
>>> n = rf.N(f=[1,2,3],s=[1,1,1],z0=50, name = 'open')
>>> n.write()
>>> n2 = rf.read('open.ntwk')
```

skrf.network.Network.write_touchstone

```
Network.write_touchstone (filename=None, dir='./', write_z0=False) write a contents of the Network to a touchstone file.
```

Parameters filename: a string, optional

touchstone filename, without extension. if 'None', then will use the network's name.

```
dir: string, optional
```

the directory to save the file in. Defaults to cwd './'.

write_z0: boolean

write impedance information into touchstone as comments, like Ansoft HFSS does

Notes

format supported at the moment is, HZ S RI

The functionality of this function should take place in the touchstone class.

3.2.2 Connecting Networks

connect(ntwkA, k, ntwkB, l[, num])	connect two n-port networks together.
innerconnect(ntwkA, k, l[, num])	connect ports of a single n-port network.
cascade(ntwkA, ntwkB)	Cascade two 2-port Networks together
de_embed(ntwkA, ntwkB)	De-embed <i>ntwkA</i> from <i>ntwkB</i> .
flip(a)	invert the ports of a networks s-matrix, 'flipping' it over

skrf.network.connect

```
skrf.network.connect (ntwkA, k, ntwkB, l, num=1)
connect two n-port networks together.
```

specifically, connect ports k thru k+num-1 on ntwkA to ports l thru l+num-1 on ntwkB. The resultant network has (ntwkA.nports+ntwkB.nports-2*num) ports. The port indices ('k','l') start from 0. Port impedances **are** taken into account.

```
Parameters ntwkA: Network

network 'A'

k: int

starting port index on ntwkA (port indices start from 0)

ntwkB: Network

network 'B'

1: int

starting port index on ntwkB

num: int

number of consecutive ports to connect (default 1)

Returns ntwkC: Network

new network of rank (ntwkA.nports + ntwkB.nports - 2*num)

See Also:
```

connect_s actual S-parameter connection algorithm.

innerconnect_s actual S-parameter connection algorithm.

Notes

the effect of mis-matched port impedances is handled by inserting a 2-port 'mismatch' network between the two connected ports. This mismatch Network is calculated with the <code>impedance_mismatch()</code> function.

Examples

To implement a cascade of two networks

```
>>> ntwkA = rf.Network('ntwkA.s2p')
>>> ntwkB = rf.Network('ntwkB.s2p')
>>> ntwkC = rf.connect(ntwkA, 1, ntwkB,0)
```

skrf.network.innerconnect

```
skrf.network.innerconnect (ntwkA, k, l, num=1)
    connect ports of a single n-port network.

this results in a (n-2)-port network. remember port indices start from 0.

Parameters ntwkA: Network
    network 'A'

k,l: int
    starting port indices on ntwkA ( port indices start from 0 )

num: int
    number of consecutive ports to connect

Returns ntwkC: Network
    new network of rank (ntwkA.nports - 2*num)
```

See Also:

connect_s actual S-parameter connection algorithm.
innerconnect_s actual S-parameter connection algorithm.

Notes

a 2-port 'mismatch' network is inserted between the connected ports if their impedances are not equal.

Examples

```
To connect ports '0' and port '1' on ntwkA
```

```
>>> ntwkA = rf.Network('ntwkA.s3p')
>>> ntwkC = rf.innerconnect(ntwkA, 0,1)
```

skrf.network.cascade

```
skrf.network.cascade(ntwkA, ntwkB)
```

Cascade two 2-port Networks together

Connects port 1 of *ntwkA* to port 0 of *ntwkB*. This calls *connect(ntwkA,1, ntwkB,0)*, which is a more general function.

Parameters ntwkA: Network

network ntwkA

ntwkB: Network

network ntwkB

Returns C: Network

the resultant network of ntwkA cascaded with ntwkB

See Also:

connect connects two Networks together at arbitrary ports.

skrf.network.de embed

```
skrf.network.de embed(ntwkA, ntwkB)
```

De-embed *ntwkA* from *ntwkB*.

This calls *ntwkA.inv* ** *ntwkB*. The syntax of cascading an inverse is more explicit, it is recomended that it be used instead of this function.

Parameters ntwkA: Network

network ntwkA

 $ntwkB: {\tt Network}$

network ntwkB

Returns C: Network

the resultant network of ntwkB de-embeded from ntwkA

See Also:

connect connects two Networks together at arbitrary ports.

skrf.network.flip

```
skrf.network.flip(a)
```

invert the ports of a networks s-matrix, 'flipping' it over

Parameters a: numpy.ndarray

scattering parameter matrix. shape should be should be 2x2, or fx2x2

Returns a': numpy.ndarray

flipped scattering parameter matrix, ie interchange of port 0 and port 1

3.2.3 Interpolation and Stitching

Network.resample(npoints, **kwargs)	Interpolate network based on a new number of frequency points
Network.interpolate(new_frequency, **kwargs)	Return an interpolated network, from a new :class:'~skrf.frequency
Network.interpolate_self(new_frequency, **kwargs)	Interpolates s-parameters given a new
<pre>Network.interpolate_from_f(f[, interp_kwargs])</pre>	Interpolates s-parameters from a frequency vector.
stitch(ntwkA, ntwkB, **kwargs)	Stitches ntwkA and ntwkB together.

skrf.network.Network.resample

```
Network.resample(npoints, **kwargs)
```

Interpolate network based on a new number of frequency points

Parameters npoints: int

number of frequency points

**kwargs: keyword arguments

passed to scipy.interpolate.interpld() initializer.

See Also:

interpolate_self same functionality but takes a Frequency object

interpolate same functionality but takes a Frequency object and returns a new Network, instead of updating itself.

Notes

The function resample () is an alias for interpolate_self_npoints().

Examples

```
In [2]: n = rf.data.ring_slot
In [3]: n
Out[3]: 2-Port Network: 'ring slot', 75-110 GHz, 501 pts, z0=[ 50.+0.j 50.+0.j]
In [4]: n.resample(501) # resample is an alias
In [5]: n
Out[5]: 2-Port Network: 'ring slot', 75-110 GHz, 501 pts, z0=[ 50.+0.j 50.+0.j]
```

skrf.network.Network.interpolate

```
Network.interpolate(new_frequency, **kwargs)
```

Return an interpolated network, from a new :class:'~skrf.frequency.Frequency'.

Interpolate the networks s-parameters linearly in real and imaginary components. Other interpolation types can be used by passing appropriate **kwargs. This function returns an interpolated Network. Alternatively interpolate_self() will interpolate self.

Parameters new_frequency: Frequency

frequency information to interpolate

**kwargs: keyword arguments

passed to scipy.interpolate.interpld() initializer.

Returns result: Network

an interpolated Network

See Also:

```
resample, interpolate_self, interpolate_from_f
```

Notes

See scipy.interpolate.interpolate.interpld() for useful kwargs. For example

kind [str or int] Specifies the kind of interpolation as a string ('linear', 'nearest', 'zero', 'slinear', 'quadratic, 'cubic') or as an integer specifying the order of the spline interpolator to use.

Examples

```
In [2]: n = rf.data.ring_slot
In [3]: n
Out[3]: 2-Port Network: 'ring slot', 75-110 GHz, 201 pts, z0=[ 50.+0.j 50.+0.j]
In [4]: new_freq = rf.Frequency(75,110,501,'ghz')
In [5]: n.interpolate(new_freq, kind = 'cubic')
Out[5]: 2-Port Network: 'ring slot', 75-110 GHz, 501 pts, z0=[ 50.+0.j 50.+0.j]
```

skrf.network.Network.interpolate_self

```
Network.interpolate_self(new_frequency, **kwargs)
```

Interpolates s-parameters given a new :class:'~skrf.frequency.Frequency' object.

See interpolate() for more information.

```
Parameters new_frequency: Frequency
```

frequency information to interpolate at

**kwargs: keyword arguments

passed to scipy.interpolate.interp1d() initializer.

See Also:

```
resample, interpolate, interpolate_from_f
```

skrf.network.Network.interpolate from f

```
Network.interpolate_from_f (f, interp_kwargs={}, **kwargs)
```

Interpolates s-parameters from a frequency vector.

Given a frequency vector, and optionally a *unit* (see **kwargs) , interpolate the networks s-parameters linearly in real and imaginary components.

See interpolate() for more information.

Parameters new_frequency: Frequency

frequency information to interpolate at

interp_kwargs::

dictionary of kwargs to be passed through to
scipy.interpolate.interpolate.interpld()

**kwargs::

passed to scipy.interpolate.interpld() initializer.

See Also:

resample, interpolate, interpolate_self

Notes

This creates a new Frequency, object using the method from_f(), and then calls interpolate_self().

skrf.network.stitch

```
skrf.network.stitch(ntwkA, ntwkB, **kwargs)
```

Stitches ntwkA and ntwkB together.

Concatenates two networks' data. Given two networks that cover different frequency bands this can be used to combine their data into a single network.

Parameters ntwkA, ntwkB: Network objects

Networks to stitch together

**kwargs : keyword args

passed to Network constructor, for output network

Returns ntwkC: Network

result of stitching the networks ntwkA and ntwkB together

Examples

```
>>> from skrf.data import wr2p2_line, wr1p5_line
>>> rf.stitch(wr2p2_line, wr1p5_line)
2-Port Network: 'wr2p2,line', 330-750 GHz, 402 pts, z0=[ 50.+0.j 50.+0.j]
```

3.2.4 IO

skrf.io.general.read(file, *args, **kwargs)	Read skrf object[s] from a pickle file
skrf.io.general.write(file, obj[, overwrite])	Write skrf object[s] to a file
Network.write([file])	Write the Network to disk using the pickle module.
Network.write_touchstone([filename, dir,])	write a contents of the Network to a touchstone file.
	Continued on next page

Table 3.9 – continued from previous page

Network.read(*args, **kwargs)	Read a Network from a 'ntwk' file
Network. read(aigs, kwaigs)	Read a Network Holli a little life

3.2.5 Noise

Network.add_noise_polar(mag_dev, phase_dev,)	adds a complex zero-mean gaussian white-noise.
Network.add_noise_polar_flatband(mag_dev,)	adds a flatband complex zero-mean gaussian white-noise signal of
Network.multiply_noise(mag_dev, phase_dev,)	multiplys a complex bivariate gaussian white-noise signal

skrf.network.Network.add_noise_polar

```
Network.add_noise_polar (mag_dev, phase_dev, **kwargs)
```

adds a complex zero-mean gaussian white-noise.

adds a complex zero-mean gaussian white-noise of a given standard deviation for magnitude and phase

Parameters mag_dev: number

standard deviation of magnitude

phase_dev : number

standard deviation of phase [in degrees]

skrf.network.Network.add_noise_polar_flatband

Network.add_noise_polar_flatband(mag_dev, phase_dev, **kwargs)

adds a flatband complex zero-mean gaussian white-noise signal of given standard deviations for magnitude and phase

Parameters mag_dev : number

standard deviation of magnitude

phase_dev : number

standard deviation of phase [in degrees]

skrf.network.Network.multiply_noise

Network.multiply_noise (mag_dev, phase_dev, **kwargs)

multiplys a complex bivariate gaussian white-noise signal of given standard deviations for magnitude and phase. magnitude mean is 0

takes: mag_dev: standard deviation of magnitude phase_dev: standard deviation of phase [in degrees] n_ports: number of ports. defualt to 1

returns: nothing

3.2.6 Supporting Functions

inv(s)	Calculates 'inverse' s-parameter matrix, used for de-embeding
$connect_s(A, k, B, l)$	connect two n-port networks' s-matricies together.
	Continued on next page

Table 3.11 – continued	from	previous	page
------------------------	------	----------	------

$innerconnect_s(A, k, l)$	connect two ports of a single n-port network's s-matrix.
s2z(s[,z0])	Convert scattering parameters [#]_ to impedance parameters [#]
s2y(s[,z0])	convert scattering parameters [#]_ to admittance parameters [#]_
s2t(s)	Converts scattering parameters [#]_ to scattering transfer parameters [#]
z2s(z[,z0])	convert impedance parameters [#]_ to scattering parameters [#]_
z2y (z)	convert impedance parameters [#]_ to admittance parameters [#]_
z2t(z)	Not Implemented yet
y2s(y[,z0])	convert admittance parameters [#]_ to scattering parameters [#]_
y2z(y)	convert admittance parameters [#]_ to impedance parameters [#]_
y2t(y)	Not Implemented Yet
t2s(t)	converts scattering transfer parameters [#]_ to scattering parameters [#]_
t2z(t)	Not Implemented Yet
t2y(t)	Not Implemented Yet

skrf.network.inv

skrf.network.inv(s)

Calculates 'inverse' s-parameter matrix, used for de-embeding

This is not literally the inverse of the s-parameter matrix. Instead, it is defined such that the inverse of the s-matrix cascaded with itself is unity.

$$inv(s) = t2s(s2t(s)^{-1})$$

where x^{-1} is the matrix inverse. In words, this is the inverse of the scattering transfer parameters matrix transformed into a scattering parameters matrix.

Parameters s: numpy.ndarray (shape fx2x2)

scattering parameter matrix.

Returns s': numpy.ndarray

inverse scattering parameter matrix.

See Also:

t2s converts scattering transfer parameters to scattering parameters

s2t converts scattering parameters to scattering transfer parameters

skrf.network.connect_s

skrf.network.connect_s (A, k, B, l)

connect two n-port networks' s-matricies together.

specifically, connect port k on network A to port l on network B. The resultant network has nports = (A.rank + B.rank-2). This function operates on, and returns s-matricies. The function connect () operates on Network types.

Parameters A: numpy.ndarray

S-parameter matrix of A, shape is fxnxn

 \mathbf{k} : int

port index on A (port indices start from 0)

```
B: numpy.ndarray
S-parameter matrix of B, shape is fxnxn
1: int
port index on B

Returns C: numpy.ndarray
new S-parameter matrix
```

See Also:

connect operates on Network types

innerconnect_s function which implements the connection connection algorithm

Notes

internally, this function creates a larger composite network and calls the innerconnect_s () function. see that function for more details about the implementation

skrf.network.innerconnect s

```
skrf.network.innerconnect_s (A, k, l) connect two ports of a single n-port network's s-matrix.
```

Specifically, connect port k to port l on A. This results in a (n-2)-port network. This function operates on, and returns s-matricies. The function innerconnect () operates on Network types.

```
Parameters A: numpy.ndarray
S-parameter matrix of A, shape is fxnxn
k: int
port index on A (port indices start from 0)
l: int
port index on A
Returns C: numpy.ndarray
new S-parameter matrix
```

Notes

The algorithm used to calculate the resultant network is called a 'sub-network growth', can be found in ⁶. The original paper describing the algorithm is given in ⁷.

⁶ Compton, R.C.; , "Perspectives in microwave circuit analysis," Circuits and Systems, 1989., Proceedings of the 32nd Midwest Symposium on , vol., no., pp.716-718 vol.2, 14-16 Aug 1989. URL: http://ieeexplore.ieee.org/stamp/stamp.jsp?tp=&arnumber=101955&isnumber=3167

⁷ Filipsson, Gunnar; , "A New General Computer Algorithm for S-Matrix Calculation of Interconnected Multiports," Microwave Conference, 1981. 11th European , vol., no., pp.700-704, 7-11 Sept. 1981. URL: http://ieeexplore.ieee.org/stamp/stamp.jsp?tp=&arnumber=4131699&isnumber=4131585

skrf.network.s2z

skrf.network.s2z(s, z0=50)

Convert scattering parameters ⁸ to impedance parameters ⁹

$$z = \sqrt{z_0} \cdot (I+s)(I-s)^{-1} \cdot \sqrt{z_0}$$

Parameters s: complex array-like

scattering parameters

z0: complex array-like or number

port impedances

Returns z : complex array-like

impedance parameters

See Also:

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.t

References

skrf.network.s2y

skrf.network.s2 \mathbf{y} (s, z0=50)

convert scattering parameters 10 to admittance parameters 11

$$y = \sqrt{y_0} \cdot (I - s)(I + s)^{-1} \cdot \sqrt{y_0}$$

Parameters s: complex array-like

scattering parameters

z0: complex array-like or number

port impedances

Returns y : complex array-like

admittance parameters

See Also:

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.z, Network.t

⁸ http://en.wikipedia.org/wiki/S-parameters

⁹ http://en.wikipedia.org/wiki/impedance_parameters

¹⁰ http://en.wikipedia.org/wiki/S-parameters

¹¹ http://en.wikipedia.org/wiki/Admittance_parameters

skrf.network.s2t

skrf.network.s2t(s)

Converts scattering parameters ¹² to scattering transfer parameters ¹³.

transfer parameters are also refered to as 'wave cascading matrix', this function only operates on 2-port networks.

Parameters s: numpy.ndarray (shape fx2x2)

scattering parameter matrix

Returns t: numpy.ndarray

scattering transfer parameters (aka wave cascading matrix)

See Also:

inv calculates inverse s-parameters

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.z, Network.t

References

skrf.network.z2s

skrf.network.**z2s**(z, z0=50)

convert impedance parameters 14 to scattering parameters 15

$$s = (\sqrt{y_0} \cdot z \cdot \sqrt{y_0} - I)(\sqrt{y_0} \cdot z \cdot \sqrt{y_0} + I)^{-1}$$

Parameters z : complex array-like

impedance parameters

z0: complex array-like or number

port impedances

Returns s: complex array-like

scattering parameters

See Also:

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.t

¹² http://en.wikipedia.org/wiki/S-parameters

 $^{^{13}\} http://en.wikipedia.org/wiki/Scattering_transfer_parameters\#Scattering_transfer_parameters$

¹⁴ http://en.wikipedia.org/wiki/impedance_parameters

¹⁵ http://en.wikipedia.org/wiki/S-parameters

skrf.network.z2y

skrf.network.z2y(z)

convert impedance parameters ¹⁶ to admittance parameters ¹⁷

$$y = z^{-1}$$

Parameters z : complex array-like

impedance parameters

Returns y : complex array-like

admittance parameters

See Also:

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.z, Network.t

References

skrf.network.z2t

skrf.network.z2t(z)

Not Implemented yet

convert impedance parameters ¹⁸ to scattering transfer parameters ¹⁹

Parameters z : complex array-like or number

impedance parameters

Returns s: complex array-like or number

scattering parameters

See Also:

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.z, Network.t

¹⁶ http://en.wikipedia.org/wiki/impedance_parameters

¹⁷ http://en.wikipedia.org/wiki/Admittance_parameters

¹⁸ http://en.wikipedia.org/wiki/impedance_parameters

¹⁹ http://en.wikipedia.org/wiki/Scattering_transfer_parameters#Scattering_transfer_parameters

skrf.network.y2s

skrf.network.y2s(y, z0=50)

convert admittance parameters 20 to scattering parameters 21

$$s = (I - \sqrt{z_0} \cdot y \cdot \sqrt{z_0})(I + \sqrt{z_0} \cdot y \cdot \sqrt{z_0})^{-1}$$

Parameters y : complex array-like

admittance parameters

z0: complex array-like or number

port impedances

Returns s: complex array-like or number

scattering parameters

See Also:

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.z, Network.t

References

skrf.network.y2z

skrf.network.y2z(y)

convert admittance parameters ²² to impedance parameters ²³

$$z = y^{-1}$$

Parameters y : complex array-like

admittance parameters

Returns z: complex array-like

impedance parameters

See Also:

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.z, Network.t

 ²⁰ http://en.wikipedia.org/wiki/Admittance_parameters
 21 http://en.wikipedia.org/wiki/S-parameters

²² http://en.wikipedia.org/wiki/Admittance_parameters

²³ http://en.wikipedia.org/wiki/impedance_parameters

skrf.network.y2t

```
skrf.network.y2t(y)
```

Not Implemented Yet

convert admittance parameters ²⁴ to scattering-transfer parameters ²⁵

Parameters y : complex array-like or number

impedance parameters

Returns t: complex array-like or number

scattering parameters

See Also:

```
s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.z, Network.t
```

References

skrf.network.t2s

```
skrf.network.t2s(t)
```

converts scattering transfer parameters ²⁶ to scattering parameters ²⁷

transfer parameters are also refered to as 'wave cascading matrix', this function only operates on 2-port networks. this function only operates on 2-port scattering parameters.

Parameters t: numpy.ndarray (shape fx2x2)

scattering transfer parameters

Returns s: numpy.ndarray

scattering parameter matrix.

See Also:

inv calculates inverse s-parameters

```
s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.z, Network.t
```

References

skrf.network.t2z

skrf.network.t2z(t)

Not Implemented Yet

²⁴ http://en.wikipedia.org/wiki/Admittance_parameters

²⁵ http://en.wikipedia.org/wiki/Scattering_transfer_parameters#Scattering_transfer_parameters

²⁶ http://en.wikipedia.org/wiki/Scattering_transfer_parameters#Scattering_transfer_parameters

²⁷ http://en.wikipedia.org/wiki/S-parameters

Convert scattering transfer parameters ²⁸ to impedance parameters ²⁹

Parameters t: complex array-like or number

impedance parameters

Returns z : complex array-like or number

scattering parameters

See Also:

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.t

References

skrf.network.t2y

skrf.network.t2y(t)

Not Implemented Yet

Convert scattering transfer parameters to admittance parameters ³⁰

Parameters t: complex array-like or number

t-parameters

Returns y : complex array-like or number

admittance parameters

See Also:

s2z, s2y, s2t, z2s, z2y, z2t, y2s, y2z, y2z, t2s, t2z, t2y, Network.s, Network.y, Network.z, Network.t

References

3.2.7 Misc Functions

average(list_of_networks)	Calculates the average network from a list of Networks.
Network.nudge([amount])	Perturb s-parameters by small amount.

skrf.network.average

skrf.network.average(list_of_networks)

Calculates the average network from a list of Networks.

This is complex average of the s-parameters for a list of Networks.

Parameters list_of_networks: list of Network objects

the list of networks to average

Returns ntwk: Network

²⁸ http://en.wikipedia.org/wiki/Scattering_transfer_parameters#Scattering_transfer_parameters

²⁹ http://en.wikipedia.org/wiki/impedance_parameters

³⁰ http://en.wikipedia.org/wiki/Scattering_transfer_parameters#Scattering_transfer_parameters

the resultant averaged Network

Notes

This same function can be accomplished with properties of a NetworkSet class.

Examples

```
>>> ntwk_list = [rf.Network('myntwk.s1p'), rf.Network('myntwk2.s1p')]
>>> mean_ntwk = rf.average(ntwk_list)
```

skrf.network.Network.nudge

```
Network.nudge (amount=1e-12)
```

Perturb s-parameters by small amount.

This is useful to work-around numerical bugs.

Parameters amount: number,

amount to add to s parameters

Notes

This function is self.s = self.s + 1e-12

3.3 networkSet (skrf.networkSet)

Provides a class representing an un-ordered set of n-port microwave networks.

Frequently one needs to make calculations, such as mean or standard deviation, on an entire set of n-port networks. To facilitate these calculations the NetworkSet class provides convenient ways to make such calculations.

The results are returned in Network objects, so they can be plotted and saved in the same way one would do with a Network.

The functionality in this module is provided as methods and properties of the NetworkSet Class.

3.3.1 NetworkSet Class

NetworkSet(ntwk_set[, name]) A set of Networks.

skrf.networkSet.NetworkSet

```
class skrf.networkSet.NetworkSet (ntwk_set, name=None)
    A set of Networks.
```

This class allows functions on sets of Networks, such as mean or standard deviation, to be calculated conveniently. The results are returned in Network objects, so that they may be plotted and saved in like Network

objects.

This class also provides methods which can be used to plot uncertainty bounds for a set of Network.

The names of the NetworkSet properties are generated dynamically upon ititialization, and thus documentation for individual properties and methods is not available. However, the properties do follow the convention:

```
>>> my_network_set.function_name_network_property_name
```

For example, the complex average (mean) Network for a NetworkSet is:

```
>>> my_network_set.mean_s
```

This accesses the property 's', for each element in the set, and **then** calculates the 'mean' of the resultant set. The order of operations is important.

Results are returned as Network objects, so they may be plotted or saved in the same way as for Network objects:

```
>>> my_network_set.mean_s.plot_s_mag()
>>> my_network_set.mean_s.write_touchstone('mean_response')
```

If you are calculating functions that return scalar variables, then the result is accessable through the Network property .s_re. For example:

```
>>> std_s_deg = my_network_set.std_s_deg
```

This result would be plotted by:

```
>>> std_s_deg.plot_s_re()
```

The operators, properties, and methods of NetworkSet object are dynamically generated by private methods

- •__add_a_operator()
- •__add_a_func_on_property()
- •__add_a_element_wise_method()
- •__add_a_plot_uncertainty()

thus, documentation on the individual methods and properties are not available.

Attributes

inv	
mean_s_db	the mean magnitude in dB.
std_s_db	the mean magnitude in dB.

skrf.networkSet.NetworkSet.inv

NetworkSet.inv

skrf.networkSet.NetworkSet.mean_s_db

```
NetworkSet.mean_s_db the mean magnitude in dB.
```

note:

the mean is taken on the magnitude before converted to db, so magnitude_2_db(mean(s_mag)) which is NOT the same as mean(s_db)

skrf.networkSet.NetworkSet.std_s_db

NetworkSet.**std_s_db** the mean magnitude in dB.

note:

the mean is taken on the magnitude before converted to db, so magnitude_2_db(mean(s_mag)) which is NOT the same as mean(s_db)

Methods

init	Initializer for NetworkSet
сору	copies each network of the network set.
element_wise_method	calls a given method of each element and returns the result as
from_zip	creates a NetworkSet from a zipfile of touchstones.
plot_logsigma	plots the uncertainty for the set in units of log-sigma.
plot_uncertainty_bounds_component	plots mean value of the NetworkSet with +- uncertainty bounds
plot_uncertainty_bounds_s	Plots complex uncertianty bounds plot on smith chart.
plot_uncertainty_bounds_s_db	this just calls
plot_uncertainty_decomposition	plots the total and component-wise uncertainty
set_wise_function	calls a function on a specific property of the networks in
signature	visualization of relative changes in a NetworkSet.
uncertainty_ntwk_triplet	returns a 3-tuple of Network objects which contain the
write	Write the NetworkSet to disk using write()

skrf.networkSet.NetworkSet. init

NetworkSet.__init__ (ntwk_set, name=None)
Initializer for NetworkSet

Parameters ntwk_set: list of Network objects

the set of ${\tt Network}$ objects

name: string

the name of the NetworkSet, given to the Networks returned from properties of this class.

skrf.networkSet.NetworkSet.copy

134

```
NetworkSet.copy()
copies each network of the network set.
```

skrf.networkSet.NetworkSet.element wise method

```
NetworkSet.element_wise_method(network_method_name, *args, **kwargs) calls a given method of each element and returns the result as a new NetworkSet if the output is a Network.
```

skrf.networkSet.NetworkSet.from_zip

```
classmethod NetworkSet.from_zip (zip_file_name, sort_filenames=True, *args, **kwargs) creates a NetworkSet from a zipfile of touchstones.
```

```
Parameters zip_file_name: string name of zipfile
```

sort_filenames: Boolean:

sort the filenames in teh zip file before constructing the NetworkSet

*args,**kwargs: arguments

passed to NetworkSet constructor

Examples

```
>>> import skrf as rf
>>> my_set = rf.NetworkSet.from_zip('myzip.zip')
```

skrf.networkSet.NetworkSet.plot_logsigma

```
NetworkSet.plot_logsigma (label_axis=True, *args, **kwargs)
```

plots the uncertainty for the set in units of log-sigma. Log-sigma is the complex standard deviation, plotted in units of dB's.

```
Parameters *args, **kwargs : arguments
passed to self.std_s.plot_s_db()
```

skrf.networkSet.NetworkSet.plot uncertainty bounds component

```
NetworkSet.plot_uncertainty_bounds_component (attribute, m=0, n=0, type='shade', n_deviations=3, alpha=0.3, color_error=None, markevery_error=20, ax=None, ppf=None, kwargs_error={}, *args, **kwargs)
```

plots mean value of the NetworkSet with +- uncertainty bounds in an Network's attribute. This is designed to represent uncertainty in a scalar component of the s-parameter. for example ploting the uncertainty in the magnitude would be expressed by,

```
mean(abs(s)) +- std(abs(s))
```

the order of mean and abs is important.

takes: attribute: attribute of Network type to analyze [string] m: first index of attribute matrix [int] n: second index of attribute matrix [int] type: ['shade' | 'bar'], type of plot to draw n_deviations: number of std deviations to plot as bounds [number] alpha: passed to matplotlib.fill_between() command. [number, 0-1] color_error: color of the +- std dev fill shading markevery_error: if type=='bar', this controls frequency

```
of error bars
```

ax: Axes to plot on ppf: post processing function. a function applied to the upper and low

*args,**kwargs: passed to Network.plot_s_re command used to plot mean response

kwargs_error: dictionary of kwargs to pass to the fill_between or errorbar plot command depending on value of type.

returns: None

Note: for phase uncertainty you probably want s_deg_unwrap, or similar. uncerainty for wrapped phase blows up at +-pi.

skrf.networkSet.NetworkSet.plot uncertainty bounds s

```
NetworkSet.plot_uncertainty_bounds_s (multiplier=200, *args, **kwargs)
```

Plots complex uncertianty bounds plot on smith chart.

This function plots the complex uncertainty of a NetworkSet as circles on the smith chart. At each frequency a circle with radii proportional to the complex standard deviation of the set at that frequency is drawn. Due to the fact that the *markersize* argument is in pixels, the radii can scaled by the input argument *multiplier*.

```
default kwargs are { 'marker':'o', 'color':'b', 'mew':0, 'ls':'', 'alpha':.1, 'label':None, }
```

Parameters multipliter: float

controls the circle sizes, by multiples of the standard deviation.

skrf.networkSet.NetworkSet.plot_uncertainty_bounds_s_db

```
NetworkSet.plot_uncertainty_bounds_s_db (*args, **kwargs)

this just calls plot_uncertainty_bounds(attribute= 's_mag','ppf':mf.magnitude_2_db*args,**kwargs)

see plot_uncertainty_bounds for help
```

skrf.networkSet.NetworkSet.plot_uncertainty_decomposition

```
NetworkSet.plot_uncertainty_decomposition (m=0, n=0) plots the total and component-wise uncertainty
```

Parameters m: int

first s-parameters index

n::

second s-parameter index

skrf.networkSet.NetworkSet.set wise function

```
NetworkSet.set_wise_function (func, a_property, *args, **kwargs) calls a function on a specific property of the networks in this NetworkSet.

example: my_ntwk_set.set_wise_func(mean,'s')
```

skrf.networkSet.NetworkSet.signature

```
NetworkSet.signature (m=0, n=0, from_mean=False, operation='__sub__', component='s_mag', vmax=None, *args, **kwargs) visualization of relative changes in a NetworkSet.
```

Creates a colored image representing the devation of each Network from the from mean Network of the NetworkSet, vs frequency.

Parameters m: int

first s-parameters index

n: int

second s-parameter index

from mean: Boolean

calculate distance from mean if True. or distance from first network in networkset if False.

```
operation: ['__sub__', '__div__'], ..
```

operation to apply between each network and the reference network, which is either the mean, or the initial ntwk.

```
component : ['s_mag','s_db','s_deg' ..]
```

scalar component of Network to plot on the imshow. should be a property of the Network object.

vmax: number

sets upper limit of colorbar, if None, will be set to 3*mean of the magnitude of the complex difference

*args,**kwargs: arguments, keyword arguments

passed to imshow()

skrf.networkSet.NetworkSet.uncertainty_ntwk_triplet

```
NetworkSet.uncertainty_ntwk_triplet(attribute, n_deviations=3)
```

returns a 3-tuple of Network objects which contain the mean, upper_bound, and lower_bound for the given Network attribute.

Used to save and plot uncertainty information data

skrf.networkSet.NetworkSet.write

```
NetworkSet.write (file=None, *args, **kwargs)
Write the NetworkSet to disk using write()

Parameters file: str or file-object
filename or a file-object. If left as None then the filename will be set to Calibration.name, if its not None. If both are None, ValueError is raised.

*args, **kwargs: arguments and keyword arguments
passed through to write()

See Also:
skrf.io.general.write, skrf.io.general.read
```

Notes

If the self.name is not None and file is can left as None and the resultant file will have the .ns extension appended to the filename.

Examples

```
>>> ns.name = 'my_ns'
>>> ns.write()
```

3.4 plotting (skrf.plotting)

This module provides general plotting functions.

3.4.1 Plots and Charts

<pre>smith([smithR, chart_type, draw_labels,])</pre>	plots the smith chart of a given radius
plot_smith(z[, smith_r, chart_type,])	plot complex data on smith chart
<pre>plot_rectangular(x, y[, x_label, y_label,])</pre>	plots rectangular data and optionally label axes.
<pre>plot_polar(theta, r[, x_label, y_label,])</pre>	plots polar data on a polar plot and optionally label axes.
<pre>plot_complex_rectangular(z[, x_label,])</pre>	plot complex data on the complex plane
<pre>plot_complex_polar(z[, x_label, y_label,])</pre>	plot complex data in polar format.

skrf.plotting.smith

```
{\tt skrf.plotting.smith} \ (smith R=1, chart\_type='z', draw\_labels=False, border=False, ax=None) \\ {\tt plots} \ the \ smith \ chart \ of \ a \ given \ radius
```

Parameters smithR : number radius of smith chart chart_type : ['z','y']

Contour type. Possible values are

```
• 'z': lines of constant impedance
```

• 'y': lines of constant admittance

draw_labels: Boolean

annotate real and imaginary parts of impedance on the chart (only if smithR=1)

border: Boolean

draw a rectangular border with axis ticks, around the perimeter of the figure. Not used if draw_labels = True

ax: matplotlib.axes object

existing axes to draw smith chart on

skrf.plotting.plot_smith

```
skrf.plotting.plot_smith(z, smith_r=1, chart_type='z', x_label='Real', y_label='Imaginary', title='Complex Plane', show_legend=True, axis='equal', ax=None, force_chart=False, *args, **kwargs)
```

plot complex data on smith chart

Parameters z : array-like, of complex data

data to plot

smith r: number

radius of smith chart

chart_type : ['z','y']

Contour type for chart.

- 'z': lines of constant impedance
- 'y': lines of constant admittance

x_label: string

x-axis label

y_label: string

y-axis label

title: string

plot title

show_legend : Boolean

controls the drawing of the legend

axis_equal: Boolean:

sets axis to be equal increments (calls axis('equal'))

force_chart : Boolean

forces the re-drawing of smith chart

ax: matplotlib.axes.AxesSubplot object

```
axes to draw on
              *args,**kwargs: passed to pylab.plot
     See Also:
     plot_rectangular plots rectangular data
     plot_complex_rectangular plot complex data on complex plane
     plot_polar plot polar data
     plot_complex_polar plot complex data on polar plane
     plot_smith plot complex data on smith chart
skrf.plotting.plot_rectangular
skrf.plotting.plot_rectangular(x,
                                                      x label=None,
                                                                        y_label=None,
                                                                                          title=None,
                                          show_legend=True, axis='tight', ax=None, *args, **kwargs)
     plots rectangular data and optionally label axes.
          Parameters z : array-like, of complex data
                  data to plot
              x_label: string
                  x-axis label
              y_label: string
                  y-axis label
              title: string
                  plot title
              show_legend: Boolean
                  controls the drawing of the legend
              ax: matplotlib.axes.AxesSubplot object
                  axes to draw on
              *args,**kwargs: passed to pylab.plot
skrf.plotting.plot_polar
skrf.plotting.plot_polar(theta, r, x_label=None, y_label=None, title=None, show_legend=True,
                                  axis_equal=False, ax=None, *args, **kwargs)
     plots polar data on a polar plot and optionally label axes.
          Parameters theta: array-like
                  data to plot
              r: array-like
              x_label: string
                  x-axis label
              y_label: string
```

```
y-axis label
              title: string
                  plot title
              show_legend: Boolean
                  controls the drawing of the legend
              ax: matplotlib.axes.AxesSubplot object
                  axes to draw on
              *args, **kwargs: passed to pylab.plot
     See Also:
     plot_rectangular plots rectangular data
     plot_complex_rectangular plot complex data on complex plane
     plot_polar plot polar data
     plot_complex_polar plot complex data on polar plane
     plot_smith plot complex data on smith chart
skrf.plotting.plot_complex_rectangular
skrf.plotting.plot_complex_rectangular(z, x_label='Real', y_label='Imag', title='Complex
                                                    Plane', show legend=True, axis='equal', ax=None,
                                                    *args, **kwargs)
     plot complex data on the complex plane
          Parameters z : array-like, of complex data
                  data to plot
              x_label: string
                  x-axis label
              y_label: string
                  y-axis label
              title: string
                  plot title
              show_legend: Boolean
                  controls the drawing of the legend
              ax: matplotlib.axes.AxesSubplot object
                  axes to draw on
              *args, **kwargs: passed to pylab.plot
     See Also:
     plot_rectangular plots rectangular data
     plot_complex_rectangular plot complex data on complex plane
```

```
plot_polar plot polar data
     plot_complex_polar plot complex data on polar plane
     plot_smith plot complex data on smith chart
skrf.plotting.plot complex polar
skrf.plotting.plot_complex_polar(z,
                                                  x_label=None,
                                                                    y_label=None,
                                                                                       title=None,
                                           show_legend=True, axis_equal=False, ax=None, *args,
                                           **kwargs)
     plot complex data in polar format.
          Parameters z : array-like, of complex data
                  data to plot
              x_label: string
                  x-axis label
              y_label: string
                  y-axis label
              title: string
                  plot title
              show_legend: Boolean
                  controls the drawing of the legend
              ax: matplotlib.axes.AxesSubplot object
                  axes to draw on
              *args,**kwargs: passed to pylab.plot
     See Also:
     plot_rectangular plots rectangular data
     plot_complex_rectangular plot complex data on complex plane
     plot_polar plot polar data
     plot_complex_polar plot complex data on polar plane
     plot_smith plot complex data on smith chart
```

3.4.2 Misc Functions

save_all_figs([dir, format])	Save all open Figures to disk.
add_markers_to_lines([ax, marker_list,])	adds markers to existing lings on a plot
legend_off([ax])	turn off the legend for a given axes.
<pre>func_on_all_figs(func, *args, **kwargs)</pre>	runs a function after making all open figures current.

skrf.plotting.save_all_figs

```
skrf.plotting.save_all_figs (dir='./', format=['eps', 'pdf', 'svg', 'png'])
Save all open Figures to disk.

Parameters dir: string

path to save figures into

format: list of strings

the types of formats to save figures as. The elements of this list are passed to :mat-
plotlib:'savefig'. This is a list so that you can save each figure in multiple formats.
```

skrf.plotting.add_markers_to_lines

```
skrf.plotting.add_markers_to_lines (ax=None, marker\_list=['o', 'D', 's', '+', 'x'], markevery=10)
```

adds markers to existing lings on a plot

this is convinient if you have already have a plot made, but then need to add markers afterwards, so that it can be interpreted in black and white. The markevery argument makes the markers less frequent than the data, which is generally what you want.

Parameters ax: matplotlib.Axes

axis which to add markers to, defaults to gca()

marker_list : list of marker characters

see matplotlib.plot help for possible marker characters

markevery: int

markevery number of points with a marker.

skrf.plotting.legend off

```
skrf.plotting.legend_off (ax=None) turn off the legend for a given axes.

if no axes is given then it will use current axes.

Parameters ax: matplotlib.Axes object axes to operate on
```

skrf.plotting.func_on_all_figs

```
skrf.plotting.func_on_all_figs (func, *args, **kwargs) runs a function after making all open figures current.
```

useful if you need to change the properties of many open figures at once, like turn off the grid.

```
Parameters func: function
function to call
*args, **kwargs: pased to func
```

Examples

```
>>> rf.func_on_all_figs(grid,alpha=.3)
```

3.5 mathFunctions (skrf.mathFunctions)

Provides commonly used mathematical functions.

3.5.1 Complex Component Conversion

$complex_2_reim(z)$	takes:
complex_2_magnitude(input)	returns the magnitude of a complex number.
complex_2_db(input)	returns the magnitude in dB of a complex number.
complex_2_radian(input)	returns the angle complex number in radians.
complex_2_degree(input)	returns the angle complex number in radians.
complex_2_magnitude(input)	returns the magnitude of a complex number.

skrf.mathFunctions.complex_2_reim

```
skrf.mathFunctions.complex_2_reim(z)
```

takes: input: complex number or array

return: real: real part of input imag: imaginary part of input

note: this just calls 'complex_components'

skrf.mathFunctions.complex_2_magnitude

```
skrf.mathFunctions.complex_2_magnitude(input) returns the magnitude of a complex number.
```

skrf.mathFunctions.complex_2_db

```
\label{eq:skrf.mathFunctions.complex_2_db} {\it dinput}) \\ {\it returns the magnitude in dB of a complex number.}
```

returns: 20*log10(|z|)

where z is a complex number

skrf.mathFunctions.complex_2_radian

```
skrf.mathFunctions.complex_2_radian(input) returns the angle complex number in radians.
```

skrf.mathFunctions.complex_2_degree

skrf.mathFunctions.complex_2_degree(input) returns the angle complex number in radians.

skrf.mathFunctions.complex_2_magnitude

skrf.mathFunctions.complex_2_magnitude(input) returns the magnitude of a complex number.

3.5.2 Phase Unwrapping

unwrap_rad(input)	unwraps a phase given in radians
sqrt_phase_unwrap(input)	takes the square root of a complex number with unwraped phase

skrf.mathFunctions.unwrap rad

skrf.mathFunctions.unwrap_rad(input)
 unwraps a phase given in radians
 the normal numpy unwrap is not what you usually want for some reason

skrf.mathFunctions.sqrt phase unwrap

skrf.mathFunctions.sqrt_phase_unwrap(input)
takes the square root of a complex number with unwraped phase
this idea came from Lihan Chen

3.5.3 Unit Conversion

radian_2_degree(rad)	
degree_2_radian(deg)	
np_2_db(x)	converts a value in dB to neper's
db_2_np(x)	converts a value in nepers to dB

skrf.mathFunctions.radian_2_degree

skrf.mathFunctions.radian_2_degree(rad)

skrf.mathFunctions.degree 2 radian

skrf.mathFunctions.degree_2_radian(deg)

skrf.mathFunctions.np_2_db

```
skrf.mathFunctions.np_2_db (x) converts a value in dB to neper's
```

skrf.mathFunctions.db_2_np

```
skrf.mathFunctions.db_2_np(x) converts a value in nepers to dB
```

3.5.4 Scalar-Complex Conversion

These conversions are useful for wrapping other functions that dont support complex numbers.

complex2Scalar(input)
scalar2Complex(input)

skrf.mathFunctions.complex2Scalar

```
skrf.mathFunctions.complex2Scalar(input)
```

skrf.mathFunctions.scalar2Complex

skrf.mathFunctions.scalar2Complex(input)

3.5.5 Special Functions

dirac_delta(x)	the dirac function.
neuman(x)	neumans number
null(A[, eps])	calculates the null space of matrix A.

skrf.mathFunctions.dirac_delta

```
skrf.mathFunctions.dirac_delta(x) the dirac function.

can take numpy arrays or numbers returns 1 or 0
```

skrf.mathFunctions.neuman

```
skrf.mathFunctions.neuman(x)
neumans number
2-dirac_delta(x)
```

skrf.mathFunctions.null

skrf.mathFunctions.null (A, eps=1e-15) calculates the null space of matrix A. i found this on stack overflow.

3.6 tlineFunctions (skrf.tlineFunctions)

This module provides functions related to transmission line theory.

3.6.1 Impedance and Reflection Coefficient

These functions relate basic tranmission line quantities such as characteristic impedance, input impedance, reflection coefficient, etc. Each function has two names. One is a long-winded but readable name and the other is a short-hand variable-like names. Below is a table relating these two names with each other as well as common mathematical symbols.

Symbol	Variable Name	Long Name
Z_l	z_1	load_impedance
Z_{in}	z_in	input_impedance
Γ_0	Gamma_0	reflection_coefficient
Γ_{in}	Gamma_in	reflection_coefficient_at_theta
θ	theta	electrical_length

There may be a bit of confusion about the difference between the load impedance the input impedance. This is because the load impedance **is** the input impedance at the load. An illustration may provide some useful reference.

Below is a (bad) illustration of a section of uniform transmission line of characteristic impedance Z_0 , and electrical length θ . The line is terminated on the right with some load impedance, Z_l . The input impedance Z_{in} and input reflection coefficient Γ_{in} are looking in towards the load from the distance θ from the load.

$$Z_0, \theta$$
 $0===0=[Z_l]$
 \rightarrow
 Z_{in}, Γ_{in}
 Z_l, Γ_0

So, to clarify the confusion,

$$Z_{in} = Z_l,$$
 $\Gamma_{in} = \Gamma_l \text{ at } \theta = 0$

Short names

theta(gamma, f, d[, deg])	Calculates the electrical length of a section of transmission line.
$z1_2$ _Gamma0($z0$, $z1$)	Returns the reflection coefficient for a given load impedance, and characteristic impedan
Gamma0_2_z1(z0, Gamma)	calculates the input impedance given a reflection coefficient and
$z1_2zin(z0, zl, theta)$	input impedance of load impedance zl at a given electrical length,
$z1_2$ _Gamma_in($z0$, zl , theta)	
Gamma0_2_Gamma_in(Gamma0, theta)	reflection coefficient at a given electrical length.
Gamma0_2_zin(z0, Gamma0, theta)	calculates the input impedance at electrical length theta, given a

skrf.tlineFunctions.theta

skrf.tlineFunctions.theta(gamma, f, d, deg=False)

Calculates the electrical length of a section of transmission line.

$$\theta = \gamma(f) \cdot d$$

Parameters gamma: function

propagation constant function, which takes frequency in hz as a sole argument. see Notes.

1: number or array-like

length of line, in meters

f: number or array-like

frequency at which to calculate

deg: Boolean

return in degrees or not.

Returns theta: number or array-like

electrical length in radians or degrees, depending on value of deg.

See Also:

electrical_length_2_distance opposite conversion

Notes

the convention has been chosen that forward propagation is represented by the positive imaginary part of the value returned by the gamma function

skrf.tlineFunctions.zl_2_Gamma0

skrf.tlineFunctions.zl_2_Gamma0 (z0, zl)

Returns the reflection coefficient for a given load impedance, and characteristic impedance.

For a transmission line of characteristic impedance Z_0 terminated with load impedance Z_l , the complex reflection coefficient is given by,

$$\Gamma = \frac{Z_l - Z_0}{Z_l + Z_0}$$

Parameters z0: number or array-like

characteristic impedance

zl: number or array-like

load impedance (aka input impedance)

Returns gamma: number or array-like

reflection coefficient

See Also:

Gamma 0_2_zl reflection coefficient to load impedance

Notes

inputs are typecasted to 1D complex array

skrf.tlineFunctions.Gamma0_2_zl

skrf.tlineFunctions.Gamma0_2_zl(z0, Gamma)

calculates the input impedance given a reflection coefficient and characterisitc impedance

$$Z_0(\frac{1+\Gamma}{1-\Gamma})$$

Parameters Gamma: number or array-like

complex reflection coefficient

z0: number or array-like

characteristic impedance

Returns zin: number or array-like

input impedance

skrf.tlineFunctions.zl 2 zin

skrf.tlineFunctions.zl_2_zin(z0, zl, theta)

input impedance of load impedance zl at a given electrical length, given characteristic impedance z0.

Parameters **z0**: characteristic impedance.

zl: load impedance

theta: electrical length of the line, (may be complex)

skrf.tlineFunctions.zl_2_Gamma_in

skrf.tlineFunctions.zl_2_Gamma_in(z0, zl, theta)

skrf.tlineFunctions.Gamma0_2_Gamma_in

skrf.tlineFunctions.**Gamma0_2_Gamma_in** (*Gamma0*, *theta*) reflection coefficient at a given electrical length.

$$\Gamma_{in} = \Gamma_0 e^{-2j\theta}$$

Parameters Gamma0: number or array-like

reflection coefficient at theta=0

theta: number or array-like

electrical length, (may be complex)

Returns Gamma_in: number or array-like

input reflection coefficient

skrf.tlineFunctions.Gamma0_2_zin

skrf.tlineFunctions.Gamma0_2_zin(z0, Gamma0, theta)

calculates the input impedance at electrical length theta, given a reflection coefficient and characterisitc impedance of the medium Parameters ———-

z0 - characteristic impedance. Gamma: reflection coefficient theta: electrical length of the line, (may be complex)

returns zin: input impedance at theta

Long-names

distance_2_electrical_length(gamma, f, d[, deg])	Calculates the electrical length of a section of trans
electrical_length_2_distance(theta, gamma, f0)	Convert electrical length to a physical distance.
reflection_coefficient_at_theta(Gamma0, theta)	reflection coefficient at a given electrical length.
reflection_coefficient_2_input_impedance(z0,)	calculates the input impedance given a reflection c
reflection_coefficient_2_input_impedance_at_theta(z0,)	calculates the input impedance at electrical length
input_impedance_at_theta(z0, zl, theta)	input impedance of load impedance zl at a given el
load_impedance_2_reflection_coefficient(z0, zl)	Returns the reflection coefficient for a given load i
load_impedance_2_reflection_coefficient_at_theta(z0,)	

skrf.tlineFunctions.distance_2_electrical_length

skrf.tlineFunctions.distance_2_electrical_length(gamma, f, d, deg=False)
Calculates the electrical length of a section of transmission line.

$$\theta = \gamma(f) \cdot d$$

Parameters gamma: function

propagation constant function, which takes frequency in hz as a sole argument. see Notes.

1: number or array-like

length of line, in meters

f: number or array-like

frequency at which to calculate

deg: Boolean

return in degrees or not.

Returns theta: number or array-like

electrical length in radians or degrees, depending on value of deg.

See Also:

electrical_length_2_distance opposite conversion

Notes

the convention has been chosen that forward propagation is represented by the positive imaginary part of the value returned by the gamma function

skrf.tlineFunctions.electrical length 2 distance

skrf.tlineFunctions.electrical_length_2_distance (theta, gamma, f0, deg=True) Convert electrical length to a physical distance.

$$d = \frac{\theta}{\gamma(f_0)}$$

Parameters theta: number or array-like

electical length. units depend on deg option

gamma: function

propagation constant function, which takes frequency in hz as a sole argument. see Notes

f0: number or array-like

frequency at which to calculate

deg: Boolean

return in degrees or not.

Returns d: physical distance :

See Also:

distance_2_electrical_length opposite conversion

Notes

the convention has been chosen that forward propagation is represented by the positive imaginary part of the value returned by the gamma function

skrf.tlineFunctions.reflection_coefficient_at_theta

skrf.tlineFunctions.reflection_coefficient_at_theta(GammaO, theta) reflection coefficient at a given electrical length.

$$\Gamma_{in} = \Gamma_0 e^{-2j\theta}$$

Parameters Gamma0: number or array-like

reflection coefficient at theta=0

theta: number or array-like

electrical length, (may be complex)

Returns Gamma in: number or array-like

input reflection coefficient

skrf.tlineFunctions.reflection coefficient 2 input impedance

skrf.tlineFunctions.reflection_coefficient_2_input_impedance (z0, Gamma) calculates the input impedance given a reflection coefficient and characterisite impedance

$$Z_0(\frac{1+\Gamma}{1-\Gamma})$$

Parameters Gamma: number or array-like

complex reflection coefficient

z0: number or array-like

characteristic impedance

Returns zin: number or array-like

input impedance

$skrf.tlineFunctions.reflection_coefficient_2_input_impedance_at_theta$

skrf.tlineFunctions.reflection_coefficient_2_input_impedance_at_theta(z0,

Gamma0,

theta)

calculates the input impedance at electrical length theta, given a reflection coefficient and characterisitc impedance of the medium Parameters ————

z0 - characteristic impedance. Gamma: reflection coefficient theta: electrical length of the line, (may be complex)

returns zin: input impedance at theta

skrf.tlineFunctions.input impedance at theta

skrf.tlineFunctions.input_impedance_at_theta(z0, zl, theta)

input impedance of load impedance zl at a given electrical length, given characteristic impedance z0.

Parameters z0 : characteristic impedance.

zl: load impedance

theta: electrical length of the line, (may be complex)

skrf.tlineFunctions.load impedance 2 reflection coefficient

skrf.tlineFunctions.load_impedance_2_reflection_coefficient (z0, zl)

Returns the reflection coefficient for a given load impedance, and characteristic impedance.

For a transmission line of characteristic impedance Z_0 terminated with load impedance Z_l , the complex reflection coefficient is given by,

$$\Gamma = \frac{Z_l - Z_0}{Z_l + Z_0}$$

Parameters **z0**: number or array-like

characteristic impedance

zl: number or array-like

load impedance (aka input impedance)

Returns gamma: number or array-like

reflection coefficient

See Also:

Gamma 0_2_zl reflection coefficient to load impedance

Notes

inputs are typecasted to 1D complex array

skrf.tlineFunctions.load_impedance_2_reflection_coefficient_at_theta

skrf.tlineFunctions.load_impedance_2_reflection_coefficient_at_theta(z0, zl, theta)

3.6.2 Distributed Circuit and Wave Quantities

distributed_circuit_2_propagation_impedance(...) Converts distrubuted circuit values to wave quantities.
propagation_impedance_2_distributed_circuit(...) Converts wave quantities to distrubuted circuit values.

skrf.tlineFunctions.distributed_circuit_2_propagation_impedance

 ${\tt skrf.tlineFunctions.distributed_circuit_2_propagation_impedance} \ ({\it distributed_admittance}, \\ {\it distributed_circuit_2_propagation_impedance} \ ({\it distributed_circuit_2_propagation_impedance} \ ({\it distributed_admittance}, \\ {\it distributed_circuit_2_propagation_impedance} \ ({\it distributed_admittance}, \\ {\it distributed_circuit_2_propagation_impedance} \ ({\it distr$

tributed_impedance)

Converts distrubuted circuit values to wave quantities.

This converts complex distributed impedance and admittance to propagation constant and characteristic

impedance. The relation is

$$Z_0 = \sqrt{\frac{Z'}{Y'}}$$
 $\gamma = \sqrt{Z'Y'}$

Parameters distributed_admittance: number, array-like

distributed admittance

distributed_impedance: number, array-like

distributed impedance

Returns propagation_constant : number, array-like

distributed impedance

characteristic_impedance : number, array-like

distributed impedance

See Also:

propagation_impedance_2_distributed_circuit opposite conversion

skrf.tlineFunctions.propagation_impedance_2_distributed_circuit

Converts wave quantities to distrubuted circuit values.

Converts complex propagation constant and characteristic impedance to distributed impedance and admittance. The relation is,

$$Z^{'}=\gamma Z_{0} \qquad Y^{'}=rac{\gamma}{Z_{0}}$$

Parameters propagation_constant : number, array-like

distributed impedance

characteristic_impedance : number, array-like

distributed impedance

Returns distributed_admittance : number, array-like

distributed admittance

distributed_impedance: number, array-like

distributed impedance

See Also:

distributed_circuit_2_propagation_impedance opposite conversion

3.6.3 Transmission Line Physics

skin_depth(f, rho, mu_r)	the skin depth for a material.
<pre>surface_resistivity(f, rho, mu_r)</pre>	surface resistivity.

skrf.tlineFunctions.skin_depth

```
skrf.tlineFunctions.skin_depth (f, rho, mu_r)
the skin depth for a material.

see www.microwaves101.com for more info.

Parameters f: number or array-like
frequency, in Hz

rho: number of array-like
bulk resistivity of material, in ohm*m
mu_r: number or array-like
relative permiability of material

Returns skin depth: number or array-like
```

the skin depth, in m

skrf.tlineFunctions.surface_resistivity

3.7 constants (skrf.constants)

This module contains pre-initialized objects's.

3.7.1 Standard Waveguide Bands

Frequency Objects

These are predefined Frequency objects that correspond to standard waveguide bands. This information is taken from the VDI Application Note 1002^{31} .

Object Name	Description
f_wr10	WR-10, 75-110 GHz
f_wr3	WR-3, 220-325 GHz
f_wr2p2	WR-2.2, 330-500 GHz
f_wr1p5	WR-1.5, 500-750 GHz
f_wr1	WR-1, 750-1100 GHz

RectangularWaveguide Objects

These are predefined RectangularWaveguide objects for standard waveguide bands.

Object Name	Description
wr10	WR-10, 75-110 GHz
wr3	WR-3, 220-325 GHz
wr2p2	WR-2.2, 330-500 GHz
wr1p5	WR-1.5, 500-750 GHz
wr1	WR-1, 750-1100 GHz

3.7.2 Shorthand Names

Below is a list of shorthand object names which can be use to save some typing. These names are defined in the main __init__ module.

Shorthand	Full Object Name	
F	Frequency	
N	Network	
NS	NetworkSet	
M	Media	
С	Calibration	

The following are shorthand names for commonly used, but unfortunately longwinded functions.

Shorthand	Full Object Name
saf	save_all_figs()

3.7.3 References

3.8 util (skrf.util)

Holds utility functions that are general conveniences.

³¹ VDI Application Note: VDI Waveguide Band Designations (VDI-1002) http://vadiodes.com/VDI/pdf/waveguidechart200908.pdf

3.8.1 General

now_string()	returns a unique sortable string, representing the current time
find_nearest(array, value)	find nearest value in array.
find_nearest_index(array, value)	find nearest value in array.
get_fid(file, *args, **kwargs) Returns a file object, given a filename or file object	
get_extn(filename)	Get the extension from a filename.

skrf.util.now string

```
skrf.util.now_string()
```

returns a unique sortable string, representing the current time

nice for generating date-time stamps to be used in file-names

skrf.util.find_nearest

```
skrf.util.find_nearest(array, value)
```

find nearest value in array.

taken from http://stackoverflow.com/questions/2566412/find-nearest-value-in-numpy-array

Parameters array: numpy.ndarray

array we are searching for a value in

value: element of the array value to search for

Returns found_value: an element of the array

the value that is numerically closest to value

skrf.util.find_nearest_index

```
skrf.util.find_nearest_index(array, value)
```

find nearest value in array.

Parameters array: numpy.ndarray

array we are searching for a value in

value: element of the array

value to search for

Returns found_index : int

the index at which the numerically closest element to value was found at

from http://stackoverflow.com/questions/2566412/find-nearest-value-in-numpytaken

array:

skrf.util.get_fid

```
skrf.util.get_fid(file, *args, **kwargs)
```

Returns a file object, given a filename or file object

Useful when you want to allow the arguments of a function to be either files or filenames

Parameters file: str or file-object

file to open

*args, **kwargs: arguments and keyword arguments

passed through to pickle.load

skrf.util.get_extn

```
skrf.util.get_extn(filename)
```

Get the extension from a filename.

The extension is defined as everything passed the last '.'. Returns None if it aint got one

Parameters filename: string

the filename

Returns ext: string, None

either the extension (not including '.') or None if there isnt one

3.9 io (skrf.io)

This Package provides functions and objects for input/output.

The general functions read() and write() can be used to read and write [almost] any skrf object to disk, using the pickle module.

Reading and writing touchstone files is supported through the Touchstone class, which can be more easily used through the Network constructor, __init__()

3.9.1 general (skrf.io.general)

General io functions for reading and writing skrf objects

read(file, *args, **kwargs)	Read skrf object[s] from a pickle file
read_all([dir, contains])	Read all skrf objects in a directory
write(file, obj[, overwrite])	Write skrf object[s] to a file
write_all(dict_objs[, dir])	Write a dictionary of skrf objects individual files in <i>dir</i> .
<pre>save_sesh(dict_objs[, file, module,])</pre>	Save all <i>skrf</i> objects in the local namespace.

skrf.io.general.read

```
skrf.io.general.read(file, *args, **kwargs)
```

Read skrf object[s] from a pickle file

Reads a skrf object that is written with write (), which uses the pickle module.

```
Parameters file: str or file-object
                   name of file, or a file-object
               *args, **kwargs: arguments and keyword arguments
                   passed through to pickle.load
     See Also:
     read read a skrf object
     write write skrf object[s]
     read_all read all skrf objects in a directory
     write_all write dictionary of skrf objects to a directory
     Notes
     if file is a file-object it is left open, if it is a file-object is opened and closed. If file is a file-object
     and reading fails, then the position is reset back to 0 using seek if possible.
     Examples
     >>> n = rf.Network(f=[1,2,3],s=[1,1,1],z0=50)
     >>> n.write('my_ntwk.ntwk')
     >>> n_2 = rf.read('my_ntwk.ntwk')
skrf.io.general.read all
skrf.io.general.read_all (dir='.', contains=None)
     Read all skrf objects in a directory
     Attempts to load all files in dir, using read(). Any file that is not readable by skrf is skipped. Optionally,
     simple filtering can be achieved through the use of contains argument.
           Parameters dir: str, optional
                   the directory to load from, default '.'
               contains: str, optional
                   if not None, only files containing this substring will be loaded
           Returns out : dictionary
                   dictionary containing all loaded skrf objects. keys are the filenames without extensions,
                   and the values are the objects
     See Also:
     read read a skrf object
```

3.9. io (skrf.io) 159

write write skrf object[s]

read_all read all skrf objects in a directory

write_all write dictionary of skrf objects to a directory

Examples

```
>>> rf.read_all('skrf/data/')
{'delay_short': 1-Port Network: 'delay_short', 75-110 GHz, 201 pts, z0=[ 50.+0.j],
'line': 2-Port Network: 'line', 75-110 GHz, 201 pts, z0=[ 50.+0.j 50.+0.j],
'ntwk1': 2-Port Network: 'ntwk1', 1-10 GHz, 91 pts, z0=[ 50.+0.j 50.+0.j],
'one_port': one port Calibration: 'one_port', 500-750 GHz, 201 pts, 4-ideals/4-measured,
...
```

skrf.io.general.write

```
skrf.io.general.write(file, obj, overwrite=True)
Write skrf object[s] to a file
```

This uses the pickle module to write skrf objects to a file. Note that you can write any pickl-able python object. For example, you can write a list or dictionary of Network objects or Calibration objects. This will write out a single file. If you would like to write out a seperate file for each object, use write_all().

Parameters file: file or string

File or filename to which the data is saved. If file is a file-object, then the filename is unchanged. If file is a string, an appropriate extension will be appended to the file name if it does not already have an extension.

```
obj: an object, or list/dict of objects
object or list/dict of objects to write to disk
```

overwrite: Boolean

if file exists, should it be overwritten?

See Also:

```
read read a skrf object
write write skrf object[s]
read_all read all skrf objects in a directory
write_all write dictionary of skrf objects to a directory
skrf.network.Network.write write method of Network
skrf.calibration.calibration.Calibration.write write method of Calibration
```

Notes

If file is a str, but doesn't contain a suffix, one is chosen automatically. Here are the extensions

skrf object	extension
Frequency	'.freq'
Network	ʻ.ntwk'
NetworkSet	'.ns'
Calibration	'.cal'
Media	'.med'
other	'.p'

To make file written by this method cross-platform, the pickling protocol 2 is used. See pickle for more info.

Examples

Convert a touchstone file to a pickled Network,

```
>>> n = rf.Network('my_ntwk.s2p')
>>> rf.write('my_ntwk', n)
>>> n_red = rf.read('my_ntwk.ntwk')

Writing a list of different objects
>>> n = rf.Network('my_ntwk.s2p')
>>> ns = rf.NetworkSet([n,n,n])
>>> rf.write('out',[n,ns])
>>> n_red = rf.read('out.p')
```

skrf.io.general.write_all

```
skrf.io.general.write_all (dict_objs, dir='.', *args, **kwargs)
Write a dictionary of skrf objects individual files in dir.
```

Each object is written to its own file. The filename used for each object is taken from its key in the dictionary. If no extension exists in the key, then one is added. See write() for a list of extensions. If you would like to write the dictionary to a single output file use write().

```
Parameters dict_objs: dict
    dictionary of skrf objects

dir: str
    directory to save skrf objects into
*args, **kwargs::
    passed through to write(). overwrite option may be of use.
```

See Also:

```
read read a skrf object
write write skrf object[s]
read_all read all skrf objects in a directory
write_all write dictionary of skrf objects to a directory
```

Notes

Any object in dict_objs that is pickl-able will be written.

Examples

Writing a diction of different skrf objects

```
>>> from skrf.data import line, short
>>> d = {'ring_slot':ring_slot, 'one_port_cal':one_port_cal}
>>> rf.write_all(d)
```

3.9. io (skrf.io) 161

skrf.io.general.save sesh

```
skrf.io.general.save_sesh (dict_objs, file='skrfSesh.p', module='skrf', exclude_prefix='_')
Save all skrf objects in the local namespace.
```

This is used to save current workspace in a hurry, by passing it the output of locals() (see Examples). Note this can be used for other modules as well by passing a different *module* name.

Parameters dict_objs: dict

dictionary containing skrf objects. See the Example.

file: str or file-object, optional the file to save all objects to

module: str, optional

the module name to grep for.

exclude_prefix: str, optional:

dont save objects which have this as a prefix.

See Also:

```
read read a skrf object
write write skrf object[s]
read_all read all skrf objects in a directory
write_all write dictionary of skrf objects to a directory
```

Examples

Write out all skrf objects in current namespace.

```
>>> rf.write_all(locals(), 'mysesh.p')
```

3.9.2 touchstone (skrf.io.touchstone)

Touchstone class

Touchstone(file) class to read touchstone s-parameter files

skrf.io.touchstone.Touchstone

```
class skrf.io.touchstone.Touchstone (file)
    class to read touchstone s-parameter files
```

The reference for writing this class is the draft of the Touchstone(R) File Format Specification Rev 2.0 32

Methods

³² http://www.eda-stds.org/ibis/adhoc/interconnect/touchstone_spec2_draft.pdf

init	constructor	
get_format	returns the file format string used for the given format.	
get_noise_data	TODO: NIY	
get_noise_names	TODO: NIY	
get_sparameter_arrays	returns the sparameters as a tuple of arrays, where the first element is	
get_sparameter_data	get the data of the sparameter with the given format.	
get_sparameter_names	generate a list of column names for the s-parameter data	
load_file	Load the touchstone file into the interal data structures	

skrf.io.touchstone.Touchstone.__init__

```
Touchstone.__init__(file)
constructor
```

Parameters file: str or file-object

touchstone file to load

Examples

From filename

```
>>> t = rf.Touchstone('network.s2p')
```

From file-object

```
>>> file = open('network.s2p')
>>> t = rf.Touchstone(file)
```

skrf.io.touchstone.Touchstone.get format

```
Touchstone.get_format (format='ri')
```

returns the file format string used for the given format. This is usefull to get some informations.

skrf.io.touchstone.Touchstone.get_noise_data

```
Touchstone.get_noise_data()
          TODO: NIY
```

skrf.io.touchstone.Touchstone.get_noise_names

```
Touchstone.get_noise_names()
TODO: NIY
```

skrf.io.touchstone.Touchstone.get_sparameter_arrays

Touchstone.get_sparameter_arrays()

returns the sparameters as a tuple of arrays, where the first element is the frequency vector (in Hz) and the s-parameters are a 3d numpy array. The values of the sparameters are complex number. usage:

3.9. io (skrf.io) 163

```
f_{a} = self.sgetparameter\_arrays() s11 = a[:,0,0]
```

skrf.io.touchstone.Touchstone.get_sparameter_data

```
Touchstone.get_sparameter_data(format='ri')
```

get the data of the sparameter with the given format. supported formats are:

orig: unmodified s-parameter data ri: data in real/imaginary ma: data in magnitude and angle (degree) db: data in log magnitute and angle (degree)

Returns a list of numpy.arrays

skrf.io.touchstone.Touchstone.get_sparameter_names

```
Touchstone.get_sparameter_names(format='ri')
```

generate a list of column names for the s-parameter data The names are different for each format. possible format parameters:

ri, ma, db, orig (where orig refers to one of the three others)

returns a list of strings.

skrf.io.touchstone.Touchstone.load_file

```
Touchstone.load file (fid)
```

Load the touchstone file into the interal data structures

Functions related to reading/writing touchstones.

hfss_touchstone_2_gamma_z0(filename)	Extracts Z0 and Gamma comments from touchstone file
hfss_touchstone_2_media(filename[, f_unit])	Creates a Media object from a a HFSS-style touchstone file with Gamma an

skrf.io.touchstone.hfss_touchstone_2_gamma_z0

```
skrf.io.touchstone.hfss_touchstone_2_gamma_z0 (filename)
```

Extracts Z0 and Gamma comments from touchstone file

Takes a HFSS-style touchstone file with Gamma and Z0 comments and extracts a triplet of arrays being: (frequency, Gamma, Z0)

Parameters filename: string

the HFSS-style touchstone file

Returns f : numpy.ndarray

frequency vector (in Hz)

gamma: complex numpy.ndarray

complex propagation constant

z0: numpy.ndarray

complex port impedance

Examples

```
>>> f,gamm,z0 = rf.hfss_touchstone_2_gamma_z0('line.s2p')
```

skrf.io.touchstone.hfss_touchstone_2_media

```
skrf.io.touchstone.hfss_touchstone_2_media(filename,f_unit='ghz')
```

Creates a Media object from a a HFSS-style touchstone file with Gamma and Z0 comments

Parameters filename: string

the HFSS-style touchstone file

f_unit : ['hz','khz','mhz','ghz']

passed to f_unit parameters of Frequency constructor

Returns my_media: skrf.media.Media object

the transmission line model defined by the gamma, and z0 comments in the HFSS file.

See Also:

hfss_touchstone_2_gamma_z0 returns gamma, and z0

Examples

```
>>> port1_media, port2_media = rf.hfss_touchstone_2_media('line.s2p')
```

3.10 calibration (skrf.calibration)

This Package provides a high-level class representing a calibration instance, as well as calibration algorithms and supporting functions.

Both one and two port calibrations are supported. These calibration algorithms allow for redundant measurements, by using a simple least squares estimator to solve for the embedding network.

3.10.1 Modules

calibration (skrf.calibration.calibration)

Contains the Calibration class, and supporting functions

Calibration Class

Calibration(measured, ideals[, type, ...]) An object to represent a VNA calibration instance.

skrf.calibration.calibration.Calibration

 $\begin{array}{ll} \textbf{class} \; \texttt{skrf.calibration.calibration.Calibration} \; (\textit{measured}, & \textit{ideals}, & \textit{type=None}, \\ & \textit{is_reciprocal=False}, & \textit{name=None}, \\ & \textit{sloppy_input=False}, \; **kwargs) \end{array}$

An object to represent a VNA calibration instance.

A Calibration object is used to perform a calibration given a set meaurements and ideals responses. It can run a calibration, store results, and apply the results to calculate corrected measurements.

Attributes

Ts	T-matricies used for de-embeding, a two-port calibration.	
caled_ntwk_sets	returns a NetworkSet for each caled_ntwk, based on their names	
caled_ntwks	list of the calibrated, calibration standards.	
calibration_algorithm_dict		
coefs	coefs: a dictionary holding the calibration coefficients	
error_ntwk	A Network object which represents the error network being	
nports	the number of ports in the calibration	
nstandards	number of ideal/measurement pairs in calibration	
output_from_cal	a dictionary holding all of the output from the calibration	
residual_ntwks	returns a the residuals for each calibration standard in the	
residuals	if calibration is overdeteremined, this holds the residuals	
type	string representing what type of calibration is to be	

skrf.calibration.calibration.Calibration.Ts

Calibration.Ts

T-matricies used for de-embeding, a two-port calibration.

$skrf.calibration.calibration.caled_ntwk_sets$

Calibration.caled_ntwk_sets

returns a NetworkSet for each caled_ntwk, based on their names

skrf.calibration.calibration.Calibration.caled_ntwks

Calibration.caled_ntwks

list of the calibrated, calibration standards.

$skrf. calibration. calibration. calibration_algorithm_dict$

Calibration.calibration_algorithm_dict = {'two port': <function two_port at 0x471dc80>, 'one port parametric': dictionary holding calibration algorithms.

skrf.calibration.calibration.Calibration.coefs

Calibration.coefs

coefs: a dictionary holding the calibration coefficients

for one port cal's 'directivity':e00 'reflection tracking':e01e10 'source match':e11

for 7-error term two port cal's TODO:

skrf.calibration.calibration.Calibration.error_ntwk

Calibration.error ntwk

A Network object which represents the error network being calibrated out.

skrf.calibration.calibration.Calibration.nports

Calibration.nports

the number of ports in the calibration

skrf.calibration.calibration.Calibration.nstandards

Calibration.nstandards

number of ideal/measurement pairs in calibration

$skrf.calibration.calibration.calibration.output_from_cal$

Calibration.output_from_cal

a dictionary holding all of the output from the calibration algorithm

skrf.calibration.calibration.Calibration.residual ntwks

Calibration.residual_ntwks

returns a the residuals for each calibration standard in the form of a list of Network types.

these residuals are calculated in the 'calibrated domain', meaning they are

$$r = (E.inv ** m - i)$$

where, r: residual network, E: embedding network, m: measured network i: ideal network

This way the units of the residual networks are meaningful

note: the residuals are only calculated if they are not existent.

so, if you want to re-calculate the residual networks then you delete the property '_residual_ntwks'.

skrf.calibration.calibration.Calibration.residuals

Calibration.residuals

if calibration is overdeteremined, this holds the residuals in the form of a vector.

also available are the complex residuals in the form of skrf.Network's, see the property 'residual_ntwks'

from numpy.lstsq: residues: the sum of the residues; squared euclidean norm for each column vector in b (given ax=b)

skrf.calibration.calibration.Calibration.type

Calibration.type

string representing what type of calibration is to be performed. supported types at the moment are:

'one port': standard one-port cal. if more than 2 measurement/ideal pairs are given it will calculate the least squares solution.

'two port': two port calibration based on the error-box model

note: algorithms referenced by calibration_algorithm_dict, are stored in calibrationAlgorithms.py

Methods

init	Calibration initializer.
apply_cal	apply the current calibration to a measurement.
	Continued on next page

	Table 3.3 4	l – continued	from	previous	page
--	--------------------	---------------	------	----------	------

apply_cal_to_all_in_dir	convience function to apply calibration to an entire directory
biased_error	estimate of biased error for overdetermined calibration with
func_per_standard	
mean_residuals	
plot_coefs_db	plot magnitude of the error coeficient dictionary
plot_errors	plot calibration error metrics for an over-determined calibration.
plot_residuals	plots a component of the residual errors on the Calibration-plane.
plot_residuals_db	see plot_residuals
plot_residuals_mag	see plot_residuals
plot_residuals_smith	see plot_residuals
plot_uncertainty_per_standard	Plots uncertainty associated with each calibration standard.
run	runs the calibration algorihtm.
total_error	estimate of total error for overdetermined calibration with
unbiased_error	estimate of unbiased error for overdetermined calibration with
uncertainty_per_standard	given that you have repeat-connections of single standard,
write	Write the Calibration to disk using write()

skrf.calibration.calibration.Calibration.__init__

Calibration.__init__(measured, ideals, type=None, is_reciprocal=False, name=None, sloppy_input=False, **kwargs)

Calibration initializer.

Parameters measured: list of Network objects

Raw measurements of the calibration standards. The order must align with the *ideals* parameter

ideals: list of Network objects

Predicted ideal response of the calibration standards. The order must align with *ideals* list

Notes

All calibration algorithms are in stored in skrf.calibration.calibrationAlgorithms, refer to that file for documentation on the algorithms themselves. The Calibration class accesses those functions through the attribute 'calibration_algorithm_dict'.

References

Examples

See the *Calibration* tutorial, or the examples sections for *One-Port Calibration* and $../../examples/twoport_calibration$

skrf.calibration.calibration.Calibration.apply_cal

Calibration.apply_cal(input_ntwk)

apply the current calibration to a measurement.

takes:

input_ntwk: the measurement to apply the calibration to, a Network type.

returns: caled: the calibrated measurement, a Network type.

```
skrf.calibration.calibration.Calibration.apply_cal_to_all_in_dir
```

Calibration.apply_cal_to_all_in_dir(dir='.', contains=None, f_unit='ghz')

convience function to apply calibration to an entire directory of measurements, and return a dictionary of the calibrated results, optionally the user can 'grep' the direction by using the contains switch.

takes: dir: directory of measurements (string) contains: will only load measurements who's filename contains this string.

f_unit: frequency unit, to use for all networks. see frequency.Frequency.unit for info.

returns:

ntwkDict: a dictionary of calibrated measurements, the keys are the filenames.

skrf.calibration.calibration.Calibration.biased error

Calibration.biased_error(std_names=None)

estimate of biased error for overdetermined calibration with multiple connections of each standard

takes:

std_names: list of strings to uniquely identify each standard.*

returns:

systematic error: skrf.Network type who's .s_mag is proportional to the systematic error metric

note:

mathematically, this is mean $s(|mean\ c(r)|)$

where: r: complex residual errors mean_c: complex mean taken accross connection mean_s: complex mean taken accross standard

skrf.calibration.calibration.Calibration.func_per_standard

Calibration.func_per_standard(func, attribute='s', std_names=None)

skrf.calibration.calibration.Calibration.mean_residuals

Calibration.mean_residuals()

skrf.calibration.calibration.Calibration.plot_coefs_db

Calibration.plot_coefs_db (ax=None, show_legend=True, **kwargs) plot magnitude of the error coeficient dictionary

skrf.calibration.calibration.Calibration.plot_errors

```
Calibration.plot_errors (std_names=None, scale='db', *args, **kwargs) plot calibration error metrics for an over-determined calibration.

see biased_error, unbiased_error, and total_error for more info
```

```
skrf.calibration.calibration.Calibration.plot residuals
Calibration.plot_residuals(attribute, *args, **kwargs)
     plots a component of the residual errors on the Calibration-plane.
     takes:
          attribute: name of ploting method of Network class to call
               possible options are: 'mag', 'db', 'smith', 'deg', etc
          *args, **kwargs: passed to plot_s_'atttribute'()
     note: the residuals are calculated by:
          (self.apply_cal(self.measured[k])-self.ideals[k])
skrf.calibration.calibration.Calibration.plot\_residuals\_db
Calibration.plot residuals db(*args, **kwargs)
     see plot residuals
skrf.calibration.calibration.Calibration.plot_residuals_mag
Calibration.plot_residuals_mag(*args, **kwargs)
     see plot_residuals
skrf.calibration.calibration.Calibration.plot residuals smith
Calibration.plot_residuals_smith(*args, **kwargs)
     see plot_residuals
skrf.calibration.calibration.Calibration.plot_uncertainty_per_standard
Calibration.plot_uncertainty_per_standard(scale='db', *args, **kwargs)
     Plots uncertainty associated with each calibration standard.
     This requires that each calibration standard is measured multiple times. The uncertainty associated with each
     standard is calculated by the complex standard deviation.
          Parameters scale: 'db', 'lin'
                   plot uncertainties on linear or log scale
               *args, **kwargs: passed to uncertainty_per_standard()
     See Also:
     uncertainty_per_standard()
skrf.calibration.calibration.Calibration.run
```

```
Calibration.run()
```

runs the calibration algorihtm.

this is automatically called the first time any dependent property is referenced (like error_ntwk), but only the first time. if you change something and want to re-run the calibration

use this.

skrf.calibration.calibration.Calibration.total error

Calibration.total_error(std_names=None)

estimate of total error for overdetermined calibration with multiple connections of each standard. This is the combined effects of both biased and un-biased errors

takes:

std names: list of strings to uniquely identify each standard.*

returns:

composit error: skrf.Network type who's .s_mag is proportional to the composit error metric

note:

mathematically, this is std_cs(r)

where: r: complex residual errors std_cs: standard deviation taken accross connections and standards

skrf.calibration.calibration.Calibration.unbiased error

Calibration.unbiased_error(std_names=None)

estimate of unbiased error for overdetermined calibration with multiple connections of each standard

takes:

std_names: list of strings to uniquely identify each standard.*

returns:

stochastic error: skrf.Network type who's .s_mag is proportional to the stochastic error metric

see also: uncertainty_per_standard, for this a measure of unbiased errors for each standard

note:

mathematically, this is mean_s(std_c(r))

where: r: complex residual errors std_c: standard deviation taken accross connections mean_s: complex mean taken accross standards

skrf.calibration.calibration.Calibration.uncertainty_per_standard

Calibration.uncertainty_per_standard(std_names=None, attribute='s')

given that you have repeat-connections of single standard, this calculates the complex standard deviation (distance) for each standard in the calibration across connection #.

takes:

std_names: list of strings to uniquely identify each standard.*

attribute: string passed to func_on_networks to calculate std deviation on a component if desired. ['s']

returns: list of skrf.Networks, whose magnitude of s-parameters is proportional to the standard deviation for that standard

*example:

if your calibration had ideals named like: 'short 1', 'short 2', 'open 1', 'open 2', etc. **you would pass this** mycal.uncertainty_per_standard(['short','open','match'])

skrf.calibration.calibration.Calibration.write

```
Calibration.write (file=None, *args, **kwargs)
Write the Calibration to disk using write()
```

Parameters file: str or file-object

filename or a file-object. If left as None then the filename will be set to Calibration.name, if its not None. If both are None, ValueError is raised.

*args, **kwargs: arguments and keyword arguments

```
passed through to write ()
```

See Also:

```
skrf.io.general.write, skrf.io.general.read
```

Notes

If the self.name is not None and file is can left as None and the resultant file will have the .ntwk extension appended to the filename.

Examples

```
>>> cal.name = 'my_cal'
>>> cal.write()
```

calibrationAlgorithms (skrf.calibration.calibrationAlgorithms)

Contains calibrations algorithms and related functions, which are used in the Calibration class.

Calibration Algorithms

172

one_port(measured, ideals)	Standard algorithm for a one port calibration.
one_port_nls(measured, ideals)	one port non-linear least squares.
two_port(measured, ideals[, switch_terms])	Two port calibration based on the 8-term error model.
parameterized_self_calibration(measured, ideals)	An iterative, general self-calibration routine.
parameterized_self_calibration_nls(measured,)	An iterative, general self-calibration routine.

skrf.calibration.calibrationAlgorithms.one_port

```
skrf.calibration.calibrationAlgorithms.one_port (measured, ideals)
Standard algorithm for a one port calibration.
```

If more than three standards are supplied then a least square algorithm is applied.

Parameters measured: list of Network objects or numpy.ndarray

a list of the measured reflection coefficients. The elements of the list can either a kxnxn numpy.ndarray, representing a s-matrix, or list of 1-port Network objects.

ideals: list of Network objects or numpy.ndarray

a list of the ideal reflection coefficients. The elements of the list can either a kxnxn numpy.ndarray, representing a s-matrix, or list of 1-port Network objects.

Returns output: a dictionary

output information from the calibration, the keys are

- 'error coeffcients': dictionary containing standard error coefficients
- 'residuals': a matrix of residuals from the least squared calculation. see numpy.linalg.lstsq() for more info

See Also:

one_port_nls for a non-linear least square implementation

Notes

uses numpy.linalg.lstsq() for least squares calculation

skrf.calibration.calibrationAlgorithms.one_port_nls

skrf.calibration.calibrationAlgorithms.one_port_nls(measured, ideals) one port non-linear least squares.

Parameters measured: list of Network objects or numpy.ndarray

a list of the measured reflection coefficients. The elements of the list can either a kxnxn numpy.ndarray, representing a s-matrix, or list of 1-port Network objects.

ideals: list of Network objects or numpy.ndarray

a list of the ideal reflection coefficients. The elements of the list can either a kxnxn numpy.ndarray, representing a s-matrix, or list of 1-port Network objects.

Returns output: a dictionary

a dictionary containing the following keys:

- 'error coeffcients': dictionary containing standard error coefficients
- 'residuals': a matrix of residuals from the least squared calculation. see numpy.linalg.lstsq() for more info
- 'cov_x': covariance matrix

Notes

Uses scipy.optmize.leastsq() for non-linear least squares calculation

skrf.calibration.calibrationAlgorithms.two_port

skrf.calibration.calibrationAlgorithms.two_port(measured, ideals, switch terms=None)

Two port calibration based on the 8-term error model.

Takes two ordered lists of measured and ideal responses. Optionally, switch terms ³³ can be taken into account by passing a tuple containing the forward and reverse switch terms as 1-port Networks. This algorithm is based on the work in ³⁴.

³³ Marks, Roger B.; , "Formulations of the Basic Vector Network Analyzer Error Model including Switch-Terms," ARFTG Conference Digest-Fall, 50th , vol.32, no., pp.115-126, Dec. 1997. URL: http://ieeexplore.ieee.org/stamp/stamp.jsp?tp=&arnumber=4119948&isnumber=4119931

³⁴ Speciale, R.A.;, "A Generalization of the TSD Network-Analyzer Calibration Procedure, Covering n-Port Scattering-Parameter Measurements, Affected by Leakage Errors," Microwave Theory and Techniques, IEEE Transactions on , vol.25, no.12, pp. 1100-1115, Dec 1977. URL: http://ieeexplore.ieee.org/stamp/stamp.jsp?tp=&arnumber=1129282&isnumber=25047

Parameters measured: list of 2-port Network objects

Raw measurements of the calibration standards. The order must align with the *ideals* parameter

ideals: list of 2-port Network objects

Predicted ideal response of the calibration standards. The order must align with *ideals* list measured: ordered list of measured networks. list elements

```
switch_terms: tuple of Network objects
```

The two measured switch terms in the order (forward, reverse). This is only applicable in two-port calibrations. See Roger Mark's paper on switch terms ³ for explanation of what they are.

Returns output: a dictionary

output information, contains the following keys: * 'error coefficients': * 'error vector': * 'residuals':

Notes

support for gathering switch terms on HP8510C is in skrf.vi.vna

References

skrf.calibration.calibrationAlgorithms.parameterized self calibration

An iterative, general self-calibration routine.

A self calibration routine based off of residual error minimization which can take any mixture of parameterized standards.

```
Parameters measured: list of Network objects
```

a list of the measured networks

ideals: list of ParametricStandard objects

a list of the ideal networks

showProgress: Boolean

turn printing progress on/off

**kwargs: key-word arguments

passed to minimization algorithm (scipy.optimize.fmin)

Returns output: a dictionary

a dictionary containing the following keys:

- 'error_coefficients' : dictionary of error coefficients
- 'residuals': residual matrix (shape depends on #stds)

- 'parameter_vector_final': final results for parameter vector
- 'mean_residual_list': the mean, magnitude of the residuals at each iteration of calibration. this is the variable being minimized.

See Also:

parametricStandard sub-module for more info on them

parameterized_self_calibration_nls similar algorithm, but uses a non-linear least-squares estimator

skrf.calibration.calibrationAlgorithms.parameterized_self_calibration_nls

```
skrf.calibration.calibrationAlgorithms.parameterized_self_calibration_nls(measured, ide-als_ps, show-Progress=True, **kwargs)
```

An iterative, general self-calibration routine.

A self calibration routine based off of residual error minimization which can take any mixture of parameterized standards. Uses a non-linear least squares estimator to calculate the residuals.

Parameters measured: list of Network objects

a list of the measured networks

ideals: list of Network objects a list of the ideal networks

showProgress: Boolean

turn printing progress on/off
**kwargs: key-word arguments

passed to minimization algorithm (scipy.optimize.fmin)

Returns output: a dictionary

a dictionary containing the following keys:

- 'error_coefficients' : dictionary of error coefficients
- 'residuals': residual matrix (shape depends on #stds)
- 'parameter_vector_final': final results for parameter vector
- 'mean_residual_list': the mean, magnitude of the residuals at each iteration of calibration. this is the variable being minimized.

See Also:

parametricStandard sub-module for more info on them

parameterized_self_calibration_nls similar algorithm, but uses a non-linear least-squares estimator

Supporting Functions

unterminate_switch_terms(two_port, gamma_f,)	unterminates switch terms from raw measurements.
abc_2_coefs_dict(abc)	converts an abc ndarry to a dictionarry containing the error
eight_term_2_one_port_coefs(coefs)	

$skrf.calibration.calibrationAlgorithms.unterminate_switch_terms$

```
 skrf. calibration. calibration Algorithms. {\it unterminate\_switch\_terms} \ ({\it two\_port}, gamma\_f, gamma\_r)
```

unterminates switch terms from raw measurements.

takes: two_port: the raw measurement, a 2-port Network type. gamma_f: the measured forward switch term, a 1-port Network type gamma_r: the measured reverse switch term, a 1-port Network type

returns: un-terminated measurement, a 2-port Network type

see: 'Formulations of the Basic Vector Network Analyzer Error Model including Switch Terms' by Roger B. Marks

skrf.calibration.calibrationAlgorithms.abc_2_coefs_dict

```
{\tt skrf.calibration.calibrationAlgorithms.abc\_2\_coefs\_dict} \ (abc) \\ {\tt converts} \ an \ abc \ ndarry \ to \ a \ dictionarry \ containing \ the \ error \ coefficients.
```

takes:

```
abc [Nx3 numpy.ndarray, which holds the complex calibration]
```

```
coefficients. the components of abc are a[:] = abc[:,0] b[:] = abc[:,1] c[:] = abc[:,2],
```

a, b and c are related to the error network by a = det(e) = e01*e10 - e00*e11 b = e00 c = e11

returns:

```
coefsDict: dictionary containing the following 'directivity':e00 'reflection tracking':e01e10 'source match':e11
```

note: e00 = directivity error e10e01 = reflection tracking error e11 = source match error

$skrf. calibration. calibration Algorithms. eight_term_2_one_port_coefs$

```
skrf.calibration.calibrationAlgorithms.eight_term_2_one_port_coefs(coefs)
```

calibrationFunctions (skrf.calibration.calibrationFunctions)

Functions which operate on or pertain to Calibration Objects

cartesian_product_calibration_set(ideals, ...) This function is used for calculating calibration uncertainty due to un-b

skrf.calibration.calibrationFunctions.cartesian_product_calibration_set

```
skrf.calibration.calibrationFunctions.cartesian_product_calibration_set(ideals, measured, *args, **kwargs)
```

This function is used for calculating calibration uncertainty due to un-biased, non-systematic errors.

It creates an ensemble of calibration instances, the set of measurement lists used in the ensemble is the Cartesian Product of all instances of each measured standard.

The idea is that if you have multiple measurements of each standard, then the multiple calibrations can be made by generating all possible combinations of measurements. This produces a conceptually simple, but computationally expensive way to estimate calibration uncertainty.

takes: ideals: list of ideal Networks measured: list of measured Networks *args, **kwargs: passed to Calibration initializer

returns: cal_ensemble: a list of Calibration instances.

you can use the output to estimate uncertainty by calibrating a DUT with all calibrations, and then running statistics on the resultant set of Networks. for example

import skrf as rf # define you lists of ideals and measured networks cal_ensemble = rf.cartesian_product_calibration_ensemble(ideals, measured) dut = rf.Network('dut.s1p') network_ensemble = [cal.apply_cal(dut) for cal in cal_ensemble] rf.plot_uncertainty_mag(network_ensemble) [network.plot_s_smith() for network in network_ensemble]

3.10.2 Classes

Calibration(measured, ideals[, type, ...]) An object to represent a VNA calibration instance.

skrf.calibration.calibration.Calibration

class skrf.calibration.calibration.Calibration (measured, ideals, type=None, is_reciprocal=False, name=None, sloppy_input=False, **kwargs)

An object to represent a VNA calibration instance.

A Calibration object is used to perform a calibration given a set meaurements and ideals responses. It can run a calibration, store results, and apply the results to calculate corrected measurements.

Attributes

Ts	T-matricies used for de-embeding, a two-port calibration.
caled_ntwk_sets	returns a NetworkSet for each caled_ntwk, based on their names
caled_ntwks	list of the calibrated, calibration standards.
calibration_algorithm_dict	
coefs	coefs: a dictionary holding the calibration coefficients
error_ntwk	A Network object which represents the error network being
nports	the number of ports in the calibration
nstandards	number of ideal/measurement pairs in calibration
output_from_cal	a dictionary holding all of the output from the calibration
residual_ntwks	returns a the residuals for each calibration standard in the
residuals	if calibration is overdeteremined, this holds the residuals
type	string representing what type of calibration is to be

skrf.calibration.calibration.Calibration.Ts

Calibration.Ts

T-matricies used for de-embeding, a two-port calibration.

skrf.calibration.calibration.Calibration.caled_ntwk_sets

Calibration.caled ntwk sets

returns a NetworkSet for each caled_ntwk, based on their names

skrf.calibration.calibration.Calibration.caled_ntwks

Calibration.caled ntwks

list of the calibrated, calibration standards.

skrf.calibration.calibration.Calibration.calibration_algorithm_dict

Calibration.calibration_algorithm_dict = {'two port': <function two_port at 0x471dc80>, 'one port parametric': dictionary holding calibration algorithms.

skrf.calibration.calibration.Calibration.coefs

Calibration.coefs

coefs: a dictionary holding the calibration coefficients

for one port cal's 'directivity':e00 'reflection tracking':e01e10 'source match':e11

for 7-error term two port cal's TODO:

skrf.calibration.calibration.Calibration.error_ntwk

```
Calibration.error ntwk
```

A Network object which represents the error network being calibrated out.

skrf.calibration.calibration.Calibration.nports

```
Calibration.nports
```

the number of ports in the calibration

skrf.calibration.calibration.Calibration.nstandards

Calibration.nstandards

number of ideal/measurement pairs in calibration

skrf.calibration.calibration.Calibration.output_from_cal

${\tt Calibration.output_from_cal}$

a dictionary holding all of the output from the calibration algorithm

skrf.calibration.calibration.Calibration.residual ntwks

Calibration.residual_ntwks

returns a the residuals for each calibration standard in the form of a list of Network types.

these residuals are calculated in the 'calibrated domain', meaning they are

$$r = (E.inv ** m - i)$$

where, r: residual network, E: embedding network, m: measured network i: ideal network

This way the units of the residual networks are meaningful

note: the residuals are only calculated if they are not existent.

so, if you want to re-calculate the residual networks then you delete the property '_residual_ntwks'.

skrf.calibration.calibration.Calibration.residuals

Calibration.residuals

if calibration is overdeteremined, this holds the residuals in the form of a vector.

also available are the complex residuals in the form of skrf.Network's, see the property 'residual ntwks'

from numpy.lstsq: residues: the sum of the residues; squared euclidean norm for each column vector in b (given ax=b)

skrf.calibration.calibration.Calibration.type

Calibration.type

string representing what type of calibration is to be performed. supported types at the moment are:

'one port': standard one-port cal. if more than 2 measurement/ideal pairs are given it will calculate the least squares solution.

'two port': two port calibration based on the error-box model

note: algorithms referenced by calibration_algorithm_dict, are stored in calibrationAlgorithms.py

Methods

init	Calibration initializer.
apply_cal	apply the current calibration to a measurement.
apply_cal_to_all_in_dir	convience function to apply calibration to an entire directory
biased_error	estimate of biased error for overdetermined calibration with
func_per_standard	
mean_residuals	
plot_coefs_db	plot magnitude of the error coeficient dictionary
plot_errors	plot calibration error metrics for an over-determined calibration.
plot_residuals	plots a component of the residual errors on the Calibration-plane.
plot_residuals_db	see plot_residuals
plot_residuals_mag	see plot_residuals
plot_residuals_smith	see plot_residuals
	Continued on next page

7D 11	2 40	4.0	•	•	
Table	3.40	continued	trom	previous	nage

plot_uncertainty_per_standard	Plots uncertainty associated with each calibration standard.
run	runs the calibration algorihtm.
total_error	estimate of total error for overdetermined calibration with
unbiased_error	estimate of unbiased error for overdetermined calibration with
uncertainty_per_standard	given that you have repeat-connections of single standard,
write	Write the Calibration to disk using write ()

skrf.calibration.calibration.Calibration.__init__

Calibration.__init__ (measured, ideals, type=None, is_reciprocal=False, name=None, sloppy_input=False, **kwargs)

Calibration initializer.

Parameters measured: list of Network objects

Raw measurements of the calibration standards. The order must align with the *ideals* parameter

ideals: list of Network objects

Predicted ideal response of the calibration standards. The order must align with *ideals* list

Notes

All calibration algorithms are in stored in skrf.calibration.calibrationAlgorithms, refer to that file for documentation on the algorithms themselves. The Calibration class accesses those functions through the attribute 'calibration_algorithm_dict'.

References

Examples

See the *Calibration* tutorial, or the examples sections for *One-Port Calibration* and ../../examples/twoport_calibration

skrf.calibration.calibration.Calibration.apply_cal

Calibration.apply_cal(input_ntwk)

apply the current calibration to a measurement.

takes:

input_ntwk: the measurement to apply the calibration to, a Network type.

returns: caled: the calibrated measurement, a Network type.

skrf.calibration.calibration.Calibration.apply_cal_to_all_in_dir

Calibration.apply_cal_to_all_in_dir(dir='.', contains=None, f_unit='ghz')

convience function to apply calibration to an entire directory of measurements, and return a dictionary of the calibrated results, optionally the user can 'grep' the direction by using the contains switch.

takes: dir: directory of measurements (string) contains: will only load measurements who's filename contains this string.

f_unit: frequency unit, to use for all networks. see frequency. Frequency. unit for info.

returns:

ntwkDict: a dictionary of calibrated measurements, the keys are the filenames.

```
skrf.calibration.calibration.Calibration.biased_error
```

```
Calibration.biased error(std names=None)
```

estimate of biased error for overdetermined calibration with multiple connections of each standard

takes:

std_names: list of strings to uniquely identify each standard.*

returns:

systematic error: skrf.Network type who's .s_mag is proportional to the systematic error metric

note:

mathematically, this is mean_s(|mean_c(r)|)

where: r: complex residual errors mean_c: complex mean taken accross connection mean_s: complex mean taken accross standard

skrf.calibration.calibration.Calibration.func_per_standard

```
Calibration.func_per_standard(func, attribute='s', std_names=None)
```

skrf.calibration.calibration.Calibration.mean_residuals

```
Calibration.mean_residuals()
```

skrf.calibration.calibration.Calibration.plot_coefs_db

```
Calibration.plot_coefs_db (ax=None, show_legend=True, **kwargs) plot magnitude of the error coeficient dictionary
```

skrf.calibration.calibration.Calibration.plot errors

```
Calibration.plot_errors (std_names=None, scale='db', *args, **kwargs) plot calibration error metrics for an over-determined calibration. see biased_error, unbiased_error, and total_error for more info
```

```
skrf.calibration.calibration.Calibration.plot_residuals
Calibration.plot_residuals(attribute, *args, **kwargs)
     plots a component of the residual errors on the Calibration-plane.
     takes:
          attribute: name of ploting method of Network class to call
               possible options are: 'mag', 'db', 'smith', 'deg', etc
          *args, **kwargs: passed to plot_s_'atttribute'()
     note: the residuals are calculated by:
          (self.apply_cal(self.measured[k])-self.ideals[k])
skrf.calibration.calibration.Calibration.plot_residuals_db
Calibration.plot_residuals_db(*args, **kwargs)
     see plot_residuals
skrf.calibration.calibration.Calibration.plot_residuals_mag
Calibration.plot_residuals_mag(*args, **kwargs)
     see plot_residuals
skrf.calibration.calibration.Calibration.plot residuals smith
Calibration.plot_residuals_smith(*args, **kwargs)
     see plot_residuals
skrf.calibration.calibration.Calibration.plot uncertainty per standard
Calibration.plot_uncertainty_per_standard(scale='db', *args, **kwargs)
     Plots uncertainty associated with each calibration standard.
     This requires that each calibration standard is measured multiple times. The uncertainty associated with each
     standard is calculated by the complex standard deviation.
          Parameters scale: 'db', 'lin'
                   plot uncertainties on linear or log scale
               *args, **kwargs: passed to uncertainty_per_standard()
     See Also:
     uncertainty_per_standard()
skrf.calibration.calibration.Calibration.run
Calibration.run()
     runs the calibration algorihtm.
```

this is automatically called the first time any dependent property is referenced (like error_ntwk), but only the first time. if you change something and want to re-run the calibration

use this.

skrf.calibration.calibration.Calibration.total error

```
Calibration.total_error(std_names=None)
```

estimate of total error for overdetermined calibration with multiple connections of each standard. This is the combined effects of both biased and un-biased errors

takes:

std_names: list of strings to uniquely identify each standard.*

returns:

composit error: skrf.Network type who's .s_mag is proportional to the composit error metric

note:

mathematically, this is std_cs(r)

where: r: complex residual errors std_cs: standard deviation taken accross connections and standards

skrf.calibration.calibration.Calibration.unbiased error

```
Calibration.unbiased_error(std_names=None)
```

estimate of unbiased error for overdetermined calibration with multiple connections of each standard

takes:

std_names: list of strings to uniquely identify each standard.*

returns:

stochastic error: skrf.Network type who's .s_mag is proportional to the stochastic error metric

see also: uncertainty_per_standard, for this a measure of unbiased errors for each standard

note:

mathematically, this is $mean_s(std_c(r))$

where: r: complex residual errors std_c: standard deviation taken accross connections mean_s: complex mean taken accross standards

skrf.calibration.calibration.Calibration.uncertainty_per_standard

```
Calibration.uncertainty_per_standard(std_names=None, attribute='s')
```

given that you have repeat-connections of single standard, this calculates the complex standard deviation (distance) for each standard in the calibration across connection #.

takes:

std names: list of strings to uniquely identify each standard.*

attribute: string passed to func_on_networks to calculate std deviation on a component if desired.

['s']

returns: list of skrf.Networks, whose magnitude of s-parameters is proportional to the standard deviation for that standard

*example:

```
if your calibration had ideals named like: 'short 1', 'short 2', 'open 1', 'open 2', etc. you would pass this mycal.uncertainty_per_standard(['short','open','match'])
```

skrf.calibration.calibration.Calibration.write

```
Calibration.write(file=None, *args, **kwargs)
Write the Calibration to disk using write()

Parameters file: str or file-object
filename or a file-object. If left as None then the filename will be set to Calibration.name, if its not None. If both are None, ValueError is raised.

*args, **kwargs: arguments and keyword arguments
passed through to write()

See Also:
skrf.io.general.write, skrf.io.general.read
```

Notes

If the self.name is not None and file is can left as None and the resultant file will have the .ntwk extension appended to the filename.

Examples

```
>>> cal.name = 'my_cal'
>>> cal.write()
```

3.11 media (skrf.media)

This package provides objects representing transmission line mediums.

The Media object is the base-class that is inherited by specific transmission line instances, such as Freespace, or RectangularWaveguide. The Media object provides generic methods to produce Network's for any transmission line medium, such as line () and delay_short (). These methods are inherited by the specific transmission line classes, which interally define relevant quantities such as propagation constant, and characteristic impedance. This allows the specific transmission line mediums to produce networks without re-implementing methods for each specific media instance.

Network components specific to an given transmission line medium such as cpw_short() and microstrip_bend(), are implemented in those object

3.11.1 Media base-class

Media The base-class for all transmission line mediums.

skrf.media.media.Media

class skrf.media.media.Media (frequency, $propagation_constant$, $characteristic_impedance$, z0=None)

The base-class for all transmission line mediums.

The Media object provides generic methods to produce Network's for any transmision line medium, such as line() and delay_short().

The initializer for this class has flexible argument types. This allows for the important attributes of the Media object to be dynamic. For example, if a Media object's propagation constant is a function of some attribute of that object, say *conductor_width*, then the propagation constant will change when that attribute changes. See __init__() for details.

The network creation methods build off of each other. For example, the specicial load cases, suc as <code>short()</code> and <code>open()</code> call <code>load()</code> with given arguments for Gamma0, and the <code>delay_</code> and <code>shunt_</code> functions call <code>line()</code> and <code>shunt()</code> respectively. This minimizes re-implementation.

Most methods initialize the Network by calling match () to create a 'blank' Network, and then fill in the s-matrix.

Attributes

characteristic_impedance	Characterisitc impedance
propagation_constant	Propagation constant
z0	Port Impedance

skrf.media.media.Media.characteristic_impedance

Media.characteristic_impedance

Characterisitc impedance

The characteristic_impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the characteristic impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns characteristic_impedance: numpy.ndarray

skrf.media.media.Media.propagation constant

Media.propagation_constant

Propagation constant

The propagation constant can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the propagation constant to be dynamic, meaning changing with some attribute of the media. See ___init___() for more explanation.

Returns propagation_constant: numpy.ndarray

complex propagation constant for this media

Notes

propagation_constant must adhere to the following convention,

- positive real(propagation_constant) = attenuation
- positive imag(propagation_constant) = forward propagation

skrf.media.media.Media.z0

Media.z0

Port Impedance

The port impedance is usually equal to the characteristic_impedance. Therefore, if the port impedance is *None* then this will return characteristic_impedance.

However, in some cases such as rectangular waveguide, the port impedance is traditionally set to 1 (normalized). In such a case this property may be used.

The Port Impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the Port Impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns port_impedance: numpy.ndarray

the media's port impedance

Methods

init	The Media initializer.
capacitor	Capacitor
delay_load	Delayed load
delay_open	Delayed open transmission line
delay_short	Delayed Short
electrical_length	calculates the electrical length for a given distance, at
from_csv	create a Media from numerical values stored in a csv file.
<pre>guess_length_of_delay_short</pre>	Guess physical length of a delay short.
impedance_mismatch	Two-port network for an impedance miss-match
inductor	Inductor
line	Matched transmission line of given length
load	Load of given reflection coefficient.
match	Perfect matched load ($\Gamma_0 = 0$).
open	Open ($\Gamma_0 = 1$)
resistor	Resistor
short	Short ($\Gamma_0 = -1$)
shunt	Shunts a Network
shunt_capacitor	Shunted capacitor
shunt_delay_load	Shunted delayed load
shunt_delay_open	Shunted delayed open
shunt_delay_short	Shunted delayed short
shunt_inductor	Shunted inductor
splitter	Ideal, lossless n-way splitter.
tee	Ideal, lossless tee.
	Continued on next page

Table 3.43 – continued from previous page

theta_2_d	Converts electrical length to physical distance.
thru	Matched transmission line of length 0.
white_gaussian_polar	Complex zero-mean gaussian white-noise network.
write_csv	write this media's frequency, z0, and gamma to a csv file.

skrf.media.media.Media.__init__

Media.__init__ (frequency, propagation_constant, characteristic_impedance, z0=None)
The Media initializer.

This initializer has flexible argument types. The parameters *propagation_constant*, *characterisitc_impedance* and *z0* can all be either static or dynamic. This is achieved by allowing those arguments to be either:

- •functions which take no arguments or
- •values (numbers or arrays)

In the case where the media's propagation constant may change after initialization, because you adjusted a parameter of the media, then passing the propagation_constant as a function allows it to change when the media's parameters do.

Parameters frequency: Frequency object

frequency band of this transmission line medium

propagation_constant : number, array-like, or a function

propagation constant for the medium.

characteristic_impedance: number,array-like, or a function

characteristic impedance of transmission line medium.

z0: number, array-like, or a function

the port impedance for media, IF its different from the characterisite impedance of the transmission line medium (None) [a number]. if z0= None then will set to characterisite impedance

See Also:

from_csv() function to create a Media object from a csv file containing gamma/z0

Notes

propagation_constant must adhere to the following convention,

- positive real(gamma) = attenuation
- positive imag(gamma) = forward propagation

the z0 parameter is needed in some cases. For example, the RectangularWaveguide is an example where you may need this, because the characteristic impedance is frequency dependent, but the touchstone's created by most VNA's have z0=1

skrf.media.media.Media.capacitor Media.capacitor(C, **kwargs) Capacitor **Parameters** C: number, array Capacitance, in Farads. If this is an array, must be of same length as frequency vector. **kwargs : key word arguments passed to match (), which is called initially to create a 'blank' network. **Returns** capacitor: a 2-port Network See Also: match function called to create a 'blank' network skrf.media.media.Media.delay_load Media.delay_load(Gamma0, d, unit='m', **kwargs) Delayed load A load with reflection coefficient *Gamma0* at the end of a matched line of length d. Parameters Gamma0: number, array-like reflection coefficient of load (not in dB) d: number the length of transmissin line (see unit argument) unit : ['m','deg','rad'] the units of d. possible options are: • *m* : meters, physical length in meters (default) • deg :degrees, electrical length in degrees • rad :radians, electrical length in radians **kwargs : key word arguments passed to match (), which is called initially to create a 'blank' network. Returns delay_load : Network object a delayed load See Also: line creates the network for line load creates the network for the load

Notes

This calls

```
line(d,unit, **kwargs) ** load(Gamma0, **kwargs)
     Examples
     >>> my_media.delay_load(-.5, 90, 'deg', z0=50)
skrf.media.media.Media.delay_open
Media.delay_open(d, unit='m', **kwargs)
     Delayed open transmission line
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay_open: Network object
                   a delayed open
     See Also:
     delay_load delay_short just calls this function
skrf.media.media.Media.delay short
Media.delay_short (d, unit='m', **kwargs)
     Delayed Short
     A transmission line of given length terminated with a short.
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
```

```
Returns delay_short: Network object
                  a delayed short
     See Also:
     delay_load delay_short just calls this function
skrf.media.media.Media.electrical length
Media.electrical_length(d, deg=False)
     calculates the electrical length for a given distance, at the center frequency.
          Parameters d: number or array-like :
                  delay distance, in meters
               deg: Boolean:
                  return electral length in deg?
          Returns theta: number or array-like:
                  electrical length in radians or degrees, depending on value of deg.
skrf.media.media.Media.from csv
classmethod Media.from csv(filename, *args, **kwargs)
     create a Media from numerical values stored in a csv file.
     the csv file format must be written by the function write_csv() which produces the following format
          f[$unit], Re(Z0), Im(Z0), Re(gamma), Im(gamma), Re(port Z0), Im(port Z0) 1, 1, 1, 1, 1, 1, 1, 2, 1,
          1, 1, 1, 1, 1 .....
skrf.media.media.Media.guess_length_of_delay_short
Media.guess_length_of_delay_short (aNtwk)
     Guess physical length of a delay short.
     Unwraps the phase and determines the slope, which is then used in conjunction with
     propagation_constant to estimate the physical distance to the short.
          Parameters aNtwk: Network object
                  (note: if this is a measurment it needs to be normalized to the reference plane)
skrf.media.media.Media.impedance_mismatch
Media.impedance_mismatch(z1, z2, **kwargs)
     Two-port network for an impedance miss-match
          Parameters z1: number, or array-like
                  complex impedance of port 1
               z2: number, or array-like
                  complex impedance of port 2
```

```
**kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns missmatch: Network object
                   a 2-port network representing the impedance missmatch
     See Also:
     match called to create a 'blank' network
     Notes
     If z1 and z2 are arrays, they must be of same length as the Media.frequency.npoints
skrf.media.media.Media.inductor
Media.inductor(L, **kwargs)
     Inductor
           Parameters L: number, array
                   Inductance, in Henrys. If this is an array, must be of same length as frequency vector.
               **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns inductor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.media.Media.line
Media.line (d, unit='m', **kwargs)
     Matched transmission line of given length
     The units of length are interpreted according to the value of unit.
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns line: Network object
```

matched tranmission line of given length

```
Examples
```

```
>>> my_media.line(90, 'deg', z0=50)
skrf.media.media.Media.load
Media.load(Gamma0, nports=1, **kwargs)
     Load of given reflection coefficient.
           Parameters Gamma0: number, array-like
                   Reflection coefficient of load (linear, not in db). If its an array it must be of shape:
                   kxnxn, where k is #frequency points in media, and n is nports
               nports: int
                   number of ports
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns load :class: '~skrf.network.Network' object :
                   n-port load, where S = Gamma0*eye(...)
skrf.media.media.Media.match
Media.match (nports=1, z0=None, **kwargs)
     Perfect matched load (\Gamma_0 = 0).
           Parameters nports: int
                   number of ports
               z0: number, or array-like
                   characterisitc impedance. Default is None, in which case the Media's z0 is used. This
                   sets the resultant Network's z0.
               **kwargs: key word arguments
                   passed to Network initializer
           Returns match: Network object
                   a n-port match
```

Examples

```
>>> my_match = my_media.match(2,z0 = 50, name='Super Awesome Match')
```

skrf.media.media.Media.open

```
Media.open (nports=1, **kwargs)
      Open (\Gamma_0 = 1)
           Parameters nports: int
                   number of ports
               **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns match: Network object
                   a n-port open circuit
      See Also:
      match function called to create a 'blank' network
skrf.media.media.Media.resistor
Media.resistor(R, *args, **kwargs)
      Resistor
           Parameters R: number, array
                   Resistance, in Ohms. If this is an array, must be of same length as frequency vector.
               *args, **kwargs: arguments, key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns resistor: a 2-port Network
      See Also:
      match function called to create a 'blank' network
skrf.media.media.Media.short
Media.short(nports=1, **kwargs)
      Short (\Gamma_0 = -1)
           Parameters nports: int
                   number of ports
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns match: Network object
                   a n-port short circuit
      See Also:
      match function called to create a 'blank' network
```

skrf.media.media.Media.shunt

```
Media.shunt (ntwk, **kwargs)
     Shunts a Network
     This creates a tee () and connects connects ntwk to port 1, and returns the result
          Parameters ntwk: Network object
              **kwargs: keyword arguments
                  passed to tee()
          Returns shunted_ntwk: Network object
                  a shunted a ntwk. The resultant shunted ntwk will have (2 + ntwk.number of ports -1)
                  ports.
skrf.media.media.Media.shunt_capacitor
Media.shunt_capacitor(C, *args, **kwargs)
     Shunted capacitor
          Parameters C: number, array-like
                  Capacitance in Farads.
              *args, **kwargs: arguments, keyword arguments
                  passed to func: delay_open
          Returns shunt_capacitor: Network object
                  shunted capcitor(2-port)
     Notes
     This calls:
     shunt(capacitor(C, *args, **kwargs))
skrf.media.media.Media.shunt delay load
Media.shunt_delay_load(*args, **kwargs)
     Shunted delayed load
          Parameters *args,**kwargs: arguments, keyword arguments
                  passed to func: delay_load
          Returns shunt_delay_load : Network object
                  a shunted delayed load (2-port)
```

Notes This calls: shunt(delay_load(*args, **kwargs)) skrf.media.media.Media.shunt_delay_open Media.shunt_delay_open(*args, **kwargs) Shunted delayed open Parameters *args,**kwargs: arguments, keyword arguments passed to func: delay_open Returns shunt_delay_open: Network object shunted delayed open (2-port) Notes This calls: shunt(delay_open(*args, **kwargs)) skrf.media.media.Media.shunt_delay_short Media.shunt_delay_short(*args, **kwargs) Shunted delayed short Parameters *args, **kwargs : arguments, keyword arguments passed to func: delay_open Returns shunt_delay_load : Network object shunted delayed open (2-port) **Notes** This calls: shunt(delay_short(*args, **kwargs)) skrf.media.media.Media.shunt_inductor Media.shunt_inductor(L, *args, **kwargs) Shunted inductor

Parameters L : number, array-like Inductance in Farads.

*args,**kwargs: arguments, keyword arguments

```
passed to func: delay_open
           Returns shunt_inductor: Network object
                   shunted inductor(2-port)
      Notes
      This calls:
      shunt(inductor(C,*args, **kwargs))
skrf.media.media.Media.splitter
Media.splitter(nports, **kwargs)
      Ideal, lossless n-way splitter.
           Parameters nports: int
                   number of ports
               **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns tee: Network object
                   a n-port splitter
      See Also:
      match called to create a 'blank' network
skrf.media.media.Media.tee
Media.tee(**kwargs)
      Ideal, lossless tee. (3-port splitter)
           Parameters **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns tee: Network object
                   a 3-port splitter
      See Also:
      splitter this just calls splitter(3)
      match called to create a 'blank' network
skrf.media.media.Media.theta 2 d
Media.theta_2_d(theta, deg=True)
      Converts electrical length to physical distance.
      The given electrical length is to be at the center frequency.
```

```
Parameters theta: number
                   electrical length, at band center (see deg for unit)
               deg: Boolean
                   is theta in degrees?
           Returns d: number
                   physical distance in meters
skrf.media.media.Media.thru
Media.thru(**kwargs)
     Matched transmission line of length 0.
           Parameters **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns thru: Network object
                   matched tranmission line of 0 length
     See Also:
     line this just calls line(0)
skrf.media.media.Media.white_gaussian_polar
Media.white_gaussian_polar(phase_dev, mag_dev, n_ports=1, **kwargs)
     Complex zero-mean gaussian white-noise network.
     Creates a network whose s-matrix is complex zero-mean gaussian white-noise, of given standard deviations for
     phase and magnitude components. This 'noise' network can be added to networks to simulate additive noise.
           Parameters phase_mag: number
                   standard deviation of magnitude
               phase_dev : number
                   standard deviation of phase
               n_ports: int
                   number of ports.
               **kwargs: passed to Network
                   initializer
           Returns result: Network object
```

a noise network

skrf.media.media.Media.write csv

Media.write_csv(filename='f, gamma, z0.csv')

write this media's frequency, z0, and gamma to a csv file.

Parameters filename: string

file name to write out data to

See Also:

from_csv class method to initialize Media object from a csv file written from this function

3.11.2 Transmission Line Classes

DistributedCircuit	Generic, distributed circuit TEM transmission line
RectangularWaveguide	Rectangular Waveguide medium.
CPW	Coplanar waveguide class
Freespace	Represents a plane-wave in a homogeneous freespace, defined by the space's relative permativity and

skrf.media.distributedCircuit.DistributedCircuit

Generic, distributed circuit TEM transmission line

A TEM transmission line, defined in terms of distributed impedance and admittance values. A Distributed Circuit may be defined in terms of the following attributes,

Quantity	Symbol	Property
Distributed Capacitance	$C^{'}$	С
Distributed Inductance	$I^{'}$	I
Distributed Resistance	$R^{'}$	R
Distributed Conductance	$G^{'}$	G

From these, the following quantities may be calculated, which are functions of angular frequency (ω) :

Quantity	Symbol	Property
Distributed Impedance	$Z^{'} = R^{'} + j\omega I^{'}$	Z
Distributed Admittance	$Y' = G' + j\omega C'$	Y

From these we can calculate properties which define their wave behavior:

Quantity	Symbol	Method
Characteristic Impedance	$Z_0 = \sqrt{\frac{Z'}{Y'}}$	Z0()
Propagation Constant	$\gamma = \sqrt{Z'Y'}$	gamma()

Given the following definitions, the components of propagation constant are interpreted as follows:

$$+\Re e\{\gamma\}=$$
 attenuation $-\Im m\{\gamma\}=$ forward propagation

Attributes

Y	Distributed Admittance, Y
Z	Distributed Impedance, $Z^{'}$
characteristic_impedance	Characterisitc impedance
propagation_constant	Propagation constant
z0	Port Impedance

skrf.media.distributedCircuit.DistributedCircuit.Y

Defined as

$$Y^{'} = G^{'} + j\omega C^{'}$$

Returns Y: numpy.ndarray

Distributed Admittance in units of S/m

skrf.media.distributedCircuit.DistributedCircuit.Z

Distributed Circuit. ${f Z}$ Distributed Impedance, $Z^{'}$

Defined as

$$Z^{'}=R^{'}+j\omega I^{'}$$

Returns Z : numpy.ndarray

Distributed impedance in units of ohm/m

$skrf. media. distributed Circuit. Distributed Circuit. characteristic_impedance$

DistributedCircuit.characteristic_impedance

Characterisitc impedance

The characteristic_impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the characteristic impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns characteristic_impedance: numpy.ndarray

$skrf. media. distributed Circuit. Distributed Circuit. propagation_constant$

DistributedCircuit.propagation_constant

Propagation constant

The propagation constant can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the propagation constant to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns propagation_constant: numpy.ndarray

complex propagation constant for this media

Notes

propagation_constant must adhere to the following convention,

- positive real(propagation_constant) = attenuation
- positive imag(propagation_constant) = forward propagation

skrf.media.distributedCircuit.DistributedCircuit.z0

DistributedCircuit.**z0**

Port Impedance

The port impedance is usually equal to the characteristic_impedance. Therefore, if the port impedance is *None* then this will return characteristic_impedance.

However, in some cases such as rectangular waveguide, the port impedance is traditionally set to 1 (normalized). In such a case this property may be used.

The Port Impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the Port Impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns port_impedance: numpy.ndarray

the media's port impedance

Methods

Ζ0	Characteristic Impedance, Z0
	* '
init	Distributed Circuit constructor.
capacitor	Capacitor
delay_load	Delayed load
delay_open	Delayed open transmission line
delay_short	Delayed Short
electrical_length	calculates the electrical length for a given distance, at
from_Media	Initializes a DistributedCircuit from an existing
from_csv	create a Media from numerical values stored in a csv file.
gamma	Propagation Constant, γ
<pre>guess_length_of_delay_short</pre>	Guess physical length of a delay short.
impedance_mismatch	Two-port network for an impedance miss-match
inductor	Inductor
line	Matched transmission line of given length
load	Load of given reflection coefficient.
match	Perfect matched load ($\Gamma_0 = 0$).
open	Open ($\Gamma_0 = 1$)
resistor	Resistor
short	Short ($\Gamma_0 = -1$)
shunt	Shunts a Network
	Continued on next page

Table 3.46 – continued from previous page

shunt_capacitor	Shunted capacitor
shunt_delay_load	Shunted delayed load
shunt_delay_open	Shunted delayed open
shunt_delay_short	Shunted delayed short
shunt_inductor	Shunted inductor
splitter	Ideal, lossless n-way splitter.
tee	Ideal, lossless tee.
theta_2_d	Converts electrical length to physical distance.
thru	Matched transmission line of length 0.
white_gaussian_polar	Complex zero-mean gaussian white-noise network.
write_csv	write this media's frequency, z0, and gamma to a csv file.

skrf.media.distributedCircuit.DistributedCircuit.Z0

DistributedCircuit. ${f 20}$ () Characteristic Impedance, ${\it Z0}$

$$Z_0 = \sqrt{\frac{Z'}{Y'}}$$

Returns Z0: numpy.ndarray

Characteristic Impedance in units of ohms

skrf.media.distributedCircuit.DistributedCircuit.__init__

DistributedCircuit.__init__ (frequency, C, I, R, G, *args, **kwargs)

Distributed Circuit constructor.

Parameters frequency: Frequency object

C : number, or array-like

distributed capacitance, in F/m

I: number, or array-like

distributed inductance, in H/m

R: number, or array-like

distributed resistance, in Ohm/m

G: number, or array-like

distributed conductance, in S/m

Notes

C,I,R,G can all be vectors as long as they are the same length

This object can be constructed from a Media instance too, see the classmethod from_Media()

skrf.media.distributedCircuit.DistributedCircuit.capacitor

```
DistributedCircuit.capacitor(C, **kwargs)
     Capacitor
           Parameters C: number, array
                   Capacitance, in Farads. If this is an array, must be of same length as frequency vector.
               **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns capacitor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.distributedCircuit.DistributedCircuit.delay_load
DistributedCircuit.delay_load(Gamma0, d, unit='m', **kwargs)
     Delayed load
     A load with reflection coefficient Gamma0 at the end of a matched line of length d.
           Parameters Gamma0: number, array-like
                   reflection coefficient of load (not in dB)
               d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay_load : Network object
                   a delayed load
     See Also:
     line creates the network for line
     load creates the network for the load
     Notes
     This calls
```

```
line(d,unit, **kwargs) ** load(Gamma0, **kwargs)
     Examples
     >>> my_media.delay_load(-.5, 90, 'deg', z0=50)
skrf.media.distributedCircuit.DistributedCircuit.delay_open
DistributedCircuit.delay_open (d, unit='m', **kwargs)
     Delayed open transmission line
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay_open: Network object
                   a delayed open
     See Also:
     delay_load delay_short just calls this function
skrf.media.distributedCircuit.DistributedCircuit.delay short
DistributedCircuit.delay_short (d, unit='m', **kwargs)
     Delayed Short
     A transmission line of given length terminated with a short.
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
```

```
Returns delay_short: Network object
                   a delayed short
     See Also:
     delay_load delay_short just calls this function
skrf.media. distributed Circuit. Distributed Circuit. electrical\_length
DistributedCircuit.electrical_length(d, deg=False)
     calculates the electrical length for a given distance, at the center frequency.
           Parameters d: number or array-like :
                   delay distance, in meters
               deg: Boolean:
                   return electral length in deg?
           Returns theta: number or array-like:
                   electrical length in radians or degrees, depending on value of deg.
skrf.media.distributedCircuit.DistributedCircuit.from Media
classmethod DistributedCircuit.from_Media (my_media, *args, **kwargs)
     Initializes a DistributedCircuit from an existing :class:'~skrf.media.media.Media' instance.
skrf.media.distributedCircuit.DistributedCircuit.from_csv
classmethod DistributedCircuit.from_csv (filename, *args, **kwargs)
     create a Media from numerical values stored in a csv file.
     the csv file format must be written by the function write_csv() which produces the following format
           f[$unit], Re(Z0), Im(Z0), Re(gamma), Im(gamma), Re(port Z0), Im(port Z0) 1, 1, 1, 1, 1, 1, 1, 2, 1,
           1, 1, 1, 1, 1 .....
skrf.media.distributedCircuit.DistributedCircuit.gamma
DistributedCircuit.gamma()
     Propagation Constant, \gamma
     Defined as,
                                                    \gamma = \sqrt{Z'Y'}
```

Returns gamma: numpy.ndarray

Propagation Constant,

Notes

The components of propagation constant are interpreted as follows:

positive real(gamma) = attenuation positive imag(gamma) = forward propagation

skrf.media.distributedCircuit.DistributedCircuit.guess length of delay short

```
DistributedCircuit.guess_length_of_delay_short(aNtwk)
```

Guess physical length of a delay short.

Unwraps the phase and determines the slope, which is then used in conjunction with propagation_constant to estimate the physical distance to the short.

Parameters aNtwk: Network object

(note: if this is a measurment it needs to be normalized to the reference plane)

skrf.media.distributedCircuit.DistributedCircuit.impedance_mismatch

```
DistributedCircuit.impedance_mismatch(z1, z2, **kwargs)
```

Two-port network for an impedance miss-match

Parameters z1: number, or array-like

complex impedance of port 1

z2: number, or array-like

complex impedance of port 2

**kwargs: key word arguments

passed to match (), which is called initially to create a 'blank' network.

Returns missmatch: Network object

a 2-port network representing the impedance missmatch

See Also:

match called to create a 'blank' network

Notes

If z1 and z2 are arrays, they must be of same length as the Media.frequency.npoints

skrf.media.distributedCircuit.DistributedCircuit.inductor

```
DistributedCircuit.inductor(L, **kwargs)
Inductor
```

D 4 T 1

Parameters L: number, array

Inductance, in Henrys. If this is an array, must be of same length as frequency vector.

**kwargs : key word arguments

```
Returns inductor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.distributedCircuit.DistributedCircuit.line
DistributedCircuit.line(d, unit='m', **kwargs)
     Matched transmission line of given length
     The units of length are interpreted according to the value of unit.
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns line: Network object
                   matched tranmission line of given length
     Examples
     >>> my_media.line(90, 'deg', z0=50)
skrf.media.distributedCircuit.DistributedCircuit.load
DistributedCircuit.load(Gamma0, nports=1, **kwargs)
     Load of given reflection coefficient.
           Parameters Gamma0: number, array-like
                   Reflection coefficient of load (linear, not in db). If its an array it must be of shape:
                   kxnxn, where k is #frequency points in media, and n is nports
               nports: int
                   number of ports
               **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns load :class: '~skrf.network.Network' object :
                   n-port load, where S = Gamma0*eye(...)
```

passed to match (), which is called initially to create a 'blank' network.

skrf.media.distributedCircuit.DistributedCircuit.match

```
DistributedCircuit.match(nports=1, z0=None, **kwargs)
     Perfect matched load (\Gamma_0 = 0).
          Parameters nports: int
                   number of ports
               z0: number, or array-like
                   characterisite impedance. Default is None, in which case the Media's z0 is used. This
                   sets the resultant Network's z0.
               **kwargs: key word arguments
                   passed to Network initializer
          Returns match: Network object
                  a n-port match
     Examples
     >>> my_match = my_media.match(2,z0 = 50, name='Super Awesome Match')
skrf.media.distributedCircuit.DistributedCircuit.open
DistributedCircuit.open(nports=1, **kwargs)
     Open (\Gamma_0 = 1)
          Parameters nports: int
                  number of ports
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
          Returns match: Network object
                  a n-port open circuit
     See Also:
     match function called to create a 'blank' network
skrf.media.distributedCircuit.DistributedCircuit.resistor
DistributedCircuit.resistor(R, *args, **kwargs)
     Resistor
          Parameters R: number, array
                   Resistance, in Ohms. If this is an array, must be of same length as frequency vector.
               *args, **kwargs: arguments, key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
```

```
Returns resistor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.distributedCircuit.DistributedCircuit.short
DistributedCircuit.short(nports=1, **kwargs)
     Short (\Gamma_0 = -1)
          Parameters nports: int
                  number of ports
               **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns match: Network object
                  a n-port short circuit
     See Also:
     match function called to create a 'blank' network
skrf.media.distributedCircuit.DistributedCircuit.shunt
DistributedCircuit.shunt(ntwk, **kwargs)
     Shunts a Network
     This creates a tee () and connects connects ntwk to port 1, and returns the result
          Parameters ntwk: Network object
              **kwargs: keyword arguments
                  passed to tee()
          Returns shunted_ntwk: Network object
                  a shunted a ntwk. The resultant shunted_ntwk will have (2 + ntwk.number_of_ports -1)
                  ports.
skrf.media.distributedCircuit.DistributedCircuit.shunt_capacitor
DistributedCircuit.shunt_capacitor(C, *args, **kwargs)
     Shunted capacitor
          Parameters C : number, array-like
                  Capacitance in Farads.
               *args, **kwargs: arguments, keyword arguments
                  passed to func: delay_open
          Returns shunt_capacitor: Network object
                  shunted capcitor(2-port)
```

Notes This calls: shunt(capacitor(C,*args, **kwargs)) $skrf.media.distributed Circuit. Distributed Circuit. shunt_delay_load$ DistributedCircuit.shunt_delay_load(*args, **kwargs) Shunted delayed load **Parameters** *args,**kwargs: arguments, keyword arguments passed to func: delay_load Returns shunt_delay_load : Network object a shunted delayed load (2-port) **Notes** This calls: shunt(delay_load(*args, **kwargs)) skrf.media.distributedCircuit.DistributedCircuit.shunt delay open DistributedCircuit.shunt_delay_open(*args, **kwargs) Shunted delayed open Parameters *args,**kwargs: arguments, keyword arguments passed to func: delay_open Returns shunt_delay_open: Network object shunted delayed open (2-port) **Notes** This calls: shunt(delay_open(*args, **kwargs)) $skrf.media.distributed Circuit. Distributed Circuit. shunt_delay_short$ DistributedCircuit.shunt_delay_short(*args, **kwargs) Shunted delayed short **Parameters** *args,**kwargs: arguments, keyword arguments

passed to func: delay_open

Returns shunt_delay_load : Network object
shunted delayed open (2-port)

```
Notes
     This calls:
     shunt(delay_short(*args, **kwargs))
skrf.media.distributedCircuit.DistributedCircuit.shunt_inductor
DistributedCircuit.shunt_inductor(L, *args, **kwargs)
     Shunted inductor
          Parameters L : number, array-like
                  Inductance in Farads.
               *args,**kwargs: arguments, keyword arguments
                  passed to func: delay_open
          Returns shunt_inductor: Network object
                  shunted inductor(2-port)
     Notes
     This calls:
     shunt(inductor(C, *args, **kwargs))
skrf.media.distributedCircuit.DistributedCircuit.splitter
DistributedCircuit.splitter(nports, **kwargs)
     Ideal, lossless n-way splitter.
          Parameters nports: int
                  number of ports
              **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns tee: Network object
                  a n-port splitter
     See Also:
     match called to create a 'blank' network
skrf.media.distributedCircuit.DistributedCircuit.tee
DistributedCircuit.tee(**kwargs)
     Ideal, lossless tee. (3-port splitter)
          Parameters **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
```

```
Returns tee: Network object
                   a 3-port splitter
     See Also:
     splitter this just calls splitter(3)
     match called to create a 'blank' network
skrf.media.distributedCircuit.DistributedCircuit.theta 2 d
DistributedCircuit.theta_2_d(theta, deg=True)
     Converts electrical length to physical distance.
     The given electrical length is to be at the center frequency.
           Parameters theta: number
                   electrical length, at band center (see deg for unit)
               deg: Boolean
                   is theta in degrees?
           Returns d: number
                   physical distance in meters
skrf.media.distributedCircuit.DistributedCircuit.thru
DistributedCircuit.thru(**kwargs)
     Matched transmission line of length 0.
           Parameters **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns thru: Network object
                   matched tranmission line of 0 length
     See Also:
     line this just calls line(0)
skrf.media.distributedCircuit.DistributedCircuit.white gaussian polar
DistributedCircuit.white_qaussian_polar(phase_dev, mag_dev, n_ports=1, **kwargs)
     Complex zero-mean gaussian white-noise network.
     Creates a network whose s-matrix is complex zero-mean gaussian white-noise, of given standard deviations for
     phase and magnitude components. This 'noise' network can be added to networks to simulate additive noise.
           Parameters phase_mag: number
                   standard deviation of magnitude
               phase dev: number
                   standard deviation of phase
```

n_ports: int

number of ports.

**kwargs: passed to Network

initializer

Returns result: Network object

a noise network

skrf.media.distributedCircuit.DistributedCircuit.write_csv

```
DistributedCircuit.write_csv (filename='f, gamma, z0.csv') write this media's frequency, z0, and gamma to a csv file.
```

Parameters filename: string

file name to write out data to

See Also:

from_csv class method to initialize Media object from a csv file written from this function

skrf.media.rectangularWaveguide.RectangularWaveguide

```
class skrf.media.rectangularWaveguide.RectangularWaveguide (frequency, a, b=None, mode\_type='te', m=1, n=0, ep\_r=1, mu\_r=1, *args, **kwargs)
```

Rectangular Waveguide medium.

Represents a single mode of a homogeneously filled rectangular waveguide of cross-section $a \times b$. The mode is determined by mode-type (te or tm) and mode indecies (m and n).

Quantity	Symbol	Variable
Characteristic Wave Number	k_0	k0
Cut-off Wave Number	k_c	kc
Longitudinal Wave Number	k_z	kz
Transverse Wave Number (a)	k_x	kx
Transverse Wave Number (b)	k_y	ky
Characteristic Impedance	Z_0	Z0

Attributes

characteristic_impedance	Characterisitc impedance
ер	The permativity of the filling material
k0	Characteristic wave number
kc	Cut-off wave number
kx	Eigen value in the 'a' direction
ky	Eigen-value in the <i>b</i> direction.
mu	The permeability of the filling material
propagation_constant	Propagation constant
z 0	Port Impedance

skrf.media.rectangularWaveguide.RectangularWaveguide.characteristic impedance

 ${\tt RectangularWaveguide.characteristic_impedance}$

Characterisitc impedance

The characteristic_impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the characteristic impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns characteristic_impedance: numpy.ndarray

skrf.media.rectangularWaveguide.RectangularWaveguide.ep

RectangularWaveguide.ep

The permativity of the filling material

Returns ep: number

filling material's relative permativity

skrf.media.rectangularWaveguide.RectangularWaveguide.k0

RectangularWaveguide.k0

Characteristic wave number

Returns k0: number

characteristic wave number

skrf.media.rectangularWaveguide.RectangularWaveguide.kc

RectangularWaveguide.kc

Cut-off wave number

Defined as

$$k_c = \sqrt{k_x^2 + k_y^2} = \sqrt{m \frac{\pi^2}{a} + n \frac{\pi^2}{b}}$$

Returns kc: number

cut-off wavenumber

skrf.media.rectangularWaveguide.RectangularWaveguide.kx

RectangularWaveguide.kx

Eigen value in the 'a' direction

Defined as

$$k_x = m\frac{\pi}{a}$$

Returns kx: number

eigen-value in a direction

skrf.media.rectangularWaveguide.RectangularWaveguide.ky

RectangularWaveguide.ky

Eigen-value in the *b* direction.

Defined as

$$k_y = n\frac{\pi}{b}$$

Returns ky: number

eigen-value in b direction

skrf.media.rectangularWaveguide.RectangularWaveguide.mu

RectangularWaveguide.mu

The permeability of the filling material

Returns mu: number

filling material's relative permeability

skrf.media.rectangularWaveguide.RectangularWaveguide.propagation_constant

RectangularWaveguide.propagation_constant

Propagation constant

The propagation constant can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the propagation constant to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns propagation_constant: numpy.ndarray

complex propagation constant for this media

Notes

propagation_constant must adhere to the following convention,

- positive real(propagation_constant) = attenuation
- positive imag(propagation_constant) = forward propagation

skrf.media.rectangularWaveguide.RectangularWaveguide.z0

RectangularWaveguide.z0

Port Impedance

The port impedance is usually equal to the characteristic_impedance. Therefore, if the port impedance is *None* then this will return characteristic_impedance.

However, in some cases such as rectangular waveguide, the port impedance is traditionally set to 1 (normalized). In such a case this property may be used.

The Port Impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the Port Impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns port_impedance: numpy.ndarray

the media's port impedance

Methods

Z0	The characteristic impedance
init	RectangularWaveguide initializer
capacitor	Capacitor
delay_load	Delayed load
delay_open	Delayed open transmission line
delay_short	Delayed Short
electrical_length	calculates the electrical length for a given distance, at
from_csv	create a Media from numerical values stored in a csv file.
<pre>guess_length_of_delay_short</pre>	Guess physical length of a delay short.
impedance_mismatch	Two-port network for an impedance miss-match
inductor	Inductor
kz	The Longitudinal wave number, aka propagation constant.
line	Matched transmission line of given length
load	Load of given reflection coefficient.
match	Perfect matched load ($\Gamma_0 = 0$).
open	Open ($\Gamma_0 = 1$)
resistor	Resistor
short	Short $(\Gamma_0 = -1)$
shunt	Shunts a Network
shunt_capacitor	Shunted capacitor
shunt_delay_load	Shunted delayed load
shunt_delay_open	Shunted delayed open
shunt_delay_short	Shunted delayed short
shunt_inductor	Shunted inductor
splitter	Ideal, lossless n-way splitter.
tee	Ideal, lossless tee.
theta_2_d	Converts electrical length to physical distance.
thru	Matched transmission line of length 0.
white_gaussian_polar	Complex zero-mean gaussian white-noise network.
write_csv	write this media's frequency, z0, and gamma to a csv file.

skrf. media. rectangular Waveguide. Rectangular Waveguide. Z0

RectangularWaveguide.Z0()

The characteristic impedance

skrf.media.rectangularWaveguide.RectangularWaveguide.__init__

RectangularWaveguide.__init__ (frequency, a, b=None, mode_type='te', m=1, n=0, ep_r=1, $mu_r=1$, **args, **kwargs)

RectangularWaveguide initializer

Parameters frequency: class:~skrf.frequency.Frequency object

frequency band for this media

```
a: number
    width of waveguide, in meters.
b: number
    height of waveguide, in meters. If None defaults to a/2
mode_type : ['te','tm']
    mode type, transverse electric (te) or transverse magnetic (tm) to-z. where z is direction
    of propagation
m: int
    mode index in 'a'-direction
n: int
    mode index in 'b'-direction
ep_r: number, array-like,
    filling material's relative permativity
mu_r: number, array-like
    filling material's relative permeability
*args,**kwargs: arguments, keywrod arguments
    passed to Media's constructor (__init___()
```

Examples

Most common usage is standard aspect ratio (2:1) dominant mode, TE10 mode of wr10 waveguide can be constructed by

```
>>> freq = rf.Frequency(75,110,101,'ghz')
>>> rf.RectangularWaveguide(freq, 100*mil)
```

skrf.media.rectangularWaveguide.RectangularWaveguide.capacitor

match function called to create a 'blank' network

```
RectangularWaveguide.capacitor (C, **kwargs)
Capacitor

Parameters C: number, array

Capacitance, in Farads. If this is an array, must be of same length as frequency vector.

**kwargs: key word arguments

passed to match(), which is called initially to create a 'blank' network.

Returns capacitor: a 2-port Network

See Also:
```

skrf.media.rectangularWaveguide.RectangularWaveguide.delay_load

```
RectangularWaveguide.delay_load(Gamma0, d, unit='m', **kwargs)
     Delayed load
     A load with reflection coefficient Gamma0 at the end of a matched line of length d.
          Parameters Gamma0: number, array-like
                  reflection coefficient of load (not in dB)
               d: number
                  the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                  the units of d. possible options are:
                     • m : meters, physical length in meters (default)
                     • deg :degrees, electrical length in degrees
                     • rad :radians, electrical length in radians
               **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns delay_load : Network object
                  a delayed load
     See Also:
     line creates the network for line
     load creates the network for the load
     Notes
     This calls
     line(d,unit, **kwargs) ** load(Gamma0, **kwargs)
     Examples
     >>> my_media.delay_load(-.5, 90, 'deg', z0=50)
skrf.media.rectangularWaveguide.RectangularWaveguide.delay_open
RectangularWaveguide.delay_open(d, unit='m', **kwargs)
     Delayed open transmission line
          Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
```

```
• m: meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay open: Network object
                   a delayed open
     See Also:
     delay_load delay_short just calls this function
skrf.media.rectangularWaveguide.RectangularWaveguide.delay_short
RectangularWaveguide.delay short (d, unit='m', **kwargs)
     Delayed Short
     A transmission line of given length terminated with a short.
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay short: Network object
                   a delayed short
     See Also:
     delay_load delay_short just calls this function
skrf.media.rectangularWaveguide.RectangularWaveguide.electrical_length
RectangularWaveguide.electrical_length(d, deg=False)
     calculates the electrical length for a given distance, at the center frequency.
           Parameters d: number or array-like :
                   delay distance, in meters
               deg: Boolean:
                   return electral length in deg?
           Returns theta: number or array-like:
```

electrical length in radians or degrees, depending on value of deg.

skrf.media.rectangularWaveguide.RectangularWaveguide.from_csv

```
classmethod RectangularWaveguide.from_csv (filename, *args, **kwargs)
    create a Media from numerical values stored in a csv file.

the csv file format must be written by the function write_csv() which produces the following format
    f[$unit], Re(Z0), Im(Z0), Re(gamma), Im(gamma), Re(port Z0), Im(port Z0) 1, 1, 1, 1, 1, 1, 1, 2, 1,
    1, 1, 1, 1, .....
```

skrf.media.rectangularWaveguide.RectangularWaveguide.guess length of delay short

```
RectangularWaveguide.guess_length_of_delay_short (aNtwk) Guess physical length of a delay short.
```

Unwraps the phase and determines the slope, which is then used in conjunction with propagation_constant to estimate the physical distance to the short.

```
Parameters aNtwk: Network object
```

(note: if this is a measurment it needs to be normalized to the reference plane)

skrf.media.rectangularWaveguide.RectangularWaveguide.impedance_mismatch

Returns missmatch: Network object

a 2-port network representing the impedance missmatch

See Also:

match called to create a 'blank' network

Notes

If z1 and z2 are arrays, they must be of same length as the Media.frequency.npoints

skrf.media.rectangularWaveguide.RectangularWaveguide.inductor

Rectangular Waveguide.inductor (L, **kwargs)Inductor

Parameters L: number, array

Inductance, in Henrys. If this is an array, must be of same length as frequency vector.

**kwargs : key word arguments

passed to match (), which is called initially to create a 'blank' network.

Returns inductor: a 2-port Network

See Also:

match function called to create a 'blank' network

skrf.media.rectangularWaveguide.RectangularWaveguide.kz

RectangularWaveguide.kz()

The Longitudinal wave number, aka propagation constant.

Defined as

$$k_z = \pm \sqrt{k_0^2 - k_c^2}$$

This is.

- IMAGINARY for propagating modes
- REAL for non-propagating modes,

Returns kz: number

The propagation constant

skrf. media. rectangular Waveguide. Rectangular Waveguide. line

RectangularWaveguide.line(d, unit='m', **kwargs)

Matched transmission line of given length

The units of *length* are interpreted according to the value of *unit*.

Parameters d: number

the length of transmissin line (see unit argument)

unit : ['m','deg','rad']

the units of d. possible options are:

- *m* : meters, physical length in meters (default)
- deg :degrees, electrical length in degrees
- rad :radians, electrical length in radians

**kwargs : key word arguments

passed to match (), which is called initially to create a 'blank' network.

```
Returns line: Network object matched transission line of given length
```

Examples

```
>>> my_media.line(90, 'deg', z0=50)
```

skrf.media.rectangularWaveguide.RectangularWaveguide.load

```
RectangularWaveguide.load(GammaO, nports=1, **kwargs)
Load of given reflection coefficient.
```

```
Parameters Gamma0: number, array-like
```

Reflection coefficient of load (linear, not in db). If its an array it must be of shape: kxnxn, where k is #frequency points in media, and n is *nports*

```
nports: int number of ports
```

**kwargs: key word arguments

passed to match (), which is called initially to create a 'blank' network.

Returns load :class: '~skrf.network.Network' object :

```
n-port load, where S = Gamma0*eye(...)
```

skrf.media.rectangularWaveguide.RectangularWaveguide.match

```
RectangularWaveguide.match (nports=1, z0=None, **kwargs)
Perfect matched load (\Gamma_0=0).

Parameters nports: int
```

z0: number, or array-like

number of ports

characterisitc impedance. Default is None, in which case the Media's z0 is used. This sets the resultant Network's z0.

```
**kwargs: key word arguments

passed to Network initializer

Returns match: Network object
```

a n-port match

Examples

```
>>> my_match = my_media.match(2,z0 = 50, name='Super Awesome Match')
```

skrf.media.rectangularWaveguide.RectangularWaveguide.open

```
RectangularWaveguide.open(nports=1, **kwargs)
     Open (\Gamma_0 = 1)
          Parameters nports: int
                   number of ports
               **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
          Returns match: Network object
                  a n-port open circuit
     See Also:
     match function called to create a 'blank' network
skrf.media.rectangularWaveguide.RectangularWaveguide.resistor
RectangularWaveguide.resistor(R, *args, **kwargs)
     Resistor
          Parameters R: number, array
                   Resistance, in Ohms. If this is an array, must be of same length as frequency vector.
               *args, **kwargs: arguments, key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns resistor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.rectangularWaveguide.RectangularWaveguide.short
RectangularWaveguide.short (nports=1, **kwargs)
     Short (\Gamma_0 = -1)
          Parameters nports: int
                  number of ports
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
          Returns match: Network object
                  a n-port short circuit
     See Also:
     match function called to create a 'blank' network
```

skrf.media.rectangularWaveguide.RectangularWaveguide.shunt

```
RectangularWaveguide.shunt(ntwk, **kwargs)
     Shunts a Network
     This creates a tee () and connects connects ntwk to port 1, and returns the result
          Parameters ntwk: Network object
              **kwargs: keyword arguments
                  passed to tee()
          Returns shunted_ntwk: Network object
                 a shunted a ntwk. The resultant shunted ntwk will have (2 + ntwk.number of ports -1)
                  ports.
skrf.media.rectangularWaveguide.RectangularWaveguide.shunt_capacitor
RectangularWaveguide.shunt_capacitor(C, *args, **kwargs)
     Shunted capacitor
          Parameters C: number, array-like
                  Capacitance in Farads.
              *args, **kwargs: arguments, keyword arguments
                  passed to func: delay_open
          Returns shunt_capacitor: Network object
                  shunted capcitor(2-port)
     Notes
     This calls:
     shunt(capacitor(C, *args, **kwargs))
skrf.media.rectangularWaveguide.RectangularWaveguide.shunt_delay_load
RectangularWaveguide.shunt_delay_load(*args, **kwargs)
     Shunted delayed load
          Parameters *args,**kwargs: arguments, keyword arguments
                 passed to func: delay_load
          Returns shunt_delay_load : Network object
                  a shunted delayed load (2-port)
```

Notes This calls: shunt(delay_load(*args, **kwargs)) skrf.media.rectangularWaveguide.RectangularWaveguide.shunt_delay_open RectangularWaveguide.shunt_delay_open(*args, **kwargs) Shunted delayed open Parameters *args, **kwargs : arguments, keyword arguments passed to func: delay_open Returns shunt_delay_open: Network object shunted delayed open (2-port) Notes This calls: shunt(delay_open(*args, **kwargs)) skrf.media.rectangularWaveguide.RectangularWaveguide.shunt_delay_short RectangularWaveguide.shunt_delay_short(*args, **kwargs) Shunted delayed short Parameters *args, **kwargs : arguments, keyword arguments passed to func: delay_open Returns shunt_delay_load : Network object shunted delayed open (2-port) **Notes** This calls: shunt(delay_short(*args, **kwargs)) skrf.media.rectangularWaveguide.RectangularWaveguide.shunt_inductor RectangularWaveguide.shunt_inductor(L, *args, **kwargs) Shunted inductor Parameters L: number, array-like Inductance in Farads.

*args,**kwargs: arguments, keyword arguments

```
passed to func: delay_open
          Returns shunt_inductor: Network object
                  shunted inductor(2-port)
     Notes
     This calls:
     shunt(inductor(C,*args, **kwargs))
skrf.media.rectangularWaveguide.RectangularWaveguide.splitter
RectangularWaveguide.splitter(nports, **kwargs)
     Ideal, lossless n-way splitter.
          Parameters nports: int
                  number of ports
              **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns tee: Network object
                  a n-port splitter
     See Also:
     match called to create a 'blank' network
skrf.media.rectangularWaveguide.RectangularWaveguide.tee
RectangularWaveguide.tee(**kwargs)
     Ideal, lossless tee. (3-port splitter)
          Parameters **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns tee: Network object
                  a 3-port splitter
     See Also:
     splitter this just calls splitter(3)
     match called to create a 'blank' network
skrf.media.rectangularWaveguide.RectangularWaveguide.theta 2 d
RectangularWaveguide.theta_2_d(theta, deg=True)
     Converts electrical length to physical distance.
     The given electrical length is to be at the center frequency.
```

```
Parameters theta: number
electrical length, at band center (see deg for unit)
deg: Boolean
is theta in degrees?

Returns d: number
physical distance in meters
```

skrf.media.rectangularWaveguide.RectangularWaveguide.thru

```
RectangularWaveguide.thru(**kwargs)

Matched transmission line of length 0.

Parameters **kwargs: key word arguments

passed to match(), which is called initially to create a 'blank' network.

Returns thru: Network object

matched transmission line of 0 length

See Also:

line this just calls line(0)
```

$skrf.media.rectangular Waveguide. Rectangular Waveguide. white \underline{\ \ \ } gaussian \underline{\ \ \ } polar$

```
RectangularWaveguide.white_gaussian_polar(phase_dev, mag_dev, n_ports=1, **kwargs)
Complex zero-mean gaussian white-noise network.
```

Creates a network whose s-matrix is complex zero-mean gaussian white-noise, of given standard deviations for phase and magnitude components. This 'noise' network can be added to networks to simulate additive noise.

```
Parameters phase_mag: number
    standard deviation of magnitude
    phase_dev: number
    standard deviation of phase
    n_ports: int
    number of ports.

**kwargs: passed to Network
    initializer

Returns result: Network object
    a noise network
```

skrf.media.rectangularWaveguide.RectangularWaveguide.write_csv

RectangularWaveguide.write_csv (filename='f, gamma, z0.csv') write this media's frequency, z0, and gamma to a csv file.

Parameters filename: string

file name to write out data to

See Also:

from_csv class method to initialize Media object from a csv file written from this function

skrf.media.cpw.CPW

This class was made from the technical documentation 35 provided by the ques project 36 . The variables and properties of this class are coincident with their derivations.

Attributes

K_ratio	intermediary parameter. see ques does on cpw lines.
alpha_conductor	Losses due to conductor resistivity
characteristic_impedance	Characterisitc impedance
ep_re	intermediary parameter. see ques does on cpw lines.
k1	intermediary parameter. see ques does on cpw lines.
propagation_constant	Propagation constant
z0	Port Impedance

skrf.media.cpw.CPW.K_ratio

CPW.K_ratio

intermediary parameter. see ques does on cpw lines.

skrf.media.cpw.CPW.alpha_conductor

CPW.alpha_conductor

Losses due to conductor resistivity

Returns alpha_conductor: array-like

lossyness due to conductor losses

See Also:

_____·

surface_resistivity : calculates surface resistivity

³⁵ http://qucs.sourceforge.net/docs/technical.pdf

³⁶ http://www.qucs.sourceforge.net/

skrf.media.cpw.CPW.characteristic_impedance

CPW.characteristic_impedance

Characterisitc impedance

The characteristic_impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the characteristic impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns characteristic_impedance: numpy.ndarray

skrf.media.cpw.CPW.ep_re

CPW.ep_re

intermediary parameter. see ques does on cpw lines.

skrf.media.cpw.CPW.k1

CPW.k1

intermediary parameter. see ques does on cpw lines.

skrf.media.cpw.CPW.propagation_constant

CPW.propagation_constant

Propagation constant

The propagation constant can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the propagation constant to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns propagation_constant: numpy.ndarray

complex propagation constant for this media

Notes

propagation_constant must adhere to the following convention,

- positive real(propagation_constant) = attenuation
- positive imag(propagation_constant) = forward propagation

skrf.media.cpw.CPW.z0

CPW.z0

Port Impedance

The port impedance is usually equal to the characteristic_impedance. Therefore, if the port impedance is *None* then this will return characteristic_impedance.

However, in some cases such as rectangular waveguide, the port impedance is traditionally set to 1 (normalized). In such a case this property may be used.

The Port Impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the Port Impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns port_impedance: numpy.ndarray

the media's port impedance

Methods

Z0	Characterisitc impedance
init	Coplanar Waveguide initializer
capacitor	Capacitor
delay_load	Delayed load
delay_open	Delayed open transmission line
delay_short	Delayed Short
electrical_length	calculates the electrical length for a given distance, at
from_csv	create a Media from numerical values stored in a csv file.
gamma	Propagation constant
<pre>guess_length_of_delay_short</pre>	Guess physical length of a delay short.
impedance_mismatch	Two-port network for an impedance miss-match
inductor	Inductor
line	Matched transmission line of given length
load	Load of given reflection coefficient.
match	Perfect matched load ($\Gamma_0 = 0$).
open	Open ($\Gamma_0 = 1$)
resistor	Resistor
short	Short $(\Gamma_0 = -1)$
shunt	Shunts a Network
shunt_capacitor	Shunted capacitor
shunt_delay_load	Shunted delayed load
shunt_delay_open	Shunted delayed open
shunt_delay_short	Shunted delayed short
shunt_inductor	Shunted inductor
splitter	Ideal, lossless n-way splitter.
tee	Ideal, lossless tee.
theta_2_d	Converts electrical length to physical distance.
thru	Matched transmission line of length 0.
white_gaussian_polar	Complex zero-mean gaussian white-noise network.
write_csv	write this media's frequency, z0, and gamma to a csv file.

skrf.media.cpw.CPW.Z0

CPW.**ZO**()

Characterisitc impedance

skrf.media.cpw.CPW.__init__

CPW.__init__ (frequency, w, s, ep_r, t=None, rho=None, *args, **kwargs)
Coplanar Waveguide initializer

```
Parameters frequency: Frequency object
                   frequency band of this transmission line medium
               w: number, or array-like
                    width of center conductor, in m.
               s: number, or array-like
                   width of gap, in m.
               ep_r: number, or array-like
                   relative permativity of substrate
               t: number, or array-like, optional
                   conductor thickness, in m.
               rho: number, or array-like, optional:
                   resistivity of conductor (None)
skrf.media.cpw.CPW.capacitor
CPW.capacitor(C, **kwargs)
     Capacitor
           Parameters C: number, array
                   Capacitance, in Farads. If this is an array, must be of same length as frequency vector.
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns capacitor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.cpw.CPW.delay load
CPW.delay_load(Gamma0, d, unit='m', **kwargs)
     Delayed load
     A load with reflection coefficient Gamma0 at the end of a matched line of length d.
           Parameters Gamma0: number, array-like
                   reflection coefficient of load (not in dB)
               d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
```

```
• rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay_load : Network object
                   a delayed load
     See Also:
     line creates the network for line
     load creates the network for the load
     Notes
     This calls
     line(d,unit, **kwargs) ** load(Gamma0, **kwargs)
     Examples
     >>> my_media.delay_load(-.5, 90, 'deg', z0=50)
skrf.media.cpw.CPW.delay_open
CPW.delay_open(d, unit='m', **kwargs)
     Delayed open transmission line
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                     • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay_open: Network object
                   a delayed open
     See Also:
     delay_load delay_short just calls this function
```

```
skrf.media.cpw.CPW.delay_short
CPW.delay_short (d, unit='m', **kwargs)
     Delayed Short
     A transmission line of given length terminated with a short.
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay_short: Network object
                   a delayed short
     See Also:
     delay_load delay_short just calls this function
skrf.media.cpw.CPW.electrical_length
CPW.electrical_length(d, deg=False)
     calculates the electrical length for a given distance, at the center frequency.
           Parameters d: number or array-like :
                   delay distance, in meters
               deg: Boolean:
                   return electral length in deg?
           Returns theta: number or array-like:
                   electrical length in radians or degrees, depending on value of deg.
skrf.media.cpw.CPW.from csv
classmethod CPW.from_csv(filename, *args, **kwargs)
     create a Media from numerical values stored in a csv file.
     the csv file format must be written by the function write_csv() which produces the following format
           f[$unit], Re(Z0), Im(Z0), Re(gamma), Im(gamma), Re(port Z0), Im(port Z0) 1, 1, 1, 1, 1, 1, 1, 2, 1,
           1, 1, 1, 1, 1 .....
```

skrf.media.cpw.CPW.gamma

```
CPW.gamma()
     Propagation constant
     See Also:
     alpha_conductor calculates losses to conductors
skrf.media.cpw.CPW.guess_length_of_delay_short
CPW.guess_length_of_delay_short (aNtwk)
     Guess physical length of a delay short.
     Unwraps the phase and determines the slope, which is then used in conjunction with
     propagation_constant to estimate the physical distance to the short.
          Parameters aNtwk: Network object
                  (note: if this is a measurment it needs to be normalized to the reference plane)
skrf.media.cpw.CPW.impedance_mismatch
CPW.impedance_mismatch(z1, z2, **kwargs)
     Two-port network for an impedance miss-match
          Parameters z1: number, or array-like
                  complex impedance of port 1
              z2: number, or array-like
                  complex impedance of port 2
              **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns missmatch: Network object
                  a 2-port network representing the impedance missmatch
     See Also:
     match called to create a 'blank' network
     Notes
     If z1 and z2 are arrays, they must be of same length as the Media.frequency.npoints
skrf.media.cpw.CPW.inductor
CPW.inductor(L, **kwargs)
     Inductor
```

Parameters L: number, array

```
**kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns inductor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.cpw.CPW.line
CPW.line(d, unit='m', **kwargs)
     Matched transmission line of given length
     The units of length are interpreted according to the value of unit.
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns line: Network object
                   matched tranmission line of given length
     Examples
     >>> my_media.line(90, 'deg', z0=50)
skrf.media.cpw.CPW.load
CPW.load(Gamma0, nports=1, **kwargs)
     Load of given reflection coefficient.
           Parameters Gamma0: number, array-like
                   Reflection coefficient of load (linear, not in db). If its an array it must be of shape:
                   kxnxn, where k is #frequency points in media, and n is nports
               nports: int
                   number of ports
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
```

Inductance, in Henrys. If this is an array, must be of same length as frequency vector.

```
Returns load :class: '~skrf.network.Network' object :
                  n-port load, where S = Gamma0*eye(...)
skrf.media.cpw.CPW.match
CPW.match (nports=1, z0=None, **kwargs)
     Perfect matched load (\Gamma_0 = 0).
          Parameters nports: int
                   number of ports
               z0: number, or array-like
                  characterisitc impedance. Default is None, in which case the Media's z0 is used. This
                  sets the resultant Network's z 0.
               **kwargs: key word arguments
                   passed to Network initializer
          Returns match: Network object
                  a n-port match
     Examples
     >>> my_match = my_media.match(2,z0 = 50, name='Super Awesome Match')
skrf.media.cpw.CPW.open
CPW.open (nports=1, **kwargs)
     Open (\Gamma_0 = 1)
          Parameters nports: int
                   number of ports
               **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns match: Network object
                  a n-port open circuit
     See Also:
     match function called to create a 'blank' network
skrf.media.cpw.CPW.resistor
CPW.resistor(R, *args, **kwargs)
     Resistor
          Parameters R: number, array
                   Resistance, in Ohms. If this is an array, must be of same length as frequency vector.
```

```
*args, **kwargs: arguments, key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
          Returns resistor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.cpw.CPW.short
CPW.short (nports=1, **kwargs)
     Short (\Gamma_0 = -1)
          Parameters nports: int
                  number of ports
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
          Returns match: Network object
                  a n-port short circuit
     See Also:
     match function called to create a 'blank' network
skrf.media.cpw.CPW.shunt
CPW.shunt(ntwk, **kwargs)
     Shunts a Network
     This creates a tee () and connects connects ntwk to port 1, and returns the result
          Parameters ntwk: Network object
               **kwargs: keyword arguments
                   passed to tee()
          Returns shunted_ntwk: Network object
                  a shunted a ntwk. The resultant shunted_ntwk will have (2 + ntwk.number_of_ports -1)
                  ports.
skrf.media.cpw.CPW.shunt_capacitor
CPW.shunt_capacitor(C, *args, **kwargs)
     Shunted capacitor
          Parameters C: number, array-like
                   Capacitance in Farads.
               *args, **kwargs: arguments, keyword arguments
                   passed to func: delay_open
```

```
Returns shunt_capacitor: Network object
                 shunted capcitor(2-port)
     Notes
     This calls:
     shunt(capacitor(C, *args, **kwargs))
skrf.media.cpw.CPW.shunt_delay_load
CPW.shunt_delay_load(*args, **kwargs)
     Shunted delayed load
          Parameters *args,**kwargs: arguments, keyword arguments
                 passed to func: delay_load
          Returns shunt_delay_load : Network object
                 a shunted delayed load (2-port)
     Notes
     This calls:
     shunt(delay_load(*args, **kwargs))
skrf.media.cpw.CPW.shunt_delay_open
CPW.shunt_delay_open(*args, **kwargs)
     Shunted delayed open
          Parameters *args,**kwargs: arguments, keyword arguments
                 passed to func: delay_open
          Returns shunt_delay_open: Network object
                 shunted delayed open (2-port)
     Notes
     This calls:
     shunt(delay_open(*args, **kwargs))
skrf.media.cpw.CPW.shunt delay short
CPW.shunt_delay_short(*args, **kwargs)
     Shunted delayed short
          Parameters *args, **kwargs : arguments, keyword arguments
```

```
passed to func: delay_open
          Returns shunt_delay_load : Network object
                  shunted delayed open (2-port)
     Notes
     This calls:
     shunt(delay_short(*args, **kwargs))
skrf.media.cpw.CPW.shunt inductor
CPW.shunt_inductor(L, *args, **kwargs)
     Shunted inductor
          Parameters L: number, array-like
                  Inductance in Farads.
               *args, **kwargs: arguments, keyword arguments
                  passed to func: delay_open
          Returns shunt_inductor: Network object
                  shunted inductor(2-port)
     Notes
     This calls:
     shunt(inductor(C, *args, **kwargs))
skrf.media.cpw.CPW.splitter
CPW.splitter(nports, **kwargs)
     Ideal, lossless n-way splitter.
          Parameters nports: int
                  number of ports
               **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns tee: Network object
                  a n-port splitter
     See Also:
     match called to create a 'blank' network
```

skrf.media.cpw.CPW.tee

```
CPW.tee(**kwargs)
     Ideal, lossless tee. (3-port splitter)
           Parameters **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns tee: Network object
                   a 3-port splitter
     See Also:
     splitter this just calls splitter(3)
     match called to create a 'blank' network
skrf.media.cpw.CPW.theta_2_d
CPW.theta_2_d (theta, deg=True)
     Converts electrical length to physical distance.
     The given electrical length is to be at the center frequency.
           Parameters theta: number
                   electrical length, at band center (see deg for unit)
               deg: Boolean
                   is theta in degrees?
           Returns d: number
                   physical distance in meters
skrf.media.cpw.CPW.thru
CPW.thru(**kwargs)
     Matched transmission line of length 0.
           Parameters **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns thru: Network object
                   matched tranmission line of 0 length
     See Also:
     line this just calls line(0)
```

skrf.media.cpw.CPW.white_gaussian_polar

```
CPW.white_gaussian_polar (phase_dev, mag_dev, n_ports=1, **kwargs)
```

Complex zero-mean gaussian white-noise network.

Creates a network whose s-matrix is complex zero-mean gaussian white-noise, of given standard deviations for phase and magnitude components. This 'noise' network can be added to networks to simulate additive noise.

Parameters phase mag: number

standard deviation of magnitude

phase_dev : number

standard deviation of phase

n_ports: int

number of ports.

**kwargs: passed to Network

initializer

Returns result: Network object

a noise network

skrf.media.cpw.CPW.write_csv

```
CPW.write_csv(filename='f, gamma, z0.csv')
```

write this media's frequency, z0, and gamma to a csv file.

Parameters filename: string

file name to write out data to

See Also:

from_csv class method to initialize Media object from a csv file written from this function

skrf.media.freespace.Freespace

class skrf.media.freespace.Freespace(frequency, ep_r=1, mu_r=1, *args, **kwargs)

Represents a plane-wave in a homogeneous freespace, defined by the space's relative permativity and relative permeability.

The field properties of space are related to a disctributed circuit transmission line model given in circuit theory by:

Circuit Property	Field Property
distributed_capacitance	real(ep_0*ep_r)
distributed_resistance	imag(ep_0*ep_r)
distributed_inductance	real(mu_0*mu_r)
distributed_conductance	imag(mu_0*mu_r)

This class's inheritence is; Media-> DistributedCircuit-> Freespace

Attributes

Y	Distributed Admittance, $Y^{'}$
Z	Distributed Impedance, $Z^{'}$
characteristic_impedance	Characterisitc impedance
propagation_constant	Propagation constant
z 0	Port Impedance

skrf.media.freespace.Freespace.Y

Freespace.Y

Distributed Admittance, Y'

Defined as

$$Y^{'} = G^{'} + j\omega C^{'}$$

Returns Y : numpy.ndarray

Distributed Admittance in units of S/m

skrf.media.freespace.Freespace.Z

Freespace.Z

Distributed Impedance, $Z^{'}$

Defined as

$$Z^{'}=R^{'}+j\omega I^{'}$$

Returns Z : numpy.ndarray

Distributed impedance in units of ohm/m

skrf.media.freespace.Freespace.characteristic_impedance

Freespace.characteristic_impedance

Characterisitc impedance

The characteristic_impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the characteristic impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns characteristic_impedance: numpy.ndarray

skrf.media.freespace.Freespace.propagation_constant

Freespace.propagation_constant

Propagation constant

The propagation constant can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the propagation constant to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns propagation_constant: numpy.ndarray

complex propagation constant for this media

Notes

propagation_constant must adhere to the following convention,

- positive real(propagation_constant) = attenuation
- positive imag(propagation_constant) = forward propagation

skrf.media.freespace.Freespace.z0

Freespace.z0

Port Impedance

The port impedance is usually equal to the characteristic_impedance. Therefore, if the port impedance is *None* then this will return characteristic_impedance.

However, in some cases such as rectangular waveguide, the port impedance is traditionally set to 1 (normalized). In such a case this property may be used.

The Port Impedance can be either a number, array-like, or a function. If it is a function is must take no arguments. The reason to make it a function is if you want the Port Impedance to be dynamic, meaning changing with some attribute of the media. See __init__() for more explanation.

Returns port_impedance: numpy.ndarray

the media's port impedance

Methods

Z 0	Characteristic Impedance, $Z0$
init	Freespace initializer
capacitor	Capacitor
delay_load	Delayed load
delay_open	Delayed open transmission line
delay_short	Delayed Short
electrical_length	calculates the electrical length for a given distance, at
from_Media	Initializes a DistributedCircuit from an existing
from_csv	create a Media from numerical values stored in a csv file.
gamma	Propagation Constant, γ
guess_length_of_delay_short	Guess physical length of a delay short.
impedance_mismatch	Two-port network for an impedance miss-match
inductor	Inductor
line	Matched transmission line of given length
load	Load of given reflection coefficient.
match	Perfect matched load ($\Gamma_0 = 0$).
	Continued on next page

TO 11 0 FA	4. 1.0	•
Table 3.52	— continued from	previous page

open	Open ($\Gamma_0 = 1$)
resistor	Resistor
short	Short $(\Gamma_0 = -1)$
shunt	Shunts a Network
shunt_capacitor	Shunted capacitor
shunt_delay_load	Shunted delayed load
shunt_delay_open	Shunted delayed open
shunt_delay_short	Shunted delayed short
shunt_inductor	Shunted inductor
splitter	Ideal, lossless n-way splitter.
tee	Ideal, lossless tee.
theta_2_d	Converts electrical length to physical distance.
thru	Matched transmission line of length 0.
white_gaussian_polar	Complex zero-mean gaussian white-noise network.
write_csv	write this media's frequency, z0, and gamma to a csv file.

skrf.media.freespace.Freespace.Z0

Freespace. ${f Z0}$ () Characteristic Impedance, ${\cal Z}0$

$$Z_0 = \sqrt{\frac{Z'}{Y'}}$$

Returns Z0: numpy.ndarray

Characteristic Impedance in units of ohms

skrf.media.freespace.Freespace.__init__

Freespace.__init__ (frequency, ep_r=1, mu_r=1, *args, **kwargs)
Freespace initializer

 ${\bf Parameters} \quad {\bf frequency}: {\tt Frequency} \ object$

frequency band of this transmission line medium

ep_r : number, array-like

complex relative permativity

mu_r: number, array-like

possibly complex, relative permiability

*args, **kwargs: arguments and keyword arguments

Notes

The distributed circuit parameters are related to a space's field properties by

Circuit Property	Field Property
distributed_capacitance	real(ep_0*ep_r)
distributed_resistance	imag(ep_0*ep_r)
distributed_inductance	real(mu_0*mu_r)
distributed_conductance	imag(mu_0*mu_r)

skrf.media.freespace.Freespace.capacitor

```
Freespace.capacitor(C, **kwargs)
     Capacitor
           Parameters C: number, array
                   Capacitance, in Farads. If this is an array, must be of same length as frequency vector.
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns capacitor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.freespace.Freespace.delay load
Freespace.delay_load(Gamma0, d, unit='m', **kwargs)
     Delayed load
     A load with reflection coefficient Gamma0 at the end of a matched line of length d.
           Parameters Gamma0: number, array-like
                   reflection coefficient of load (not in dB)
               d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay_load: Network object
                   a delayed load
     See Also:
     line creates the network for line
```

load creates the network for the load

Notes

```
This calls
     line(d,unit, **kwargs) ** load(Gamma0, **kwargs)
     Examples
     >>> my_media.delay_load(-.5, 90, 'deg', z0=50)
skrf.media.freespace.Freespace.delay open
Freespace.delay_open(d, unit='m', **kwargs)
     Delayed open transmission line
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay_open: Network object
                   a delayed open
     See Also:
     delay_load delay_short just calls this function
skrf.media.freespace.Freespace.delay_short
Freespace.delay_short (d, unit='m', **kwargs)
     Delayed Short
     A transmission line of given length terminated with a short.
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
```

• rad :radians, electrical length in radians

```
**kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns delay_short : Network object
                   a delayed short
     See Also:
     delay_load delay_short just calls this function
skrf.media.freespace.Freespace.electrical length
Freespace.electrical_length(d, deg=False)
     calculates the electrical length for a given distance, at the center frequency.
           Parameters d: number or array-like :
                   delay distance, in meters
               deg: Boolean:
                   return electral length in deg?
           Returns theta: number or array-like:
                   electrical length in radians or degrees, depending on value of deg.
skrf.media.freespace.Freespace.from Media
classmethod Freespace.from_Media (my_media, *args, **kwargs)
     Initializes a DistributedCircuit from an existing :class:'~skrf.media.media.Media' instance.
skrf.media.freespace.Freespace.from csv
classmethod Freespace.from_csv (filename, *args, **kwargs)
     create a Media from numerical values stored in a csv file.
     the csv file format must be written by the function write_csv() which produces the following format
           f[$unit], Re(Z0), Im(Z0), Re(gamma), Im(gamma), Re(port Z0), Im(port Z0) 1, 1, 1, 1, 1, 1, 1, 2, 1,
           1, 1, 1, 1, 1 .....
skrf.media.freespace.Freespace.gamma
Freespace.gamma()
     Propagation Constant, \gamma
     Defined as,
                                                    \gamma = \sqrt{Z'Y'}
           Returns gamma: numpy.ndarray
```

Propagation Constant,

Notes

The components of propagation constant are interpreted as follows:

positive real(gamma) = attenuation positive imag(gamma) = forward propagation

skrf.media.freespace.Freespace.guess length of delay short

```
Freespace.guess_length_of_delay_short (aNtwk)
```

Guess physical length of a delay short.

Unwraps the phase and determines the slope, which is then used in conjunction with propagation_constant to estimate the physical distance to the short.

Parameters aNtwk: Network object

(note: if this is a measurment it needs to be normalized to the reference plane)

skrf.media.freespace.Freespace.impedance_mismatch

```
Freespace.impedance_mismatch(z1, z2, **kwargs)
```

Two-port network for an impedance miss-match

Parameters z1: number, or array-like

complex impedance of port 1

z2: number, or array-like

complex impedance of port 2

**kwargs: key word arguments

passed to match (), which is called initially to create a 'blank' network.

Returns missmatch: Network object

a 2-port network representing the impedance missmatch

See Also:

match called to create a 'blank' network

Notes

If z1 and z2 are arrays, they must be of same length as the Media.frequency.npoints

skrf.media.freespace.Freespace.inductor

```
Freespace.inductor(L, **kwargs)
Inductor
```

Parameters L: number, array

Inductance, in Henrys. If this is an array, must be of same length as frequency vector.

**kwargs : key word arguments

```
Returns inductor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.freespace.Freespace.line
Freespace.line(d, unit='m', **kwargs)
     Matched transmission line of given length
     The units of length are interpreted according to the value of unit.
           Parameters d: number
                   the length of transmissin line (see unit argument)
               unit : ['m','deg','rad']
                   the units of d. possible options are:
                      • m : meters, physical length in meters (default)
                      • deg :degrees, electrical length in degrees
                      • rad :radians, electrical length in radians
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns line: Network object
                   matched tranmission line of given length
     Examples
     >>> my_media.line(90, 'deg', z0=50)
skrf.media.freespace.Freespace.load
Freespace.load(Gamma0, nports=1, **kwargs)
     Load of given reflection coefficient.
           Parameters Gamma0: number, array-like
                   Reflection coefficient of load (linear, not in db). If its an array it must be of shape:
                   kxnxn, where k is #frequency points in media, and n is nports
               nports: int
                   number of ports
               **kwargs : key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns load :class: '~skrf.network.Network' object :
                   n-port load, where S = Gamma0*eye(...)
```

passed to match (), which is called initially to create a 'blank' network.

skrf.media.freespace.Freespace.match

```
Freespace.match (nports=1, z0=None, **kwargs)
     Perfect matched load (\Gamma_0 = 0).
          Parameters nports: int
                   number of ports
               z0: number, or array-like
                   characterisite impedance. Default is None, in which case the Media's z0 is used. This
                   sets the resultant Network's z0.
               **kwargs: key word arguments
                  passed to Network initializer
          Returns match: Network object
                  a n-port match
     Examples
     >>> my_match = my_media.match(2,z0 = 50, name='Super Awesome Match')
skrf.media.freespace.Freespace.open
Freespace.open (nports=1, **kwargs)
     Open (\Gamma_0 = 1)
          Parameters nports: int
                  number of ports
               **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
          Returns match: Network object
                   a n-port open circuit
     See Also:
     match function called to create a 'blank' network
skrf.media.freespace.Freespace.resistor
Freespace.resistor(R, *args, **kwargs)
     Resistor
          Parameters R: number, array
                   Resistance, in Ohms. If this is an array, must be of same length as frequency vector.
               *args, **kwargs: arguments, key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
```

```
Returns resistor: a 2-port Network
     See Also:
     match function called to create a 'blank' network
skrf.media.freespace.Freespace.short
Freespace.short (nports=1, **kwargs)
     Short (\Gamma_0 = -1)
          Parameters nports: int
                  number of ports
              **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns match: Network object
                  a n-port short circuit
     See Also:
     match function called to create a 'blank' network
skrf.media.freespace.Freespace.shunt
Freespace.shunt (ntwk, **kwargs)
     Shunts a Network
     This creates a tee () and connects connects ntwk to port 1, and returns the result
          Parameters ntwk: Network object
              **kwargs: keyword arguments
                  passed to tee()
          Returns shunted_ntwk: Network object
                  a shunted a ntwk. The resultant shunted_ntwk will have (2 + ntwk.number_of_ports -1)
                  ports.
skrf.media.freespace.Freespace.shunt_capacitor
Freespace.shunt_capacitor(C, *args, **kwargs)
     Shunted capacitor
          Parameters C: number, array-like
                  Capacitance in Farads.
              *args,**kwargs: arguments, keyword arguments
                  passed to func: delay_open
          Returns shunt_capacitor: Network object
                  shunted capcitor(2-port)
```

Notes This calls: shunt(capacitor(C,*args, **kwargs)) skrf.media.freespace.Freespace.shunt_delay_load Freespace.shunt_delay_load(*args, **kwargs) Shunted delayed load **Parameters** *args,**kwargs: arguments, keyword arguments passed to func: delay_load Returns shunt_delay_load : Network object a shunted delayed load (2-port) **Notes** This calls: shunt(delay_load(*args, **kwargs)) skrf.media.freespace.Freespace.shunt_delay_open Freespace.shunt_delay_open(*args, **kwargs) Shunted delayed open Parameters *args,**kwargs: arguments, keyword arguments passed to func: delay_open Returns shunt_delay_open: Network object shunted delayed open (2-port) **Notes** This calls: shunt(delay_open(*args, **kwargs)) skrf.media.freespace.Freespace.shunt_delay_short Freespace.shunt_delay_short (*args, **kwargs) Shunted delayed short

Parameters *args,**kwargs: arguments, keyword arguments

passed to func: delay_open

Returns shunt_delay_load : Network object
shunted delayed open (2-port)

```
Notes
     This calls:
     shunt(delay_short(*args, **kwargs))
skrf.media.freespace.Freespace.shunt_inductor
Freespace.shunt_inductor(L, *args, **kwargs)
     Shunted inductor
          Parameters L : number, array-like
                  Inductance in Farads.
              *args,**kwargs: arguments, keyword arguments
                  passed to func: delay_open
          Returns shunt_inductor: Network object
                  shunted inductor(2-port)
     Notes
     This calls:
     shunt(inductor(C, *args, **kwargs))
skrf.media.freespace.Freespace.splitter
Freespace.splitter(nports, **kwargs)
     Ideal, lossless n-way splitter.
          Parameters nports: int
                  number of ports
              **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
          Returns tee: Network object
                  a n-port splitter
     See Also:
     match called to create a 'blank' network
skrf.media.freespace.Freespace.tee
Freespace.tee(**kwargs)
     Ideal, lossless tee. (3-port splitter)
          Parameters **kwargs: key word arguments
                  passed to match (), which is called initially to create a 'blank' network.
```

```
Returns tee: Network object
                   a 3-port splitter
     See Also:
     splitter this just calls splitter(3)
     match called to create a 'blank' network
skrf.media.freespace.Freespace.theta 2 d
Freespace.theta_2_d (theta, deg=True)
     Converts electrical length to physical distance.
     The given electrical length is to be at the center frequency.
           Parameters theta: number
                   electrical length, at band center (see deg for unit)
               deg: Boolean
                   is theta in degrees?
           Returns d: number
                   physical distance in meters
skrf.media.freespace.Freespace.thru
Freespace.thru(**kwargs)
     Matched transmission line of length 0.
           Parameters **kwargs: key word arguments
                   passed to match (), which is called initially to create a 'blank' network.
           Returns thru: Network object
                   matched tranmission line of 0 length
     See Also:
     line this just calls line(0)
skrf.media.freespace.Freespace.white gaussian polar
Freespace.white_qaussian_polar(phase_dev, mag_dev, n_ports=1, **kwargs)
     Complex zero-mean gaussian white-noise network.
     Creates a network whose s-matrix is complex zero-mean gaussian white-noise, of given standard deviations for
     phase and magnitude components. This 'noise' network can be added to networks to simulate additive noise.
           Parameters phase_mag: number
                   standard deviation of magnitude
               phase dev: number
                   standard deviation of phase
```

```
n_ports : int
    number of ports.

**kwargs : passed to Network
    initializer

Returns result : Network object
```

skrf.media.freespace.Freespace.write_csv

```
Freespace.write_csv (filename='f, gamma, z0.csv') write this media's frequency, z0, and gamma to a csv file.
```

Parameters filename: string

a noise network

file name to write out data to

See Also:

from_csv class method to initialize Media object from a csv file written from this function

3.12 vi (skrf.vi)

This module holds Virtual Instruments that are intricately related to skrf.

3.12.1 Vector Network Analyzers (skrf.vi.vna)

Warning: These Virtual Instruments are very spotily written, and may be subject to major re-writing in the future.

PNAX([address, channel])	Agilent PNAX
ZVA40([address, active_channel, continuous])	Rohde&Scharz ZVA40
HP8510C([address])	good ole 8510
HP8720([address])	

skrf.vi.vna.PNAX

```
class skrf.vi.vna.PNAX (address=16, channel=1, **kwargs)
    Agilent PNAX
```

Examples

```
>>> from skrf.vi.vna import PNAX
>>> v = PNAX()
>>> dut = v.network
```

Attributes

continuous	
frequency	Gets frequency data, returning a Frequency object
network	Initiates a sweep and returns a Network type represting the data.

skrf.vi.vna.PNAX.continuous

PNAX.continuous

skrf.vi.vna.PNAX.frequency

PNAX.frequency

Gets frequency data, returning a Frequency object

Gets the

skrf.vi.vna.PNAX.network

PNAX.network

Initiates a sweep and returns a Network type represting the data.

If you are taking multiple sweeps, and want the sweep timing to work, put the turn continuous mode off, with pnax.continuous='off'

Examples

```
>>> from skrf.vi.vna import PNAX
>>> v = PNAX()
>>> dut = v.network
```

Methods

__init__

skrf.vi.vna.PNAX.__init__

```
PNAX.__init__(address=16, channel=1, **kwargs)
```

skrf.vi.vna.ZVA40

```
class skrf.vi.vna.ZVA40 (address=20, active_channel=1, continuous=True, **kwargs)
    Rohde&Scharz ZVA40
```

3.12. vi(skrf.vi) 255

Examples

```
>>> from skrf.vi.vna import ZVA40
>>> v = ZVA40()
>>> dut = v.network
```

Attributes

continuous	set/get continuous sweep mode on/off [boolean]
error	returns list errors stored on vna
fdata	formated s-parameter data [a numpy array]
frequency	a frequency object, representing the current frequency axis
one_port	a network representing the current active trace
s11	this is just for legacy support, there is no gurantee this
sdata	unformated s-parameter data [a numpy array]

skrf.vi.vna.ZVA40.continuous

ZVA40.continuous

set/get continuous sweep mode on/off [boolean]

skrf.vi.vna.ZVA40.error

${\tt ZVA40.error}$

returns list errors stored on vna

skrf.vi.vna.ZVA40.fdata

ZVA40.fdata

formated s-parameter data [a numpy array]

skrf.vi.vna.ZVA40.frequency

ZVA40.frequency

a frequency object, representing the current frequency axis [skrf Frequency object]

skrf.vi.vna.ZVA40.one_port

ZVA40.one_port

a network representing the current active trace [skrf Network object]

skrf.vi.vna.ZVA40.s11

ZVA40.**s11**

this is just for legacy support, there is no gurantee this will return s11. it just returns active trace

skrf.vi.vna.ZVA40.sdata

ZVA40.sdata

unformated s-parameter data [a numpy array]

Methods

init	
add_trace	
initiate	initiate a sweep on current channel (low level timing)
set_active_trace	
sweep	initiate a sweep on current channel. if vna is in continous
update_trace_list	
upload_cal_data	for explanation of this code see the
wait	wait for preceding command to finish before executing subsequent

skrf.vi.vna.ZVA40. init

ZVA40.__init__(address=20, active_channel=1, continuous=True, **kwargs)

skrf.vi.vna.ZVA40.add_trace

ZVA40.add_trace(parameter, name)

skrf.vi.vna.ZVA40.initiate

ZVA40.initiate()

initiate a sweep on current channel (low level timing)

skrf.vi.vna.ZVA40.set_active_trace

ZVA40.set_active_trace(name)

skrf.vi.vna.ZVA40.sweep

ZVA40.sweep()

initiate a sweep on current channel. if vna is in continous mode it will put in single sweep mode, then request a sweep, and then return sweep mode to continous.

skrf.vi.vna.ZVA40.update_trace_list

ZVA40.update_trace_list()

3.12. vi (skrf.vi) 257

skrf.vi.vna.ZVA40.upload_cal_data

```
ZVA40.upload_cal_data (error_data, cal_name='test', port=1) for explanation of this code see the zva manual (v1145.1084.12 p6.193)
```

skrf.vi.vna.ZVA40.wait

```
ZVA40.wait()
```

wait for preceding command to finish before executing subsequent commands

skrf.vi.vna.HP8510C

```
class skrf.vi.vna.HP8510C (address=16, **kwargs)
    good ole 8510
```

Attributes

averaging	averaging factor
continuous	
error	
frequency	
one_port	Initiates a sweep and returns a Network type represting the
s11	
s12	
s21	
s22	
switch_terms	measures forward and reverse switch terms and returns them as a
two_port	Initiates a sweep and returns a Network type represting the

skrf.vi.vna.HP8510C.averaging

HP8510C.averaging averaging factor

skrf.vi.vna.HP8510C.continuous

HP8510C.continuous

skrf.vi.vna.HP8510C.error

HP8510C.error

skrf.vi.vna.HP8510C.frequency

HP8510C.frequency

skrf.vi.vna.HP8510C.one_port

HP8510C.one_port

Initiates a sweep and returns a Network type represting the data.

if you are taking multiple sweeps, and want the sweep timing to work, put the turn continuous mode off. like pnax.continuous='off'

skrf.vi.vna.HP8510C.s11

HP8510C.**s11**

skrf.vi.vna.HP8510C.s12

HP8510C.s12

skrf.vi.vna.HP8510C.s21

HP8510C.s21

skrf.vi.vna.HP8510C.s22

HP8510C.s22

skrf.vi.vna.HP8510C.switch_terms

HP8510C.switch_terms

measures forward and reverse switch terms and returns them as a pair of one-port networks.

returns:

forward, reverse: a tuple of one ports holding forward and reverse switch terms.

see also: skrf.calibrationAlgorithms.unterminate_switch_terms

notes: thanks to dylan williams for making me aware of this, and providing the gpib commands in his statistical help

skrf.vi.vna.HP8510C.two_port

HP8510C.two_port

Initiates a sweep and returns a Network type represting the data.

if you are taking multiple sweeps, and want the sweep timing to work, put the turn continuous mode off. like pnax.continuous='off'

Methods

___init___

3.12. vi(skrf.vi) 259

skrf.vi.vna.HP8510C.__init__

HP8510C.__init__(address=16, **kwargs)

skrf.vi.vna.HP8720

class skrf.vi.vna.HP8720 (address=16, **kwargs)

Attributes

averaging	
continuous	
error	
frequency	
ifbw	
one_port	Initiates a sweep and returns a Network type represting the
s11	
s12	
s21	
s22	
switch_terms	measures forward and reverse switch terms and returns them as a
two_port	Initiates a sweep and returns a Network type represting the

skrf.vi.vna.HP8720.averaging

 ${\tt HP8720.averaging}$

skrf.vi.vna.HP8720.continuous

HP8720.continuous

skrf.vi.vna.HP8720.error

 ${\tt HP8720.error}$

skrf.vi.vna.HP8720.frequency

 ${\tt HP8720.frequency}$

skrf.vi.vna.HP8720.ifbw

HP8720.ifbw

skrf.vi.vna.HP8720.one_port

HP8720.one_port

Initiates a sweep and returns a Network type represting the data.

if you are taking multiple sweeps, and want the sweep timing to work, put the turn continuous mode off. like pnax.continuous='off'

skrf.vi.vna.HP8720.s11

HP8720.**s11**

skrf.vi.vna.HP8720.s12

HP8720.**s12**

skrf.vi.vna.HP8720.s21

HP8720.s21

skrf.vi.vna.HP8720.s22

HP8720.s22

skrf.vi.vna.HP8720.switch_terms

HP8720.switch_terms

measures forward and reverse switch terms and returns them as a pair of one-port networks.

returns:

forward, reverse: a tuple of one ports holding forward and reverse switch terms.

see also: skrf.calibrationAlgorithms.unterminate_switch_terms

notes: thanks to dylan williams for making me aware of this, and providing the gpib commands in his statistical help

skrf.vi.vna.HP8720.two_port

HP8720.two_port

Initiates a sweep and returns a Network type represting the data.

if you are taking multiple sweeps, and want the sweep timing to work, put the turn continuous mode off. like pnax.continuous='off'

Methods

__init__

3.12. vi(skrf.vi) 261

```
skrf.vi.vna.HP8720.__init__
```

```
HP8720.__init__(address=16, **kwargs)
```

3.12.2 Spectrum Analyzers (skrf.vi.sa)

HP8500([address]) HP8500's series Spectrum Analyzers

skrf.vi.sa.HP8500

Examples

Get trace, and store in a Network object

```
>>> from skrf.vi.sa import HP
>>> my_sa = HP() # default address is 18
>>> trace = my_sa.get_ntwk()
```

Activate single sweep mode, get a trace, return to continuous sweep

```
>>> my_sa.single_sweep()
>>> my_sa.sweep()
>>> trace_a = my_sa.trace_a
>>> my_sa.cont_sweep()
```

Attributes

f_start	starting frequency
f_stop	stopping frequency
frequency	
get_ntwk	Get a trace and return the data in a Network format
trace_a	trace 'a'
trace_b	trace 'b'

skrf.vi.sa.HP8500.f_start

```
HP8500.f_start starting frequency
```

skrf.vi.sa.HP8500.f_stop

```
HP8500.f_stop stopping frequency
```

skrf.vi.sa.HP8500.frequency

```
HP8500.frequency
```

skrf.vi.sa.HP8500.get_ntwk

HP8500.get_ntwk

Get a trace and return the data in a Network format

This will save instrument stage to reg 1, activate single sweep mode, sweep, save data, then recal state from reg

Returning the data in a the form of a Network allows all the plotting methods and IO functions of that class to be used. Not all the methods of Network make sense for this type of data (scalar), but we assume the user is knows this.

```
Parameters trace: ['a', 'b']
        save trace 'a' or trace 'b'
    goto_local: Boolean
        Go to local mode after taking a sweep
    *args,**kwargs::
        passed to ___init___()
```

skrf.vi.sa.HP8500.trace a

```
HP8500.trace_a
    trace 'a'
```

skrf.vi.sa.HP8500.trace b

```
HP8500.trace_b
    trace 'b'
```

Methods

init	Initializer
cont_sweep	Activate continuous sweep mode
goto_local	Switches from remote to local control
recall_state	Recall current state to a given register
save_state	Save current state to a given register
single_sweep	Activate single sweep mode
sweep	trigger a sweep, return when done

skrf.vi.sa.HP8500.__init__

```
HP8500.__init__(address=18, *args, **kwargs)
     Initializer
```

3.12. vi (skrf.vi) 263

```
Parameters address: int
                 GPIB address
              *args, **kwargs::
                 passed to visa.GpibInstrument.__init__
skrf.vi.sa.HP8500.cont sweep
HP8500.cont_sweep()
     Activate continuous sweep mode
skrf.vi.sa.HP8500.goto_local
HP8500.goto_local()
     Switches from remote to local control
skrf.vi.sa.HP8500.recall_state
HP8500.recall_state(reg_n)
     Recall current state to a given register
skrf.vi.sa.HP8500.save state
HP8500.save_state(reg_n=1)
     Save current state to a given register
skrf.vi.sa.HP8500.single_sweep
HP8500.single_sweep()
     Activate single sweep mode
skrf.vi.sa.HP8500.sweep
HP8500.sweep()
     trigger a sweep, return when done
3.12.3 Stages (skrf.vi.stages)
                                         Newport Universal Motion Controller/Driver Model ESP300
       ESP300([address, current_axis, ...])
skrf.vi.stages.ESP300
class skrf.vi.stages.ESP300 (address=1, current_axis=1, always_wait_for_stop=True, delay=0,
                                 **kwargs)
     Newport Universal Motion Controller/Driver Model ESP300
```

all axis control commands are sent to the number axis given by the local variable self.current_axis. An example usage

```
from skrf.vi.stages import ESP300
esp = ESP300()
esp.current_axis = 1
esp.position = 10
print esp.position
```

Attributes

UNIT_DICT	
acceleration	
current_axis	current axis used in all subsequent commands
deceleration	
error_message	
home	
motor_on	
position	
position_relative	
units	
velocity	the velocity of current axis

skrf.vi.stages.ESP300.UNIT_DICT

ESP300.UNIT_DICT = {'micro inches': 6, 'inches': 4, 'micrometer': 3, 'milliradian': 10, 'millimeter': 2, 'milli inches': 5, 'enc

skrf.vi.stages.ESP300.acceleration

ESP300.acceleration

skrf.vi.stages.ESP300.current_axis

```
ESP300.current axis
```

current axis used in all subsequent commands

skrf.vi.stages.ESP300.deceleration

ESP300.deceleration

skrf.vi.stages.ESP300.error_message

ESP300.error_message

skrf.vi.stages.ESP300.home

ESP300.home

3.12. vi (skrf.vi) 265

```
skrf.vi.stages.ESP300.motor_on
```

ESP300.motor_on

skrf.vi.stages.ESP300.position

ESP300.position

skrf.vi.stages.ESP300.position_relative

ESP300.position_relative

skrf.vi.stages.ESP300.units

ESP300.units

skrf.vi.stages.ESP300.velocity

ESP300.velocity the velocity of current axis

Methods

init	Initializer
send_stop	
wait_for_stop	

skrf.vi.stages.ESP300.__init__

ESP300.__init__ (address=1, current_axis=1, always_wait_for_stop=True, delay=0, **kwargs)
Initializer

Parameters address: int

Gpib address

current axis: int

number of current axis

always_wait_for_stop : Boolean

wait for stage to stop before returning control to calling program

**kwargs::

passed to GpibInstrument initializer

skrf.vi.stages.ESP300.send_stop

 $ESP300.send_stop()$

skrf.vi.stages.ESP300.wait_for_stop

ESP300.wait_for_stop()

3.13 Indices and tables

- genindex
- modindex
- search

3.13. Indices and tables 267

PYTHON MODULE INDEX

S skrf.calibration, 165 skrf.calibration.calibration, 165 skrf.calibration.calibrationAlgorithms, skrf.calibration.calibrationFunctions, skrf.constants, 155 skrf.frequency, 53 skrf.io, 158 skrf.io.general, 158 skrf.io.touchstone, 162 skrf.mathFunctions, 144 skrf.media, 184 skrf.network, 57 skrf.networkSet, 132 skrf.plotting, 138 skrf.tlineFunctions, 147 skrf.util, 156 skrf.vi, 254 skrf.vi.sa, 262 skrf.vi.stages, 264 skrf.vi.vna, 254

SCIKII'II DOGUIIIEIIIAIIOII. DEIEASE GE	n. Release dev	cikit-rf Documentation.
---	----------------	-------------------------

270 Python Module Index

INDEX

Symbols	add_trace() (skrf.vi.vna.ZVA40 method), 257
init() (skrf.calibration.calibration.Calibration	alpha_conductor (skrf.media.cpw.CPW attribute), 227
method), 168, 180	apply_cal() (skrf.calibration.calibration.Calibration
init() (skrf.frequency.Frequency method), 56	method), 168, 180
init() (skrf.io.touchstone.Touchstone method), 163	apply_cal_to_all_in_dir()
init() (skrf.media.cpw.CPW method), 229	(skrf.calibration.calibration.Calibration
init() (skrf.media.distributedCircuit.DistributedCircuit	method), 169, 180 average() (in module skrf.network), 131
method), 201	averaging (skrf.vi.vna.HP8510C attribute), 258
init() (skrf.media.freespace.Freespace method), 243	averaging (skrf.vi.vna.HP8720 attribute), 260
init() (skrf.media.media.Media method), 187	
init() (skrf.media.rectangularWaveguide.RectangularWaveguide), 215	
init() (skrf.network.Network method), 72	biased_error() (skrf.calibration.calibration.Calibration method), 169, 181
init() (skrf.networkSet.NetworkSet method), 134	method), 109, 181
init() (skrf.vi.sa.HP8500 method), 263	C
init() (skrf.vi.stages.ESP300 method), 266	caled_ntwk_sets (skrf.calibration.calibration.Calibration
init() (skrf.vi.vna.HP8510C method), 260	attribute), 166, 178
init() (skrf.vi.vna.HP8720 method), 262	caled_ntwks (skrf.calibration.calibration.Calibration at-
init() (skrf.vi.vna.PNAX method), 255	tribute), 166, 178
init() (skrf.vi.vna.ZVA40 method), 257	Calibration (class in skrf.calibration.calibration), 165, 177
A	calibration_algorithm_dict
a (skrf.network.Network attribute), 60	(skrf.calibration.calibration.Calibration at-
a_arcl (skrf.network.Network attribute), 60	tribute), 166, 178
a_arcl_unwrap (skrf.network.Network attribute), 61	capacitor() (skrf.media.cpw.CPW method), 230
a_db (skrf.network.Network attribute), 61	capacitor() (skrf.media.distributed Circuit. Distributed Circuit
a_deg (skrf.network.Network attribute), 61	method), 202
a_deg_unwrap (skrf.network.Network attribute), 61	capacitor() (skrf.media.freespace.Freespace method), 244
a_im (skrf.network.Network attribute), 61	capacitor() (skrf.media.media.Media method), 188
a_mag (skrf.network.Network attribute), 61	capacitor() (skrf.media.rectangular Waveguide. Rectangular Waveguide)
a_rad (skrf.network.Network attribute), 62	method), 216
a_rad_unwrap (skrf.network.Network attribute), 62	cartesian_product_calibration_set() (in module
a_re (skrf.network.Network attribute), 62	skrf.calibration.calibrationFunctions), 176
abc_2_coefs_dict() (in module	cascade() (in module skrf.network), 119
skrf.calibration.calibrationAlgorithms), 176	center (skrf.frequency.Frequency attribute), 54
acceleration (skrf.vi.stages.ESP300 attribute), 265	characteristic_impedance (skrf.media.cpw.CPW at-
add_markers_to_lines() (in module skrf.plotting), 143	tribute), 228
add_noise_polar() (skrf.network.Network method), 73,	characteristic_impedance (skrf.media.distributedCircuit.DistributedCircuit
123	attribute), 199
add_noise_polar_flatband() (skrf.network.Network	characteristic_impedance
method), 73, 123	(skrf.media.freespace.Freespace attribute),
	(SKIT.IIICGIa.IIICGpacc.IIICGpacc attitioute),

241	delay_short() (skrf.media.freespace.Freespace method),
characteristic_impedance (skrf.media.media.Media at-	245
tribute), 185	delay_short() (skrf.media.media.Media method), 189
characteristic_impedance	delay_short() (skrf.media.rectangularWaveguide.RectangularWaveguide
(skrf.media.rectangularWaveguide.RectangularW	
attribute), 213	dirac_delta() (in module skrf.mathFunctions), 146
coefs (skrf.calibration.calibration.Calibration attribute),	distance_2_electrical_length() (in module
166, 178	skrf.tlineFunctions), 150
complex2Scalar() (in module skrf.mathFunctions), 146	distributed_circuit_2_propagation_impedance() (in mod-
complex_2_db() (in module skrf.mathFunctions), 144	ule skrf.tlineFunctions), 153
complex_2_degree() (in module skrf.mathFunctions), 145	DistributedCircuit (class in
complex_2_magnitude() (in module skrf.mathFunctions),	skrf.media.distributedCircuit), 198
144, 145	E
complex_2_radian() (in module skrf.mathFunctions), 144 complex_2_reim() (in module skrf.mathFunctions), 144	
connect() (in module skrf.network), 117	eight_term_2_one_port_coefs() (in module
connect_s() (in module skrf.network), 117	skrf.calibration.calibrationAlgorithms), 176
cont_sweep() (skrf.vi.sa.HP8500 method), 264	electrical_length() (skrf.media.cpw.CPW method), 232 electrical_length() (skrf.media.distributedCircuit.DistributedCircuit
continuous (skrf.vi.vna.HP8510C attribute), 258	method), 204
continuous (skrf.vi.vna.HP8720 attribute), 260	electrical_length() (skrf.media.freespace.Freespace
continuous (skrf.vi.vna.PNAX attribute), 255	method), 246
continuous (skrf.vi.vna.ZVA40 attribute), 256	electrical_length() (skrf.media.media.Media method),
copy() (skrf.frequency.Frequency method), 57	190
copy() (skrf.network.Network method), 73	electrical_length() (skrf.media.rectangularWaveguide.RectangularWaveguide
copy() (skrf.networkSet.NetworkSet method), 134	method), 218
copy_from() (skrf.network.Network method), 74	electrical_length_2_distance() (in module
CPW (class in skrf.media.cpw), 227	skrf.tlineFunctions), 151
current_axis (skrf.vi.stages.ESP300 attribute), 265	element_wise_method() (skrf.networkSet.NetworkSet
Б	method), 135
D	ep (skrf.media.rectangularWaveguide.RectangularWaveguide
db_2_np() (in module skrf.mathFunctions), 146	attribute), 213
de_embed() (in module skrf.network), 119	ep_re (skrf.media.cpw.CPW attribute), 228
deceleration (skrf.vi.stages.ESP300 attribute), 265	error (skrf.vi.vna.HP8510C attribute), 258
degree_2_radian() (in module skrf.mathFunctions), 145	error (skrf.vi.vna.HP8720 attribute), 260
delay_load() (skrf.media.cpw.CPW method), 230	error (skrf.vi.vna.ZVA40 attribute), 256
delay_load() (skrf.media.distributedCircuit.DistributedCirc	
method), 202	error_ntwk (skrf.calibration.calibration at-
delay_load() (skrf.media.freespace.Freespace method),	tribute), 166, 178
244	ESP300 (class in skrf.vi.stages), 264
delay_load() (skrf.media.media.Media method), 188 delay_load() (skrf.media.rectangularWaveguide.Rectangula	Wayaguida
method), 217	
delay_open() (skrf.media.cpw.CPW method), 231	f (skrf.frequency.Frequency attribute), 54 f (skrf.network.Network attribute), 62
delay_open() (skrf.media.distributedCircuit.DistributedCirc	1 (SKIL HELWORK INCLWORK ALLIDOULE), 02
method), 203	f_start (skrf.vi.sa.HP8500 attribute), 262
delay_open() (skrf.media.freespace.Freespace method),	f_stop (skrf.vi.sa.HP8500 attribute), 262
245	fdata (skrf.vi.vna.ZVA40 attribute), 256
delay_open() (skrf.media.media.Media method), 189	find_nearest() (in module skrf.util), 157
delay_open() (skrf.media.rectangularWaveguide.Rectangular	afWavaguies: index() (in module skrf.util), 157
method), 217	flip() (in module skrf.network), 119
delay_short() (skrf.media.cpw.CPW method), 232	flip() (skrf.network.Network method), 74
$delay_short() (skrf.media.distributed Circuit. Distributed Circuit. $	Preespace (class in skrf.media.freespace), 240
method), 203	
	Frequency (class in skrf.frequency), 53

frequency (skrf.vi.sa.HP8500 attribute), 263 frequency (skrf.vi.vna.HP8510C attribute), 258 frequency (skrf.vi.vna.HP8720 attribute), 260	guess_length_of_delay_short()
frequency (skrf.vi.vna.PNAX attribute), 255 frequency (skrf.vi.vna.ZVA40 attribute), 256	guess_length_of_delay_short() (skrf.media.media.Media method), 190
from_csv() (skrf.media.cpw.CPW class method), 232	guess_length_of_delay_short()
from_csv() (skrf.media.distributedCircuit.DistributedCircuit class method), 204	
from_csv() (skrf.media.freespace.Freespace class method), 246	Н
from_csv() (skrf.media.media.Media class method), 190	hfss_touchstone_2_gamma_z0() (in module
$from_csv() (skrf.media.rectangular Waveguide. Rectangular Waveguide. The standard of the s$	Waveguide skrf.io.touchstone), 164
class method), 219	hfss_touchstone_2_media() (in module
from_f() (skrf.frequency.Frequency class method), 57	skrf.io.touchstone), 165
$from_Media() (skrf.media.distributed Circuit.Distributed Circu$	"Highe (skrf.vi.stages.ESP300 attribute), 265
class method), 204	HP8500 (class in skrf.vi.sa), 262
from_Media() (skrf.media.freespace.Freespace class	HP8510C (class in skrf.vi.vna), 258
method), 246	HP8720 (class in skrf.vi.vna), 260
from_zip() (skrf.networkSet.NetworkSet class method), 135	1
func_on_all_figs() (in module skrf.plotting), 143	ifbw (skrf.vi.vna.HP8720 attribute), 260
func_per_standard() (skrf.calibration.calibration.Calibration method), 169, 181	nimpedance_mismatch() (skrf.media.cpw.CPW method), 233
G	impedance_mismatch() (skrf.media.distributedCircuit.DistributedCircuit method), 205
gamma() (skrf.media.cpw.CPW method), 233	impedance_mismatch() (skrf.media.freespace.Freespace
gamma() (skrf.media.distributed Circuit. Distributed Circuit	method), 247
method), 204	impedance_mismatch() (skrf.media.media.Media
gamma() (skrf.media.freespace.Freespace method), 246	method), 190
Gamma0_2_Gamma_in() (in module skrf.tlineFunctions), 149	impedance_mismatch() (skrf.media.rectangularWaveguide.RectangularWaveguide), 219
Gamma0_2_zin() (in module skrf.tlineFunctions), 150	inductor() (skrf.media.cpw.CPW method), 233
Gamma0_2_zl() (in module skrf.tlineFunctions), 149	inductor() (skrf.media.distributedCircuit.DistributedCircuit
get_extn() (in module skrf.util), 158	method), 205
get_fid() (in module skrf.util), 158	inductor() (skrf.media.freespace.Freespace method), 247
get_format() (skrf.io.touchstone.Touchstone method),	inductor() (skrf.media.media.Media method), 191
163	inductor() (skrf.media.rectangularWaveguide.RectangularWaveguide
<pre>get_noise_data() (skrf.io.touchstone.Touchstone method),</pre>	method), 220
163	initiate() (skrf.vi.vna.ZVA40 method), 257
get_noise_names() (skrf.io.touchstone.Touchstone	innerconnect() (in module skrf.network), 118
method), 163	innerconnect_s() (in module skrf.network), 125
get_ntwk (skrf.vi.sa.HP8500 attribute), 263	input_impedance_at_theta() (in module
get_sparameter_arrays() (skrf.io.touchstone.Touchstone	skrf.tlineFunctions), 152
method), 163	interpolate() (skrf.network.Network method), 74, 120
get_sparameter_data() (skrf.io.touchstone.Touchstone	interpolate_from_f() (skrf.network.Network method), 75,
method), 164	121
get_sparameter_names() (skrf.io.touchstone.Touchstone method), 164	interpolate_self() (skrf.network.Network method), 75, 121
goto_local() (skrf.vi.sa.HP8500 method), 264	interpolate_self_npoints() (skrf.network.Network
guess_length_of_delay_short() (skrf.media.cpw.CPW	method), 76
method), 233	inv (skrf.network.Network attribute), 63
<pre>guess_length_of_delay_short()</pre>	inv (skrf.networkSet.NetworkSet attribute), 133
(skrf.media.distributedCircuit.DistributedCircuit method), 205	inv() (in module skrf.network), 124

K	multiply_noise() (skrf.network.Network method), 76, 123			
k0 (skrf.media.rectangularWaveguide.RectangularWaveguidattribute), 213	^d Ñ			
k1 (skrf.media.cpw.CPW attribute), 228	Network (class in skrf.network), 58			
K_ratio (skrf.media.cpw.CPW attribute), 227	network (skrf.vi.vna.PNAX attribute), 255			
kc (skrf.media.rectangularWaveguide.RectangularWaveguideWetworkSet (class in skrf.networkSet), 132 attribute), 213 neuman() (in module skrf.mathFunctions), 146				
kx (skrf.media.rectangularWaveguide.RectangularWaveguide	dpow_string() (in module skrf.util), 157			
attribute), 213	np_2_db() (in module skrf.mathFunctions), 146			
ky (skrf.media.rectangularWaveguide.RectangularWaveguide.tribute), 214	dapoints (skrf.frequency.Frequency attribute), 55 nports (skrf.calibration.calibration.Calibration attribute),			
kz() (skrf.media.rectangularWaveguide.RectangularWavegu	uide 167, 178			
method), 220	nports (skrf.network.Network attribute), 63 nstandards (skrf.calibration.calibration.Calibration			
L	attribute), 167, 178			
labelXAxis() (skrf.frequency.Frequency method), 57	nudge() (skrf.network.Network method), 77, 132			
legend_off() (in module skrf.plotting), 143	null() (in module skrf.mathFunctions), 147			
line() (skrf.media.cpw.CPW method), 234	number_of_ports (skrf.network.Network attribute), 63			
line() (skrf.media.distributedCircuit.DistributedCircuit method), 206	0			
line() (skrf.media.freespace.Freespace method), 248	one_port (skrf.vi.vna.HP8510C attribute), 259			
line() (skrf.media.media.Media method), 191	one_port (skrf.vi.vna.HP8720 attribute), 261			
line() (skrf.media.rectangularWaveguide.RectangularWaveguide), 220	goide_port (skrf.vi.vna.ZVA40 attribute), 256 one_port() (in module			
load() (skrf.media.cpw.CPW method), 234	skrf.calibration.calibrationAlgorithms), 172			
load() (skrf.media.distributedCircuit.DistributedCircuit	one_port_nls() (in module			
method), 206	skrf.calibration.calibrationAlgorithms), 173			
load() (skrf.media.freespace.Freespace method), 248	open() (skrf.media.cpw.CPW method), 235			
load() (skrf.media.media.Media method), 192	open() (skrf.media.distributedCircuit.DistributedCircuit			
load() (skrf.media.rectangularWaveguide.RectangularWavemethod), 221	guide method), 207 open() (skrf.media.freespace.Freespace method), 249			
load_file() (skrf.io.touchstone.Touchstone method), 164	open() (skrf.media.media.Media method), 193			
load_impedance_2_reflection_coefficient() (in module skrf.tlineFunctions), 153	open() (skrf.media.rectangularWaveguide.RectangularWaveguide method), 222			
load_impedance_2_reflection_coefficient_at_theta() (in module skrf.tlineFunctions), 153	output_from_cal (skrf.calibration.calibration.Calibration attribute), 167, 178			
M	P			
match() (skrf.media.cpw.CPW method), 235	parameterized_self_calibration() (in module			
match() (skrf.media.distributedCircuit.DistributedCircuit method), 207	skrf.calibration.calibrationAlgorithms), 174 parameterized_self_calibration_nls() (in module			
match() (skrf.media.freespace.Freespace method), 249	skrf.calibration.calibrationAlgorithms), 175			
match() (skrf.media.media.Media method), 192	passivity (skrf.network.Network attribute), 63			
match() (skrf.media.rectangularWaveguide.RectangularWav				
method), 221	plot_a_arcl_unwrap() (skrf.network.Network method), 78			
mean_residuals() (skrf.calibration.calibration.Calibration	plot_a_complex() (skrf.network.Network method), 78			
method), 169, 181	plot_a_db() (skrf.network.Network method), 79			
mean_s_db (skrf.networkSet.NetworkSet attribute), 133	plot_a_deg() (skrf.network.Network method), 80			
Media (class in skrf.media.media), 185	plot_a_deg_unwrap() (skrf.network.Network method), 81			
motor_on (skrf.vi.stages.ESP300 attribute), 266	plot_a_im() (skrf.network.Network method), 81			
mu (skrf.media.rectangularWaveguide.RectangularWaveguidelot_a_mag() (skrf.network.Network method), 82				
attribute), 214	plot_a_polar() (skrf.network.Network method), 83			
multiplier (skrf.frequency.Frequency attribute), 54	plot_a_rad() (skrf.network.Network method), 84			
multiplier diet (ekrf fraguency Fraguency attribute) 55	nlot a rad unwran() (skrf network Network method) 84			

	plot_y_deg_unwrap() (skrf.network.Network method),
plot_coefs_db() (skrf.calibration.calibration.Calibration	100
method), 169, 181	plot_y_im() (skrf.network.Network method), 101
plot_complex_polar() (in module skrf.plotting), 142	plot_y_mag() (skrf.network.Network method), 101
plot_complex_rectangular() (in module skrf.plotting),	plot_y_polar() (skrf.network.Network method), 102
141	plot_y_rad() (skrf.network.Network method), 103
plot_errors() (skrf.calibration.calibration.Calibration method), 169, 181	plot_y_rad_unwrap() (skrf.network.Network method), 104
plot_it_all() (skrf.network.Network method), 86	plot_y_re() (skrf.network.Network method), 104
plot_logsigma() (skrf.networkSet.NetworkSet method),	plot_z_arcl() (skrf.network.Network method), 105
135	plot_z_arcl_unwrap() (skrf.network.Network method),
plot_passivity() (skrf.network.Network method), 86	106
plot_polar() (in module skrf.plotting), 140	plot_z_complex() (skrf.network.Network method), 107
plot_rectangular() (in module skrf.plotting), 140	plot_z_db() (skrf.network.Network method), 107
plot_residuals() (skrf.calibration.calibration.Calibration	plot_z_deg() (skrf.network.Network method), 108
method), 170, 182	plot_z_deg_unwrap() (skrf.network.Network method),
plot_residuals_db() (skrf.calibration.calibration.Calibration	
method), 170, 182	plot_z_im() (skrf.network.Network method), 110
$plot_residuals_mag() (skrf.calibration.calibration.Calibrati$	
method), 170, 182	plot_z_polar() (skrf.network.Network method), 111
plot_residuals_smith() (skrf.calibration.calibration.Calibra	· · · ·
method), 170, 182	plot_z_rad_unwrap() (skrf.network.Network method),
plot_s_arcl() (skrf.network.Network method), 86	113
plot_s_arcl_unwrap() (skrf.network.Network method), 87	plot_z_re() (skrf.network.Network method), 113
plot_s_complex() (skrf.network.Network method), 88	PNAX (class in skrf.vi.vna), 254
plot_s_db() (skrf.network.Network method), 89	position (skrf.vi.stages.ESP300 attribute), 266
plot_s_deg() (skrf.network.Network method), 89	position_relative (skrf.vi.stages.ESP300 attribute), 266
plot_s_deg_unwrap() (skrf.network.Network method), 90	propagation_constant (skrf.media.cpw.CPW attribute),
plot_s_im() (skrf.network.Network method), 91	228
plot_s_mag() (skrf.network.Network method), 92	propagation_constant (skrf.media.distributedCircuit.DistributedCircuit
plot_s_polar() (skrf.network.Network method), 92	attribute), 199
plot_s_rad() (skrf.network.Network method), 93	propagation_constant (skrf.media.freespace.Freespace at-
plot_s_rad_unwrap() (skrf.network.Network method), 94	tribute), 241
plot_s_re() (skrf.network.Network method), 95	propagation_constant (skrf.media.media.Media attribute),
plot_s_smith() (skrf.network.Network method), 95	185
plot_smith() (in module skrf.plotting), 139	propagation_constant (skrf.media.rectangularWaveguide.RectangularWavegattribute), 214
plot_uncertainty_bounds_component()	
(skrf.networkSet.NetworkSet method), 135 plot_uncertainty_bounds_s()	propagation_impedance_2_distributed_circuit() (in module skrf.tlineFunctions), 154
(skrf.networkSet.NetworkSet method), 136	tile skii.timer tiletions), 134
plot_uncertainty_bounds_s_db()	R
(skrf.networkSet.NetworkSet method), 136	
plot_uncertainty_decomposition()	radian_2_degree() (in module skrf.mathFunctions), 145
(skrf.networkSet.NetworkSet method), 136	read() (in module skrf.io.general), 158 read() (skrf.network.Network method), 114
plot_uncertainty_per_standard()	read_all() (in module skrf.io.general), 159
(skrf.calibration.calibration.Calibration	read_touchstone() (skrf.network.Network method), 115
method), 170, 182	recall_state() (skrf.vi.sa.HP8500 method), 264
plot_y_arcl() (skrf.network.Network method), 96	RectangularWaveguide (class in
plot_y_arcl_unwrap() (skrf.network.Network method),	skrf.media.rectangularWaveguide), 212
97	reflection_coefficient_2_input_impedance() (in module
plot_y_complex() (skrf.network.Network method), 98	skrf.tlineFunctions), 152
plot_y_db() (skrf.network.Network method), 98	reflection_coefficient_2_input_impedance_at_theta() (in
plot_y_deg() (skrf.network.Network method), 99	module skrf.tlineFunctions), 152

skrf.tlineFunctions), 151	method), 137 short() (skrf.media.cpw.CPW method), 236
renumber() (skrf.network.Network method), 115 resample() (skrf.network.Network method), 115, 120	short() (skrf.media.distributedCircuit.DistributedCircuit
residual_ntwks (skrf.calibration.calibration.Calibration	method), 208
attribute), 167, 179	short() (skrf.media.freespace.Freespace method), 250
residuals (skrf.calibration.calibration at-	short() (skrf.media.media.Media method), 193
tribute), 167, 179	short() (skrf.media.media.wedia mediod), 193 short() (skrf.media.rectangularWaveguide.RectangularWaveguide
resistor() (skrf.media.cpw.CPW method), 235	method), 222
resistor() (skrf.media.distributedCircuit.DistributedCircuit	
method), 207	shunt() (skrf.media.distributedCircuit.DistributedCircuit
resistor() (skrf.media.freespace.Freespace method), 249	method), 208
resistor() (skrf.media.media.Media method), 193	shunt() (skrf.media.freespace.Freespace method), 250
resistor() (skrf.media.rectangularWaveguide.RectangularWa	
method), 222	shunt() (skrf.media.rectangularWaveguide.RectangularWaveguide
run() (skrf.calibration.calibration method),	method), 223
170, 182	shunt_capacitor() (skrf.media.cpw.CPW method), 236
170, 102	shunt_capacitor() (skrf.media.distributedCircuit.DistributedCircuit
S	method), 208
s (skrf.network.Network attribute), 64	shunt_capacitor() (skrf.media.freespace.Freespace
s11 (skrf.network.Network attribute), 64	method), 250
s11 (skrf.vi.vna.HP8510C attribute), 259	shunt_capacitor() (skrf.media.media.Media method), 194
s11 (skrf.vi.vna.HP8720 attribute), 261	shunt_capacitor() (skrf.media.rectangularWaveguide.RectangularWaveguide
s11 (skrf.vi.vna.ZVA40 attribute), 256	method), 223
s12 (skrf.network.Network attribute), 64	shunt_delay_load() (skrf.media.cpw.CPW method), 237
s12 (skrf.vi.vna.HP8510C attribute), 259	shunt_delay_load() (skrf.media.distributedCircuit.DistributedCircuit
s12 (skrf.vi.vna.HP8720 attribute), 261	method), 209
s21 (skrf.network.Network attribute), 64	shunt_delay_load() (skrf.media.freespace.Freespace
s21 (skrf.vi.vna.HP8510C attribute), 259	method), 251
s21 (skrf.vi.vna.HP8720 attribute), 261	shunt_delay_load() (skrf.media.media.Media method),
s22 (skrf.network.Network attribute), 64	194
s22 (skrf.vi.vna.HP8510C attribute), 259	shunt_delay_load() (skrf.media.rectangularWaveguide.RectangularWaveguide.
s22 (skrf.vi.vna.HP8720 attribute), 261	method), 223
s2t() (in module skrf.network), 127	shunt_delay_open() (skrf.media.cpw.CPW method), 237
s2y() (in module skrf.network), 126	shunt_delay_open() (skrf.media.distributedCircuit.DistributedCircuit
s2z() (in module skrf.network), 126	method), 209
s_arcl (skrf.network.Network attribute), 64	shunt_delay_open() (skrf.media.freespace.Freespace
s_arcl_unwrap (skrf.network.Network attribute), 65	method), 251
s_db (skrf.network.Network attribute), 65	shunt_delay_open() (skrf.media.media.Media method),
s_deg (skrf.network.Network attribute), 65	195
s_deg_unwrap (skrf.network.Network attribute), 65	$shunt_delay_open() (skrf.media.rectangular Waveguide. Rectangular Waveguide. Rectangula$
s_im (skrf.network.Network attribute), 65	method), 224
s_mag (skrf.network.Network attribute), 65	shunt_delay_short() (skrf.media.cpw.CPW method), 237
s_rad (skrf.network.Network attribute), 66	shunt_delay_short() (skrf.media.distributedCircuit.DistributedCircuit
s_rad_unwrap (skrf.network.Network attribute), 66	method), 209
s_re (skrf.network.Network attribute), 66	shunt_delay_short() (skrf.media.freespace.Freespace
save_all_figs() (in module skrf.plotting), 143	method), 251
save_sesh() (in module skrf.io.general), 162	shunt_delay_short() (skrf.media.media.Media method),
save_state() (skrf.vi.sa.HP8500 method), 264	195
scalar2Complex() (in module skrf.mathFunctions), 146	shunt_delay_short() (skrf.media.rectangularWaveguide.RectangularWavegu
sdata (skrf.vi.vna.ZVA40 attribute), 257	method), 224
send_stop() (skrf.vi.stages.ESP300 method), 266	shunt_inductor() (skrf.media.cpw.CPW method), 238
set_active_trace() (skrf.vi.vna.ZVA40 method), 257	shunt_inductor() (skrf.media.distributedCircuit.DistributedCircuit method), 210

shunt_inductor() method), 252	(skrf.media.freespace.Freespace		module skrf.network), 130		
/ /			rf.media.cpw.CPW method), 239		
	nedia.media.Media method), 195	tee()	(skrf.media.distributedCircuit.DistributedCircuit		
	nedia.rectangularWaveguide.Rectan				
method), 224	1.G		rf.media.freespace.Freespace method), 252		
	kSet.NetworkSet method), 137		rf.media.media.Media method), 196		
	sa.HP8500 method), 264	tee() (skrf.media.rectangularWaveguide.RectangularWaveguide			
	skrf.tlineFunctions), 155	method), 225			
skrf.calibration (module			theta() (in module skrf.tlineFunctions), 148		
skrf.calibration.calibrati		theta_2_d() (skrf.media.cpw.CPW method), 239			
	onAlgorithms (module), 172	$theta_2_d() (skrf.media.distributed Circuit. Distributed Circuit$			
	onFunctions (module), 176	method), 211			
skrf.constants (module)		theta_2_	_d() (skrf.media.freespace.Freespace method),		
skrf.frequency (module)), 53		253		
skrf.io (module), 158			d() (skrf.media.media.Media method), 196		
skrf.io.general (module)		theta_2_	$\underline{d()}(skrf.media.rectangular Waveguide.Rectangular Waveguide$		
skrf.io.touchstone (mod			method), 225		
skrf.mathFunctions (mo		thru() (s	krf.media.cpw.CPW method), 239		
skrf.media (module), 18	34	thru()	(skrf.media.distributedCircuit.DistributedCircuit		
skrf.network (module),	57		method), 211		
skrf.networkSet (modul	e), 132	thru() (s	krf.media.freespace.Freespace method), 253		
skrf.plotting (module),	138		krf.media.media.Media method), 197		
skrf.tlineFunctions (mod	dule), 147	thru() (s	krf.media.rectangularWaveguide.RectangularWaveguide		
skrf.util (module), 156			method), 226		
skrf.vi (module), 254		total_err	cor() (skrf.calibration.calibration.Calibration		
skrf.vi.sa (module), 262			method), 171, 183		
skrf.vi.stages (module),	264	Touchst	one (class in skrf.io.touchstone), 162		
skrf.vi.vna (module), 25	54	trace_a	(skrf.vi.sa.HP8500 attribute), 263		
smith() (in module skrf.	plotting), 138	trace_b	(skrf.vi.sa.HP8500 attribute), 263		
span (skrf.frequency.Fre		Ts (skrf.calibration.calibration.Calibration attribute), 166,			
splitter() (skrf.media.cpw.CPW method), 238			178		
	tributedCircuit.DistributedCircuit	two_por	t (skrf.vi.vna.HP8510C attribute), 259		
method), 210			t (skrf.vi.vna.HP8720 attribute), 261		
splitter() (skrf.media.fre	espace.Freespace method), 252	two_por			
	edia.Media method), 196		skrf.calibration.calibrationAlgorithms), 173		
splitter() (skrf.media.rectangularWaveguide.RectangularWav		a vege id é s			
method), 225		, v	167, 179		
	in module skrf.mathFunctions),		,		
145		U			
start (skrf.frequency.Fre	quency attribute), 55	unbiased	d_error() (skrf.calibration.calibration.Calibration		
	Set.NetworkSet attribute), 134	01101450	method), 171, 183		
step (skrf.frequency.Fre		uncertai	nty_ntwk_triplet() (skrf.networkSet.NetworkSet		
stitch() (in module skrf.		uncertui	method), 137		
stop (skrf.frequency.Fre		uncertai	nty_per_standard()		
	module skrf.tlineFunctions), 155	uncertui	(skrf.calibration.calibration.Calibration		
sweep() (skrf.vi.sa.HP8			method), 171, 183		
sweep() (skrf.vi.vna.ZV		unit (ski	f.frequency.Frequency attribute), 55		
1 "	na.HP8510C attribute), 259	,	t (skrf.frequency.Frequency attribute), 55		
	na.HP8720 attribute), 261		DICT (skrf.vi.stages.ESP300 attribute), 265		
S.TIGH_GIIII (SKII.VI.VI			erf.vi.stages.ESP300 attribute), 266		
Τ			nate_switch_terms() (in module		
	attributa) 66	uncini	skrf.calibration.calibrationAlgorithms), 176		
t (skrf.network.Network attribute), 66 t2s() (in module skrf.network), 130		unwrap_rad() (in module skrf.mathFunctions), 145			
t2y() (in module skrf.ne			trace_list() (skrf.vi.vna.ZVA40 method), 257		
12y() (III IIIOUUIE SKII.IIE	twoinj, 101	apaaic_	1100 (SKII. 11. 114.2 17 10 Hethou), 257		

upload_cal_data() (skrf.vi.vna.ZVA40 method), 258	Z
V	Z (skrf.media.distributedCircuit.DistributedCircuit attribute), 199
velocity (skrf.vi.stages.ESP300 attribute), 266	Z (skrf.media.freespace.Freespace attribute), 241
W	z (skrf.network.Network attribute), 68 z0 (skrf.media.cpw.CPW attribute), 228
w (skrf.frequency.Frequency attribute), 56 wait() (skrf.vi.vna.ZVA40 method), 258	z0 (skrf.media.distributedCircuit.DistributedCircuit attribute), 200
wait_for_stop() (skrf.vi.stages.ESP300 method), 267	z0 (skrf.media.freespace.Freespace attribute), 242
white_gaussian_polar() (skrf.media.cpw.CPW method), 240	z0 (skrf.media.media.Media attribute), 186 z0 (skrf.media.rectangularWaveguide.RectangularWaveguide
white_gaussian_polar() (skrf.media.distributedCircuit.DistributedOircu	z0 (skrf.network.Network attribute), 69
white_gaussian_polar() (skrf.media.freespace.Freespace method), 253	Z0() (skrf.media.cpw.CPW method), 229 Z0() (skrf.media.distributedCircuit.DistributedCircuit
white_gaussian_polar() (skrf.media.media.Media	method), 201
method), 197	Z0() (skrf.media.freespace.Freespace method), 243
white_gaussian_polar() (skrf.media.rectangularWaveguide.method), 226	Rectangular Waveguide. Rectangular Waveguide method), 215
write() (in module skrf.io.general), 160	z2s() (in module skrf.network), 127
write() (skrf.calibration.calibration.Calibration method),	z2t() (in module skrf.network), 128
172, 184	z2y() (in module skrf.network), 128
write() (skrf.network.Network method), 116	z_arcl (skrf.network.Network attribute), 69
write() (skrf.networkSet.NetworkSet method), 138	z_arcl_unwrap (skrf.network.Network attribute), 69
write_all() (in module skrf.io.general), 161	z_db (skrf.network.Network attribute), 69
write_csv() (skrf.media.cpw.CPW method), 240	z_deg (skrf.network.Network attribute), 69
write_csv() (skrf.media.distributedCircuit.DistributedCircu	
method), 212	z_im (skrf.network.Network attribute), 70
write_csv() (skrf.media.freespace.Freespace method),	z_mag (skrf.network.Network attribute), 70
254	z_rad (skrf.network.Network attribute), 70
write_csv() (skrf.media.media.Media method), 198	z_rad_unwrap (skrf.network.Network attribute), 70
write_csv() (skrf.media.rectangularWaveguide.Rectangular method), 227	zl_2_Gamma0() (in module skrf.tlineFunctions), 148
write_touchstone() (skrf.network.Network method), 116	zl_2_Gamma_in() (in module skrf.tlineFunctions), 149 zl_2_zin() (in module skrf.tlineFunctions), 149
Υ	ZVA40 (class in skrf.vi.vna), 255
Y (skrf.media.distributedCircuit.DistributedCircuit attribute), 199	
Y (skrf.media.freespace.Freespace attribute), 241	
y (skrf.network.Network attribute), 66	
y2s() (in module skrf.network), 129	
y2t() (in module skrf.network), 130	
y2z() (in module skrf.network), 129	
y_arcl (skrf.network.Network attribute), 67	
y_arcl_unwrap (skrf.network.Network attribute), 67	
y_db (skrf.network.Network attribute), 67	
y_deg (skrf.network.Network attribute), 67	
y_deg_unwrap (skrf.network.Network attribute), 67	
y_im (skrf.network.Network attribute), 68	
y_mag (skrf.network.Network attribute), 68	
y_rad (skrf.network.Network attribute), 68	
y_rad_unwrap (skrf.network.Network attribute), 68	
v re (skrf network Network attribute) 68	