03.112 Fuel Cell Standby

(03. ECLSS)

OBJECTIVE:

To place one or both of the fuel cells in standby mode for maintenance or off-nominal activities.

EQUIPMENT:

PPE safety glasses Orange caution cone 1x

L1C Subf

1. SAFE FUEL CELLS (IF ACTIVATED)

- 1.1 Remove floor panel 1C and temp stow. Place orange caution cone to side of opening.
- 1.2 Don PPE safety glasses.




Figure 1: Fuel Cell Control Panel

1.3 Check 15 amp circuit breaker is not tripped by verifying there is no white ring visible on the circuit breaker (see Figure 1).

If tripped, contact MCC.

10 Jan 2018 Page 1 of 2

(03. ECLSS)

1.4 Check fuel cell 1 and 2 green operate lights are illuminated (see Figure 2).



Figure 2: Fuel Cell Operate Light

NOTE

Fuel Cell power switch has three positions:

Down = Operate Mode

Neutral (Center) = Power Removed

Up = Standby Mode

- 1.5 Lift switch guards for fuel cells 1 and 2 power and flip power to Standby Mode.
- 1.6 Check fuel cell 1 and 2 yellow standby lights are illuminated and green operate lights are off (see Figure 3).



Figure 3: Fuel Cell Standby Light

- 1.7 Doff PPE safety glasses.
- 1.8 Retrieve and reinstall floor panel 1C.
- 1.9 Stow all equipment.

10 Jan 2018 Page 2 of 2