

Contents

Bridge Index	1
Bridge: CSV-Based AXI4 Crossbar Generator - Specification 1	
Document Organization	2
Chapter 0: Quick Start	2
Chapter 1: Overview	2
Chapter 2: Internal Block Architecture	2
Chapter 3: AXI4 Interface Reference	2
Chapter 4: CSV Generator	3
Chapter 5: Generated RTL	3
Chapter 6: Usage Examples	3
Quick Navigation	4
For RTL Designers	4
For System Architects	4
For Verification Engineers	4
For Protocol Reference	4
Key Features Documented	4
Phase 1 Features (Complete)	4
Phase 2 Features (Complete)	4
Phase 2+ Features (Complete - 2025-11-10)	5
Future Enhancements (Planned)	5
Document Conventions	5
Notation	5
Signal Naming	5
CSV Notation	6
Version History	6
Related Documentation	6

Bridge Index

Generated: 2025-11-14

Bridge: CSV-Based AXI4 Crossbar Generator - Specification

Component: Bridge - CSV-Based AXI4 Crossbar Generator **Version:** 0.90 **Last Updated:** 2025-11-14 **Status:** Phase 2+ Complete
- Bridge ID Tracking Fully Implemented

Document Organization

This specification documents the Bridge CSV-based AXI4 crossbar generator, which creates parameterized SystemVerilog crossbars from human-readable CSV configuration files.

Chapter 0: Quick Start

Location: ch00_quick_start/

- 01_installation.md - Installation and setup
- 02_first_bridge.md - Creating your first bridge
- 03_simulation.md - Simulating the bridge
- 04_integration.md - Integration into designs

Chapter 1: Overview

Location: ch01_overview/

- 01_overview.md - What is Bridge, key features, and applications
- 02_architecture.md - System architecture and design philosophy
- 03_clocks_and_reset.md - Clocking and reset strategy
- 04_acronyms.md - Acronyms and terminology
- 05_references.md - References and related documents

Chapter 2: Internal Block Architecture

Location: ch02_blocks/

This chapter documents the internal functional blocks that make up the AXI4 bridge crossbar.

- 01_master_adapter.md - Master interface adaptation and ID extension
- 02_slave_router.md - Address decoding and slave selection
- 03_crossbar_core.md - Core switching fabric architecture
- 04_arbitration.md - Multi-master arbitration schemes
- 05_id_management.md - Transaction ID tracking (CAM/FIFO)
- 06_width_conversion.md - Data width conversion logic
- 07_protocol_conversion.md - AXI4-to-APB protocol conversion
- 08_response_routing.md - Response path routing and merging
- 09_error_handling.md - Error detection and handling

Chapter 3: AXI4 Interface Reference

Location: ch03_interfaces/

Complete reference for all AXI4 signals, timing, and protocol rules used in the bridge.

- 01_axi4_signals.md - Write Address Channel (AW) detailed reference
- 02_write_data.md - Write Data Channel (W) specification
- 03_write_response.md - Write Response Channel (B) specification
- 04_read_address.md - Read Address Channel (AR) detailed reference
- 05_read_data.md - Read Data and Response Channel (R) specification

Chapter 4: CSV Generator

Location: ch02_csv_generator/

- 04_channel_specific.md - Channel-specific masters (wr/rd/rw)

Chapter 5: Generated RTL

Location: ch03_generated_rtl/

- 01_module_structure.md - Generated module organization
- 02_arbiter_fsms.md - AW/AR arbiter finite state machines
- 07_bridge_id_tracking.md - Bridge ID tracking for multi-master response routing

PlantUML Diagrams: assets/puml/

- aw_arbiter_fsm.puml - AW channel arbiter FSM
- ar_arbiter_fsm.puml - AR channel arbiter FSM

Graphviz Block Diagrams: assets/graphviz/

- bridge_2x2.gv - 2 master × 2 slave configuration
- bridge_1x4.gv - 1 master × 4 slave configuration

Chapter 6: Usage Examples

Location: ch04_usage_examples/

(To be documented - examples of bridge configuration and usage)

Quick Navigation

For RTL Designers

- Start with Quick Start Guide
- Review Overview
- Study Internal Blocks
- Reference AXI4 Signals

For System Architects

- Start with Architecture Overview
- Review Crossbar Core
- Study Arbitration
- Review ID Management

For Verification Engineers

- Start with Internal Blocks
- Review Error Handling
- Study AXI4 Protocol
- Review Generated RTL

For Protocol Reference

- Complete AXI4 Signal Reference
 - Understand Channel Interactions
 - Study Out-of-Order Behavior
-

Key Features Documented

Phase 1 Features (Complete)

- CSV configuration parsing
- Custom signal prefixes per port
- Mixed AXI4/APB protocol support
- Mixed data widths
- Partial connectivity matrices
- Automatic converter identification
- Port generation with custom prefixes

Phase 2 Features (Complete)

- **Channel-Specific Masters** - Write-only (wr), read-only (rd), full (rw)

- Conditional AXI4 channel generation
- Optimized width converter instantiation
- Channel-aware direct connections
- Resource optimization for dedicated masters

Phase 2+ Features (Complete - 2025-11-10)

- **Bridge ID Tracking** - Multi-master response routing with `bridge_id`
- Per-master unique BRIDGE_ID parameter
- Slave adapter CAM/FIFO transaction tracking
- Configurable out-of-order support per slave (`enable_ooo`)
- Crossbar `bridge_id`-based response routing
- Zero-latency FIFO mode for in-order slaves
- 1-cycle CAM mode for out-of-order slaves

Future Enhancements (Planned)

- **Monitored Interface Versions:** AXI4/AXIL4 master/slave monitor ports for debugging
 - `axi4_master_rd_mon.sv` / `axi4_master_wr_mon.sv`
 - `axi4_slave_rd_mon.sv` / `axi4_slave_wr_mon.sv`
 - `axil4_master_rd_mon.sv` / `axil4_master_wr_mon.sv`
 - `axil4_slave_rd_mon.sv` / `axil4_slave_wr_mon.sv`
 - monbus aggregation (similar to stream component `monbus_axil_group.sv`)
 - APB converter placeholder implementation
 - Slave-side width converter downsize
 - Variable-width crossbar internal data path
 - Performance monitoring integration
-

Document Conventions

Notation

- **bold** - Important terms, file names
- `code` - CSV fields, signal names, commands
- *italic* - Emphasis, notes

Signal Naming

- `{prefix}awaddr` - AXI4 Write Address channel address
- `{prefix}araddr` - AXI4 Read Address channel address
- `{prefix}paddr` - APB address

- `aclk` - AXI4 clock
- `aresetn` - AXI4 active-low reset
- `pclk` - APB clock
- `presetn` - APB active-low reset

CSV Notation

- `port_name` - Unique identifier for port
 - `channels` - Channel specification: `rw/wr/rd`
 - `N/A` - Not applicable field value
-

Version History

Version	Date	Changes
1.0	2025-10-19	Initial specification with Phase 1 features
1.1	2025-10-26	Added channel-specific master support (Phase 2)
1.2	2025-11-10	Added bridge ID tracking for multi-master routing (Phase 2+)
0.90	2025-11-14	Added Chapter 2 (Internal Blocks) and Chapter 3 (AXI4 Interface Reference)

Related Documentation

- `../PRD.md` - Product Requirements Document
 - `../CLAUDE.md` - AI integration guide
 - `../CSV_BRIDGE_STATUS.md` - Implementation status and phase tracking
 - `../TASKS.md` - Development tasks
 - `../bin/bridge_csv_generator.py` - Generator source code
-

Next: Chapter 0 - Quick Start or Chapter 1 - Overview