# Asterix category 034 - Transmission of Monoradar Service Messages

category: 034
edition: 1.28
date: 2021-03-02

#### **Preamble**

Surveillance data exchange.

## Description of standard data items

### I034/000 - Message Type

definition: This Data Item allows for a more convenient handling of the messages at the receiver side by further defining the type of transaction.

Element bit size: 8 Values:

- 1: North marker message
- 2: Sector crossing message
- 3: Geographical filtering message
- 4: Jamming strobe message
- 5: Solar Storm Message

#### Notes:

- 1. In applications where transactions of various types are exchanged, the Message Type Data Item facilitates the proper message handling at the receiver side.
- 2. All Message Type values are reserved for common standard use.
- 3. The list of items present for the four message types is defined in the following table.

M stands for mandatory, O for optional, X for never present.

TODO: message types table

#### **I034/010 - Data Source Identifier**

definition: Identification of the radar station from which the data are received. Group

### I034/010/SAC - System Area Code

Element bit size: 8 Raw Content

#### I034/010/SIC - System Identification Code

Element bit size: 8 Raw Content

#### **Note:**

• The up-to-date list of SACs is published on the EUROCONTROL Web Site (http://www.eurocontrol.int/asterix).

#### 1034/020 - Sector Number

definition: Eight most significant bits of the antenna azimuth defining a particular azimuth sector.

```
Element bit size: 8 Unsigned quantity LSB = 360/2^8 ° \approx 1.40625 ° unit: "°"
```

#### **I034/030 - Time of Day**

definition: Absolute time stamping expressed as UTC time.

```
Element bit size: 24 Unsigned quantity LSB = 1/2^7 s \approx 7.8125e - 3 s unit: "s"
```

Notes:

• The time of day value is reset to zero each day at midnight.

#### 1034/041 - Antenna Rotation Speed

definition: Antenna rotation period as measured between two consecutive North crossings or as averaged during a period of time.

```
Element bit size: 16 Unsigned quantity LSB = 1/2^7 s \approx 7.8125e - 3 s unit: "s"
```

Notes:

 This item represents the antenna rotation period as measured by the radar station between two consecutive North crossings, or a calculated antenna rotation speed as averaged during a period of time, or during a number of antenna rotation scans.

### **I034/050 - System Configuration and Status**

definition: Information concerning the configuration and status of a System. Compound

```
I034/050/COM - Common Part

Group

I034/050/COM/NOGO - Operational Release Status of the System

Element
bit size: 1
Values:
```

- **0:** System is released for operational use
- **1:** Operational use of System is inhibited, i.e. the data shall be discarded by an operational SDPS

# ${\bf I034/050/COM/RDPC - Radar\, Data\, Processor\, Chain\, Selection\,\, Status}$

Element bit size: 1 Values:

**0:** RDPC-1 selected **1:** RDPC-2 selected

### I034/050/COM/RDPR - Event to Signal a Reset/restart of the Selected Radar Data Processor Chain, I.e. Expect a New Assignment of Track Numbers

Element bit size: 1 Values:

**0:** Default situation **1:** Reset of RDPC

# I034/050/COM/OVLRDP - Radar Data Processor Overload Indicator

Element bit size: 1 Values:

0: Default, no overload1: Overload in RDP

# I034/050/COM/OVLXMT - Transmission Subsystem Overload Status

Element bit size: 1 Values:

0: Default, no overload

1: Overload in transmission subsystem

# I034/050/COM/MSC - Monitoring System Connected Status

Element bit size: 1 Values:

**0:** Monitoring system connected**1:** Monitoring system disconnected

#### **I034/050/COM/TSV** - Time Source Validity

Element
bit size: 1
Values:

0: Valid
1: Invalid
Spare bits: 1

Spare Spare

### I034/050/PSR - Specific Status Information for a PSR Sensor

Group

#### I034/050/PSR/ANT - Selected Antenna

Element bit size: 1 Values:

0: Antenna 1

#### 1: Antenna 2

### I034/050/PSR/CHAB - Channel A/B Selection Status

Element bit size: 2 Values:

- 0: No channel selected
- 1: Channel A only selected
- 2: Channel B only selected
- 3: Diversity mode; Channel A and B selected

#### I034/050/PSR/OVL - Overload Condition

Element bit size: 1 Values:

**0:** No overload

1: Overload

# I034/050/PSR/MSC - Monitoring System Connected Status

Element bit size: 1 Values:

**0:** Monitoring system connected**1:** Monitoring system disconnected

Spare bits: 3

### 1034/050/SSR - Specific Status Information for a SSR Sensor

Group

#### I034/050/SSR/ANT - Selected Antenna

Element bit size: 1 Values:

**0:** Antenna 1 **1:** Antenna 2

#### I034/050/SSR/CHAB - Channel A/B Selection Status

Element bit size: 2 Values:

0: No channel selected

- 1: Channel A only selected
- 2: Channel B only selected
- **3:** Invalid combination

#### I034/050/SSR/OVL - Overload Condition

Element bit size: 1 Values:

0: No overload1: Overload

# I034/050/SSR/MSC - Monitoring System Connected Status:

Element bit size: 1 Values:

**0:** Monitoring system connected

1: Monitoring system disconnected

Spare bits: 3

### 1034/050/MDS - Specific Status Information for a Mode S Sensor

#### Group

### I034/050/MDS/ANT - Selected Antenna

Element bit size: 1 Values:

**0:** Antenna 1 **1:** Antenna 2

### I034/050/MDS/CHAB - Channel A/B Selection Status

Element bit size: 2 Values:

0: No channel selected

1: Channel A only selected

2: Channel B only selected

3: Illegal combination

### I034/050/MDS/OVLSUR - Overload Condition

Element bit size: 1 Values:

0: No overload1: Overload

# I034/050/MDS/MSC - Monitoring System Connected Status:

Element bit size: 1 Values:

0: Monitoring system connected

1: Monitoring system disconnected

# I034/050/MDS/SCF - Channel A/B Selection Status for Surveillance Co-ordination Function

Element bit size: 1 Values:

**0:** Channel A in use **1:** Channel B in use

# I034/050/MDS/DLF - Channel A/B Selection Status for Data Link Function

Element bit size: 1 Values:

**0:** Channel A in use **1:** Channel B in use

# ${\bf I034/050/MDS/OVLSCF\ -\ Overload\ in\ Surveillance\ Coordination\ Function}$

Element bit size: 1 Values:

0: No overload1: Overload

#### I034/050/MDS/OVLDLF - Overload in Data Link Function

Element bit size: 1 Values:

0: No overload1: Overload

Spare bits: 7

#### 1034/060 - System Processing Mode

definition: Status concerning the processing options, in use during the last antenna revolution, for the various Sensors, composing the System.

Compound

#### I034/060/COM - Common Part

Group

Spare bits: 1

# I034/060/COM/REDRDP - Reduction Steps in Use for An Overload of the RDP

Element bit size: 3 Values:

- **0:** No reduction active
- 1: Reduction step 1 active
- 2: Reduction step 2 active
- 3: Reduction step 3 active
- 4: Reduction step 4 active
- 5: Reduction step 5 active
- **6:** Reduction step 6 active
- 7: Reduction step 7 active

# I034/060/COM/REDXMT - Reduction Steps in Use for An Overload of the Transmission Subsystem

Element bit size: 3 Values:

- **0:** No reduction active
- 1: Reduction step 1 active
- 2: Reduction step 2 active
- **3:** Reduction step 3 active
- **4:** Reduction step 4 active
- 5: Reduction step 5 active
- **6:** Reduction step 6 active **7:** Reduction step 7 active
- Spare bits: 1

Spare

Spare

# I034/060/PSR - Specific Processing Mode Information for a PSR Sensor

Group

#### I034/060/PSR/POL - Polarization in Use by PSR

Element bit size: 1 Values:

**0:** Linear polarization

1: Circular polarization

# I034/060/PSR/REDRAD - Reduction Steps in Use as Result of An Overload Within the PSR Subsystem

Element bit size: 3 Values:

**0:** No reduction active

1: Reduction step 1 active

- 2: Reduction step 2 active
- **3:** Reduction step 3 active
- **4:** Reduction step 4 active
- **5:** Reduction step 5 active
- **6:** Reduction step 6 active
- 7: Reduction step 7 active

#### I034/060/PSR/STC - Sensitivity Time Control Map in Use

Element bit size: 2 Values:

- **0:** STC Map-1
- 1: STC Map-2
- 2: STC Map-3
- 3: STC Map-4

Spare bits: 2

#### 1034/060/SSR - Specific Processing Mode Information for a SSR Sensor

Group

# I034/060/SSR/REDRAD - Reduction Steps in Use as Result of An Overload Within the SSR Subsystem

Element bit size: 3 Values:

- **0:** No reduction active
- 1: Reduction step 1 active
- 2: Reduction step 2 active
- **3:** Reduction step 3 active
- 4: Reduction step 4 active
- **5:** Reduction step 5 active
- **6:** Reduction step 6 active
- **7:** Reduction step 7 active

Spare bits: 5

# I034/060/MDS - Specific Processing Mode Information for a Mode S Sensor

Group

# ${\bf I034/060/MDS/REDRAD - Reduction\ Steps\ in\ Use\ as\ Result\ of\ An\ Overload\ Within\ the\ Mode\ S\ Subsystem}$

Element bit size: 3

Values:

- **0:** No reduction active
- 1: Reduction step 1 active
- 2: Reduction step 2 active
- 3: Reduction step 3 active
- 4: Reduction step 4 active
- 5: Reduction step 5 active
- **6:** Reduction step 6 active
- **7:** Reduction step 7 active

#### I034/060/MDS/CLU - Cluster State

Element bit size: 1 Values:

- **0:** Autonomous
- **1:** Not autonomous

Spare bits: 4

Notes:

 Applicable to all defined secondary subfields. The actual mapping between the up to seven data reduction steps and their associated data reduction measures is not subject to standardisation.

### **I034/070 - Message Count Values**

definition: Message Count values, according the various types of messages, for the last completed antenna revolution, counted between two North crossings

Repetitive

Regular, 1 byte(s) REP field size.

Group

#### I034/070/TYP - Type of Message Counter

Element bit size: 5 Values:

- **0:** No detection (number of misses)
- 1: Single PSR target reports
- 2: Single SSR target reports (Non-Mode S)
- **3:** SSR+PSR target reports (Non-Mode S)
- **4:** Single All-Call target reports (Mode S)
- 5: Single Roll-Call target reports (Mode S)
- **6:** All-Call + PSR (Mode S) target reports
- 7: Roll-Call + PSR (Mode S) target reports
- 8: Filter for Weather data
- **9:** Filter for Jamming Strobe
- 10: Filter for PSR data
- 11: Filter for SSR/Mode S data
- 12: Filter for SSR/Mode S+PSR data
- 13: Filter for Enhanced Surveillance data
- 14: Filter for PSR+Enhanced Surveillance
- **15:** Filter for PSR+Enhanced Surveillance + SSR/Mode S data not in Area of Prime Interest
- **16:** Filter for PSR+Enhanced Surveillance + all SSR/Mode S data
- **17:** Re-Interrogations (per sector)
- **18:** BDS Swap and wrong DF replies(per sector)
- **19:** Mode A/C FRUIT (per sector)
- 20: Mode S FRUIT (per sector)

#### 1034/070/COUNT - COUNTER

Element bit size: 11 Unsigned integer

#### 1034/090 - Collimation Error

definition: Averaged difference in range and in azimuth for the primary target position with respect to the SSR target position as calculated by the radar station.

Group

#### I034/090/RNG - Range Error

Element bit size: 8 Signed quantity LSB =  $1/2^7$  NM  $\approx 7.8125e - 3$  NM unit: "NM"

### I034/090/AZM - Azimuth Error

Element bit size: 8 Signed quantity LSB =  $360/2^14$  °  $\approx 2.197265625e-2$  ° unit: "°"

#### Notes:

• Negative values are coded in two's complement form.

#### 1034/100 - Generic Polar Window

definition: Geographical window defined in polar co-ordinates. Group

#### I034/100/RHOST - Rho Start

Element bit size: 16 Unsigned quantity LSB =  $1/2^8$  NM  $\approx 3.90625e-3$  NM unit: "NM" <=256.0

### I034/100/RHOEND - Rho End

Element bit size: 16 Unsigned quantity LSB =  $1/2^8$  NM  $\approx 3.90625e-3$  NM unit: "NM" <=256.0

#### I034/100/THETAST - Theta Start

Element bit size: 16 Unsigned quantity LSB =  $360/2^16$  °  $\approx 5.4931640625e-3$  ° unit: "°"

#### I034/100/THETAEND - Theta End

Element bit size: 16 Unsigned quantity LSB =  $360/2^16$  °  $\approx 5.4931640625e-3$  ° unit: "°"

#### I034/110 - Data Filter

definition: Data Filter, which allows suppression of individual data types.

Element bit size: 8 Values:

- 0: Invalid value
- 1: Filter for Weather data
- 2: Filter for Jamming Strobe
- 3: Filter for PSR data
- 4: Filter for SSR/Mode S data
- 5: Filter for SSR/Mode S + PSR data
- 6: Enhanced Surveillance data

- 7: Filter for PSR+Enhanced Surveillance data
- **8:** Filter for PSR+Enhanced Surveillance + SSR/Mode S data not in Area of Prime Interest
- 9: Filter for PSR+Enhanced Surveillance + all SSR/Mode S data

#### Notes:

- 1. This Data Item is often used in conjunction with I034/100 and represents a Data Filter for a specific geographical subarea. A Data Source may have zero, one or multiple data filters active at any time.
- 2. If I034/110 is not accompanied with I034/100, then the Data Filter is valid throughout the total area of coverage.

#### I034/120 - 3D-Position Of Data Source

definition: 3D-Position of Data Source in WGS 84 Co-ordinates Group

### I034/120/HGT - Height of Data Source

Element bit size: 16 Signed quantity LSB =  $1 \text{ m} \approx 1.0 \text{ m}$  unit: "m"

#### I034/120/LAT - Latitude

Element bit size: 24 Signed quantity LSB =  $180/2^23$  °  $\approx 2.1457672119140625e-5$  ° unit: "°" >= -90.0 <= 90.0

### I034/120/LON - Longitude

Element bit size: 24 Signed quantity LSB =  $180/2^23$  °  $\approx 2.1457672119140625e-5$  ° unit: "°" >= -180.0 <= 180.0

#### **I034/RE - Reserved Expansion Field**

definition: Expansion Explicit (ReservedExpansion)

#### 1034/SP - Special Purpose Field

definition: Special Purpose Field Explicit (SpecialPurpose)

### **User Application Profile**

- 1: I034/010 Data Source Identifier
- 2: I034/000 Message Type
- 3: I034/030 Time of Day
- 4: I034/020 Sector Number
- 5: I034/041 Antenna Rotation Speed
- 6: I034/050 System Configuration and Status
- 7: I034/060 System Processing Mode
- (FX) Field extension indicator
- 8: I034/070 Message Count Values
- 9: 1034/100 Generic Polar Window
- 10: I034/110 Data Filter
- 11: I034/120 3D-Position Of Data Source
- 12: I034/090 Collimation Error
- 13: I034/RE Reserved Expansion Field
- 14: I034/SP Special Purpose Field
- (FX) Field extension indicator