UNIVERSITY OF SOUTHAMPTON

FACULTY OF PHYSICAL AND APPLIED SCIENCES

Electronics and Computer Science

Supervisor: Prof. Steve Gunn Second Examiner: Prof. Mark Zwolinski

Two Dimensional Stereoscopic Mapping Robot

by

Henry S. Lovett

A project report for a Part Three Project for the award of BEng Electronic Engineering

December 5, 2012

UNIVERSITY OF SOUTHAMPTON

$\underline{ABSTRACT}$

FACULTY OF PHYSICAL AND APPLIED SCIENCES Electronics and Computer Science

TWO DIMENSIONAL STEREOSCOPIC MAPPING ROBOT

by Henry S. Lovett

This paper describes the research, designing and building of a stereoscopic mapping robot. Mapping robots usually utilise Infra-red or laser range finders to do the distance calculations. By using two cameras, distances to objects can be calculated. The end goal is to build up an occupancy map which shows the state of an explored area as either unknown, free or occupied.

Contents

N	omer	ıclatur	·e	xiii
1	Intr	oducti	ion	1
2	Res	earch		3
	2.1	Hardw	vare Research	3
	2.2	Image	Algorithms	3
		2.2.1	Comparison Algorithms	
3	Init	ial Haı	rdware and Firmware Development	5
	3.1	Camer	ra	5
		3.1.1	Single Camera Operation	6
		3.1.2	Dual Camera Operation	7
	3.2	SD Ca	ard	7
		3.2.1	Storing Images	8
		3.2.2	User Interface	9
	3.3	Motor	Control	10
	3.4	PCB I	Development	10
4	Inve	estigati	ion into Vision Algorithms	11
	4.1	Compa	arison	11
		4.1.1	Sum of Absolue Differences	12
		4.1.2	Sum of Squared Differences	12
		4.1.3	NCC	12
		4.1.4	Comparison	13
		4.1.5	Conclusion	15
	4.2	Range	e Finding	15
		4.2.1	Derivations	15
			4.2.1.1 Object is between the Cameras	15
			4.2.1.2 Object is infront of a camera	17
			4.2.1.3 Object is to the same side in each camera	17
5	Con	clusio	ns and Further Work	19
A	Circ	cuit Di	iagrams	21
	A. 1	OV767	70 Breakout Board Schematic	21
	Α 2	Il Mat	tto and Dual Camera Schematic	21

vi CONTENTS

\mathbf{B}	Bitr	nap File Format				
	B.1	Bitma	p File For	mat	23	
	C				o -	
\mathbf{C}		rce Co			27	
	C.1	C Cod	e for AVF		27	
		C.1.1	Dual Car	mera Operation	27	
			C.1.1.1	main.c	27	
			C.1.1.2	Bitmap.h	31	
			C.1.1.3	Bitmap.c	31	
			C.1.1.4	Config.h	33	
			C.1.1.5	Config.c	34	
			C.1.1.6	DualCameras.h	35	
			C.1.1.7	DualCameras.c	40	
			C.1.1.8	PCA9542A.h	48	
			C.1.1.9	PCA9542A.c	49	
			C.1.1.10	TWI_Master.h	50	
			C.1.1.11	TWI_Master.c	52	
			C.1.1.12	Usart.h	58	
			C.1.1.13	Usart.c	58	
		C.1.2	Dual Car	mera User Interface	60	
			C.1.2.1	DualCamera_UI.c	60	
			C.1.2.2	TWI_slave.h	62	
			C.1.2.3	TWI_slave.c	65	
	C.2	MATL	AB Code	for Image Algorithm Prototyping	71	
			C.2.0.4	loadimages.m	71	
			C.2.0.5	GetSubImage.m	71	
			C.2.0.6	SADAll.m		
			C.2.0.7	SSDAll.m	73	
			C208	NCC m	7/	

List of Figures

3.1	the SD Card	g
4.1	Stereoscopic Test Images from MATLAB Examples	11
4.2	Result Graphs of Comparison Algorithms	14
4.3	Problem 1 - Object is between the Cameras	16
4.4	Problem 1 : Left Camera Simplified	16
4.5	Problem 3 - Object is to the same side in both cameras	17
A.1	The circuit diagram for the OV7670 breakout board	21
A.2	The circuit diagram for Dual Cameras using the Il Matto Board	22

List of Tables

3.1	A table comparing different image formats available ([?])	8
3.2	Pin Connections of the ATMega 644P for Dual Camera Operation	,
B.1	Feasible triples for a highly variable Grid	23

Listings

Nomenclature

 I^2C Inter-Integrated Circuit TWI Two Wire Interface SCCB Serial Camera Control Bus kB KiloBytes φ_0 Field of View of the Camera B Seperation Distance of two Cameras i,j Pixel Index of an Image

Introduction

The Introduction to my Report ...

The initial idea of the project was taken from Pirobot([?]).

what it will do. Define everything. Use. Very general

General - mapping robots.

stereovision - uses etc.

other similar projects

why mine is important

Research

The research done for this project is split down into three sections:

- 1. Hardware
- 2. Software, broken down into:
 - (a) Firmware
 - (b) Algorithms

2.1 Hardware Research

Talk about why I chose to develop with AVRs, comparison with other uControllers. Why I used the OV7670 Camera etc etc

2.2 Image Algorithms

2.2.1 Comparison Algorithms

Before

Initial Hardware and Firmware Development

For initial development, an *Il Matto* board, designed by Steve Gunn, which has an ATMega644P, was used. The system is clocked at 16MHz and has an on-board SD card connector.

The following section is broken down into parts listed below:

- 1. Camera Code
- 2. SD Card
- 3. Motor Control
- 4. PCB Development

3.1 Camera

The camera that was used was an OV7670 by OmniVision. It is mounted onto a break out board and connected to a AL422B FIFO Buffer. The breakout board also had all passive components and a 24MHz clock mounted. The schematic for the device can be seen in Appendix A.

Original code for the camera operation was given to me by Steve Gunn, of which I used to gain the operation required.

3.1.1 Single Camera Operation

The camera uses a SCCB Interface([?]) created by OmniVision. This is almost identical to the I^2C Interface by Phillips. The original code used a bit-banged SCCB interface which was very slow and used up processing time. This was changed to make used of the built in interrupt driven I^2C interface (named TWI in Atmel AVRs)¹. This communication bus is used to set up the control registers of the OV7670 to enable operation in the correct format. RGB565 is used in my application.

RGB565 is a 16 bit pixel representation where bits 0:4 represent the blue intensity, 5:10 contain green intensity and 11:15 represent the red intensity. This is a compact way of storing data but only allows 65536 colours. Greys can also appear to be slightly green due to an inconsistent colour ratio of the green field.

The camera must use a high speed clock in order to ensure the pixels obtained are from the same frame. This makes it difficult for an AVRs (ATMegas typically clocked at 12-16MHz) to be able to respond to the camera quick enough. This highlights the importance of the necessity of the FIFO Buffer.

The OV7670 is set up so that the VSYNC pin goes low at the beginning of every full frame of data and HREF is high when the data being output is valid. The pixel data is then clocked out on every rising edge of PCLK. To control the buffer, WEN (write enable) is NAND with the HREF signal. When both are high, the write enable to the buffer will be active and the data will be clocked in by PCLK. In order to acquire a full frame, the first VSYNC pin is set up to interrupt the AVR to enable WEN. The operation is then automatic and all the data is clocked into the buffer until the second interrupt of VSYNC where WEN is disabled. At this point, the entire frame of data is stored in the buffer.

To obtain the data from the buffer, the AVR manually pulses the read clock and stores the data on the input port. All the data is then read in one pixel at a time.

Difficulties arose at this point with the storage of the data. The ATMega644P has 4kB of internal SRAM, but 153.6kB of memory are needed to store a single frame or image at QVGA (320 by 240 pixels) quality.

Firstly, data was sent straight to a desktop computer via a COM Port. A simple desktop program written in C# to store all the data and convert binary into a Bitmap image. This method was slow, taking around 30 seconds to transmit one uncompressed image.

The second option then was to use extra memory connected to the microcontroller. An SD card was decided to be used in as a FAT file system. This will allow data to be looked at by a user on a computer of image files and log files. This is discussed in section 2.

 $^{^1}I^2C$, SCCB and TWI are all the same but are called differently due to Phillips owning the right to the term I^2C

3.1.2 Dual Camera Operation

In order for stereovision to be successful, two cameras separated by a horizontal distance will need to be driven at the same time to obtain photos of the same time frame.

The buffers have an output enable pin so the data bus can be shared by both cameras to the AVR. All buffer function pins are driven from pins, although a demultiplexer could be used if pins are short. The ATMega644P offers three interrupt pins, two of which are used by the two VSYNC pins for the cameras.

Two ISRs are used to control the VSYNC method and when taking a photo, both frames are taken at a time period close together to capture the same scenario. The data for both images are read back from one and then the other by the AVR.

A major problem now occurred with using the I^2C interface to set up both cameras. The camera has a set I^2C address of 21_{16} which cannot be changed. Two I^2C devices with exactly the same address cannot be used on the same bus. Two solutions to this are possible: driving one from I^2C and one from SCCB, or using an I^2C multiplexer. By using two different buses, there is no contention on the bus. However, SCCB is slow and processor hungry as it deals with the protocol bit by bit. Space for the code then has to be made and this code cannot be reused.

An I^2C multiplexer sits on the bus and has multiple output buses. The master can then address the MUX and select whether to pass the bus to bus 0, bus 1 or not allow the data to be transferred. This saves processor time, but means a write operation has to be done to select the camera bus before being able to write to the camera. This slows down the operation but not as much as using SCCB. The main disadvantage to the I^2C MUX is the extra hardware needed. Firstly, the MUX itself, but also 7 extra resistors to pull up the two extra buses and the three interrupt lines must be added.

Overall, the disadvantages posed by using a MUX are small and simplify the operation and reduce the code size so an I^2C MUX will be used. A suitable multiplexer is the Phillips PCA9542A([?]).

Operation to read an image is identical to using one camera. An ID number is passed through the functions to make a decision on the pins to use to read the buffer and enable the output. Care was taken to avoid bus contention, but no checking procedure is explicitly in place. Both images are then read back from the buffers and stored to memory.

3.2 SD Card

	Bitmap	JPEG	PNG	GIF
Extension	*.bmp	*.jpg /*.jpeg	*.png	*.gif
Compression	No	Lossless and	Lossless ZIP	Lossy
		Lossy		
File Size of 320	225	20	23	24
by 240 pixel Im-				
age (kB)				
Bits per Pixel	8, 16, 24 or 32	24	24, 32 or 48	24, but only 256
				Colours

Table 3.1: A table comparing different image formats available ([?])

Sort Reference Out

To use the SD card, the FATFS library [?] was used. The library supplies all the functions for writing a FAT File System in the files ff.c, ff.h, ffconf.h, diskio.c, diskio.h and integer.h. The diskio.h functions control what device is being used - SD/MMC Card, USB drive etc. The ff.h header contains all the functions to write to in a FAT File system.

An SD card was chosen to be used due to it's small size, low cost and a large data storage. The cards work using an SPI bus which can be used for other devices within the system so the card only uses one extra enable pin in hardware to function.

3.2.1 Storing Images

Many image formats are common such as Joint Photographic Expert Group (JPEG), Portable Network Graphics (PNG), Bitmap (BMP) and Graphics Interchange Format (GIF). Table 3.1 shows a summary of some common image formats.

It is clear that the best choice for images would be either PNG or JPEG. However, these require much computational time to compress the image to obtain the correct format. To avoid compression, and thereby save computational time, Bitmap was decided to be used at the expense of using more memory. The data in a bitmap image is also stored in RGB format so can be read back easily when processing the data. Appendix B shows the make up of a Bitmap File that was used.

By writing the image in this format, the images are then able to be opened on any operating system. This aids debugging and allows the protopping of image algorithms in a more powerful environment. Figure 3.1 shows a photo taken by the OV7670 and stored on a SD card.



Figure 3.1: An Example Image taken using the OV7670 and stored as a Bitmap on the SD Card $\,$

	Port A	Port B	Port C	Port D
0	Data 0	SD Write Protect	I^2C SCL	
1	Data 1	SD Card Detect	I^2CSDA	
2	Data 2	USB Data Plus	Read Clock 1	VSync 0
3	Data 3	USB Data Minus	Read Reset 1	VSync 1
4	Data 4	SPI Chip Select	Write Enable 1	Read Clock 0
5	Data 5	SPI MOSI	Write Reset 1	Read Reset 0
6	Data 6	SPI MISO	Output Enable 0	Write Enable 0
7	Data 7	SPI Clock	Output Enable 0	Write Reset 0

Table 3.2: Pin Connections of the ATMega 644P for Dual Camera Operation.

3.2.2 User Interface

The ATMega 664P pinout for the Dual Camera operation can be seen in table 3.2. Due to a lack of Input / Output pins remaining, an ATMega 168 was added on the I^2C bus to act as a port extender. The 168 accepts a read or write, places the write data on Port D and reads in the lower nibble of Port C. When a button is pressed, this is stored in the 168 until a read has been done. This is so the master doesn't miss any button presses while busy doing lengthy operations such as writing an image. The code is based on [?] written for IAR Compiler. This code was altered to compile with GCC under Atmel Studio. AVRs contain a hardware based I^2C protocol that is interrupt based in software. The interrupt service routine of the TWI vector is a state machine which loads the data to send, stores received data, responds to acknowledges and address calls and deals with bus errors that can occur.

3.3 Motor Control

do something of this SOON

3.4 PCB Development

Also do something of this SOON Circuit Diagram for Rev A

Investigation into Vision Algorithms

4.1 Comparison

find some references to back these claims up

In computer vision, there are many different ways of comparing two similar images. These include the sum of absolute differences (S.A.D.) ([?]), the sum of squared differences (S.S.D.) and normalised cross correlation (N.C.C.). Each of these methods will be explained and tested to compare them. All testing will use images seen in figure 4.1. Each test uses the same size of image to compare to of 50×50 pixels of the same part of the image.

Maybe do a basic 5x5 example for each?




Figure 4.1: Stereoscopic Test Images from MATLAB Examples

4.1.1 Sum of Absolue Differences

Given two indentically sized matricies, A, B of dimensions I, J, SAD is defined as

$$SAD = \sum_{i=0}^{I-1} \sum_{j=0}^{J-1} A[i,j] - B[i,j]$$
(4.1)

This method takes each sub image and subtracts the observed sub image from the expected. All differences are then added together. This algorithm is simple and requires a small amount of computation. The algorithm returns values where a small result means the two images are well matched.

4.1.2 Sum of Squared Differences

$$SSD = \sum_{i=0}^{I-1} \sum_{j=0}^{J-1} (A[i,j] - B[i,j])^2$$
(4.2)

This is very similar to S.A.D. but adds more complexity by squaring each difference. This removes the ability of equally different but opposite differences cancelling each other out (grey to white of one pixel will cancel out a white to grey difference in the other). Again, a low result is a match in this case.

4.1.3 NCC

$$NCC = \frac{1}{n} \sum_{i,j} \frac{(A[i,j] - \bar{A}) \cdot (B[i,j] - \bar{B})}{\sigma_A \cdot \sigma_B}$$

$$\tag{4.3}$$

Where n is the number of pixels in A and B, σ is the standard deviation of the image, and \bar{A} is the a average pixel value.

Find a source for this equation

No date on Reference

NCC is very similar to cross correlation, but normalised to reduce the error if one image is brighter than the other. It is common in computer vision ([?]) as cross correlation is a common operation in DSP so fast algorithms have been made to calculate this.

Unlike S.S.D. and S.A.D., the normalised cross correlation gives a high value for a match. The downside to this algorithm comes with the complexity of the equation with division in it and a square root to calculate the standard deviation. These operations

are rarely implemented in hardware and are time consuming to carry out. They also require floating point registers and operations slow on a Microcontroller with a small amount of floating point registers.

4.1.4 Comparison

To compare these equations, a 50 by 50 image taken from the Right picture was compared with the left image over the entire valid range. The coordinates on the graph give the centre pixel of the calculation. Fi


Each of the graphs show the correct area being indentified as a match, but this also highlights the downfalls of the SAD and SSD. The figures in figure 4.2 are orientated to match the orientation of the images in figure 4.1. Each of the images is tested by attempting to match the phone from the test figure. The actual match should be around (170, 176). An exact result cannot be estimated as the images are not matched perfectly - there isn't an exact integer of pixel difference between the images. This is the sub pixel problem.

reference for sub pixel problem?


SAD results in figure 4.2(b) show large areas of matching. The actual match is at (170, 175) and a minimum does occur at this position as expected of a value of 5.66×10^4 . However, along the bottom of the image where a dark area occurs in the lower part of figures 4.1 below the desk, the SAD algorithm detects a greater comparison with the lowest value in this area being 3370 at (227, 275). This creates a false detection here.

SSD shows matches in the same two areas: where a match should occur and the dark area beneath the desk. The minimum values where the match should occur is 4.355×10^5 at location (170, 176). However, again, there is thought to be a large match correlation between the dark area under the desk where the actual lowest value of 2.768 is at (225, 274). This, again, is a false match and is a downfall of this algorithm.


The NCC results are visible in figure 4.2(c). A match can be seen at coordinate (195, 201) with a peak value of 0.9654. The coordinate is different to the previous results because the cross correlation works over the boundary of the image creating more results. The dimensions of the image are 300×400 , but the NCC returns an data set of dimensions 350×450 when using a box size of 50×50 . To get the actual match, half of the box size must be subtracted from the returned coordinate. This means the match occurs at (170, 176).



(a) S.A.D Results (Low match)



(b) S.S.D. Results (Low match)



(c) N.C.C. Results (High match)

Figure 4.2: Result Graphs of Comparison Algorithms

4.1.5 Conclusion

It can be seen there is a direct correlation between the complexity of the matching algorithm to the reliability of the match returned. In brightly lit, colourful environments absent of dark colours, SAD and SSD should provide a reliable result, but this cannot guaranteed to always be the case. Therefore further development of the matching algorithm will start with using the Normalised Cross Correlation. There is a compromise of complexity for reliability, of which reliability is more desirable. Cross correlation is also a large area of research, so optimised algorithms do exist.

4.2 Range Finding

Derive the range finding equations and test them

4.2.1 Derivations

By using two images separated by a horizontal difference, the range of an object can be found given some characteristics of the camera. The following is a derivation of the equations used to calculate distance.

The problem is broken down into 3

- 1. Object is between the cameras (Figure 4.3)
- 2. Object is directly in front of a camera
- 3. Object is in left or right hand sides of both images

4.2.1.1 Object is between the Cameras

Derivation from [?].

$$B = B_1 + B_2 = D\tan(\varphi_1) + D\tan(\varphi_2) \tag{4.4}$$

$$D = \frac{B}{\tan(\varphi_1) + \tan(\varphi_2)} \tag{4.5}$$

$$D\tan(\frac{\varphi_0}{2}) = x_0/2\tag{4.6}$$




Figure 4.3: Problem 1 - Object is between the Cameras




Figure 4.4: Problem 1 : Left Camera Simplified

$$D\tan(\varphi_1) = x_1 \tag{4.7}$$

Dividing (4.7) by (4.6)

$$\frac{\tan(\varphi_1)}{\tan(\frac{\varphi_0}{2})} = \frac{2x_1}{x_0} \tag{4.8}$$

$$\tan(\varphi_1) = \frac{2x_1 \tan(\frac{\varphi_0}{2})}{x_0} \tag{4.9}$$




Figure 4.5: Problem 3 - Object is to the same side in both cameras $\,$

It can also be shown that for the right camera:

$$\tan(\varphi_2) = \frac{-2x_2 \tan(\frac{\varphi_0}{2})}{x_0} \tag{4.10}$$

Substitution equations (4.9) and (4.10) into (4.5) gives

$$D = \frac{Bx_0}{2\tan(\frac{\varphi_0}{2})(x_1 - x_2)} \tag{4.11}$$

4.2.1.2 Object is infront of a camera

4.2.1.3 Object is to the same side in each camera

Conclusions and Further Work

It works.

Appendix A

Circuit Diagrams

A.1 OV7670 Breakout Board Schematic

A.2 Il Matto and Dual Camera Schematic




Figure A.1: The circuit diagram for the OV7670 breakout board




Figure A.2: The circuit diagram for Dual Cameras using the Il Matto Board

Appendix B

Bitmap File Format

B.1 Bitmap File Format

Table B.1: Feasible triples for highly variable Grid, MLMMH.

Section	Field	Description	Size (Bytes)	Value (hex)
Bitmap	Signature	Declares the file is a	2	424D
Header		Bitamp Image		
	File Size	Size of the whole file in-	4	36580200
		cluding headers		$(153654)^{1}$
	Reserved		4	00000000
	Offset to Pixel	The address of the start	4	36000000
	Array	of the pixel data from		
		the beginning of the file		
DIB (Device	Size	Size of the DIB Header	4	7C000000
Indepen-		(dictates the version)		
dant Bitmap)				
Header				
	Width	Width of the image (320 pixels)	4	40010000
	Height	Height of the image	4	F0000000
		(240 pixels)		
	Planes	Number of colour	2	0100
		planes		
	Bit Count	Number of bits per pixel	2	1000
	Compression	Compression Being	4	03 00 00 00
		Used, RGB Bit Fields		
Continued on next page				

 $^{^{1}}$ This is different to the 225kB said in Table 3.1 due to ommitting many optional fields

Table B.1 – continued from previous page

Section	Field	Description	Size (Bytes)	Value (hex)
	Image Size	Size of the image	4	00 86 25 00
	X Resolution	Horizontal resolution in	4	13 0B 00 00
		pixels per metre		
	Y Resolution	Vertical resolution in	4	13 0B 00 00
		pixels per metre		
	Colours in Ta-	Number of colours in	4	00 00 00 00
	ble	the colour table (not		
		used)		
	Important	Number of Important	4	00 00 00 00
	Colours	Colours (0 means all		
		colours are important)		
	Red Mask	Bit mask of Red field	4	00 F8 00 00
	Green Mask	Bit mask of Green field	4	E0 07 00 00
	Blue Mask	Bit mask of Blue field	4	1F 00 00 00
	Alpha Mask	Bit mask of Alpha field	4	00 00 00 00
	Colour Space	Colour Space of the DIB	4	01 00 00 00
	Type			
	Colour Space	Sets endpoints for	36	Whole
	Endpoints	colours within the		Field = 0
		bitmap (not used)		
	Gamma Red	Gamma Value of Red	4	00 00 00 00
		Field (not used)		
	Gamma Green	Gamma Value of Green	4	00 00 00 00
		Field (not used)		
	Gamma Blue	Gamma Value of Blue	4	00 00 00 00
		Field (not used)		
	Intent	Enum dictating the in-	4	03 00 00 00
		tent of the image (Pic-		
		ture)		
	ICC Profile	Offset from the file start	4	00 00 00 00
	Data	to the ICC Colour Pro-		
		file (Not Used)		
	ICC Profile	Size of the ICC Colour	4	00 00 00 00
	Size	Profile (not used)		
	Reserved		4	00 00 00 00
Continued on next page				

Table B.1 – continued from previous page

Section	Field	Description	Size (Bytes)	Value (hex)
Image Data	Each field con-	Padding is used to make		
Format	tains all the	the table width a mul-		
	pixel data	tiple of 4 (Not always		
		needed)		
Pix[0, h-1]	Pix[1, h-1]		Pix[w-1, h-	Padding
			1]	
:	:	:	:	:
Pix[0, 1]	Pix[1, 1]		Pix[w-1, 1]	Padding
Pix[0, 0]	Pix[1, 0]		Pix[w-1, 0]	Padding

Appendix C

Source Code

C.1 C Code for AVR

```
should I include FatFS Files?
```

C.1.1 Dual Camera Operation

C.1.1.1 main.c

../Code/DualOV7670/main.c

```
1
    * DualOV7670.c
2
    * Created: 09/11/2012 11:43:13
    * Author: hl13g10
    */
   #include "Config.h"
   //static FILE mystdout = FDEV_SETUP_STREAM(File_Write_Printf, NULL,
11
       _FDEV_SETUP_WRITE);
   //FatFS Variables
12
   FILINFO Finfo;
   FATFS Fatfs[_VOLUMES]; /* File system object for each logical drive */
   //FIL Files[2]; /* File object */
   uint8_t StatusReg;
                            /* Console input buffer */
   // char Line[100];
                        /* Working buffer */
   //char Buff[100];
   char ImageRName[20];
   char ImageLName[20];
   #define STATUS_OKAY
                           0x01
   #define STATUS_SDOkay
   #define STATUS_CAMOOkay 0x04
24 #define STATUS_CAM10kay 0x08
```

```
#define STATUS_READY 0x10
   #define STATUS_CAPTURING 0x20
   #define STATUS_Exit_Bad
   #define Button_Capture
29
   #define Button_Exit
30
   unsigned char UI_LEDs(uint8_t LED)
31
32
33
    unsigned char mesbuf[TWI_BUFFER_SIZE];
    mesbuf[0] = (0x15 << TWI_ADR_BITS) | (FALSE << TWI_READ_BIT);</pre>
34
     mesbuf[1] = 0x10;
     mesbuf[2] = LED;
     TWI_Start_Transceiver_With_Data(mesbuf, 3);
     while(TWI_Transceiver_Busy());
39
    return TWI_statusReg.lastTransOK;
40
   unsigned char UI_Buttons()
41
42
     unsigned char messageBuf[TWI_BUFFER_SIZE]; //Initialise a buffer
43
     messageBuf[0] = (0x15<<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); // The first</pre>
44
       byte must always consist of General Call code or the TWI slave address.
                                         \ensuremath{//} The first byte is used for the command
      messageBuf[1] = 0x20;
      TWI_Start_Transceiver_With_Data( messageBuf, 2 );
      _delay_us(250);
      // Request/collect the data from the Slave
48
     messageBuf[0] = (0x15<<TWI_ADR_BITS) | (TRUE<<TWI_READ_BIT); // The first</pre>
49
        byte must always consist of General Call code or the TWI slave address.
      TWI_Start_Transceiver_With_Data( messageBuf, 2 );
50
     \ensuremath{//} Get the received data from the transceiver buffer
     TWI_Get_Data_From_Transceiver( messageBuf, 2 );
     return messageBuf[1];
   }
   ISR(TIMERO_COMPA_vect)
     disk_timerproc(); /* Drive timer procedure of low level disk I/O module */
   // if(!TWI_statusReg.lastTransOK) //if the last TWI transmission failed,
       reset the protocol
   //
         TWI_Start_Transceiver();
60
   // if(!TWI_Transceiver_Busy())
61
         UI_LEDs(StatusReg);
   11
62
63
   }
   int main(void)
64
65
66
     unsigned long int a = 0;
     uint8_t b = 0;
     FRESULT fr;
     uint8_t PhotoCount = 0;
69
     TWI_Master_Initialise();
70
     IO_Init();
71
      sei();
72
     PCA9542A_Init();
73
     StatusReg = STATUS_OKAY;
75
     UI_LEDs(StatusReg);
76
     fr = f_mount(0, &Fatfs[0]);
   if(fr != FR_OK)
```

```
81
        StatusReg |= (STATUS_Exit_Bad);
82
        StatusReg &= ~(STATUS_OKAY);
83
        UI_LEDs(StatusReg);
84
        return 0;
85
      }
86
      else
87
        StatusReg |= STATUS_SDOkay;
88
      UI_LEDs(StatusReg);
      fr = f_open(&Files[0], "/log.txt", FA_WRITE|FA_CREATE_ALWAYS);
91
      if(fr != FR_OK)
92
        StatusReg |= (STATUS_Exit_Bad);
        StatusReg &= ~(1<<STATUS_SDOkay) | (1<<STATUS_OKAY);</pre>
        UI_LEDs(StatusReg);
96
        return 0:
97
      }
98
      UI_LEDs(StatusReg);
99
101
      f_close(&Files[0]);
      f_open(&Files[0], "/log.txt", FA_WRITE);
      //stdout = &mystdout;
      b = MCUSR;
      MCUSR = 0;
105
      f_write(&Files[0],"Il Matto Dual Camera\n", sizeof("Il Matto Dual Camera\n")
106
         . &a):
      /*f\_write(\&Files[0], "System Startup Complete.\n", 26, \&a);*/
108
      PCA9542A_SetChannel(CH1);
110
      b = 0V7670_init();
111
      if(b == 0)
112
        StatusReg |= STATUS_CAM10kay;
113
114
      PCA9542A_SetChannel(NO_SELECT);
115
      UI_LEDs(StatusReg);
      sprintf(Buff, "OV7670_1 Initialise result : %d\n", b);
116
      f_write(&Files[0], &Buff, 33, &a);
117
      PCA9542A_SetChannel(CHO);
119
      b = 0V7670_init();
120
      if(b == 0)
121
        StatusReg |= STATUS_CAMOOkay;
122
123
      UI_LEDs(StatusReg);
      PCA9542A_SetChannel(NO_SELECT);
      sprintf(Buff, "OV7670_0 Initialise result : %d\n", b);
      f_write(&Files[0], &Buff, 33, &a);
127
      FIFO_init();
      //f_close(&Files[0]);
129
      StatusReg |= STATUS_READY;
130
      UI_LEDs(StatusReg);
131
      _delay_ms(250);
132
      uint8_t Input;
133
135
        while (1)
136
         Input = (~UI_Buttons() & OxOF);//Data is received negative
        if(Input)//if a button has been pressed
138
```

```
139
           _delay_ms(250);
140
           sprintf(Buff, "Button Received : %d\n", Input);
141
           f_write(&Files[0], Buff, 21, &a);
142
           StatusReg&= ~(STATUS_READY);//no longer ready
144
           switch(Input)
146
147
             case (1<<Button_Capture):</pre>
148
               StatusReg |= STATUS_CAPTURING;
               UI_LEDs(StatusReg);
               //Reset both buffers
151
               FIFO_Reset(0);
152
153
               FIFO_Reset(1);
               f_write(&Files[0], "Capturing Images...\n", 20, &a);
154
               LoadImagesToBuffer();//Load both images
155
               //Create Bitmap for image 0
157
               //PSTR("Image_r.bmp");
158
               f_open(&Files[1], "Image_r.bmp", FA_CREATE_ALWAYS | FA_WRITE);
160
               f_write(&Files[0], "Created imageO file.\n", 22, &a);
               f_lseek(&Files[1], BMPFileSize);
               f_lseek(&Files[1], 0);
163
               f_close(&Files[1]);
164
               f_write(&Files[0], "Extended image0 file.\n", 22, &a);
165
               //Create Bitmap for image 1
167
               f_open(&Files[1],"image_l.bmp", FA_CREATE_ALWAYS | FA_WRITE);
168
               f_write(\&Files[0], "Created image1 file.\n", 22, &a);
169
170
               f_lseek(&Files[1], BMPFileSize);
               f_lseek(&Files[1], 0);
171
               f_close(&Files[1]);
173
               f_write(&Files[0], "Extended image1 file.\n", 22, &a);
174
               //Get image 0
               f_open(&Files[1], "Image_r.bmp", FA_WRITE);
175
               while (2 == GetImageIfAvailiable(&Files[1], 0));
176
               f_close(&Files[1]);
177
               f_write(\&Files[0], "Captured image0.\n", 17, &a);
178
               //get image 1
179
               f_open(&Files[1], "image_l.bmp", FA_WRITE);
180
               while (2 == GetImageIfAvailiable(&Files[1], 1));
181
182
               f_close(&Files[1]);
               f_write(\&Files[0], "Captured image1.\n", 17, &a);
183
               StatusReg |= STATUS_READY;
               StatusReg &= ~STATUS_CAPTURING;
               UI_LEDs(StatusReg);
186
               break;//break case(1<<ButtonCapture)</pre>
187
             case (1<<Button_Exit):</pre>
189
               f_write(&Files[0], "\nSystem Exiting...\n",19 ,&a);
190
               f_close(&Files[0]);//close log file
191
193
               StatusReg = 0x41;
               UI_LEDs(StatusReg);
194
               return 0;//Q
           }//End switch
         }//End if(Input)
```

C.1.1.2 Bitmap.h

../Code/DualOV7670/Bitmap.h

```
1
    * Bitmap.h
2
3
    * Created: 29/10/2012 11:31:11
4
       Author: hslovett
5
   #ifndef BITMAP_H_
10
   #define BITMAP_H_
12
   #define BMPHEADERSIZE 14
   #define DIBHEADERSIZE 124 //v5
13
   #define FILESIZE 153738
14
   #include "ff.h"
16
   #include "Config.h"
17
   FRESULT WriteBMPHeader(FIL *File);
   FRESULT WriteDIBHeader(FIL *File);
  #endif /* BITMAP_H_ */
```

C.1.1.3 Bitmap.c

../Code/DualOV7670/Bitmap.c

```
/*
2 * Bitmap.c
3 * Contains Methods to write the Bitmap and DIB Header. File must already be open.
4 * Created: 29/10/2012 11:30:58
5 * Author: Henry Lovett (hl13g10@ecs.soton.ac.uk)
6 */
7 #include "Bitmap.h"
9 uint8_t DIBHead[DIBHEADERSIZE] = { 0x7C, 0x00, 0x00, 0x00, //Number of bytes
```

```
0x40, 0x01, 0x00, 0x00, //Width - 320
10
                          0xF0, 0x00, 0x00, 0x00, //Height - 240
11
                          0x01, 0x00,
                                               //Planes
12
                          0x10, 0x00,
                                                //Bits per Pixel
13
                          0x03, 0x00, 0x00, 0x00, //Compression
14
                          \texttt{0x00}\,\text{, }\texttt{0x86}\,\text{, }\texttt{0x25}\,\text{, }\texttt{0x00}\,\text{, }//\texttt{Size} of Raw Data
15
                          \mbox{Ox}13\,\mbox{, }\mbox{Ox}0B\,\mbox{, }\mbox{Ox}00\,\mbox{, }\mbox{//Horizontal Resolution}
16
                          \texttt{0x13}\,,\,\,\texttt{0x0B}\,,\,\,\texttt{0x00}\,,\,\,\texttt{0x00}\,,\,\,//\,\texttt{Vertical} Resolution
17
                          0x00, 0x00, 0x00, 0x00, //Colours in Palette
18
                          0x00, 0x00, 0x00, 0x00, //Important Colours
19
                          \texttt{0x00}\,\text{, }\texttt{0xF8}\,\text{, }\texttt{0x00}\,\text{, }\texttt{0x00}\,\text{, }\texttt{//Red Mask}
                          0xE0, 0x07, 0x00, 0x00, //Green Mask
                          0x1F, 0x00, 0x00, 0x00, //Blue Mask
                          0x00, 0x00, 0x00, 0x00, //Alpha Mask
23
                          0x01, 0x00, 0x00, 0x00, //Colour Space Type
24
                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
25
                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
26
                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
27
                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
28
                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
29
                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
30
                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
31
                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
32
                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
33
                          0x00, 0x00, 0x00, 0x00, //Gamma Red
34
                          0x00, 0x00, 0x00, 0x00, //Gamma Green
35
                          0x00, 0x00, 0x00, 0x00, //Gamma Blue
36
                          0x03, 0x00, 0x00, 0x00, //Intent - Photo
37
                          0\,x00\,\text{,}~0\,x00\,\text{,}~0\,x00\,\text{,}~//\text{ICC} Profile Data
38
                          0x00, 0x00, 0x00, 0x00, //ICC Profile Size
39
                          0x00, 0x00, 0x00, 0x00}; //Reserved
40
    uint8_t BMPHeader[BMPHEADERSIZE] = { 0x42, 0x4D,
                            0x8A, 0x58, 0x02, 0x00, //Size
43
44
                            0x00, 0x00, 0x00, 0x00, //Reserved
                            0x8A, 0x00, 0x00, 0x00 //Offset to Pixel Array
46
    FRESULT WriteBMPHeader(FIL *File)
50
51
52
      uint32_t p;
     FRESULT f;
53
      f_lseek(File, 0);
      f = f_write(File, BMPHeader, BMPHEADERSIZE, &p);
      return f;
58
59
    FRESULT WriteDIBHeader(FIL *File)
61
62
63
      uint32_t p;
      FRESULT f;
       f_lseek(File, BMPHEADERSIZE);//place just after the bitmap header
       f = f_write(File, DIBHead, DIBHEADERSIZE, &p);
    return f;
```

```
69 }
```

C.1.1.4 Config.h

../Code/DualOV7670/Config.h

```
1
2
   * Config.h
3
   * Created: 25/10/2012 21:58:56
   * Author: hslovett
   */
  #define F_CPU 12000000UL
  #include <avr/io.h>
  #include <avr/interrupt.h>
  #include <avr/pgmspace.h>
10
  #include <stdio.h>
11
  #include <stdlib.h>
12
13
  #include <string.h>
  #include <util/delay.h>
  #include "TWI_Master.h"
  #include "ff.h"
17
  #include "diskio.h"
  #include "Bitmap.h"
18
  #include "DualCameras.h"
19
  #include "PCA9542A.h"
20
  #ifndef CONFIG_H_
21
  #define CONFIG_H_
  void IO_Init(void);
  #define TRUE 1
  #define FALSE 0
  FIL Files[2];
  char Buff[1024];
31
  #define BMPFileSize
                  153738
33
  #define RGBFileSize 153600
34
  #define FIFO_AVR_DPRT
                    DDRA
  #define FIFO_AVR_PORT
                    PORTA
  #define FIFO_AVR_PINP
                    PINA
  42
  // Port B
  43
  #define SD_WP
               PB0
44
  #define SD_CD
               PB1
45
               PB2
  //#define
46
  //#define
47
               PB3
  #define SPI_nSS_SD PB4
  #define SPI_MOSI
               PB5
50 #define SPI_MISO PB6
```

```
#define SPI_SCK PB7
  // Port C
53
 #define TWI_SCL
 #define TWI_SDA
             PC1
56
 #define FIFO_RCLK_1 PC2
57
 #define FIFO_nRRST_1 PC3
 #define FIFO_WEN_1 PC4
 #define FIFO_WRST_1 PC5
 #define FIFO_nOE_0 PC6
 #define FIFO_nOE_1
               PC7
 // Port D
 #define USARTO_RX PDO
66
 #define USARTO_TX
             PD1
67
 #define OV7670_VSYNC_O PD2 //MUST BE AN INTERRUPT PIN
68
 #define OV7670_VSYNC_1 PD3 //MUST BE AN INTERRUPT PIN
 #define FIFO_RCLK_0 PD4
70
 #define FIFO_nRRST_0 PD5
71
72
 #define FIFO_WEN_0
               PD6
 #define FIFO_WRST_0 PD7
 #endif /* CONFIG_H_ */
```

C.1.1.5 Config.c

../Code/DualOV7670/Config.c

```
* Config.c
    * Contains Global Methods and initialisations
5
    * Created: 25/10/2012 21:59:06
6
    * Author: hslovett
7
    */
8
   #include "Config.h"
10
   #include <avr/io.h>
12
   void IO_Init(void)
13
     //initialise timer 0 to interrupt every 10 ms
14
     TIMSKO |= (1 << OCIEOA);
15
     TCCROA \mid = (1 << WGMO1);
16
     OCROA = 117; //10ms interrupt at 12MHz
17
     TCCROB |= (1 << CSO2) | (1 << CSO0);
18
21
    DDRA = 0x00;
22
     //PORTB = OxBF;
     DDRC = 0xFC;
DDRD = 0xF2;
```

C.1.1.6 DualCameras.h

../Code/DualOV7670/DualCameras.h

```
1
  * DualCameras.h
2
3
  * Created: 10/11/2012 15:19:52
4
  * Author: hslovett
5
6
  #ifndef DUALCAMERAS_H_
10
 #define DUALCAMERAS_H_
 #include "Config.h"
12
  14
  // Constants
15
 #define HEIGHT
             240
17
 #define WIDTH
            320
 #define PIXELSIZE
             2
 #define SETTINGS_LENGTH 167
 #define OV7670_ADDR
             0x21
 const char default_settings[SETTINGS_LENGTH][2];
 volatile uint8_t VSYNC_O_Count;
 volatile uint8_t VSYNC_1_Count;
 // Methods
  unsigned char OV7670_init(void);
                           //Initialises Camera
  uint8_t GetImageIfAvailiable(FIL *File, uint8_t CameraID);
  void LoadImagesToBuffer(void);
  unsigned char rdOV7670Reg(unsigned char regID, unsigned char *regDat);
35
 unsigned char OV7670_SCCB_init(void);
36
 void FIFO_Reset(uint8_t CameraID);
37
  38
39
 // Pins & Macros
 41
 #define FIFO_RCLK_1 PC2
 #define FIFO_nRRST_1 PC3
43 #define FIFO_WEN_1 PC4
```

```
#define FIFO_WRST_1 PC5
   #define FIFO_nOE_0
   #define FIFO_nOE_1
46
   #define FIFO_RCLK_1_SET { PORTC |= (1 << FIFO_RCLK_1); }</pre>
48
   #define FIFO_RCLK_1_CLR { PORTC &= ~(1 << FIFO_RCLK_1); }</pre>
49
   #define FIFO_nRRST_1_SET { PORTC |= (1 << FIFO_nRRST_1); }</pre>
50
   #define FIFO_nRRST_1_CLR { PORTC &= ~(1 << FIFO_nRRST_1); }</pre>
   #define FIFO_WEN_1_SET { PORTC |= (1 << FIFO_WEN_1); }</pre>
   #define FIFO_WEN_1_CLR { PORTC &= ~(1 << FIFO_WEN_1); }</pre>
   #define FIFO_WRST_1_SET { PORTC |= (1 << FIFO_WRST_1); }</pre>
   #define FIFO_WRST_1_CLR { PORTC &= ~(1 << FIFO_WRST_1); }</pre>
   #define FIFO_nOE_O_SET { PORTC |= (1 << FIFO_nOE_O); }</pre>
   #define FIFO_nOE_O_CLR { PORTC &= ~(1 << FIFO_nOE_O); }</pre>
   #define FIF0_n0E_1_SET { PORTC |= (1 << FIF0_n0E_1);</pre>
   #define FIFO_nOE_1_CLR { PORTC &= ~(1 << FIFO_nOE_1); }</pre>
   #define FIFO_RCLK_0
                      PD4
62
   #define FIFO_nRRST_0 PD5
63
   #define FIFO_WEN_0
                      PD6
64
   #define FIFO_WRST_0
                          { PORTD |= (1 << FIFO_RCLK_0); }
   #define FIFO_RCLK_O_SET
                         { PORTD &= ~(1 << FIFO_RCLK_0); }
   #define FIFO_RCLK_O_CLR
68
   #define FIFO_nRRST_0_SET { PORTD |= (1 << FIFO_nRRST_0);</pre>
69
   #define FIFO_nRRST_0_CLR { PORTD &= ~(1 << FIFO_nRRST_0);</pre>
70
   #define FIFO_WEN_O_SET { PORTD |= (1 << FIFO_WEN_0); }</pre>
71
                         { PORTD &= ~(1 << FIFO_WEN_0); }
   #define FIFO_WEN_O_CLR
72
   #define FIFO_WRST_0_SET { PORTD |= (1 << FIFO_WRST_0); }</pre>
73
   #define FIFO_WRST_0_CLR { PORTD &= ~(1 << FIFO_WRST_0); }</pre>
   //Camera Register Address definitions
   0x00 //Gain Control Setting - ACG[7:0]
   #define OV_GAIN
   #define OV_BLUE
                    0x01 //Blue Channel Gain
   #define OV_RED
                   0x02 //Red Channel Gain
81
   #define OV_VREF
                   0x03 //Vertical Frame Control & ACG[9:8]
82
   #define OV_COM1
                   0x04 //CCIR656 enable, AEC low bits (AECHH, AECH)
83
                    0x05 //U/B Average level - AUTO UPDATED
   #define OV_BAVE
   85
   86
                    0x08 //V/R Average level - AUTO UPDATED
   #define OV_RAVE
87
   #define OV_COM2
                    0x09 //Soft Sleep, Output drive capability
                    OxOA //Product ID MSB Read only
   #define OV_PID
                    OxOB //Product ID LSB Read Only
   #define OV_VER
   #define OV_COM3
                    0x0C //Output data MSB/LSB swap + other stuff
91
   #define OV_COM4
                    0x0D //Average values - MUST BE SAME AS COM17
92
   #define OV_COM5
                    0x0E //RESERVED
93
   #define OV_COM6
                    0x0F //COM6
94
   #define OV_AECH
                    0x10 //Exposure value [9:2] (see AECHH, COM1)
95
   96
                   0x12 //RESET, Output format
   #define OV_COM7
97
                    0x13 //Common control 8
   #define OV_COM8
98
   #define OV_COM9
                    0x14 //Automatic Gain Ceiling
   #define OV_RSVD
                    0x16 //RESERVED
102 #define OV_HSTART 0x17 //Output format Horizontal Frame start
```

```
#define OV_VSTRT
                0x19 //Output format Vertical Frame start
   #define OV_VSTOP
                0x1A //Output format Vertical Frame Stop
105
  106
   READ ONLY
107
  READ ONLY
108
  109
110 #define OV_LAEC
               0x1F //RESERVED
#define OV_ADCCTRO 0x20 //ADC Control
#define OV_ADCCTR1 0x21 //RESERVED
#define OV_ADCCTR2 0x22 //RESERVED
#define OV_ADCCTR3 0x23 //RESERVED
#define OV_AEW 0x24 //ACG/AEC Stable Operating Region Upper Limit
#define OV_BBIAS 0x27 //B Channel Signal Output Bias
  #define OV_GbBIAS 0x28 //Gb Channel Output Bias
119
  120
  #define OV_EXHCH Ox2A //Dummy Pixel Insert MSB
121
  122
  #define OV_RBIAS Ox2C //R Channel Signal Output Bias
123
   #define OV_ADVFL
                0x2D //LSB of insert dummy line in vertical direction
               0x2E //MSB of insert dummy line in vertical direction
   #define OV_ADVFH
125
                0x2F //Y/G Channel Average Value
   #define OV_YAVE
   #define OV_HSYST
                0x30 //HSYNC Rising Edge Delay (low 8 bits)
127
                0x31 //HSYNCE Falling Edge Delay (low 8 bits)
   #define OV_HSYEN
128
  #define OV_HREF Ox32 //HREF Control
129
  #define OV_CHLF
                0x33 //Array Current Control - RESERVED
130
  #define OV_ARBLM 0x34 //Array Reference Control - RESERVED
131
  132
  133
  #define OV_ADCCTRL 0x37 //ADC Control - RESERVED
134
  #define OV_ACOM Ox38 //ADC and Analog Common Mode Control - RESERVED
  #define OV_OFON 0x39 //ADC Offset Control
  #define OV_COM13 0x3D //COM13
140
  141
142 #define OV_EDGE
               0x3F //Edge Detection Adjustment
  #define OV_COM15 0x40 //COM15
143
  144
               0x42 //COM17
  #define OV_COM17
145
  #define OV_AWBC1 0x43
146
  #define OV_AWBC2
147
                0x44
  #define OV_AWBC3
                0x45
   #define OV_AWBC4
                0x46
   #define OV_AWBC5
                0x47
150
   #define OV_AWBC6
                0 \times 48
151
   #define OV_RSVD4
                0 \times 49
152
  #define OV_RSVD5
                0 \times 40
153
  #define OV_RSVD6
                0 \times 4 A
154
  #define OV_REG4B
                0 \times 4B
155
  #define OV_DNSTH
               0 x 4 C
156
  #define OV_RSVD7
               0 x 4 D
157
#define OV_RSVD8 0x4E
  160 #define OV_MTX2
                0x50
#define OV_MTX3 0x51
```

```
#define OV_MTX4
                     0x52
    #define OV_MTX5
    #define OV_MTX6
                         0x54
164
    #define OV_BRIGHT
                         0x55
165
    #define OV_CONTRAS
                         0x56
166
    #define OV_CONTRASCNTR 0x57
167
    #define OV_MTXS
168
                       0 \times 58
    #define OV_RSVD9
                         0x59
169
    #define OV_RSVD9_1
                         0 x 5 A
    #define OV_RSVD9_2
171
                          0x5B
    #define OV_RSVD9_3
                          0x5C
172
    #define OV_RSVD9_4
                         0x5D
173
    #define OV_RSVD9_5
                         0x5E
174
    #define OV_RSVD9_6
175
                        0x5F
    #define OV_RSVD10
176
                       0x60
    #define OV_RSVD11
177
                       0x61
    #define OV_LCC1
                        0x62
178
    #define OV_LCC2
                        0x63
179
    #define OV_LCC3
                        0x64
180
    #define OV_LCC4
                        0x65
181
    #define OV_LCC5
182
                        0x66
    #define OV_MANU
183
                         0x67
    #define OV_MANV
                         0x68
    #define OV_GFIX
                         0x69
    #define OV_GGAIN
                         0x6A
186
    #define OV_DBLV
187
                         0x6B
    #define OV_AWBCTR3
                          0x6C
188
    #define OV_AWBCTR2
                          0x6D
189
    #define OV_AWBCTR1
                          0x6E
190
    #define OV_AWBCTRO
                          0x6F
191
    #define OV_SCALING_XSC 0x70
192
    #define OV_SCALING_YSC 0x71
193
    #define OV_SCALING_DCWCTR 0x72
    #define OV_SCALING_PCLK_DIV 0x73
196
    #define OV_REG74
                       0x74
197
    #define OV_REG75
                        0x75
    #define OV_REG76
198
    #define OV_REG77
                        0x77
199
    #define OV_RSVD12
                       0x78
200
    #define OV_RSVD13
                       0x79
201
    #define OV_GAM1
                         0x7A
202
    #define OV_GAM2
                         0x7B
203
    #define OV_GAM3
                         0x7C
204
    #define OV_GAM4
205
                         0 x 7 D
    #define OV_GAM5
                         0x7E
    #define OV_GAM6
                         0x7F
    #define OV_GAM7
                         0x80
209
    #define OV_GAM8
                         0x81
    #define OV_GAM9
                         0x82
210
    #define OV_GAM10
                         0x83
211
    #define OV_GAM11
                         0x84
212
    #define OV_GAM12
                         0x85
213
    #define OV_GAM13
                        0 x 8 6
214
    #define OV_GAM14
                         0x87
215
    #define OV_GAM15
                         0x88
216
    #define OV_GAM16
                         0x89
   #define OV_RSVD14
                         0x8A
   #define OV_RSVD15
                         0x8B
220 #define OV_RSVD16
                       0x8C
```

```
221 #define OV_RSVD17
                        0x8D
    #define OV_RSVD18
                        0x8E
    #define OV_RSVD19
223
                        0x8F
    #define OV_RSVD20
                        0x90
224
    #define OV_RSVD21
                        0x91
225
   #define OV_DM_LNL
                        0 \times 92
226
    #define OV_DM_LNH
                       0x93
227
   #define OV_LCC6
                        0x94
228
   #define OV_LCC7
                        0x95
   #define OV_RSVD22 0x96
230
   #define OV_RSVD23
                       0x97
   #define OV_RSVD24
                       0x98
   #define OV_RSVD25
                       0x99
   #define OV_RSVD26
234
                       0x9A
   #define OV_RSVD27
                       0x9B
236
   #define OV_RSVD28
                       0x9C
   #define OV_BD50ST
                        0x9D
237
   #define OV_BD60ST 0x9E
238
   #define OV_HISTO
                        0x9F
239
   #define OV_HIST1
                        0xA0
240
    #define OV_HIST2
                        0 x A 1
241
    #define OV_HIST3
                        0 x A 2
    #define OV_HIST4
                        0 x A 3
    #define OV_HIST5
                        0xA4
    #define OV_HIST6
                        0xA5
245
    #define OV_HIST7
                        0xA6
246
    #define OV_HIST8
                        0xA7
247
    #define OV_HIST9
                        0xA8
248
    #define OV_HIST10
                        0 \times A9
249
    #define OV_HIST11
                        0 \times A A
250
   #define OV_HIST12
                        0xAB
251
   #define OV_STR_OPT
                        0xAC
   #define OV_STR_R
                        0xAD
   #define OV_STR_G
                        0 x A E
   #define OV_STR_B
                        0xAF
   #define OV_RSVD30
                       0 x B 2
258
   #define OV_THL_ST 0xB3
259
   #define OV_RSVD31
                        0 x B 4
260
   #define OV_THL_DLT
                        0xB5
   #define OV_RSVD32
                        0 x B 6
262
   #define OV_RSVD33
                        0 x B 7
   #define OV_RSVD34
                        0 x B 8
   #define OV_RSVD35
                        0 x B 9
    #define OV_RSVD36
                        0 x B A
    #define OV_RSVD37
                        0xBB
268
    #define OV_RSVD38
                        0 xBC
    #define OV_RSVD39
                        0 xBD
269
    #define OV_AD_CHB
                        0xBE
270
    #define OV_AD_CHR
                        0xBF
271
   #define OV_AD_CHGb
                         0 x C 0
272
   #define OV_AD_CHGr
                          0 \times C1
273
   #define OV_RSVD40
                       0 x C 2
274
   #define OV_RSVD41
                        0 x C 3
275
   #define OV_RSVD42
                       0 x C 4
   #define OV_RSVD43
                        0xC5
   #define OV_RSVD44
                        0xC6
279 #define OV_RSVD45
                       0 x C 7
```

```
#define OV_RSVD46 OxC8
#define OV_SATCTR OxC9

#endif /* DUALCAMERAS_H_ */
```

C.1.1.7 DualCameras.c

../Code/DualOV7670/DualCameras.c

```
* DualCameras.c
     * Created: 10/11/2012 15:20:03
    * Author: hl13g10
5
6
   #include "DualCameras.h"
8
   const char default_settings[SETTINGS_LENGTH][2]=
10
11
12
   \{OV\_TSLB, Ox04\},
13
    \{OV\_COM15, OxdO\}, //RGB565 / RGB555
   {OV_COM7, 0x14},
14
   {OV_HREF, 0x80},
15
   {OV_HSTART, 0x16},
16
   \{OV\_HSTOP, Ox04\},
17
   {OV_VSTRT, 0x02},
18
   {OV_VSTOP, 0x7b},//0x7a,
19
   {OV_VREF, 0x06},//0x0a,
20
   {OV_COM3, 0x00},
21
   {OV_COM14, 0x00},//
   {OV_SCALING_XSC, 0x00},
   {OV_SCALING_YSC, 0x00},
   {OV_SCALING_DCWCTR, 0x11},
   {OV_SCALING_PCLK_DIV, 0x00},//
   {0xa2, 0x02},
27
   {OV_CLKRC, 0x01},
28
   \{OV\_GAM1, Ox20\},
29
   {OV_GAM2, Ox1c},
30
   {OV_GAM3, 0x28},
31
   {OV_GAM4, Ox3c},
32
   \{OV\_GAM5, Ox55\},
33
    \{OV\_GAM6, Ox68\},
34
    \{OV\_GAM7, Ox76\},
    \{OV\_GAM8, Ox80\},
36
   \{OV\_GAM9, Ox88\},
37
   {OV_GAM10, 0x8f},
38
39
   {OV_GAM11, 0x96},
   {OV_GAM12, 0xa3},
40
   \{OV\_GAM13, Oxaf\},
41
   {OV_GAM14, 0xc4},
42
   {OV_GAM15, 0xd7},
43
   {OV_GAM16, 0xe8},
45
   {OV_COM8, OxeO},
46 {OV_GAIN, 0x00},//AGC
47 {OV_AECH, 0x00},
```

```
48 {OV_COM4, 0x00},
    \{OV\_COM9, Ox20\}, //Ox38, limit the max gain
    {OV_HIST6, 0x05},
50
    {OV_HIST12, 0x07},
51
    {OV_AEW, 0x75},
52
   {OV_AEB, 0x63},
53
   {OV_VPT, OxA5},
54
   {OV_HISTO, 0x78},
   {OV_HIST1, 0x68},
   \{OV\_HIST2, Ox03\},//Ox0b,
   {OV_HIST7, Oxdf},//Oxd8,
   {OV_HIST8, Oxdf},//Oxd8,
   {OV_HIST9, Oxf0},
   {OV_HIST10, 0x90},
61
   {OV_HIST11, 0x94},
62
   {OV_COM8, 0xe5},
63
   {OV_COM5, 0x61},
   {OV_COM6, 0x4b},
   \{0x16, 0x02\},\
   \{OV\_MVFP, Ox27\},//Ox37,
67
    {0x21, 0x02},
68
    \{0x22, 0x91\},\
    \{0x29, 0x07\},\
    \{0x33, 0x0b\},\
71
    \{0x35, 0x0b\},\
72
    \{0x37, 0x1d\},\
73
    \{0x38, 0x71\},
74
    {OV_OFON, Ox2a},//
75
    {OV_COM12, 0x78},
76
    \{0x4d, 0x40\},\
77
   \{0x4e, 0x20\},\
78
   79
   {OV_DBLV, 0x60},//PLL
   {OV_REG74, 0x19},
   {0x8d, 0x4f},
   {0x8e, 0x00},
   {0x8f, 0x00},
   \{0x90, 0x00\},\
85
   \{0x91, 0x00\},\
86
   {OV_DM_LNL, 0x00},//0x19,//0x66
87
   {0x96, 0x00},
88
   {0x9a, 0x80},
89
   {0xb0, 0x84},
90
   {0xb1, 0x0c},
91
    {0xb2, 0x0e},
92
    {OV_THL_ST, 0x82},
    {0xb8, 0x0a},
    {OV_AWBC1, 0x14},
95
    {OV_AWBC2, OxfO},
96
    {OV_AWBC3, 0x34},
97
    \{OV\_AWBC4, Ox58\},
98
    \{OV\_AWBC5, Ox28\},
99
   {OV_AWBC6, Ox3a},
100
   \{0x59, 0x88\},\
101
   {0x5a, 0x88},
102
   \{0x5b, 0x44\},
   \{0x5c, 0x67\},
   \{0x5d, 0x49\},\
106 {0x5e, 0x0e},
```

```
{OV_LCC3, 0x04},
    {OV_LCC4, 0x20},
108
    {OV_LCC5, 0x05},
109
    {OV_LCC6, 0x04},
110
    {OV_LCC7, 0x08},
111
    {OV_AWBCTR3, OxOa},
112
    {OV_AWBCTR2, 0x55},
113
    {OV_AWBCTR1, 0x11},
114
    {OV_AWBCTRO, Ox9f},//Ox9e for advance AWB
    {OV_GGAIN, 0x40},
    {OV_BLUE, 0x40},
    {OV_RED, 0x40},
    {OV_COM8, Oxe7},
119
    {OV_COM10, 0x02},//VSYNC negative
120
    {OV_MTX1, 0x80},
121
    {OV_MTX2, 0x80},
122
    {OV_MTX3, 0x00},
123
    {OV_MTX4, 0x22},
124
    {OV_MTX5, 0x5e},
125
    {OV_MTX6, 0x80},
126
    {OV_MTXS, 0x9e},
127
    {OV_COM16, 0x08},
    {OV_EDGE, 0x00},
    {OV_REG75, 0x05},
    {OV_REG76, 0xe1},
131
    {OV_DNSTH, 0x00},
132
    {OV_REG77, 0x01},
133
    {OV_COM13, Oxc2}, //Oxc0,
134
    {OV_REG4B, 0x09},
135
    {OV_SATCTR, 0x60},
136
    {OV_COM16, 0x38},
137
    {OV_CONTRAS, 0x40},
138
139
    \{0x34, 0x11\},\
    {OV\_COM11, 0x02},//0x00,//0x02,
141
    {OV_HIST5, 0x89},//0x88,
142
    \{0x96, 0x00\},\
143
    \{0x97, 0x30\},\
    \{0x98, 0x20\},\
144
    \{0x99, 0x30\},\
145
    \{0x9a, 0x84\},
146
    \{0x9b, 0x29\},
147
    {0x9c, 0x03},
148
    {OV_BD50ST, 0x4c},
149
    {OV_BD60ST, 0x3f},
150
    \{0x78, 0x04\},
    \{0x79, 0x01\}, //Some weird thing with reserved registers.
    {0xc8, 0xf0},
154
    {0x79, 0x0f},
    {0xc8, 0x00},
155
    \{0x79, 0x10\},\
156
    {0xc8, 0x7e},
157
    \{0x79, 0x0a\},
158
    {0xc8, 0x80},
159
    \{0x79, 0x0b\},\
160
    {0xc8, 0x01},
161
    \{0x79, 0x0c\},\
    {0xc8, 0x0f},
    \{0x79, 0x0d\},\
165 {0xc8, 0x20},
```

```
\{0x79, 0x09\},\
166
    {0xc8, 0x80},
167
    \{0x79, 0x02\},\
168
    {0xc8, 0xc0},
169
    \{0x79, 0x03\},\
170
    {0xc8, 0x40},
171
    \{0x79, 0x05\},
172
   {0xc8, 0x30},
173
   \{0x79, 0x26\},\
174
   {OV_COM2, 0x03},
175
   {OV_BRIGHT, 0x00},
   {OV_CONTRAS, 0x40},
   {OV_COM11, 0x42},//0x82,//0xc0,//0xc2, //night mode
    };
180
    //ISR for controlling WEN.
184
    ISR(INTO_vect)
185
186
       //printf("ISR INTO Entered\n");
187
188
       if (VSYNC_0_Count==1)//start a frame read
189
         FIFO_WEN_O_SET;
190
         VSYNC_O_Count++;
191
192
       else if (VSYNC_0_Count == 2) // end a frame read
193
194
         FIFO_WEN_O_CLR;
195
        VSYNC_O_Count++;
196
197
       else if(VSYNC_0_Count == 3)
198
199
200
        FIFO_WEN_O_CLR;
201
      }
202
       else
203
         FIFO_WEN_O_CLR
204
         VSYNC_0_Count = 0;//wait for a read to be started
205
206
    }
207
    //ISR for controlling WEN.
208
    ISR(INT1_vect)
209
210
       //printf("ISR INT1 Entered\n");
212
       if (VSYNC_1_Count == 1) // start a frame read
213
         FIFO_WEN_1_SET;
214
         VSYNC_1_Count++;
215
216
      else if (VSYNC_1_Count == 2) // end a frame read
217
218
        FIFO_WEN_1_CLR;
219
         VSYNC_1_Count++;
220
      7
221
       else if(VSYNC_1_Count == 3)
    FIFO_WEN_1_CLR;
```

```
else
227
        FIFO_WEN_1_CLR
228
        VSYNC_1_Count = 0;//wait for a read to be started
229
      }
230
    }
231
233
    //Write Register Method
    unsigned char wrOV7670Reg(unsigned char regID, unsigned char regDat)
234
235
      /* I2C Traffic Generated:
236
      * S | OV_7670 + W | A | RegID | A | Data | A | P |
238
      //I2C Interface
239
240
      unsigned char messageBuf[TWI_BUFFER_SIZE];
      messageBuf[0] = (0V7670_ADDR <<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); //</pre>
241
        The first byte must always consit of General Call code or the TWI slave
        address.
      messageBuf[1] = regID;
                                           \ensuremath{//} The first byte is used for commands.
242
                                                        // The second byte is used
      messageBuf[2] = regDat;
243
        for the data.
      TWI_Start_Transceiver_With_Data( messageBuf, 3 );
      while(TWI_Transceiver_Busy()) ; //Wait for transceiver to clear
246
      return TWI_statusReg.lastTransOK;
248
249
    //Read Register Method
251
    unsigned char rdOV7670Reg(unsigned char regID, unsigned char *regDat)
252
253
      /* I2C Traffic Generated:
254
       * S | OV_ADDR + W | A | RegID | A | P |
255
       * S | OV_ADDR + R | A | Data | ~A | P |
       */
      //I2C Interface
      unsigned char messageBuf[TWI_BUFFER_SIZE]; //Initialise a buffer
259
      messageBuf[0] = (0V7670_ADDR<<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); // The</pre>
260
        first byte must always consist of General Call code or the TWI slave
        address.
                                           // The first byte is used for Address
      messageBuf[1] = regID;
261
        Pointer.
      TWI_Start_Transceiver_With_Data( messageBuf, 2 );
262
      // Request/collect the data from the Slave
      messageBuf[0] = (0V7670_ADDR<<TWI_ADR_BITS) | (TRUE<<TWI_READ_BIT); // The</pre>
        first byte must always consist of General Call code or the TWI slave
        address.
      TWI_Start_Transceiver_With_Data( messageBuf, 2 );
266
      // Get the received data from the transceiver buffer
268
      TWI_Get_Data_From_Transceiver( messageBuf, 2 );
269
      *regDat = messageBuf[1];
270
271
      return TWI_statusReg.lastTransOK;
    }
272
unsigned char OV7670_init()
```

```
276
       uint8_t i = 0;
277
       if(0==wr0V7670Reg(OV_COM7, 0x80)) //Reset Camera
278
279
280
        return 1;
281
       _delay_ms(10);
282
       for(i=0; i<SETTINGS_LENGTH; i++)</pre>
283
284
         if( 0==wr0V7670Reg(default_settings[i][0], default_settings[i][1] ))
285
286
287
           return 1;
288
289
         _delay_ms(1);
290
      return 0;
292
    }
293
    void FIFO_init( void )
295
296
297
      //disable both outputs
       FIF0_n0E_0_SET;
       FIFO_nOE_1_SET;
       //Reset Buffer 0
300
      FIFO_WRST_O_CLR;
301
      FIFO_RCLK_O_CLR;
302
      //FIFO_nOE_O_CLR;
303
      FIFO_nRRST_O_SET;
304
      FIFO_WEN_O_CLR;
305
       _delay_us(10);
306
      FIFO_RCLK_O_SET;
307
       _delay_us(10);
      FIFO_RCLK_O_CLR;
310
      FIFO_nRRST_O_CLR;
311
       _delay_us(10);
312
      FIFO_RCLK_O_SET;
       _delay_us(10);
313
      FIFO_RCLK_O_CLR;
314
      FIFO_nRRST_O_SET;
315
       _delay_us(10);
316
      FIF0_WRST_0_SET;
317
      //Reset Buffer 1
319
       FIFO_WRST_1_CLR;
       FIFO_RCLK_1_CLR;
       //FIFO_nOE_1_CLR;
323
       FIFO_nRRST_1_SET;
       FIFO_WEN_1_CLR;
324
       _delay_us(10);
325
      FIFO_RCLK_1_SET;
326
       _delay_us(10);
327
       FIFO_RCLK_1_CLR;
328
      FIFO_nRRST_1_CLR;
329
330
       _delay_us(10);
      FIFO_RCLK_1_SET;
331
       _delay_us(10);
332
       FIFO_RCLK_1_CLR;
      FIFO_nRRST_1_SET;
334
```

```
_delay_us(10);
335
       FIFO_WRST_1_SET;
336
    }
338
     //Write one pixel in {\tt AVR}
340
    uint16_t FIF0_T0_AVR(uint8_t ID)
341
342
343
      uint16_t data = 0;
       DDRA = 0;
345
       if(ID == 1)
347
         FIFO_RCLK_1_SET;
348
         data = PINA;
349
         FIFO_RCLK_1_CLR;
350
         data <<= 8;
351
         FIFO_RCLK_1_SET;
352
         data |= PINA;
353
         FIFO_RCLK_1_CLR;
354
       }
355
356
       else
         FIFO_RCLK_O_SET;
358
         data = PINA;
359
         FIFO_RCLK_O_CLR;
360
         data <<= 8;
361
         FIFO_RCLK_O_SET;
362
         data |= PINA;
363
         FIFO_RCLK_O_CLR;
364
       }
365
366
       return(data);
    }
     //Resets both pointers
371
    void FIFO_Reset(uint8_t CameraID)
372
     {
       FIF0_n0E_0_SET;
373
       FIF0_n0E_1_SET;
374
       if(CameraID == 0)
375
376
         FIFO_WRST_O_CLR;
377
         FIFO_nRRST_O_CLR;
378
         FIFO_RCLK_O_SET;
379
         FIFO_RCLK_O_CLR;
         FIFO_nRRST_O_SET;
382
         FIFO_WRST_O_SET;
383
       }
       else
384
385
         FIFO_WRST_1_CLR;
386
         FIFO_nRRST_1_CLR;
387
         FIFO_RCLK_1_SET;
388
         FIFO_RCLK_1_CLR;
389
         FIFO_nRRST_1_SET;
391
         FIFO_WRST_1_SET;
       }
```

```
void LoadImagesToBuffer()
395
396
      VSYNC_O_Count = 0;
397
      VSYNC_1_Count = 0;
398
      FIFO_Reset(0);
399
      FIFO_Reset(1);
400
      VSYNC_O_Count = 1;
401
      VSYNC_1_Count = 1;
402
404
    uint8_t GetImageIfAvailiable(FIL *File, uint8_t CameraID)
405
406
       if( ((CameraID == 0) && (VSYNC_0_Count == 3)) ||
408
         ((CameraID == 1) && (VSYNC_1_Count == 3)) )
409
410
         //Write Bitmap Headers
412
         WriteBMPHeader(File);
413
         WriteDIBHeader(File);
414
         if (CameraID == 0)
           //Enable output of Camera 0
417
           FIFO_nOE_O_CLR;
418
           //Reset Read Pointer
419
           FIFO_nRRST_O_CLR;
420
           FIFO_RCLK_O_SET;
421
           FIFO_RCLK_O_CLR;
422
           FIFO_nRRST_O_SET;
423
         }
424
425
         else
426
           //Enable output of Camera 0
428
           FIFO_nOE_1_CLR;
429
           //Reset Read Pointer
           FIFO_nRRST_1_CLR;
430
          FIFO_RCLK_1_SET;
431
           FIFO_RCLK_1_CLR;
432
           FIFO_nRRST_1_SET;
433
434
         int i, j;
435
         uint32_t pointer;
436
         uint16_t Temp;
437
438
         uint32_t p;
         FRESULT fr;
         //for(j = HEIGHT; j>0; j--)
441
         for(j = 0; j < HEIGHT; j++)
442
           pointer = 0;
443
           for(i = 0; i < WIDTH; i++)</pre>
444
445
             Temp = FIFO_TO_AVR(CameraID);
446
             //USARTO_Senduint16(Temp);
447
             Buff[pointer++] = (uint8_t)(Temp >> 8);
449
             Buff[pointer++] = (uint8_t)Temp;
```

```
pointer = (uint32_t)j * (uint32_t)WIDTH * 2 + BMPHEADERSIZE +
452
         DIBHEADERSIZE;
           f_lseek(File, pointer);
453
           fr = f_write(File, Buff, WIDTH * 2, &p);
454
           if(fr != FR_OK)
455
456
             //printf("Write Fail.\n");
457
             VSYNC_0_Count = 0;
458
             VSYNC_1_Count = 0;
             FIFO_Reset(CameraID);
             FIF0_n0E_0_SET;
             FIF0_n0E_1_SET;
             return 1;
463
          }
464
         }
465
         FIFO_Reset(CameraID);
466
        //fr = f_close(File);
467
        FIFO_nOE_O_SET;
468
        FIFO_nOE_1_SET;
469
         return 0;
470
      }
471
472
      else
         return 2;
475
    }
476
```

C.1.1.8 PCA9542A.h

../Code/DualOV7670/PCA9542A.h

```
* PCA9542A.h
2
    * Created: 13/11/2012 23:24:48
    * Author: hslovett
5
   #ifndef PCA9542A_H_
9
   #define PCA9542A_H_
10
   #include "Config.h"
11
   #define A0 0
   #define A1 0
14
   #define A2 1
15
   #define PCA9542A_ADDR (0x70 | (A2 << 2) | (A1 << 1) | A0)
   #define NO_SELECT 0x00
18
   #define CHO
                   0x04
19
   #define CH1
                    0x05
20
   unsigned char PCA9542A_Init();
22
   unsigned char PCA9542A_SetChannel(uint8_t Channel);
25 #endif /* PCA9542A_H_ */
```

C.1.1.9 PCA9542A.c

../Code/DualOV7670/PCA9542A.c

```
* PCA9542A.c
2
    * Created: 13/11/2012 23:24:40
    * Author: hslovett
    */
   #include "PCA9542A.h"
   unsigned char PCA9542A_Init()
10
11
     unsigned char messageBuf[TWI_BUFFER_SIZE];
12
     messageBuf[0] = (PCA9542A_ADDR <<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); //</pre>
13
       The first byte must always consit of General Call code or the TWI slave
       address.
     messageBuf[1] = NO_SELECT;
                                              // The first byte is used for
14
       commands.
     // The second byte is used for the data.
15
     TWI_Start_Transceiver_With_Data( messageBuf, 2 );
16
     while(TWI_Transceiver_Busy()) ; //Wait for transceiver to clear
18
     return TWI_statusReg.lastTransOK;
20
21
   unsigned char PCA9542A_SetChannel( uint8_t Channel )
23
24
     unsigned char messageBuf[TWI_BUFFER_SIZE];
25
     messageBuf[0] = (PCA9542A_ADDR <<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); //</pre>
26
       The first byte must always consit of General Call code or the TWI slave
       address.
27
     messageBuf[1] = Channel;
                                            // The first byte is used for commands.
                            // The second byte is used for the data.
28
     TWI_Start_Transceiver_With_Data( messageBuf, 2 );
29
     while(TWI_Transceiver_Busy()) ; //Wait for transceiver to clear
31
     return TWI_statusReg.lastTransOK;
33
   }
34
   unsigned char PCA9542A_ReadChannel()
36
     unsigned char messageBuf[TWI_BUFFER_SIZE];
     messageBuf[0] = (PCA9542A_ADDR <<TWI_ADR_BITS) | (TRUE<<TWI_READ_BIT); //</pre>
       The first byte must always consit of General Call code or the TWI slave
       address.
     TWI_Start_Transceiver_With_Data( messageBuf, 1 );
41
43
     while(TWI_Transceiver_Busy()) ; //Wait for transceiver to clear
```

```
// Get the received data from the transceiver buffer

TWI_Get_Data_From_Transceiver( messageBuf, 2 );

return TWI_statusReg.lastTransOK;

}
```

C.1.1.10 TWI_Master.h

../Code/DualOV7670/TWI_Master.h

```
*********
2
  * Atmel Corporation
  * File
                 : TWI_Master.h
  * Compiler
                 : IAR EWAAVR 2.28a/3.10c
  * Revision
                 : Revision: 1.13
                 : Date: 24. mai 2004 11:31:22
  * Updated by
                 : Author: ltwa
10
11
  * Support mail
                 : avr@atmel.com
  st Supported devices : All devices with a TWI module can be used.
14
                   The example is written for the ATmega16
15
  * AppNote
                 : AVR315 - TWI Master Implementation
16
17
  * Description
                : Header file for TWI_Master.c
18
                   Include this file in the application.
19
20
  /* Modified by Henry Lovett (hl13g10@ecs.soton.ac.uk) to allow SCL frequency
    to be specified and TWBR calculated
   * Also allows AVR internal pull up resistors to be used.
   */
  #ifndef _TWI_MASTER_H
26
  #define _TWI_MASTER_H
  #include <avr/io.h>
  #include <avr/interrupt.h>
  #include "Config.h"
30
  31
   TWI Status/Control register definitions
32
                                 **********************************
33
  ************
  #define INTERNAL_PULLUPS 0
  #define TWI_BUFFER_SIZE 4 // Set this to the largest message size that will
     be sent including address byte.
                100000 //SCL Frequency in Hertz
  #define SCL_Freq
39
  TWBR Based on SCL Frequency and Clock Frequency
                   0x0C //400KHz // TWI Bit rate Register
  //#define TWI_TWBR
  setting.
```

```
43 //#define TWI_TWBR 0x34 //100KHz
     Se Application note for detailed
                              // information on setting this value.
44
  // Not used defines!
45
  //#define TWI_TWPS
                     0 x 0 0
                              // This driver presumes prescaler = 00
46
  48
   Global definitions
49
  union TWI_statusReg
                               // Status byte holding flags.
    unsigned char all;
54
55
    struct
56
       unsigned char lastTransOK:1;
57
       unsigned char unusedBits:7;
58
     }:
59
 };
60
  extern union TWI_statusReg TWI_statusReg;
62
  Function definitions
65
  *********************************
66
  void TWI_Master_Initialise( void );
67
  unsigned char TWI_Transceiver_Busy( void );
68
  unsigned char TWI_Get_State_Info( void );
69
  void TWI_Start_Transceiver_With_Data( unsigned char * , unsigned char );
70
  void TWI_Start_Transceiver( void );
71
  unsigned char TWI_Get_Data_From_Transceiver( unsigned char *, unsigned char );
72
  74
   Bit and byte definitions
75
  #define TWI_ADR_BITS 1
                      // Bit position for LSB of the slave address
    bits in the init byte.
  #define TRUE
80
  #define FALSE
81
  /************************************
83
   TWI State codes
84
  // General TWI Master staus codes
  #define TWI_START
                          0x08 // START has been transmitted
  #define TWI_REP_START
                          0x10 // Repeated START has been
88
     transmitted
  #define TWI_ARB_LOST
                          0x38 // Arbitration lost
89
  // TWI Master Transmitter staus codes
91
                          0x18 // SLA+W has been tramsmitted and ACK
  #define TWI_MTX_ADR_ACK
92
     received
                          0x20 // SLA+W has been tramsmitted and
  #define TWI_MTX_ADR_NACK
    NACK received
                      0x28 // Data byte has been tramsmitted and
  #define TWI_MTX_DATA_ACK
  ACK received
```

```
95 #define TWI_MTX_DATA_NACK 0x30 // Data byte has been tramsmitted and
       NACK received
   // TWI Master Receiver staus codes
97
   #define TWI_MRX_ADR_ACK
                                   0x40 // SLA+R has been tramsmitted and ACK
        received
                                   0x48 // SLA+R has been tramsmitted and
   #define TWI_MRX_ADR_NACK
99
      NACK received
    #define TWI_MRX_DATA_ACK
                                   0x50 // Data byte has been received and
      ACK tramsmitted
    #define TWI_MRX_DATA_NACK
                                   0x58 // Data byte has been received and
      NACK tramsmitted
   // TWI Slave Transmitter staus codes
   #define TWI_STX_ADR_ACK OxA8 // Own SLA+R has been received; ACK
104
       has been returned
    #define TWI_STX_ADR_ACK_M_ARB_LOST 0xB0 // Arbitration lost in SLA+R/W as
105
       Master; own SLA+R has been received; ACK has been returned
    106
       transmitted; ACK has been received
                                   0xCO // Data byte in TWDR has been
    #define TWI_STX_DATA_NACK
107
       transmitted; NOT ACK has been received
    #define TWI_STX_DATA_ACK_LAST_BYTE 0xC8 // Last data byte in TWDR has been
       transmitted (TWEA = 0 ); ACK has been received
    // TWI Slave Receiver staus codes
110
                                   0x60 // Own SLA+W has been received ACK
    #define TWI_SRX_ADR_ACK
111
       has been returned
    #define TWI_SRX_ADR_ACK_M_ARB_LOST 0x68 // Arbitration lost in SLA+R/W as
112
       Master; own SLA+W has been received; ACK has been returned
113
    #define TWI_SRX_GEN_ACK
                                    0x70 // General call address has been
       received; ACK has been returned
    #define TWI_SRX_GEN_ACK_M_ARB_LOST 0x78 // Arbitration lost in SLA+R/W as
       Master; General call address has been received; ACK has been returned
    #define TWI_SRX_ADR_DATA_ACK 0x80 // Previously addressed with own SLA+
       W; data has been received; ACK has been returned
    #define TWI_SRX_ADR_DATA_NACK Ox88 // Previously addressed with own SLA+
116
       W; data has been received; NOT ACK has been returned
    #define TWI_SRX_GEN_DATA_ACK
                                   0x90 // Previously addressed with general
117
       call; data has been received; ACK has been returned
                                   0x98 // Previously addressed with general
   #define TWI_SRX_GEN_DATA_NACK
118
       call; data has been received; NOT ACK has been returned
   #define TWI_SRX_STOP_RESTART
                                   0xA0 // A STOP condition or repeated START
119
        condition has been received while still addressed as Slave
    // TWI Miscellaneous status codes
                                    0xF8 // No relevant state information
   #define TWI_NO_STATE
       available; TWINT = 0
    #define TWI_BUS_ERROR
                                   0x00 // Bus error due to an illegal START
123
       or STOP condition
   #endif
125
```

$C.1.1.11 TWI_Master.c$

```
2
  * Atmel Corporation
  * File
                 : TWI_Master.c
5
  * Compiler
                 : IAR EWAAVR 2.28a/3.10c
6
  * Revision
                 : Revision: 1.13
                  : Date: 24. mai 2004 11:31:20
  * Date
8
  * Updated by
                  : Author: ltwa
9
10
11
   * Support mail
                 : avr@atmel.com
12
   * Supported devices : All devices with a TWI module can be used.
13
                    The example is written for the ATmega16
14
15
16
  * AppNote
                  : AVR315 - TWI Master Implementation
17
  * Description
                 : This is a sample driver for the TWI hardware modules.
18
                    It is interrupt driveren. All functionality is
19
      controlled through
                    passing information to and from functions. Se main.c for
20
      samples
21
                    of how to use the driver.
22
23
   #include "TWI_Master.h"
27
  static unsigned char TWI_buf[ TWI_BUFFER_SIZE ]; // Transceiver buffer
29
  static unsigned char TWI_msgSize;
                                            // Number of bytes to be
30
      transmitted.
   31
      to TWI_NO_STATE.
  union TWI_statusReg TWI_statusReg = {0};
                                            // TWI_statusReg is
33
      defined in TWI_Master.h
   35
  Call this function to set up the TWI master to its initial standby state.
36
37
  Remember to enable interrupts from the main application after initializing the
   38
39
   void TWI_Master_Initialise(void)
40
41
    #if INTERNAL_PULLUPS == 1//enable built in pullups for I2C Lines
     DDRC = 0x00;
42
     PORTC = (1 << PC0) | (1 << PC1);
43
44
      #pragma message("External I2C Pull Ups Required.")
45
    #endif
46
    TWBR = TWI_TWBR;
                                           // Set bit rate register (
47
     Baudrate). Defined in header file.
    // TWSR = TWI_TWPS;
                                               // Not used. Driver
48
     presumes prescaler to be 00.
    TWDR = OxFF;
                                            // Default content = SDA
49
    released.
```

```
// Enable TWI-interface
  TWCR = (1 << TWEN) |
    and release TWI pins.
      (O<<TWIE) | (O<<TWINT) |
                                     // Disable Interupt.
51
      (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
                                     // No Signal requests.
52
      (0<<TWWC);
                                      11
53
54
  }
  Call this function to test if the TWI_ISR is busy transmitting.
  unsigned char TWI_Transceiver_Busy( void )
                              ^{\prime\prime} IF TWI Interrupt is enabled
   return ( TWCR & (1<<TWIE) );</pre>
     then the Transceiver is busy
62
  64
  Call this function to fetch the state information of the previous operation.
65
   The function will hold execution (loop)
  until the TWI_ISR has completed with the previous operation. If there was an
   error, then the function
  will return the TWI State code.
  unsigned char TWI_Get_State_Info( void )
69
70
   71
    completed the transmission.
                                    // Return error state.
   return ( TWI_state );
72
73
  75
  Call this function to send a prepared message. The first byte must contain the
     slave address and the
  read/write bit. Consecutive bytes contain the data to be sent, or empty
    locations for data to be read
  from the slave. Also include how many bytes that should be sent/read including
     the address byte.
  The function will hold execution (loop) until the TWI_ISR has completed with
79
    the previous operation,
  then initialize the next operation and return.
80
  void TWI_Start_Transceiver_With_Data( unsigned char *msg, unsigned char
82
    msgSize )
83
84
   unsigned char temp;
                                    // Wait until TWI is ready for
   while ( TWI_Transceiver_Busy() );
     next transmission.
    TWI_msgSize = msgSize;
                                     // Number of data to transmit.
88
   TWI_buf[0] = msg[0];
                                     // Store slave address with R/
89
     W setting.
   90
     then also copy data.
91
    for ( temp = 1; temp < msgSize; temp++ )</pre>
      TWI_buf[ temp ] = msg[ temp ];
TWI_statusReg.all = 0;
```

```
TWI_state = TWI_NO_STATE ;
     TWCR = (1 << TWEN)
                                            // TWI Interface enabled.
                                             // Enable TWI Interupt and
           (1<<TWIE) | (1<<TWINT) |
98
      clear the flag.
          (0<<TWEA)|(1<<TWSTA)|(0<<TWSTO)|
                                            // Initiate a START condition.
99
           (0<<TWWC);
100
   }
101
   103
   Call this function to resend the last message. The driver will reuse the data
      previously put in the transceiver buffers.
   The function will hold execution (loop) until the TWI_ISR has completed with
      the previous operation,
   then initialize the next operation and return.
106
107
   void TWI_Start_Transceiver( void )
108
109
    110
      next transmission.
    TWI_statusReg.all = 0;
111
    TWI_state = TWI_NO_STATE ;
112
                                             // TWI Interface enabled.
     TWCR = (1 << TWEN) |
113
           (1<<TWIE) | (1<<TWINT) |
                                             // Enable TWI Interupt and
      clear the flag.
          (0<<TWEA)|(1<<TWSTA)|(0<<TWSTO)| // Initiate a START condition.
115
           (0<<TWWC);
116
   }
117
   119
120
   Call this function to read out the requested data from the TWI transceiver
     buffer. I.e. first call
   TWI_Start_Transceiver to send a request for data to the slave. Then Run this
121
      function to collect the
   data when they have arrived. Include a pointer to where to place the data and
      the number of bytes
   requested (including the address field) in the function call. The function
      will hold execution (loop)
   until the TWI_ISR has completed with the previous operation, before reading
124
      out the data and returning.
   If there was an error in the previous transmission the function will return
125
      the TWI error code.
    *******************************
126
   unsigned char TWI_Get_Data_From_Transceiver( unsigned char *msg, unsigned char
127
       msgSize )
128
     unsigned char i;
     while ( TWI_Transceiver_Busy() );
                                            // Wait until TWI is ready for
131
       next transmission.
     if( TWI_statusReg.lastTransOK )
                                             // Last transmission competed
133
      successfully.
134
      for ( i=0; i<msgSize; i++ )</pre>
                                            // Copy data from Transceiver
135
      buffer.
136
       msg[ i ] = TWI_buf[ i ];
139
```

```
return( TWI_statusReg.lastTransOK );
141
    // ******* Interrupt Handlers ******* //
143
144
    This function is the Interrupt Service Routine (ISR), and called when the TWI
145
       interrupt is triggered;
146
    that is whenever a TWI event has occurred. This function should not be called
       directly from the main
    application.
147
    ISR(TWI_vect)
150
151
     static unsigned char TWI_bufPtr;
152
     switch (TWSR)
154
155
                                   // START has been transmitted
       case TWI_START:
156
        case TWI_REP_START:
                                   // Repeated START has been transmitted
157
         TWI_bufPtr = 0;
                                                             // Set buffer
158
        pointer to the TWI Address location
         {\tt case} \ {\tt TWI\_MTX\_ADR\_ACK:} \qquad \qquad // \ {\tt SLA+W} \ {\tt has} \ {\tt been} \ {\tt tramsmitted} \ {\tt and} \ {\tt ACK} \ {\tt received} 
159
        case TWI_MTX_DATA_ACK:
                                   // Data byte has been tramsmitted and ACK
        received
          if (TWI_bufPtr < TWI_msgSize)</pre>
161
162
            TWDR = TWI_buf[TWI_bufPtr++];
163
            TWCR = (1 << TWEN)
                                                              // TWI Interface
164
        enabled
                   (1<<TWIE) | (1<<TWINT) |
                                                              // Enable TWI
165
        Interupt and clear the flag to send byte
                   (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
                                                              11
166
                   (0<<TWWC);
167
168
          }else
                                   // Send STOP after last byte
            TWI_statusReg.lastTransOK = TRUE;
                                                             // Set status bits
170
        to completed successfully.
           TWCR = (1 << TWEN)
                                                              // TWI Interface
171
        enabled
                   (O<<TWIE) | (1<<TWINT) |
                                                             // Disable TWI
172
        Interrupt and clear the flag
                   (0<<TWEA)|(0<<TWSTA)|(1<<TWSTO)|
                                                             // Initiate a STOP
173
        condition.
                                                              //
174
                   (0<<TWWC);
          }
          break;
                                 // Data byte has been received and ACK
177
        case TWI_MRX_DATA_ACK:
        tramsmitted
          TWI_buf[TWI_bufPtr++] = TWDR;
178
        179
          if (TWI_bufPtr < (TWI_msgSize-1) )</pre>
                                                             // Detect the last
180
        byte to NACK it.
181
           TWCR = (1 << TWEN)
                                                              // TWI Interface
182
        enabled
                   (1<<TWIE) | (1<<TWINT) |
                                                              // Enable TWI
        Interupt and clear the flag to read next byte
```

```
(1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)| // Send ACK after
184
        reception
                   (0<<TWWC);
185
          }else
                                   // Send NACK after next reception
186
187
            TWCR = (1 << TWEN)
                                                              // TWI Interface
188
        enabled
                   (1<<TWIE) | (1<<TWINT) |
                                                              // Enable TWI
189
        Interupt and clear the flag to read next byte
                   (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
                                                              // Send NACK after
190
        reception
191
                   (0<<TWWC);
          }
192
          break;
193
        194
        tramsmitted
          TWI_buf[TWI_bufPtr] = TWDR;
195
         TWI_statusReg.lastTransOK = TRUE;
                                                            // Set status bits to
196
        completed successfully.
          TWCR = (1 << TWEN)
                                                            // TWI Interface
197
        enabled
                 (O<<TWIE)|(1<<TWINT)|
                                                            // Disable TWI
198
        Interrupt and clear the flag
                 (0<<TWEA) | (0<<TWSTA) | (1<<TWSTO) |
                                                            // Initiate a STOP
199
        condition.
                 (0<<TWWC);
200
          break:
201
        case TWI_ARB_LOST:
                                  // Arbitration lost
202
          TWCR = (1 << TWEN)
                                                            // TWI Interface
203
        enabled
                 (1<<TWIE) | (1<<TWINT) |
                                                            // Enable TWI Interupt
204
         and clear the flag
                 (0<<TWEA)|(1<<TWSTA)|(0<<TWSTO)|
                                                            // Initiate a (RE)
205
        START condition.
206
                 (0<<TWWC);
                                                            11
          break;
        case TWI_MTX_ADR_NACK:
                                   // SLA+W has been tramsmitted and NACK
208
        received
        case TWI_MRX_ADR_NACK:
                                    // SLA+R has been tramsmitted and NACK
209
        received
        case TWI_MTX_DATA_NACK:
                                    // Data byte has been tramsmitted and NACK
210
        received
                                         // No relevant state information
          case TWI_NO_STATE
211
        available; TWINT = 0
        case TWI_BUS_ERROR:
                                   // Bus error due to an illegal START or STOP
212
        condition
213
        default:
          TWI_state = TWSR;
                                                            // Store TWSR and
214
        automatically sets clears no Errors bit.
                                                            // Reset TWI Interface
215
          TWCR = (1 << TWEN)
                                                            // Enable TWI-
216
        interface and release TWI pins
                 (0<<TWIE) | (0<<TWINT) |
                                                            // Disable Interupt
217
                 (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
                                                            // No Signal requests
218
                 (0<<TWWC);
                                                            11
219
220
      }
    }
```

C.1.1.12 Usart.h

../Code/DualOV7670/Usart.h

```
1
    * Usart.h
2
3
    * Created: 25/10/2012 22:25:14
    * Author: hslovett
   #ifndef USART_H_
   #define USART_H_
   #include "Config.h"
   #include <stdio.h>
   #include <avr/io.h>
14
   #define USARTO_BITRATE 57600
   #define UBBR F_CPU/16/USARTO_BITRATE-1
   void USARTO_Init ();
   void Usart_SendChar(char data);
   unsigned char Usart_Receive( void );
   int Usart_printf(char var, FILE *stream);
   void Usart_get_line (char *buff, int len);
   void USARTO_Senduint16 (uint16_t Data);
23
   // void USARTO_SendChar( unsigned char data );
   // unsigned char USARTO_Receive( void );
   // void USARTO_SendString(char str[]);
   #endif /* USART_H_ */
```

C.1.1.13 Usart.c

../Code/DualOV7670/Usart.c

```
* Usart.c
    * Created: 25/10/2012 22:25:04
    * Author: hl13g10@ecs.soton.ac.uk
   #include "Usart.h"
12
   void USARTO_Init()
13
    uint16_t ubrr = UBBR;
14
     //Set baud rate
15
     UBRROH = (unsigned char)(ubrr >>8);
16
    UBRROL = (unsigned char)ubrr ;
17
  //Enable receiver and transmitter
```

```
UCSROB = (1 << RXENO) | (1 << TXENO);
     UCSROC = 0x06; //set asynchronous, no parity, one stop bit, 8 bit transfer.
21
     //UCSROB |= (1 << RXCIEO) | (1 << TXCIEO); //set RX and TX interrupt on
23
   }
24
   void Usart_SendChar(char data)
25
26
27
       // Wait for empty transmit buffer
       while ( !(UCSROA & (1 << UDREO)) );</pre>
28
       // Start transmission
       UDRO = data;
   }
31
   unsigned char Usart_Receive( void )
32
33
     /* Wait for data to be received */
34
     while ( !(UCSROA & (1<<RXCO)) )
35
36
     /* Get and return received data from buffer */
37
     //Usart_SendChar(UDR0);
38
     return UDRO;
39
   }
   //to use this copy the following as a global-
   // static FILE mystdout = FDEV_SETUP_STREAM(Usart_printf, NULL,
43
        _FDEV_SETUP_WRITE);
   // and add this line at the beginning of main:
44
   //
       stdout = &mystdout;
45
   // stdio.h must be used.
46
   int Usart_printf(char var, FILE *stream) {
47
       // translate \n to \r for br@y++ terminal
48
       if (var == '\n') Usart_SendChar('\r');
49
       Usart_SendChar(var);
51
       return 0;
  }
   void Usart_get_line (char *buff, int len)
   {
55
     cli();
56
     char c;
57
     int i = 0;
58
     for (;;) {
61
       c = Usart_Receive();
62
       if (c == '\r') break;
       if ((c == '\b') && i) {
         i--;
65
         Usart_SendChar(c);
66
         continue;
67
       }
68
       if (c >= ' ' && i < len - 1) { /* Visible chars */
69
         buff[i++] = c;
70
         Usart_SendChar(c);
71
       }
72
     }
73
     buff[i] = 0;
     Usart_SendChar('\n');
     sei();
```

```
77  }
78  void USARTO_Senduint16 (uint16_t Data)
79  {
80  Usart_SendChar(Data >> 8);
81  Usart_SendChar(Data & 0xFF);
82  }
```

C.1.2 Dual Camera User Interface

C.1.2.1 DualCamera_UI.c

../Code/DualCamera_UI/DualCamera_UI.c

```
* DualCamera_UI.c
3
    * Created: 12/11/2012 08:32:27
    * Author: hslovett
5
   #include <avr/io.h>
   #include <avr/interrupt.h>
10
   #include "TWI_slave.h"
13
   #define ButtonMask 0x0F
   #define TWI_CMD_MASTER_WRITE 0x10
15
   #define TWI_CMD_MASTER_READ 0x20
16
   // When there has been an error, this function is run and takes care of it
18
   unsigned char TWI_Act_On_Failure_In_Last_Transmission ( unsigned char
       TWIerrorMsg );
   int main(void)
     char ButtonStatus = 0xFF;
24
     unsigned char TWI_slaveAddress;
25
     unsigned char messageBuff[TWI_BUFFER_SIZE];
26
     DDRD = 0xFF;// Port D is the LED output
27
     DDRC = 0x00; //PortC is the switch input
28
     //PORTC = 0xFF;
29
     TWI_slaveAddress = 0x15;
30
     TWI_Slave_Initialise( (unsigned char)((TWI_slaveAddress<TWI_ADR_BITS) | (
       TRUE << TWI_GEN_BIT) ));
     sei();
     TWI_Start_Transceiver();
33
       while(1)
34
35
       ButtonStatus = (ButtonStatus & PINC) & ButtonMask;
37
       //PORTD = ButtonStatus;
38
           // Check if the TWI Transceiver has completed an operation.
39
          if ( ! TWI_Transceiver_Busy() )
```

```
41
              // Check if the last operation was successful
42
              if ( TWI_statusReg.lastTransOK )
43
44
                // Check if the last operation was a reception
45
                if ( TWI_statusReg.RxDataInBuf )
46
47
                  TWI_Get_Data_From_Transceiver(messageBuff, 2);
48
49
                  // Check if the last operation was a reception as General Call
                  if ( TWI_statusReg.genAddressCall )
50
51
                    // Put data received out to PORTB as an example.
52
                    PORTB = messageBuff[0];
53
54
                  else // Ends up here if the last operation was a reception as
55
        Slave Address Match
56
                    // Example of how to interpret a command and respond.
57
                    // TWI_CMD_MASTER_WRITE stores the data to PORTB
59
                    if (messageBuff[0] == TWI_CMD_MASTER_WRITE)
60
61
                      PORTD = messageBuff[1];
62
63
                    // TWI_CMD_MASTER_READ prepares the data from PINB in the
64
        transceiver buffer for the TWI master to fetch.
                    if (messageBuff[0] == TWI_CMD_MASTER_READ)
65
66
                      messageBuff[0] = ButtonStatus;
67
                      TWI_Start_Transceiver_With_Data( messageBuff, 1 );
68
                  ButtonStatus = ButtonMask; //clear all logged button presses
69
70
                  }
71
                }
72
73
                else // Ends up here if the last operation was a transmission
74
                  //__no_operation(); // Put own code here.
75
76
                // Check if the TWI Transceiver has already been started.
77
                // If not then restart it to prepare it for new receptions.
78
                if ( ! TWI_Transceiver_Busy() )
79
                {
80
                  TWI_Start_Transceiver();
81
                }
82
              }
83
              else // Ends up here if the last operation completed unsuccessfully
                //TWI_Act_On_Failure_In_Last_Transmission( TWI_Get_State_Info() );
86
87
        }
88
        }
89
   }
90
    unsigned char TWI_Act_On_Failure_In_Last_Transmission ( unsigned char
92
       TWIerrorMsg )
93
      // A failure has occurred, use TWIerrorMsg to determine the nature of the
       failure
   // and take appropriate actions.
```

```
// Se header file for a list of possible failures messages.

// This very simple example puts the error code on PORTB and restarts the transceiver with

// all the same data in the transmission buffers.

//PORTB = TWIerrorMsg;

TWI_Start_Transceiver();

return TWIerrorMsg;

}
```

C.1.2.2 TWI_slave.h

$../Code/DualCamera_UI/TWI_slave.h$

```
2
3
  * Atmel Corporation
4
  * File
                    : TWI_Slave.h
  * Compiler
                    : IAR EWAAVR 2.28a/3.10c
   * Revision
                    : Revision: 2475
                    : Date: 2007-09-20 12:00:43 +0200 (to, 20 sep 2007)
   * Updated by
                    : Author: mlarsson
   * Support mail
                    : avr@atmel.com
11
12
  * Supported devices : All devices with a TWI module can be used.
13
                      The example is written for the ATmega16
14
15
  * AppNote
                   : AVR311 - TWI Slave Implementation
16
  * Description : Header file for TWI_slave.c
                      Include this file in the application.
21
22
  /*! \page MISRA
23
   * General disabling of MISRA rules:
24
   \ast \ast (MISRA C rule 1) compiler is configured to allow extensions
25
   * * (MISRA C rule 111) bit fields shall only be defined to be of type
26
      unsigned int or signed int
    * * (MISRA C rule 37) bitwise operations shall not be performed on signed
      integer types
    st As it does not work well with 8bit architecture and/or IAR
    * Other disabled MISRA rules
   * * (MISRA C rule 109) use of union - overlapping storage shall not be used
31
   * * (MISRA C rule 61) every non-empty case clause in a switch statement shall
       be terminated with a break statement
33
   35
36
    TWI Status/Control register definitions
```

```
#define TWI_BUFFER_SIZE 4 // Reserves memory for the drivers transceiver
     buffer.
                        // Set this to the largest message size that
40
     will be sent including address byte.
  42
   Global definitions
43
  44
  union TWI_statusReg_t
                                 // Status byte holding flags.
46
47
    unsigned char all;
48
49
    struct
50
       unsigned char lastTransOK:1;
51
       unsigned char RxDataInBuf:1;
52
       unsigned char genAddressCall:1;
                                              // TRUE =
53
     General call, FALSE = TWI Address;
        unsigned char unusedBits:5;
54
55
     };
  };
56
  extern union TWI_statusReg_t TWI_statusReg;
  //static unsigned char dont_sleep = 0;
60
  62
   Function definitions
63
  64
  void TWI_Slave_Initialise( unsigned char );
65
  unsigned char TWI_Transceiver_Busy( void );
66
67
  unsigned char TWI_Get_State_Info( void );
  void TWI_Start_Transceiver_With_Data( unsigned char * , unsigned char );
  void TWI_Start_Transceiver( void );
  unsigned char TWI_Get_Data_From_Transceiver( unsigned char *, unsigned char );
  ISR( TWI_vect );
72
  74
   Bit and byte definitions
75
  76
  #define TWI_READ_BIT 0 // Bit position for R/W bit in "address byte".
77
  #define TWI_ADR_BITS 1 // Bit position for LSB of the slave address bits in
78
     the init byte.
  #define TWI_GEN_BIT 0 // Bit position for LSB of the general call bit in
    the init byte.
  #define TRUE
81
  #define FALSE
  84
   TWI State codes
85
  86
  // General TWI Master staus codes
87
  #define TWI_START
                          0x08 // START has been transmitted
88
  #define TWI_REP_START
                          0x10 // Repeated START has been
    transmitted
  #define TWI_ARB_LOST
                          0x38 // Arbitration lost
```

```
// TWI Master Transmitter staus codes
    #define TWI_MTX_ADR_ACK
                                     0x18 // SLA+W has been tramsmitted and ACK
         received
    #define TWI_MTX_ADR_NACK
                                     0x20 // SLA+W has been tramsmitted and
       NACK received
    #define TWI_MTX_DATA_ACK
                                     0x28 // Data byte has been tramsmitted and
95
        ACK received
    #define TWI_MTX_DATA_NACK
                                     0x30 // Data byte has been tramsmitted and
        NACK received
    // TWI Master Receiver staus codes
    #define TWI_MRX_ADR_ACK
                                     0x40 // SLA+R has been tramsmitted and ACK
        received
                                     0x48 // SLA+R has been tramsmitted and
    #define TWI_MRX_ADR_NACK
100
       NACK received
    #define TWI_MRX_DATA_ACK
                                     0x50 // Data byte has been received and
101
       ACK tramsmitted
    #define TWI_MRX_DATA_NACK
                                     0x58 // Data byte has been received and
102
       NACK tramsmitted
    // TWI Slave Transmitter staus codes
104
                                      0xA8 // Own SLA+R has been received; ACK
    #define TWI_STX_ADR_ACK
        has been returned
    #define TWI_STX_ADR_ACK_M_ARB_LOST 0xB0 // Arbitration lost in SLA+R/W as
        Master; own SLA+R has been received; ACK has been returned
    #define TWI_STX_DATA_ACK
                                      OxB8 // Data byte in TWDR has been
107
        transmitted; ACK has been received
    #define TWI_STX_DATA_NACK
                                      0xC0 // Data byte in TWDR has been
108
        transmitted; NOT ACK has been received
    #define TWI_STX_DATA_ACK_LAST_BYTE 0xC8 // Last data byte in TWDR has been
109
       transmitted (TWEA = 0 ); ACK has been received
    // TWI Slave Receiver staus codes
111
    #define TWI_SRX_ADR_ACK
                                      0x60 // Own SLA+W has been received ACK
       has been returned
113
    #define TWI_SRX_ADR_ACK_M_ARB_LOST 0x68 // Arbitration lost in SLA+R/W as
       Master; own SLA+W has been received; ACK has been returned
    #define TWI_SRX_GEN_ACK
                                      0x70 // General call address has been
114
       received; ACK has been returned
    #define TWI_SRX_GEN_ACK_M_ARB_LOST 0x78 // Arbitration lost in SLA+R/W as
115
       Master; General call address has been received; ACK has been returned
                                     0x80 // Previously addressed with own SLA+
    #define TWI_SRX_ADR_DATA_ACK
116
       W; data has been received; ACK has been returned
                                     0x88 // Previously addressed with own SLA+
117
    #define TWI_SRX_ADR_DATA_NACK
        W; data has been received; NOT ACK has been returned
    #define TWI_SRX_GEN_DATA_ACK
                                      0x90 // Previously addressed with general
        call; data has been received; ACK has been returned
    #define TWI_SRX_GEN_DATA_NACK
                                      0x98 // Previously addressed with general
119
       call; data has been received; NOT ACK has been returned
    #define TWI_SRX_STOP_RESTART
                                     OxAO // A STOP condition or repeated START
120
        condition has been received while still addressed as Slave
    // TWI Miscellaneous status codes
122
    #define TWI_NO_STATE
                                      0xF8 // No relevant state information
       available; TWINT = 0
    #define TWI_BUS_ERROR
                                     0x00 // Bus error due to an illegal START
       or STOP condition
```

C.1.2.3 TWI_slave.c

../Code/DualCamera_UI/TWI_slave.c

```
1
2
  * Atmel Corporation
3
4
  * File
                    : TWI_Slave.c
5
  * Compiler
                    : IAR EWAAVR 2.28a/3.10c
                    : Revision: 2475
  * Revision
                    : Date: 2007-09-20 12:00:43 +0200 (to, 20 sep 2007)
  * Date
  * Updated by
                    : Author: mlarsson
10
                   : avr@atmel.com
11
  * Support mail
12
  * Supported devices: All devices with a TWI module can be used.
13
                      The example is written for the ATmega16
14
15
  * AppNote
                    : AVR311 - TWI Slave Implementation
16
17
  * Description
                    : This is sample driver to AVRs TWI module.
18
                       It is interupt driveren. All functionality is controlled
       through
                      passing information to and from functions. Se main.c for
20
       samples
                       of how to use the driver.
21
22
   23
   /*! \page MISRA
24
25
    * General disabling of MISRA rules:
26
    * * (MISRA C rule 1) compiler is configured to allow extensions
27
    * * (MISRA C rule 111) bit fields shall only be defined to be of type
      unsigned int or signed int
    * * (MISRA C rule 37) bitwise operations shall not be performed on signed
      integer types
    * As it does not work well with 8bit architecture and/or IAR
30
    * Other disabled MISRA rules
32
    * * (MISRA C rule 109) use of union - overlapping storage shall not be used
33
    * * (MISRA C rule 61) every non-empty case clause in a switch statement shall
34
       be terminated with a break statement
35
   #include <avr/io.h>
   #include <avr/interrupt.h>
  #include "TWI_slave.h"
  static unsigned char TWI_buf[TWI_BUFFER_SIZE];
                                                // Transceiver buffer. Set
41
      the size in the header file
  static unsigned char TWI_msgSize = 0;
                                                 // Number of bytes to be
42
      transmitted.
  static unsigned char TWI_state = TWI_NO_STATE; // State byte. Default set
     to TWI_NO_STATE.
  // This is true when the TWI is in the middle of a transfer
46 // and set to false when all bytes have been transmitted/received
```

```
47 // Also used to determine how deep we can sleep.
  static unsigned char TWI_busy = 0;
  50
     defined in TWI_Slave.h
  Call this function to set up the TWI slave to its initial standby state.
  Remember to enable interrupts from the main application after initializing the
  Pass both the slave address and the requrements for triggering on a general
    call in the
  same byte. Use e.g. this notation when calling this function:
  TWI_Slave_Initialise( (TWI_slaveAddress<<TWI_ADR_BITS) | (TRUE<<TWI_GEN_BIT) )
  The TWI module is configured to NACK on any requests. Use a
58
   TWI_Start_Transceiver function to
  start the TWI.
59
  60
  void TWI_Slave_Initialise( unsigned char TWI_ownAddress )
61
62
   TWAR = TWI_ownAddress;
                                         // Set own TWI slave
63
     address. Accept TWI General Calls.
   TWCR = (1 << TWEN)
                                         // Enable TWI-interface
    and release TWI pins.
                                         // Disable TWI Interupt.
         (0<<TWIE) | (0<<TWINT) |
65
         (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
                                         // Do not ACK on any
66
    requests, yet.
        (0<<TWWC);
67
   TWI_busy = 0;
68
  }
69
  Call this function to test if the TWI_ISR is busy transmitting.
  unsigned char TWI_Transceiver_Busy( void )
75
   return TWI_busy;
76
77
  79
  Call this function to fetch the state information of the previous operation.
80
    The function will hold execution (loop)
  until the TWI_ISR has completed with the previous operation. If there was an
     error, then the function
  will return the TWI State code.
  unsigned char TWI_Get_State_Info( void )
84
85
   while ( TWI_Transceiver_Busy() ) {}
                                      // Wait until TWI has
86
     completed the transmission.
   return ( TWI_state );
                                      // Return error state.
87
88
  /***********************************
  Call this function to send a prepared message, or start the Transceiver for
    reception. Include
92 a pointer to the data to be sent if a SLA+W is received. The data will be
 copied to the TWI buffer.
```

```
93 Also include how many bytes that should be sent. Note that unlike the similar
     Master function, the
   Address byte is not included in the message buffers.
94
   The function will hold execution (loop) until the TWI_ISR has completed with
95
      the previous operation,
   then initialize the next operation and return.
96
   97
   void TWI_Start_Transceiver_With_Data( unsigned char *msg, unsigned char
     msgSize )
99
    unsigned char temp;
    for next transmission.
    TWI_msgSize = msgSize;
                                        // Number of data to transmit.
104
    for ( temp = 0; temp < msgSize; temp++ ) // Copy data that may be
105
     transmitted if the TWI Master requests data.
106
     TWI_buf[ temp ] = msg[ temp ];
107
108
    TWI_statusReg.all = 0;
109
    TWI_state = TWI_NO_STATE ;
110
    TWCR = (1 << TWEN)
                                        // TWI Interface enabled.
          (1<<TWIE)|(1<<TWINT)|
                                        // Enable TWI Interupt and
112
     clear the flag.
         113
     the Slave is addressed.
         (0<<TWWC);
                                        11
114
   TWI_busy = 1;
115
  }
116
   118
  Call this function to start the Transceiver without specifing new transmission
      data. Useful for restarting
  a transmission, or just starting the transceiver for reception. The driver
     will reuse the data previously put
  in the transceiver buffers. The function will hold execution (loop) until the
121
     TWI_ISR has completed with the
  previous operation, then initialize the next operation and return.
   void TWI_Start_Transceiver( void )
124
125
    while ( TWI_Transceiver_Busy() ) {}
                                         // Wait until TWI is ready
126
     for next transmission.
127
    TWI_statusReg.all = 0;
    TWI_state = TWI_NO_STATE ;
129
    TWCR = (1 << TWEN)
                                         // TWI Interface enabled.
          (1<<TWIE) | (1<<TWINT) |
                                        // Enable TWI Interupt and
130
     clear the flag.
         (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
                                        // Prepare to ACK next time
131
     the Slave is addressed.
         (0<<TWWC);
                                         11
132
   TWI_busy = 0;
133
134 }
  136 Call this function to read out the received data from the TWI transceiver
 buffer. I.e. first call
```

```
TWI_Start_Transceiver to get the TWI Transceiver to fetch data. Then Run this
       function to collect the
    data when they have arrived. Include a pointer to where to place the data and
138
       the number of bytes
    to fetch in the function call. The function will hold execution (loop) until
139
       the TWI_ISR has completed
   with the previous operation, before reading out the data and returning.
140
   If there was an error in the previous transmission the function will return
       the TWI State code.
    *******************************
142
    unsigned char TWI_Get_Data_From_Transceiver( unsigned char *msg, unsigned char
       msgSize )
144
    unsigned char i;
145
    while ( TWI_Transceiver_Busy() ) {}
// Wait until TWI is ready
147
       for next transmission.
     if( TWI_statusReg.lastTransOK )
                                               // Last transmission completed
149
        successfully.
150
       for ( i=0; i<msgSize; i++ )</pre>
                                                // Copy data from Transceiver
151
       buffer.
        msg[ i ] = TWI_buf[ i ];
153
154
       TWI_statusReg.RxDataInBuf = FALSE; // Slave Receive data has been
155
        read from buffer.
     }
156
     return( TWI_statusReg.lastTransOK );
157
   }
158
    // ******* Interrupt Handlers ******* //
161
162
    /**************
163
   This function is the Interrupt Service Routine (ISR), and called when the TWI
       interrupt is triggered;
    that is whenever a TWI event has occurred. This function should not be called
164
       directly from the main
    application.
165
    166
    ISR(TWI_vect)
167
168
     static unsigned char TWI_bufPtr;
169
171
     switch (TWSR)
172
173
       case TWI_STX_ADR_ACK:
                              // Own SLA+R has been received; ACK has
       been returned
    11
        case TWI_STX_ADR_ACK_M_ARB_LOST: // Arbitration lost in SLA+R/W as
174
       Master; own SLA+R has been received; ACK has been returned
         TWI_bufPtr = 0;
                                                       // Set buffer pointer
175
       to first data location
       case TWI_STX_DATA_ACK:
                                     // Data byte in TWDR has been transmitted
176
       ; ACK has been received
177
        TWDR = TWI_buf[TWI_bufPtr++];
        TWCR = (1 << TWEN) |
                                                        // TWI Interface
      enabled
```

```
(1<<TWIE)|(1<<TWINT)|
                                                       // Enable TWI Interupt
179
         and clear the flag to send byte
                  (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
180
                  (0<<TWWC);
181
           TWI_busy = 1;
182
183
           break;
         case TWI_STX_DATA_NACK:
                                           // Data byte in TWDR has been transmitted
184
         ; NACK has been received.
                                            \ensuremath{//} I.e. this could be the end of the
185
         transmission.
          if (TWI_bufPtr == TWI_msgSize) // Have we transceived all expected data?
186
187
            TWI_statusReg.lastTransOK = TRUE;
                                                               // Set status bits to
188
         completed successfully.
          }
189
           else
                                          // Master has sent a NACK before all data
190
         where sent.
191
            TWI_state = TWSR;
                                                                // Store TWI State as
192
         errormessage.
          }
193
          TWCR = (1 << TWEN)
                                                                // Enable TWI-
195
         interface and release TWI pins
          (1<<TWIE)|(1<<TWINT)|
                                                                // Keep interrupt
196
         enabled and clear the flag
                  (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
                                                                // Answer on next
197
         address match
                  (0<<TWWC);
198
          TWI_busy = 0; // Transmit is finished, we are not busy anymore
200
201
          break;
         case TWI_SRX_GEN_ACK:
                                           // General call address has been received
202
         ; ACK has been returned
203
          case TWI_SRX_GEN_ACK_M_ARB_LOST: // Arbitration lost in SLA+R/W as
         Master; General call address has been received; ACK has been returned
204
          TWI_statusReg.genAddressCall = TRUE;
         case TWI_SRX_ADR_ACK:
                                          // Own SLA+W has been received ACK has
205
         been returned
          case TWI_SRX_ADR_ACK_M_ARB_LOST: // Arbitration lost in SLA+R/W as
    11
206
         Master; own SLA+W has been received; ACK has been returned
                                                                // Dont need to clear
207
         {\tt TWI\_S\_statusRegister.generalAddressCall} \ \ {\tt due} \ \ {\tt to} \ \ {\tt that} \ \ {\tt it} \ \ {\tt is} \ \ {\tt the} \ \ {\tt default}
         state.
208
          TWI_statusReg.RxDataInBuf = TRUE;
          TWI_bufPtr = 0;
                                                                // Set buffer pointer
         to first data location
                                                                // Reset the TWI
211
         Interupt to wait for a new event.
          TWCR = (1 << TWEN)
                                                                // TWI Interface
212
         enabled
                  (1<<TWIE) | (1<<TWINT) |
                                                                // Enable TWI Interupt
213
          and clear the flag to send byte
                 (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
                                                               // Expect ACK on this
214
         transmission
                 (0<<TWWC);
215
           TWI_busy = 1;
216
```

```
case TWI_SRX_ADR_DATA_ACK:
                                        // Previously addressed with own SLA+W;
219
        data has been received; ACK has been returned
        case TWI_SRX_GEN_DATA_ACK: // Previously addressed with general call
220
        ; data has been received; ACK has been returned
                                  = TWDR;
          TWI_buf[TWI_bufPtr++]
221
          TWI_statusReg.lastTransOK = TRUE;
                                                           // Set flag
222
        transmission successfull.
                                                           // Reset the TWI
223
        Interupt to wait for a new event.
         TWCR = (1 << TWEN)
                                                            // TWI Interface
        enabled
                (1<<TWIE)|(1<<TWINT)|
                                                           // Enable TWI Interupt
         and clear the flag to send byte
                (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|
                                                           // Send ACK after next
226
         reception
                 (0<<TWWC):
                                                            //
227
         TWI_busy = 1;
228
          break:
229
        230
        condition has been received while still addressed as Slave
                                                            // Enter not addressed
         mode and listen to address match
         TWCR = (1 << TWEN) |
                                                            // Enable TWI-
        interface and release TWI pins
                 (1<<TWIE)|(1<<TWINT)|
                                                           // Enable interrupt
233
        and clear the flag
                 (1<<TWEA) | (0<<TWSTA) | (0<<TWSTO) |
                                                           // Wait for new
234
        address match
                (0<<TWWC);
235
         TWI_busy = 0; // We are waiting for a new address match, so we are not
237
        busy
          break;
        case TWI_SRX_ADR_DATA_NACK:
                                        // Previously addressed with own SLA+W;
        data has been received; NOT ACK has been returned
        case TWI_SRX_GEN_DATA_NACK:
                                        // Previously addressed with general call
241
        ; data has been received; NOT ACK has been returned
        case TWI_STX_DATA_ACK_LAST_BYTE: // Last data byte in TWDR has been
242
        transmitted (TWEA = 0); ACK has been received
                                        // No relevant state information
    11
         case TWI_NO_STATE
243
        available; TWINT = 0
        case TWI_BUS_ERROR:
                                  // Bus error due to an illegal START or STOP
244
        condition
         TWI_state = TWSR;
                                           //Store TWI State as errormessage,
        operation also clears noErrors bit
         TWCR = (1 << TWSTO) | (1 << TWINT);
                                           //Recover from TWI_BUS_ERROR, this
246
        will release the SDA and SCL pins thus enabling other devices to use the
          break:
247
        default:
248
          TWI_state = TWSR;
                                                            // Store TWI State as
249
        errormessage, operation also clears the Success bit.
         TWCR = (1 << TWEN)
250
                                                           // Enable TWI-
        interface and release TWI pins
                (1<<TWIE)|(1<<TWINT)|
                                                           // Keep interrupt
        enabled and clear the flag
```

C.2 MATLAB Code for Image Algorithm Prototyping

C.2.0.4 loadimages.m

../MATLAB/loadimages.m

```
left = imread('viprectification_deskLeft.png');
right = imread('viprectification_deskRight.png');

% left = imread('battery_left.bmp');
% right = imread('battery_right.bmp');

% left = imread('square_left.bmp');
% right = imread('square_right.bmp');
% left = imread('fiftycm_left.bmp');
% right = imread('fiftycm_right.bmp');
% right = imread('2objs_left.bmp');
% right = imread('2objs_right.bmp');
```

C.2.0.5 GetSubImage.m

../MATLAB/GetSubImage.m

```
function [ SubImage ] = GetSubImage( Image, BoxSize, StartCoordinates)
   %GETSUBIMAGE Returns a sub section of the image according to the other
2
   %inputs
      Image - The image of which a subimage is to be taken from
       BoxSize - A 2x1 matrix containing the size of the subImage
       StartCoordinates - A 2x1 matrix with the start point of the image
       Dimensions - How many planes - 3 for colour, 1 for grey scale
   XLow = StartCoordinates(1)-(BoxSize(1)/2);
9
   YLow = StartCoordinates(2)-(BoxSize(2)/2);
10
   if (XLow<1)
11
12
       XLow = 1;
13
   end
   if(YLow < 1)</pre>
       YLow = 1;
```

```
XHigh = XLow + BoxSize(1);
   YHigh = YLow + BoxSize(2);
20
    [~, ~, LZ] = size(Image);
   %SubImage = zeros(BoxSize);
23
   for i = XLow:XHigh
24
       for j = YLow:YHigh
25
            if LZ == 3
26
27
                for z = 1:3
                    SubImage(i-XLow+1,j-YLow+1,z) = Image(i,j,z);
            elseif LZ == 1
                SubImage(i-XLow+1,j-YLow+1) = Image(i,j);
                error('Number of Dimensions "%d" are not supported', LZ);
33
            end
34
        end
35
36
    end
   end
```

C.2.0.6 SADAll.m

../MATLAB/SADAll.m

```
%function [ Results ] = SADAll( Left, Right )
   %SADALL Function to compute all SADs of an image
      The sum of absolute differences is calculated and returned on a mesh
      graph to show how well matched the sub image is to the image. A box out
   % of the right image is taken and compared with the left image.
   loadimages;
   BoxSize = [50,50];
   [~,~,C] = size(right);
   [I,J,D] = size(left);
   if C ~= D
10
       error('Images have different number of colour planes');
11
12
   RightSub = GetSubImage(right, BoxSize, [190,190]);
14
   for i = 25:(I-25)
16
       for j = 25:(J-25)
17
           LeftSub = GetSubImage(left, BoxSize, [i, j]);
18
           Diff = LeftSub - RightSub;
19
           Results(i,j) = sum(Diff(:));
21
22
       end
23
   end
   %Display
25
26
   figure;
27
   subplot(2,2,1);
28
   imshow(left);
   title('Left Image');
```

```
subplot(2,2,2);
imshow(right);
stitle('Right Image');

subplot(2,2,3);
imshow(RightSub);
figure;
surf(Results);
shading flat;
// end
```

C.2.0.7 SSDAll.m

../MATLAB/SSDAll.m

```
%function [ Results ] = SADAll( Left, Right )
   %SADALL Function to compute all SADs of an image
2
   	ilde{\mbox{\it %}} The sum of absolute differences is calculated and returned on a mesh
       graph to show how well matched the sub image is to the image. A box out
       of the right image is taken and compared with the left image.
   loadimages;
   BoxSize = [50,50];
    [~,~,C] = size(right);
   [I,J,D] = size(left);
   if C ~= D
10
        error('Images have different number of colour planes');
11
   end
12
   RightSub = GetSubImage(right, BoxSize, [190,190]);
14
   for i = 25:(I-25)
       for j = 25:(J-25)
            LeftSub = GetSubImage(left, BoxSize, [i, j]);
            Diff = LeftSub - RightSub;
19
            Diff = Diff.^2;
20
            Results(i,j) = sum(Diff(:));
21
        end
22
   end
23
   %Display
25
   figure;
    subplot(2,2,1);
    imshow(left);
   title('Left Image');
   subplot(2,2,2);
31
   imshow(right);
32
   title('Right Image');
33
   subplot(2,2,3);
35
36
   imshow(RightSub);
   title('Right Sub');
37
39 figure;
```

```
40 surf(Results);
41 shading flat;
42 %end
```

C.2.0.8 NCC.m

../MATLAB/NCC.m

```
loadimages;
   show;
   BoxSize = [50,50];
   MaxConfMatches = 20;
   %SubCoord = [145, 300];
   figure(1);
   %[rightSub, rect_Sub] = imcrop(right);
   figure(2);
   imshow(right);
10
   rSubCoord = ginput(1);
   rSubCoord = [190,190]; [rSubCoord(2), rSubCoord(1)];
   rSubCoord = round(rSubCoord);
   close;
15
   rightSub = GetSubImage(right, BoxSize, rSubCoord);
16
   %imshow(rightSub);
17
   rightSubGray = rgb2gray(rightSub);
18
   leftGray = rgb2gray(left);
19
   rightGray = rgb2gray(right);
20
   cL = normxcorr2(rightSubGray(:,:), leftGray(:,:));
21
   figure(2);
22
   % subplot (1,2,1);
   surf(cL), shading flat;
   title('Normalised Cross Correlation of Right Sub and Left Image');
   % cR = normxcorr2(rightSubGray(:,:), rightGray(:,:));
  % subplot (1,2,2);
   % surf(cR), shading flat;
   % title('Normalised Cross Correlation of Right Sub and Right Image');
   % cD = cL - cR;
32
33
   % figure;
   % surf(cD), shading flat;
   \% title('Differences of the Normalised Cross Correlation of Right and Left');
   %Find coordintes of best match.
   [Y,X] = size(cL);
39
   maxValue = 0;
   LeftMatchCoord = [0,0];
41
   NumConfidentMatches = 0;
42
44
   for i = 1:X
45
     for j = 1:Y
46
          Val = cL(j,i);
47
          if Val > 0.9
         NumConfidentMatches = NumConfidentMatches + 1;
```

```
49
           if Val > maxValue
50
              maxValue = Val;
51
               LeftMatchCoord = [j-(BoxSize(1) / 2 ), i-(BoxSize(2) / 2 )];
52
           end
53
       end
54
55
    end
    Result = [maxValue, LeftMatchCoord];
57
    figure(1);
    if NumConfidentMatches >= 1 && NumConfidentMatches < MaxConfMatches</pre>
        left(LeftMatchCoord(1) -(BoxSize(1)/2):LeftMatchCoord(1)+(BoxSize(1)/2),
        LeftMatchCoord(2)-(BoxSize(2))/2)=255;
        left(LeftMatchCoord(1) -(BoxSize(1)/2):LeftMatchCoord(1)+(BoxSize(1)/2),
61
        LeftMatchCoord(2)+(BoxSize(2))/2)=255;
        left(LeftMatchCoord(1) -(BoxSize(1)/2), LeftMatchCoord(2) -(BoxSize(2)/2):
62
        LeftMatchCoord(2)+(BoxSize(2))/2)=255;
        left(LeftMatchCoord(1)+(BoxSize(1)/2), LeftMatchCoord(2)-(BoxSize(2)/2):
63
        LeftMatchCoord(2)+(BoxSize(2)/2))=255;
        right(rSubCoord(1)-(BoxSize(1)/2):rSubCoord(1)+(BoxSize(1)/2),rSubCoord(2)
65
        -(BoxSize(2)/2))=255;
         \texttt{right}(\texttt{rSubCoord}(1) - (\texttt{BoxSize}(1)/2) : \texttt{rSubCoord}(1) + (\texttt{BoxSize}(1)/2) , \texttt{rSubCoord}(2) \\
        +(BoxSize(2)/2))=255;
        right(rSubCoord(1)-(BoxSize(1)/2),rSubCoord(2)-(BoxSize(2)/2):rSubCoord(2)
67
        +(BoxSize(2)/2))=255;
        right(rSubCoord(1)+(BoxSize(1)/2),rSubCoord(2)-(BoxSize(2)/2):rSubCoord(2)
68
        +(BoxSize(2)/2))=255;
        subplot(1,2,1);
70
        imshow(left);
71
72
        subplot(1,2,2);
        imshow(right);
    %
          LeftMatchCoord
74
75
   %
          rSubCoord
76
          NumConfidentMatches
77
        Distance = Range(rSubCoord(2), LeftMatchCoord(2));
        sprintf('Distance to Object = %d metres', Distance)
78
    elseif NumConfidentMatches >= MaxConfMatches
79
        title(sprintf('Too many matches found : %d', NumConfidentMatches));
80
    else
81
        title(sprintf('No Reliable Match Found'));
82
84
    end
```