UNIVERSITY OF SOUTHAMPTON

FACULTY OF PHYSICAL AND APPLIED SCIENCES

Electronics and Computer Science

Two Dimensional Stereoscopic Mapping Robot

by

Henry S. Lovett

Technical Report

December 4, 2012

UNIVERSITY OF SOUTHAMPTON

<u>ABSTRACT</u>

FACULTY OF PHYSICAL AND APPLIED SCIENCES
Electronics and Computer Science

TWO DIMENSIONAL STEREOSCOPIC MAPPING ROBOT

by Henry S. Lovett

This paper describes the research, designing and building of a stereoscopic mapping robot. Mapping robots usually utilise Infra-red or laser range finders to do the distance calculations. By using two cameras, distances to objects can be calculated. The end goal is to build up an occupancy map which shows the state of an explored area as either unknown, free or occupied.

Contents

List of Figures

List of Tables

Listings

Nomenclature

I^2C Inter-Integrated Circuit

TWI Two Wire Interface

SCCB Serial Camera Control Bus

kB KiloBytes

φ_0 Field of View of the Camera

B Seperation Distance of two Cameras

i, j Pixel Index of an Image

Chapter 1

Introduction

The Introduction to my Report . . .

The initial idea of the project was taken from Pirobot(Goebel (2012)).

what it will do. Define everything. Use. Very general

General - mapping robots.

stereovision - uses etc.

other similar projects

why mine is important

Chapter 2

Research

The research done for this project is split down into three sections:

1. Hardware

2. Software, broken down into:

   (a) Firmware
   (b) Algorithms

2.1 Hardware Research

Talk about why I chose to develop with AVRs, comparison with other uControllers. Why I used the OV7670 Camera etc etc

2.2 Image Algorithms

2.2.1 Comparison Algorithms

Before

Chapter 3

Initial Hardware and Firmware Development

For initial development, an *Il Matto* board, designed by Steve Gunn, which has an ATMega644P, was used. The system is clocked at 16MHz and has an on-board SD card connector.

The following section is broken down into parts listed below:

1. Camera Code

2. SD Card

3. Motor Control

4. PCB Development

3.1   Camera

The camera that was used was an OV7670 by OmniVision. It is mounted onto a break out board and connected to a AL422B FIFO Buffer. The breakout board also had all passive components and a 24MHz clock mounted. The schematic for the device can be seen in Appendix A.

Original code for the camera operation was given to me by Steve Gunn, of which I used to gain the operation required.

3.1.1   Single Camera Operation

The camera uses a SCCB Interface(OmniVision (2007)) created by OmniVision. This is almost identical to the I^2C Interface by Phillips. The original code used a bit-banged SCCB interface which was very slow and used up processing time. This was changed to make used of the built in interrupt driven I^2C interface (named TWI in Atmel AVRs)[1]. This communication bus is used to set up the control registers of the OV7670 to enable operation in the correct format. RGB565 is used in my application.

RGB565 is a 16 bit pixel representation where bits 0:4 represent the blue intensity, 5:10 contain green intensity and 11:15 represent the red intensity. This is a compact way of storing data but only allows 65536 colours. Greys can also appear to be slightly green due to an inconsistent colour ratio of the green field.

The camera must use a high speed clock in order to ensure the pixels obtained are from the same frame. This makes it difficult for an AVRs (ATMegas typically clocked at 12-16MHz) to be able to respond to the camera quick enough. This highlights the importance of the necessity of the FIFO Buffer.

The OV7670 is set up so that the VSYNC pin goes low at the beginning of every full frame of data and HREF is high when the data being output is valid. The pixel data is then clocked out on every rising edge of PCLK. To control the buffer, WEN (write enable) is NAND with the HREF signal. When both are high, the write enable to the buffer will be active and the data will be clocked in by PCLK. In order to acquire a full frame, the first VSYNC pin is set up to interrupt the AVR to enable WEN. The operation is then automatic and all the data is clocked into the buffer until the second interrupt of VSYNC where WEN is disabled. At this point, the entire frame of data is stored in the buffer.

To obtain the data from the buffer, the AVR manually pulses the read clock and stores the data on the input port. All the data is then read in one pixel at a time.

Difficulties arose at this point with the storage of the data. The ATMega644P has 4kB of internal SRAM, but 153.6kB of memory are needed to store a single frame or image at QVGA (320 by 240 pixels) quality.

Firstly, data was sent straight to a desktop computer via a COM Port. A simple desktop program written in C# to store all the data and convert binary into a Bitmap image. This method was slow, taking around 30 seconds to transmit one uncompressed image.

The second option then was to use extra memory connected to the microcontroller. An SD card was decided to be used in as a FAT file system. This will allow data to be looked at by a user on a computer of image files and log files. This is discussed in section 2.

---

[1] I^2C , SCCB and TWI are all the same but are called differently due to Phillips owning the right to the term I^2C

3.1.2 Dual Camera Operation

In order for stereovision to be successful, two cameras separated by a horizontal distance will need to be driven at the same time to obtain photos of the same time frame.

The buffers have an output enable pin so the data bus can be shared by both cameras to the AVR. All buffer function pins are driven from pins, although a demultiplexer could be used if pins are short. The ATMega644P offers three interrupt pins, two of which are used by the two VSYNC pins for the cameras.

Two ISRs are used to control the VSYNC method and when taking a photo, both frames are taken at a time period close together to capture the same scenario. The data for both images are read back from one and then the other by the AVR.

A major problem now occurred with using the I^2C interface to set up both cameras. The camera has a set I^2C address of 21_{16} which cannot be changed. Two I^2C devices with exactly the same address cannot be used on the same bus. Two solutions to this are possible: driving one from I^2C and one from SCCB, or using an I^2C multiplexer. By using two different buses, there is no contention on the bus. However, SCCB is slow and processor hungry as it deals with the protocol bit by bit. Space for the code then has to be made and this code cannot be reused.

An I^2C multiplexer sits on the bus and has multiple output buses. The master can then address the MUX and select whether to pass the bus to bus 0, bus 1 or not allow the data to be transferred. This saves processor time, but means a write operation has to be done to select the camera bus before being able to write to the camera. This slows down the operation but not as much as using SCCB. The main disadvantage to the I^2C MUX is the extra hardware needed. Firstly, the MUX itself, but also 7 extra resistors to pull up the two extra buses and the three interrupt lines must be added.

Overall, the disadvantages posed by using a MUX are small and simplify the operation and reduce the code size so an I^2C MUX will be used. A suitable multiplexer is the Phillips PCA9542A(Phillips (2009)).

Operation to read an image is identical to using one camera. An ID number is passed through the functions to make a decision on the pins to use to read the buffer and enable the output. Care was taken to avoid bus contention, but no checking procedure is explicitly in place. Both images are then read back from the buffers and stored to memory.

3.2 SD Card

Fix the FatFS Reference

	Bitmap	JPEG	PNG	GIF
Extension	*.bmp	*.jpg /*.jpeg	*.png	*.gif
Compression	No	Lossless and Lossy	Lossless ZIP	Lossy
File Size of 320 by 240 pixel Image (kB)	225	20	23	24
Bits per Pixel	8, 16, 24 or 32	24	24, 32 or 48	24, but only 256 Colours

Table 3.1: A table comparing different image formats available (Fulton (2010))

`Sort Reference Out`

To use the SD card, the FATFS library Manufacturing (2012) was used. The library supplies all the functions for writing a FAT File System in the files *ff.c*, *ff.h*, *ffconf.h*, *diskio.c*, *diskio.h* and *integer.h*. The *diskio.h* functions control what device is being used - SD/MMC Card, USB drive etc. The *ff.h* header contains all the functions to write to in a FAT File system.

An SD card was chosen to be used due to it's small size, low cost and a large data storage. The cards work using an SPI bus which can be used for other devices within the system so the card only uses one extra enable pin in hardware to function.

3.2.1 Storing Images

Many image formats are common such as Joint Photographic Expert Group (JPEG), Portable Network Graphics (PNG), Bitmap (BMP) and Graphics Interchange Format (GIF). Table 3.1 shows a summary of some common image formats.

It is clear that the best choice for images would be either PNG or JPEG. However, these require much computational time to compress the image to obtain the correct format. To avoid compression, and thereby save computational time, Bitmap was decided to be used at the expense of using more memory. The data in a bitmap image is also stored in RGB format so can be read back easily when processing the data. Appendix B shows the make up of a Bitmap File that was used.

By writing the image in this format, the images are then able to be opened on any operating system. This aids debugging and allows the protoyping of image algorithms in a more powerful environment. Figure 3.1 shows a photo taken by the OV7670 and stored on a SD card.

3.3   Motor Control

`do something of this SOON`

Figure 3.1: An Example Image taken using the OV7670 and stored as a Bitmap on the SD Card

3.4   PCB Development

Also do something of this SOON

Chapter 4

Investigation into Vision Algorithms

4.1 Comparison

find some references to back these claims up

Talk about how to compare images and TEST them all. Make a final comparison to decide on which will be used

In computer vision, there are many different ways of comparing two similar images. These include the sum of absolute differences (S.A.D.) (Hamzah et al. (2010)), the sum of squared differences (S.S.D.) and normalised cross correlation (N.C.C.). Each of these methods will be explained and tested to compare them. All testing will use images seen in figure 4.1. Each test uses the same size of image to compare to of 50×50 pixels of the same part of the image.

Maybe do a basic 5x5 example for each?

(a) Left Image　　　　　　　　(b) Right Image

Figure 4.1: Stereoscopic Test Images from MATLAB Examples

4.1.1   Sum of Absolue Differences

Given two indentically sized matricies, A, B of dimensions I, J, SAD is defined as

$$SAD = \sum_{i=0}^{I-1} \sum_{j=0}^{J-1} A[i,j] - B[i,j] \tag{4.1}$$

This method takes each sub image and subtracts the observed sub image from the expected. All differences are then added together. This algorithm is simple and requires a small amount of computation. The algorithm returns values where a small result means the two images are well matched.

4.1.2   Sum of Squared Differences

$$SSD = \sum_{i=0}^{I-1} \sum_{j=0}^{J-1} (A[i,j] - B[i,j])^2 \tag{4.2}$$

This is very similar to S.A.D. but adds more complexity by squaring each difference. This removes the ability of equally different but opposite differences cancelling each other out (grey to white of one pixel will cancel out a white to grey difference in the other). Again, a low result is a match in this case.

4.1.3   NCC

$$NCC = \frac{1}{n} \sum_{i,j} \frac{(A[i,j] - \bar{A}).(B[i,j] - \bar{B})}{\sigma_A.\sigma_B} \tag{4.3}$$

Where n is the number of pixels in A and B,
σ is the standard deviation of the image, and
$\bar{A}$ is the a average pixel value.

Find a source for this equation

No date on Reference

NCC is very similar to cross correlation, but normalised to reduce the error if one image is brighter than the other. It is common in computer vision (Tsai and Lin ()) as cross correlation is a common operation in DSP so fast algorithms have been made to calculate this.

Unlike S.S.D. and S.A.D., the normalised cross correlation gives a high value for a match. The downside to this algorithm comes with the complexity of the equation with

division in it and a square root to calculate the standard deviation. These operations are rarely implemented in hardware and are time consuming to carry out. They also require floating point registers and operations slow on a Microcontroller with a small amount of floating point registers.

4.1.4   Comparison

To compare these equations, a 50 by 50 image taken from the Right picture was compared with the left image over the entire valid range. The coordinates on the graph give the centre pixel of the calculation. Fi

Each of the graphs show the correct area being indentified as a match, but this also highlights the downfalls of the SAD and SSD. The figures in figure 4.2 are orientated to match the orientation of the images in figure 4.1. Each of the images is tested by attempting to match the phone from the test figure. The actual match should be around $(170, 176)$. An exact result cannot be estimated as the images are not matched perfectly - there isn't an exact integer of pixel difference between the images. This is the sub pixel problem.

reference for sub pixel problem?

SAD results in figure 4.2(b) show large areas of matching. The actual match is at $(170, 175)$ and a minimum does occur at this position as expected of a value of 5.66×10^4. However, along the bottom of the image where a dark area occurs in the lower part of figures 4.1 below the desk, the SAD algorithm detects a greater comparison with the lowest value in this area being 3370 at $(227, 275)$. This creates a false detection here.

SSD shows matches in the same two areas: where a match should occur and the dark area beneath the desk. The minimum values where the match should occur is 4.355×10^5 at location $(170, 176)$. However, again, there is thought to be a large match correlation between the dark area under the desk where the actual lowest value of 2.768 is at $(225, 274)$. This, again, is a false match and is a downfall of this algorithm.

The NCC results are visible in figure 4.2(c). A match can be seen at coordinate $(195, 201)$ with a peak value of 0.9654. The coordinate is different to the previous results because the cross correlation works over the boundary of the image creating more results. The dimensions of the image are 300×400, but the NCC returns an data set of dimensions 350×450 when using a box size of 50×50. To get the actual match, half of the box size must be subtracted from the returned coordinate. This means the match occurs at $(170, 176)$.

(a) S.A.D Results (Low match)

(b) S.S.D. Results (Low match)

(c) N.C.C. Results (High match)

Figure 4.2: Result Graphs of Comparison Algorithms

4.1.5 Conclusion

It can be seen there is a direct correlation between the complexity of the matching algorithm to the reliability of the match returned. In brightly lit, colourful environments absent of dark colours, SAD and SSD should provide a reliable result, but this cannot guaranteed to always be the case. Therefore further development of the matching algorithm will start with using the Normalised Cross Correlation. There is a compromise of complexity for reliability, of which reliability is more desirable. Cross correlation is also a large area of research, so optimised algorithms do exist.

4.2 Range Finding

Derive the range finding equations and test them

4.2.1 Derivations

By using two images separated by a horizontal difference, the range of an object can be found given some characteristics of the camera. The following is a derivation of the equations used to calculate distance.

The problem is broken down into 3

1. Object is between the cameras (Figure 4.3)

2. Object is directly in front of a camera

3. Object is in left or right hand sides of both images

4.2.1.1 Object is between the Cameras

Derivation from Mrovlje and Vrančić (2008).

$$B = B_1 + B_2 = D\tan(\varphi_1) + D\tan(\varphi_2) \tag{4.4}$$

$$D = \frac{B}{\tan(\varphi_1) + \tan(\varphi_2)} \tag{4.5}$$

$$D\tan(\frac{\varphi_0}{2}) = x_0/2 \tag{4.6}$$

Figure 4.3: Problem 1 - Object is between the Cameras

Figure 4.4: Problem 1 : Left Camera Simplified

$$D \tan(\varphi_1) = x_1 \tag{4.7}$$

Dividing (4.7) by (4.6)

$$\frac{\tan(\varphi_1)}{\tan(\frac{\varphi_0}{2})} = \frac{2x_1}{x_0} \tag{4.8}$$

$$\tan(\varphi_1) = \frac{2x_1 \tan(\frac{\varphi_0}{2})}{x_0} \tag{4.9}$$

Figure 4.5: Problem 3 - Object is to the same side in both cameras

It can also be shown that for the right camera:

$$\tan(\varphi_2) = \frac{-2x_2 \tan(\frac{\varphi_0}{2})}{x_0} \tag{4.10}$$

Substitution equations (4.9) and (4.10) into (4.5) gives

$$D = \frac{Bx_0}{2 \tan(\frac{\varphi_0}{2})(x_1 - x_2)} \tag{4.11}$$

4.2.1.2 Object is infront of a camera

4.2.1.3 Object is to the same side in each camera

Chapter 5

Conclusions and Further Work

It works.

Appendix A

# Circuit Diagrams

A.1 OV7670 Breakout Board Schematic

Figure A.1: The circuit diagram for the OV7670 breakout board

Appendix B

Bitmap File Format

B.1 Bitmap File Format

Table B.1: Feasible triples for highly variable Grid, MLMMH.

Section	Field	Description	Size (Bytes)	Value (hex)
Bitmap Header	Signature	Declares the file is a Bitamp Image	2	424D
	File Size	Size of the whole file including headers	4	36580200 (153654)[1]
	Reserved		4	00000000
	Offset to Pixel Array	The address of the start of the pixel data from the beginning of the file	4	36000000
DIB (Device Independant Bitmap) Header	Size	Size of the DIB Header (dictates the version)	4	7C000000
	Width	Width of the image (320 pixels)	4	40010000
	Height	Height of the image (240 pixels)	4	F0000000
	Planes	Number of colour planes	2	0100
	Bit Count	Number of bits per pixel	2	1000
	Compression	Compression Being Used, RGB Bit Fields	4	03 00 00 00
				Continued on next page

---

[1]This is different to the 225kB said in Table 3.1 due to ommitting many optional fields

Table B.1 – continued from previous page

Section	Field	Description	Size (Bytes)	Value (hex)
	Image Size	Size of the image	4	00 86 25 00
	X Resolution	Horizontal resolution in pixels per metre	4	13 0B 00 00
	Y Resolution	Vertical resolution in pixels per metre	4	13 0B 00 00
	Colours in Table	Number of colours in the colour table (not used)	4	00 00 00 00
	Important Colours	Number of Important Colours (0 means all colours are important)	4	00 00 00 00
	Red Mask	Bit mask of Red field	4	00 F8 00 00
	Green Mask	Bit mask of Green field	4	E0 07 00 00
	Blue Mask	Bit mask of Blue field	4	1F 00 00 00
	Alpha Mask	Bit mask of Alpha field	4	00 00 00 00
	Colour Space Type	Colour Space of the DIB	4	01 00 00 00
	Colour Space Endpoints	Sets endpoints for colours within the bitmap (not used)	36	Whole Field = 0
	Gamma Red	Gamma Value of Red Field (not used)	4	00 00 00 00
	Gamma Green	Gamma Value of Green Field (not used)	4	00 00 00 00
	Gamma Blue	Gamma Value of Blue Field (not used)	4	00 00 00 00
	Intent	Enum dictating the intent of the image (Picture)	4	03 00 00 00
	ICC Profile Data	Offset from the file start to the ICC Colour Profile (Not Used)	4	00 00 00 00
	ICC Profile Size	Size of the ICC Colour Profile (not used)	4	00 00 00 00
	Reserved		4	00 00 00 00
Continued on next page				

Table B.1 – continued from previous page

Section	Field	Description	Size (Bytes)	Value (hex)
Image Data Format	Each field contains all the pixel data	Padding is used to make the table width a multiple of 4 (Not always needed)		
Pix[0, h-1]	Pix[1, h-1]	. . .	Pix[w-1, h-1]	Padding
⋮	⋮	⋮	⋮	⋮
Pix[0, 1]	Pix[1, 1]	. . .	Pix[w-1, 1]	Padding
Pix[0, 0]	Pix[1, 0]	. . .	Pix[w-1, 0]	Padding

Appendix C

Source Code

C.1 C Code for AVR

should I include FatFS Files?

C.1.1 Dual Camera Operation

C.1.1.1 main.c

```c
/*
 * DualOV7670.c
 *
 * Created: 09/11/2012 11:43:13
 *  Author: hl13g10
 */
#include "Config.h"



//static FILE mystdout = FDEV_SETUP_STREAM(File_Write_Printf, NULL, ↵
    _FDEV_SETUP_WRITE);
//FatFS Variables
FILINFO Finfo;
FATFS Fatfs[_VOLUMES];    /* File system object for each logical drive */
//FIL Files[2];       /* File object */
uint8_t StatusReg;
// char Line[100];       /* Console input buffer */
//char Buff[100];     /* Working buffer */
char ImageRName[20];
char ImageLName[20];
#define STATUS_OKAY      0x01
#define STATUS_SDOkay    0x02
#define STATUS_CAM0Okay   0x04
#define STATUS_CAM1Okay   0x08
#define STATUS_READY      0x10
```

```c
26  #define STATUS_CAPTURING   0x20
27  #define STATUS_Exit_Bad    0x80
28
29  #define Button_Capture     0
30  #define Button_Exit        3
31  unsigned char UI_LEDs(uint8_t LED)
32  {
33     unsigned char mesbuf[TWI_BUFFER_SIZE];
34     mesbuf[0] = (0x15 << TWI_ADR_BITS) | (FALSE << TWI_READ_BIT);
35     mesbuf[1] = 0x10;
36     mesbuf[2] = LED;
37     TWI_Start_Transceiver_With_Data(mesbuf, 3);
38     while(TWI_Transceiver_Busy()) ;
39     return TWI_statusReg.lastTransOK;
40  }
41  unsigned char UI_Buttons()
42  {
43     unsigned char messageBuf[TWI_BUFFER_SIZE]; //Initialise a buffer
44     messageBuf[0] = (0x15<<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); // The first ↵
          byte must always consist of General Call code or the TWI slave address.
45     messageBuf[1] = 0x20;               // The first byte is used for the command
46     TWI_Start_Transceiver_With_Data( messageBuf, 2 );
47     _delay_us(250);
48     // Request/collect the data from the Slave
49     messageBuf[0] = (0x15<<TWI_ADR_BITS) | (TRUE<<TWI_READ_BIT); // The first byte↵
           must always consist of General Call code or the TWI slave address.
50     TWI_Start_Transceiver_With_Data( messageBuf, 2 );
51
52     // Get the received data from the transceiver buffer
53     TWI_Get_Data_From_Transceiver( messageBuf, 2 );
54     return messageBuf[1];
55  }
56  ISR(TIMER0_COMPA_vect)
57  {
58     disk_timerproc(); /* Drive timer procedure of low level disk I/O module */
59  //   if(!TWI_statusReg.lastTransOK) //if the last TWI transmission failed, reset ↵
          the protocol
60  //      TWI_Start_Transceiver();
61  //   if(!TWI_Transceiver_Busy())
62  //      UI_LEDs(StatusReg);
63  }
64  int main(void)
65  {
66     unsigned long int a = 0;
67     uint8_t b = 0;
68     FRESULT fr;
69     uint8_t PhotoCount = 0;
70     TWI_Master_Initialise();
71     IO_Init();
72     sei();
73     PCA9542A_Init();
74
75     StatusReg = STATUS_OKAY;
76     UI_LEDs(StatusReg);
77
78
79     fr = f_mount(0, &Fatfs[0]);
80     if(fr != FR_OK)
81     {
```

```
82        StatusReg |= (STATUS_Exit_Bad);
83        StatusReg &= ~(STATUS_OKAY);
84        UI_LEDs(StatusReg);
85        return 0;
86      }
87      else
88        StatusReg |= STATUS_SDOkay;
89    UI_LEDs(StatusReg);
90
91    fr = f_open(&Files[0], "/log.txt", FA_WRITE|FA_CREATE_ALWAYS);
92    if(fr != FR_OK)
93    {
94        StatusReg |= (STATUS_Exit_Bad);
95        StatusReg &= ~(1<<STATUS_SDOkay) | (1<<STATUS_OKAY);
96        UI_LEDs(StatusReg);
97        return 0;
98    }
99    UI_LEDs(StatusReg);
100
101   f_close(&Files[0]);
102   f_open(&Files[0], "/log.txt", FA_WRITE);
103   //stdout = &mystdout;
104   b = MCUSR;
105   MCUSR = 0;
106   f_write(&Files[0],"Il Matto Dual Camera\n", sizeof("Il Matto Dual Camera\n"), ↵
         &a);
107
108   /*f_write(&Files[0], "System Startup Complete.\n", 26, &a);*/
109
110   PCA9542A_SetChannel(CH1);
111   b = OV7670_init();
112   if(b == 0)
113     StatusReg |= STATUS_CAM1Okay;
114   PCA9542A_SetChannel(NO_SELECT);
115   UI_LEDs(StatusReg);
116   sprintf(Buff, "OV7670_1 Initialise result : %d\n", b);
117   f_write(&Files[0], &Buff, 33, &a);
118
119   PCA9542A_SetChannel(CH0);
120   b = OV7670_init();
121   if(b == 0)
122     StatusReg |= STATUS_CAM0Okay;
123   UI_LEDs(StatusReg);
124   PCA9542A_SetChannel(NO_SELECT);
125   sprintf(Buff, "OV7670_0 Initialise result : %d\n", b);
126   f_write(&Files[0], &Buff, 33, &a);
127   FIFO_init();
128
129   //f_close(&Files[0]);
130   StatusReg |= STATUS_READY;
131   UI_LEDs(StatusReg);
132   _delay_ms(250);
133   uint8_t Input;
134
135     while(1)
136     {
137     Input = (~UI_Buttons() & 0x0F);//Data is received negative
138     if(Input)//if a button has been pressed
139     {
```

```
140          _delay_ms(250);
141          sprintf(Buff, "Button Received : %d\n", Input);
142          f_write(&Files[0], Buff, 21, &a);
143
144          StatusReg&= ~(STATUS_READY);//no longer ready
145
146          switch(Input)
147          {
148            case (1<<Button_Capture):
149                StatusReg |= STATUS_CAPTURING;
150                UI_LEDs(StatusReg);
151                //Reset both buffers
152                FIFO_Reset(0);
153                FIFO_Reset(1);
154                f_write(&Files[0], "Capturing Images...\n", 20, &a);
155                LoadImagesToBuffer();//Load both images
156
157                //Create Bitmap for image 0
158                //PSTR("Image_r.bmp");
159
160                f_open(&Files[1], "Image_r.bmp", FA_CREATE_ALWAYS | FA_WRITE);
161                f_write(&Files[0], "Created image0 file.\n", 22, &a);
162                f_lseek(&Files[1], BMPFileSize);
163                f_lseek(&Files[1], 0);
164                f_close(&Files[1]);
165                f_write(&Files[0], "Extended image0 file.\n", 22, &a);
166
167                //Create Bitmap for image 1
168                f_open(&Files[1],"image_l.bmp", FA_CREATE_ALWAYS | FA_WRITE);
169                f_write(&Files[0], "Created image1 file.\n", 22, &a);
170                f_lseek(&Files[1], BMPFileSize);
171                f_lseek(&Files[1], 0);
172                f_close(&Files[1]);
173                f_write(&Files[0], "Extended image1 file.\n", 22, &a);
174                //Get image 0
175                f_open(&Files[1], "Image_r.bmp", FA_WRITE);
176                while (2 == GetImageIfAvailiable(&Files[1], 0)) ;
177                f_close(&Files[1]);
178                f_write(&Files[0], "Captured image0.\n", 17, &a);
179                //get image 1
180                f_open(&Files[1], "image_l.bmp", FA_WRITE);
181                while (2 == GetImageIfAvailiable(&Files[1], 1)) ;
182                f_close(&Files[1]);
183                f_write(&Files[0], "Captured image1.\n", 17, &a);
184                StatusReg |= STATUS_READY;
185                StatusReg &= ~STATUS_CAPTURING;
186                UI_LEDs(StatusReg);
187                break;//break case(1<<ButtonCapture)
188
189            case (1<<Button_Exit):
190                f_write(&Files[0], "\nSystem Exiting...\n",19 ,&a);
191                f_close(&Files[0]);//close log file
192
193                StatusReg = 0x41;
194                UI_LEDs(StatusReg);
195                return 0;//Q
196          }//End switch
197        }//End if(Input)
198        else
```

```
199        {
200          StatusReg |= STATUS_READY;
201          UI_LEDs(StatusReg);
202          _delay_ms(250);//wait
203        }//end else(Input)
204      }//End while(1)
205  }//End Main
```

C.1.1.2 Bitmap.h

```
1   /*
2    * Bitmap.h
3    *
4    * Created: 29/10/2012 11:31:11
5    *  Author: hslovett
6    */
7
8
9   #ifndef BITMAP_H_
10  #define BITMAP_H_
11
12  #define BMPHEADERSIZE 14
13  #define DIBHEADERSIZE 124 //v5
14  #define FILESIZE 153738
15
16  #include "ff.h"
17  #include "Config.h"
18
19
20  FRESULT WriteBMPHeader(FIL *File);
21  FRESULT WriteDIBHeader(FIL *File);
22
23
24  #endif /* BITMAP_H_ */
```

C.1.1.3 Bitmap.c

```
1   /*
2    * Bitmap.c
3    * Contains Methods to write the Bitmap and DIB Header. File must already be ←↩
         open.
4    * Created: 29/10/2012 11:30:58
5    *  Author: Henry Lovett (hl13g10@ecs.soton.ac.uk)
6    */
7   #include "Bitmap.h"
8
9   uint8_t DIBHead[DIBHEADERSIZE] = {  0x7C, 0x00, 0x00, 0x00, //Number of bytes
10                      0x40, 0x01, 0x00, 0x00, //Width - 320
11                      0xF0, 0x00, 0x00, 0x00, //Height - 240
12                      0x01, 0x00,        //Planes
13                      0x10, 0x00,        //Bits per Pixel
```

```
14                          0x03, 0x00, 0x00, 0x00, //Compression
15                          0x00, 0x86, 0x25, 0x00, //Size of Raw Data
16                          0x13, 0x0B, 0x00, 0x00, //Horizontal Resolution
17                          0x13, 0x0B, 0x00, 0x00, //Vertical Resolution
18                          0x00, 0x00, 0x00, 0x00, //Colours in Palette
19                          0x00, 0x00, 0x00, 0x00, //Important Colours
20                          0x00, 0xF8, 0x00, 0x00, //Red Mask
21                          0xE0, 0x07, 0x00, 0x00, //Green Mask
22                          0x1F, 0x00, 0x00, 0x00, //Blue Mask
23                          0x00, 0x00, 0x00, 0x00, //Alpha Mask
24                          0x01, 0x00, 0x00, 0x00, //Colour Space Type
25                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
26                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
27                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
28                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
29                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
30                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
31                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
32                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
33                          0x00, 0x00, 0x00, 0x00, //Colour Space Endpoints
34                          0x00, 0x00, 0x00, 0x00, //Gamma Red
35                          0x00, 0x00, 0x00, 0x00, //Gamma Green
36                          0x00, 0x00, 0x00, 0x00, //Gamma Blue
37                          0x03, 0x00, 0x00, 0x00, //Intent - Photo
38                          0x00, 0x00, 0x00, 0x00, //ICC Profile Data
39                          0x00, 0x00, 0x00, 0x00, //ICC Profile Size
40                          0x00, 0x00, 0x00, 0x00}; //Reserved
41
42  uint8_t BMPHeader[BMPHEADERSIZE] = {  0x42, 0x4D,
43                          0x8A, 0x58, 0x02, 0x00, //Size
44                          0x00, 0x00, 0x00, 0x00, //Reserved
45                          0x8A, 0x00, 0x00, 0x00 //Offset to Pixel Array
46                          };
47
48
49
50  FRESULT WriteBMPHeader(FIL *File)
51  {
52     uint32_t p;
53     FRESULT f;
54
55     f_lseek(File, 0);
56     f = f_write(File, BMPHeader, BMPHEADERSIZE, &p);
57
58     return f;
59  }
60
61  FRESULT WriteDIBHeader(FIL *File)
62  {
63     uint32_t p;
64     FRESULT f;
65
66     f_lseek(File, BMPHEADERSIZE);//place just after the bitmap header
67     f = f_write(File, DIBHead, DIBHEADERSIZE, &p);
68     return f;
69  }
```

C.1.1.4   Config.h

```c
/*
 * Config.h
 *
 * Created: 25/10/2012 21:58:56
 *   Author: hslovett
 */
#define F_CPU 12000000UL
#include <avr/io.h>
#include <avr/interrupt.h>
#include <avr/pgmspace.h>
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include <util/delay.h>
#include "TWI_Master.h"
#include "ff.h"
#include "diskio.h"
#include "Bitmap.h"
#include "DualCameras.h"
#include "PCA9542A.h"
#ifndef CONFIG_H_
#define CONFIG_H_


void IO_Init(void);

#define TRUE 1
#define FALSE 0

FIL Files[2];
char Buff[1024];

#define BMPFileSize    153738
#define RGBFileSize    153600
///////////////////////////////////////////////////////////////////////
//   Port A
///////////////////////////////////////////////////////////////////////
#define FIFO_AVR_DPRT    DDRA
#define FIFO_AVR_PORT    PORTA
#define FIFO_AVR_PINP    PINA
///////////////////////////////////////////////////////////////////////
//   Port B
///////////////////////////////////////////////////////////////////////
#define SD_WP        PB0
#define SD_CD        PB1
//#define        PB2
//#define        PB3
#define SPI_nSS_SD    PB4
#define SPI_MOSI    PB5
#define SPI_MISO    PB6
#define SPI_SCK      PB7
///////////////////////////////////////////////////////////////////////
//   Port C
///////////////////////////////////////////////////////////////////////
#define TWI_SCL      PC0
```

```
56  #define TWI_SDA       PC1
57  #define FIFO_RCLK_1    PC2
58  #define FIFO_nRRST_1   PC3
59  #define FIFO_WEN_1     PC4
60  #define FIFO_WRST_1    PC5
61  #define FIFO_nOE_0     PC6
62  #define FIFO_nOE_1     PC7
63  /////////////////////////////////////////////////////////////////////////
64  //   Port D
65  /////////////////////////////////////////////////////////////////////////
66  #define USART0_RX    PD0
67  #define USART0_TX    PD1
68  #define OV7670_VSYNC_0   PD2 //MUST BE AN INTERRUPT PIN
69  #define OV7670_VSYNC_1   PD3 //MUST BE AN INTERRUPT PIN
70  #define FIFO_RCLK_0    PD4
71  #define FIFO_nRRST_0   PD5
72  #define FIFO_WEN_0     PD6
73  #define FIFO_WRST_0    PD7
74
75
76
77  #endif /* CONFIG_H_ */
```

C.1.1.5   Config.c

```
1   /*
2    * Config.c
3    *
4    * Contains Global Methods and initialisations
5    *
6    * Created: 25/10/2012 21:59:06
7    *   Author: hslovett
8    */
9
10  #include "Config.h"
11  #include <avr/io.h>
12  void IO_Init(void)
13  {
14    //initialise timer 0 to interrupt every 10 ms
15    TIMSK0 |= (1 << OCIE0A);
16    TCCR0A |= (1 << WGM01);
17    OCR0A = 117; //10ms interrupt at 12MHz
18    TCCR0B |= (1 << CS02) | (1 << CS00);
19
20
21    DDRA = 0x00;
22    //PORTB = 0xBF;
23    DDRC = 0xFC;
24    DDRD = 0xF2;
25
26
27
28    //set int0 and int1 to trigger on falling edge
29    EIMSK = (1 << INT0) | (1 << INT1);          //Enable INT0 and INT1
```

```
30      EICRA = (1 << ISC01) | (1 << ISC11);        //Trigger INT0 and INT1 on the ↵
           falling edge
31  }
```

C.1.1.6   DualCameras.h

```
1   /*
2    * DualCameras.h
3    *
4    * Created: 10/11/2012 15:19:52
5    *  Author: hslovett
6    */
7
8
9   #ifndef DUALCAMERAS_H_
10  #define DUALCAMERAS_H_
11
12  #include "Config.h"
13
14  ///////////////////////////////////////////////////////////////////////////
15  //   Constants
16  ///////////////////////////////////////////////////////////////////////////
17  #define HEIGHT          240
18  #define WIDTH        320
19  #define PIXELSIZE       2
20  #define SETTINGS_LENGTH   167
21  #define OV7670_ADDR      0x21
22  ///////////////////////////////////////////////////////////////////////////
23  //   Globals
24  ///////////////////////////////////////////////////////////////////////////
25  const char default_settings[SETTINGS_LENGTH][2];
26  volatile uint8_t VSYNC_0_Count;
27  volatile uint8_t VSYNC_1_Count;
28  ///////////////////////////////////////////////////////////////////////////
29  //   Methods
30  ///////////////////////////////////////////////////////////////////////////
31  unsigned char OV7670_init(void);               //Initialises Camera
32  void FIFO_init(void);         //Initialises Buffer
33  uint8_t GetImageIfAvailiable(FIL *File, uint8_t CameraID);
34  void LoadImagesToBuffer(void);
35  unsigned char rdOV7670Reg(unsigned char regID, unsigned char *regDat);
36  unsigned char OV7670_SCCB_init(void);
37  void FIFO_Reset(uint8_t CameraID);
38  ///////////////////////////////////////////////////////////////////////////
39  //   Pins & Macros
40  ///////////////////////////////////////////////////////////////////////////
41  #define FIFO_RCLK_1     PC2
42  #define FIFO_nRRST_1    PC3
43  #define FIFO_WEN_1      PC4
44  #define FIFO_WRST_1     PC5
45  #define FIFO_nOE_0      PC6
46  #define FIFO_nOE_1      PC7
47
48  #define FIFO_RCLK_1_SET    { PORTC |= (1 <<  FIFO_RCLK_1); }
49  #define FIFO_RCLK_1_CLR    { PORTC &= ~(1 << FIFO_RCLK_1); }
```

```c
50  #define FIFO_nRRST_1_SET   { PORTC |= (1 <<  FIFO_nRRST_1);   }
51  #define FIFO_nRRST_1_CLR   { PORTC &= ~(1 << FIFO_nRRST_1);   }
52  #define FIFO_WEN_1_SET     { PORTC |= (1 <<   FIFO_WEN_1);   }
53  #define FIFO_WEN_1_CLR     { PORTC &= ~(1 << FIFO_WEN_1);   }
54  #define FIFO_WRST_1_SET    { PORTC |= (1 <<   FIFO_WRST_1); }
55  #define FIFO_WRST_1_CLR    { PORTC &= ~(1 << FIFO_WRST_1); }
56  #define FIFO_nOE_0_SET     { PORTC |= (1 << FIFO_nOE_0);     }
57  #define FIFO_nOE_0_CLR     { PORTC &= ~(1 << FIFO_nOE_0);   }
58  #define FIFO_nOE_1_SET     { PORTC |= (1 << FIFO_nOE_1);     }
59  #define FIFO_nOE_1_CLR     { PORTC &= ~(1 << FIFO_nOE_1);   }
60
61
62  #define FIFO_RCLK_0    PD4
63  #define FIFO_nRRST_0   PD5
64  #define FIFO_WEN_0     PD6
65  #define FIFO_WRST_0    PD7
66
67  #define FIFO_RCLK_0_SET   { PORTD |= (1 <<   FIFO_RCLK_0); }
68  #define FIFO_RCLK_0_CLR   { PORTD &= ~(1 << FIFO_RCLK_0); }
69  #define FIFO_nRRST_0_SET  { PORTD |= (1 <<   FIFO_nRRST_0);   }
70  #define FIFO_nRRST_0_CLR  { PORTD &= ~(1 << FIFO_nRRST_0);   }
71  #define FIFO_WEN_0_SET    { PORTD |= (1 <<   FIFO_WEN_0);   }
72  #define FIFO_WEN_0_CLR    { PORTD &= ~(1 << FIFO_WEN_0);   }
73  #define FIFO_WRST_0_SET   { PORTD |= (1 <<   FIFO_WRST_0); }
74  #define FIFO_WRST_0_CLR   { PORTD &= ~(1 << FIFO_WRST_0); }
75
76  //////////////////////////////////////////////////////////////////////////
77  //Camera Register Address definitions
78  //////////////////////////////////////////////////////////////////////////
79  #define OV_GAIN      0x00   //Gain Control Setting - ACG[7:0]
80  #define OV_BLUE      0x01   //Blue Channel Gain
81  #define OV_RED       0x02   //Red Channel Gain
82  #define OV_VREF      0x03   //Vertical Frame Control & ACG[9:8]
83  #define OV_COM1      0x04   //CCIR656 enable, AEC low bits (AECHH, AECH)
84  #define OV_BAVE      0x05   //U/B Average level - AUTO UPDATED
85  #define OV_GbAVE     0x06   //Y/Gb Average Level - AUTO UPDATED
86  #define OV_AECHH     0x07   //Exposure value [15:10] (AECH, COM1)
87  #define OV_RAVE      0x08   //V/R Average level - AUTO UPDATED
88  #define OV_COM2      0x09   //Soft Sleep, Output drive capability
89  #define OV_PID       0x0A   //Product ID MSB  Read only
90  #define OV_VER       0x0B   //Product ID LSB  Read Only
91  #define OV_COM3      0x0C   //Output data MSB/LSB swap + other stuff
92  #define OV_COM4      0x0D   //Average values - MUST BE SAME AS COM17
93  #define OV_COM5      0x0E   //RESERVED
94  #define OV_COM6      0x0F   //COM6
95  #define OV_AECH      0x10   //Exposure value [9:2] (see AECHH, COM1)
96  #define OV_CLKRC     0x11   //Internal Clock options
97  #define OV_COM7      0x12   //RESET, Output format
98  #define OV_COM8      0x13   //Common control 8
99  #define OV_COM9      0x14   //Automatic Gain Ceiling
100 #define OV_COM10     0x15   //PCLK, HREF and VSYNC options
101 #define OV_RSVD      0x16   //RESERVED
102 #define OV_HSTART    0x17   //Output format Horizontal Frame start
103 #define OV_HSTOP     0x18   //Output format Horizontal Frame end
104 #define OV_VSTRT     0x19   //Output format Vertical Frame start
105 #define OV_VSTOP     0x1A   //Output format Vertical Frame Stop
106 #define OV_PSHFT     0x1B   //Pixel Delay Select
107 #define OV_MIDH      0x1C   //Manufacturer ID MSB -   READ ONLY
108 #define OV_MIDL      0x1D   //Manufacturer ID LSB -   READ ONLY
```

```
109  #define  OV_MVFP        0x1E   //Mirror / VFlip Enable
110  #define  OV_LAEC        0x1F   //RESERVED
111  #define  OV_ADCCTR0       0x20   //ADC Control
112  #define  OV_ADCCTR1       0x21   //RESERVED
113  #define  OV_ADCCTR2       0x22   //RESERVED
114  #define  OV_ADCCTR3       0x23   //RESERVED
115  #define  OV_AEW         0x24   //ACG/AEC Stable Operating Region Upper Limit
116  #define  OV_AEB         0x25   //ACG/AEC Stable Operation Region Lower Limit
117  #define  OV_VPT         0x26   //ACG/AEC Fast Mode Operation Region
118  #define  OV_BBIAS       0x27   //B Channel Signal Output Bias
119  #define  OV_GbBIAS      0x28   //Gb Channel Output Bias
120  #define  OV_RSVD1       0x29   //RESERVED
121  #define  OV_EXHCH       0x2A   //Dummy Pixel Insert MSB
122  #define  OV_EXHCL       0x2B   //Dummy Pixel Insert LSB
123  #define  OV_RBIAS       0x2C   //R Channel Signal Output Bias
124  #define  OV_ADVFL       0x2D   //LSB of insert dummy line in vertical direction
125  #define  OV_ADVFH       0x2E   //MSB of insert dummy line in vertical direction
126  #define  OV_YAVE        0x2F   //Y/G Channel Average Value
127  #define  OV_HSYST       0x30   //HSYNC Rising Edge Delay (low 8 bits)
128  #define  OV_HSYEN       0x31   //HSYNCE Falling Edge Delay (low 8 bits)
129  #define  OV_HREF        0x32   //HREF Control
130  #define  OV_CHLF        0x33   //Array Current Control - RESERVED
131  #define  OV_ARBLM       0x34   //Array Reference Control - RESERVED
132  #define  OV_RSVD2       0x35   //RESERVED
133  #define  OV_RSVD3       0x36   //RESERVED
134  #define  OV_ADCCTRL       0x37   //ADC Control - RESERVED
135  #define  OV_ACOM        0x38   //ADC and Analog Common Mode Control - RESERVED
136  #define  OV_OFON        0x39   //ADC Offset Control
137  #define  OV_TSLB        0x3A   //Line Buffer Test Option
138  #define  OV_COM11       0x3B   //COM11
139  #define  OV_COM12       0x3C   //COM12
140  #define  OV_COM13       0x3D   //COM13
141  #define  OV_COM14       0x3E   //COM14
142  #define  OV_EDGE        0x3F   //Edge Detection Adjustment
143  #define  OV_COM15       0x40   //COM15
144  #define  OV_COM16       0x41   //COM16
145  #define  OV_COM17       0x42   //COM17
146  #define  OV_AWBC1       0x43
147  #define  OV_AWBC2       0x44
148  #define  OV_AWBC3       0x45
149  #define  OV_AWBC4       0x46
150  #define  OV_AWBC5       0x47
151  #define  OV_AWBC6       0x48
152  #define  OV_RSVD4       0x49
153  #define  OV_RSVD5       0x40
154  #define  OV_RSVD6       0x4A
155  #define  OV_REG4B       0x4B
156  #define  OV_DNSTH       0x4C
157  #define  OV_RSVD7       0x4D
158  #define  OV_RSVD8       0x4E
159  #define  OV_MTX1        0x4F
160  #define  OV_MTX2        0x50
161  #define  OV_MTX3        0x51
162  #define  OV_MTX4        0x52
163  #define  OV_MTX5        0x53
164  #define  OV_MTX6        0x54
165  #define  OV_BRIGHT      0x55
166  #define  OV_CONTRAS       0x56
167  #define  OV_CONTRASCNTR   0x57
```

```
168   #define  OV_MTXS        0x58
169   #define  OV_RSVD9       0x59
170   #define  OV_RSVD9_1      0x5A
171   #define  OV_RSVD9_2      0x5B
172   #define  OV_RSVD9_3      0x5C
173   #define  OV_RSVD9_4      0x5D
174   #define  OV_RSVD9_5      0x5E
175   #define  OV_RSVD9_6      0x5F
176   #define  OV_RSVD10      0x60
177   #define  OV_RSVD11      0x61
178   #define  OV_LCC1        0x62
179   #define  OV_LCC2        0x63
180   #define  OV_LCC3        0x64
181   #define  OV_LCC4        0x65
182   #define  OV_LCC5        0x66
183   #define  OV_MANU        0x67
184   #define  OV_MANV        0x68
185   #define  OV_GFIX        0x69
186   #define  OV_GGAIN       0x6A
187   #define  OV_DBLV        0x6B
188   #define  OV_AWBCTR3      0x6C
189   #define  OV_AWBCTR2      0x6D
190   #define  OV_AWBCTR1      0x6E
191   #define  OV_AWBCTR0      0x6F
192   #define  OV_SCALING_XSC    0x70
193   #define  OV_SCALING_YSC    0x71
194   #define  OV_SCALING_DCWCTR  0x72
195   #define  OV_SCALING_PCLK_DIV  0x73
196   #define  OV_REG74       0x74
197   #define  OV_REG75       0x75
198   #define  OV_REG76       0x76
199   #define  OV_REG77       0x77
200   #define  OV_RSVD12      0x78
201   #define  OV_RSVD13      0x79
202   #define  OV_GAM1        0x7A
203   #define  OV_GAM2        0x7B
204   #define  OV_GAM3        0x7C
205   #define  OV_GAM4        0x7D
206   #define  OV_GAM5        0x7E
207   #define  OV_GAM6        0x7F
208   #define  OV_GAM7        0x80
209   #define  OV_GAM8        0x81
210   #define  OV_GAM9        0x82
211   #define  OV_GAM10       0x83
212   #define  OV_GAM11       0x84
213   #define  OV_GAM12       0x85
214   #define  OV_GAM13       0x86
215   #define  OV_GAM14       0x87
216   #define  OV_GAM15       0x88
217   #define  OV_GAM16       0x89
218   #define  OV_RSVD14      0x8A
219   #define  OV_RSVD15      0x8B
220   #define  OV_RSVD16      0x8C
221   #define  OV_RSVD17      0x8D
222   #define  OV_RSVD18      0x8E
223   #define  OV_RSVD19      0x8F
224   #define  OV_RSVD20      0x90
225   #define  OV_RSVD21      0x91
226   #define  OV_DM_LNL      0x92
```

```
227   #define  OV_DM_LNH       0x93
228   #define  OV_LCC6         0x94
229   #define  OV_LCC7         0x95
230   #define  OV_RSVD22       0x96
231   #define  OV_RSVD23       0x97
232   #define  OV_RSVD24       0x98
233   #define  OV_RSVD25       0x99
234   #define  OV_RSVD26       0x9A
235   #define  OV_RSVD27       0x9B
236   #define  OV_RSVD28       0x9C
237   #define  OV_BD50ST       0x9D
238   #define  OV_BD60ST       0x9E
239   #define  OV_HIST0        0x9F
240   #define  OV_HIST1        0xA0
241   #define  OV_HIST2        0xA1
242   #define  OV_HIST3        0xA2
243   #define  OV_HIST4        0xA3
244   #define  OV_HIST5        0xA4
245   #define  OV_HIST6        0xA5
246   #define  OV_HIST7        0xA6
247   #define  OV_HIST8        0xA7
248   #define  OV_HIST9        0xA8
249   #define  OV_HIST10       0xA9
250   #define  OV_HIST11       0xAA
251   #define  OV_HIST12       0xAB
252   #define  OV_STR_OPT      0xAC
253   #define  OV_STR_R        0xAD
254   #define  OV_STR_G        0xAE
255   #define  OV_STR_B        0xAF
256   #define  OV_RSVD28_1     0xB0
257   #define  OV_RSVD29       0xB1
258   #define  OV_RSVD30       0xB2
259   #define  OV_THL_ST       0xB3
260   #define  OV_RSVD31       0xB4
261   #define  OV_THL_DLT      0xB5
262   #define  OV_RSVD32       0xB6
263   #define  OV_RSVD33       0xB7
264   #define  OV_RSVD34       0xB8
265   #define  OV_RSVD35       0xB9
266   #define  OV_RSVD36       0xBA
267   #define  OV_RSVD37       0xBB
268   #define  OV_RSVD38       0xBC
269   #define  OV_RSVD39       0xBD
270   #define  OV_AD_CHB       0xBE
271   #define  OV_AD_CHR       0xBF
272   #define  OV_AD_CHGb      0xC0
273   #define  OV_AD_CHGr      0xC1
274   #define  OV_RSVD40       0xC2
275   #define  OV_RSVD41       0xC3
276   #define  OV_RSVD42       0xC4
277   #define  OV_RSVD43       0xC5
278   #define  OV_RSVD44       0xC6
279   #define  OV_RSVD45       0xC7
280   #define  OV_RSVD46       0xC8
281   #define  OV_SATCTR       0xC9
282
283   #endif  /* DUALCAMERAS_H_ */
```

C.1.1.7 DualCameras.c

```c
/*
 * DualCameras.c
 *
 * Created: 10/11/2012 15:20:03
 *  Author: hl13g10
 */

#include "DualCameras.h"

const char default_settings[SETTINGS_LENGTH][2]=
{
{OV_TSLB, 0x04},
{OV_COM15, 0xd0},//RGB565 / RGB555
{OV_COM7, 0x14},
{OV_HREF, 0x80},
{OV_HSTART, 0x16},
{OV_HSTOP, 0x04},
{OV_VSTRT, 0x02},
{OV_VSTOP, 0x7b},//0x7a,
{OV_VREF, 0x06},//0x0a,
{OV_COM3, 0x00},
{OV_COM14, 0x00},//
{OV_SCALING_XSC, 0x00},
{OV_SCALING_YSC, 0x00},
{OV_SCALING_DCWCTR, 0x11},
{OV_SCALING_PCLK_DIV, 0x00},//
{0xa2, 0x02},
{OV_CLKRC, 0x01},
{OV_GAM1, 0x20},
{OV_GAM2, 0x1c},
{OV_GAM3, 0x28},
{OV_GAM4, 0x3c},
{OV_GAM5, 0x55},
{OV_GAM6, 0x68},
{OV_GAM7, 0x76},
{OV_GAM8, 0x80},
{OV_GAM9, 0x88},
{OV_GAM10, 0x8f},
{OV_GAM11, 0x96},
{OV_GAM12, 0xa3},
{OV_GAM13, 0xaf},
{OV_GAM14, 0xc4},
{OV_GAM15, 0xd7},
{OV_GAM16, 0xe8},
{OV_COM8, 0xe0},
{OV_GAIN, 0x00},//AGC
{OV_AECH, 0x00},
{OV_COM4, 0x00},
{OV_COM9, 0x20},//0x38, limit the max gain
{OV_HIST6, 0x05},
{OV_HIST12, 0x07},
{OV_AEW, 0x75},
{OV_AEB, 0x63},
{OV_VPT, 0xA5},
{OV_HIST0, 0x78},
```

```
56    {OV_HIST1 , 0x68},
57    {OV_HIST2 , 0x03},//0x0b,
58    {OV_HIST7 , 0xdf},//0xd8,
59    {OV_HIST8 , 0xdf},//0xd8,
60    {OV_HIST9 , 0xf0},
61    {OV_HIST10 , 0x90},
62    {OV_HIST11 , 0x94},
63    {OV_COM8 , 0xe5},
64    {OV_COM5 , 0x61},
65    {OV_COM6 , 0x4b},
66    {0x16 , 0x02},
67    {OV_MVFP , 0x27},//0x37,
68    {0x21 , 0x02},
69    {0x22 , 0x91},
70    {0x29 , 0x07},
71    {0x33 , 0x0b},
72    {0x35 , 0x0b},
73    {0x37 , 0x1d},
74    {0x38 , 0x71},
75    {OV_OFON , 0x2a},//
76    {OV_COM12 , 0x78},
77    {0x4d , 0x40},
78    {0x4e , 0x20},
79    {OV_GFIX , 0x0c},///////////////////////
80    {OV_DBLV , 0x60},//PLL
81    {OV_REG74 , 0x19},
82    {0x8d , 0x4f},
83    {0x8e , 0x00},
84    {0x8f , 0x00},
85    {0x90 , 0x00},
86    {0x91 , 0x00},
87    {OV_DM_LNL , 0x00},//0x19,//0x66
88    {0x96 , 0x00},
89    {0x9a , 0x80},
90    {0xb0 , 0x84},
91    {0xb1 , 0x0c},
92    {0xb2 , 0x0e},
93    {OV_THL_ST , 0x82},
94    {0xb8 , 0x0a},
95    {OV_AWBC1 , 0x14},
96    {OV_AWBC2 , 0xf0},
97    {OV_AWBC3 , 0x34},
98    {OV_AWBC4 , 0x58},
99    {OV_AWBC5 , 0x28},
100   {OV_AWBC6 , 0x3a},
101   {0x59 , 0x88},
102   {0x5a , 0x88},
103   {0x5b , 0x44},
104   {0x5c , 0x67},
105   {0x5d , 0x49},
106   {0x5e , 0x0e},
107   {OV_LCC3 , 0x04},
108   {OV_LCC4 , 0x20},
109   {OV_LCC5 , 0x05},
110   {OV_LCC6 , 0x04},
111   {OV_LCC7 , 0x08},
112   {OV_AWBCTR3 , 0x0a},
113   {OV_AWBCTR2 , 0x55},
114   {OV_AWBCTR1 , 0x11},
```

```
115  {OV_AWBCTR0, 0x9f},//0x9e for advance AWB
116  {OV_GGAIN, 0x40},
117  {OV_BLUE, 0x40},
118  {OV_RED, 0x40},
119  {OV_COM8, 0xe7},
120  {OV_COM10, 0x02},//VSYNC negative
121  {OV_MTX1, 0x80},
122  {OV_MTX2, 0x80},
123  {OV_MTX3, 0x00},
124  {OV_MTX4, 0x22},
125  {OV_MTX5, 0x5e},
126  {OV_MTX6, 0x80},
127  {OV_MTXS, 0x9e},
128  {OV_COM16, 0x08},
129  {OV_EDGE, 0x00},
130  {OV_REG75, 0x05},
131  {OV_REG76, 0xe1},
132  {OV_DNSTH, 0x00},
133  {OV_REG77, 0x01},
134  {OV_COM13, 0xc2}, //0xc0,
135  {OV_REG4B, 0x09},
136  {OV_SATCTR, 0x60},
137  {OV_COM16, 0x38},
138  {OV_CONTRAS, 0x40},
139  {0x34, 0x11},
140  {OV_COM11, 0x02},//0x00,//0x02,
141  {OV_HIST5, 0x89},//0x88,
142  {0x96, 0x00},
143  {0x97, 0x30},
144  {0x98, 0x20},
145  {0x99, 0x30},
146  {0x9a, 0x84},
147  {0x9b, 0x29},
148  {0x9c, 0x03},
149  {OV_BD50ST, 0x4c},
150  {OV_BD60ST, 0x3f},
151  {0x78, 0x04},
152  {0x79, 0x01},//Some weird thing with reserved registers.
153  {0xc8, 0xf0},
154  {0x79, 0x0f},
155  {0xc8, 0x00},
156  {0x79, 0x10},
157  {0xc8, 0x7e},
158  {0x79, 0x0a},
159  {0xc8, 0x80},
160  {0x79, 0x0b},
161  {0xc8, 0x01},
162  {0x79, 0x0c},
163  {0xc8, 0x0f},
164  {0x79, 0x0d},
165  {0xc8, 0x20},
166  {0x79, 0x09},
167  {0xc8, 0x80},
168  {0x79, 0x02},
169  {0xc8, 0xc0},
170  {0x79, 0x03},
171  {0xc8, 0x40},
172  {0x79, 0x05},
173  {0xc8, 0x30},
```

```
174  {0x79, 0x26},
175  {OV_COM2, 0x03},
176  {OV_BRIGHT, 0x00},
177  {OV_CONTRAS, 0x40},
178  {OV_COM11, 0x42},//0x82,//0xc0,//0xc2,  //night mode
179
180  };
181
182
183
184  //ISR for controlling WEN.
185  ISR(INT0_vect)
186  {
187    //printf("ISR INT0 Entered\n");
188    if (VSYNC_0_Count==1)//start a frame read
189    {
190      FIFO_WEN_0_SET;
191      VSYNC_0_Count++;
192    }
193    else if (VSYNC_0_Count==2)//end a frame read
194    {
195      FIFO_WEN_0_CLR;
196      VSYNC_0_Count++;
197    }
198    else if(VSYNC_0_Count == 3)
199    {
200      FIFO_WEN_0_CLR;
201    }
202    else
203    {
204      FIFO_WEN_0_CLR
205      VSYNC_0_Count = 0;//wait for a read to be started
206    }
207  }
208  //ISR for controlling WEN.
209  ISR(INT1_vect)
210  {
211    //printf("ISR INT1 Entered\n");
212    if (VSYNC_1_Count==1)//start a frame read
213    {
214      FIFO_WEN_1_SET;
215      VSYNC_1_Count++;
216    }
217    else if (VSYNC_1_Count==2)//end a frame read
218    {
219      FIFO_WEN_1_CLR;
220      VSYNC_1_Count++;
221    }
222    else if(VSYNC_1_Count == 3)
223    {
224      FIFO_WEN_1_CLR;
225    }
226    else
227    {
228      FIFO_WEN_1_CLR
229      VSYNC_1_Count = 0;//wait for a read to be started
230    }
231  }
232
```

```
233   //Write Register Method
234   unsigned char wrOV7670Reg(unsigned char regID, unsigned char regDat)
235   {
236     /*  I2C Traffic Generated:
237      *  S | OV_7670 + W | A | RegID | A | Data | A | P |
238      */
239     //I2C Interface
240     unsigned char messageBuf[TWI_BUFFER_SIZE];
241     messageBuf[0] = (OV7670_ADDR <<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); // The ↩
          first byte must always consit of General Call code or the TWI slave address.
242     messageBuf[1] = regID;              // The first byte is used for commands.
243     messageBuf[2] = regDat;                       // The second byte is used for ↩
          the data.
244     TWI_Start_Transceiver_With_Data( messageBuf, 3 );
245
246     while(TWI_Transceiver_Busy()) ; //Wait for transceiver to clear
247
248     return TWI_statusReg.lastTransOK;
249   }
250
251   //Read Register Method
252   unsigned char rdOV7670Reg(unsigned char regID, unsigned char *regDat)
253   {
254     /*  I2C Traffic Generated:
255      *  S | OV_ADDR + W | A | RegID | A | P |
256      *  S | OV_ADDR + R | A | Data  |~A | P |
257      */
258     //I2C Interface
259     unsigned char messageBuf[TWI_BUFFER_SIZE]; //Initialise a buffer
260     messageBuf[0] = (OV7670_ADDR<<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); // The ↩
          first byte must always consist of General Call code or the TWI slave address↩
          .
261     messageBuf[1] = regID;               // The first byte is used for Address ↩
          Pointer.
262     TWI_Start_Transceiver_With_Data( messageBuf, 2 );
263
264     // Request/collect the data from the Slave
265     messageBuf[0] = (OV7670_ADDR<<TWI_ADR_BITS) | (TRUE<<TWI_READ_BIT); // The ↩
          first byte must always consist of General Call code or the TWI slave address↩
          .
266     TWI_Start_Transceiver_With_Data( messageBuf, 2 );
267
268     // Get the received data from the transceiver buffer
269     TWI_Get_Data_From_Transceiver( messageBuf, 2 );
270     *regDat = messageBuf[1];
271     return TWI_statusReg.lastTransOK;
272   }
273
274
275   unsigned char OV7670_init()
276   {
277     uint8_t i = 0;
278     if(0==wrOV7670Reg(OV_COM7, 0x80)) //Reset Camera
279     {
280       return 1;
281     }
282     _delay_ms(10);
283     for(i=0; i<SETTINGS_LENGTH; i++)
284     {
```

```
285        if ( 0==wrOV7670Reg ( default_settings [ i ][0] , default_settings [ i ][1] ) )
286        {
287          return 1;
288        }
289        _delay_ms(1);
290    }
291
292    return 0;
293 }
294
295 void FIFO_init ( void )
296 {
297   //disable both outputs
298   FIFO_nOE_0_SET ;
299   FIFO_nOE_1_SET ;
300   //Reset Buffer 0
301   FIFO_WRST_0_CLR ;
302   FIFO_RCLK_0_CLR ;
303   //FIFO_nOE_0_CLR ;
304   FIFO_nRRST_0_SET ;
305   FIFO_WEN_0_CLR ;
306   _delay_us (10) ;
307   FIFO_RCLK_0_SET ;
308   _delay_us (10) ;
309   FIFO_RCLK_0_CLR ;
310   FIFO_nRRST_0_CLR ;
311   _delay_us (10) ;
312   FIFO_RCLK_0_SET ;
313   _delay_us (10) ;
314   FIFO_RCLK_0_CLR ;
315   FIFO_nRRST_0_SET ;
316   _delay_us (10) ;
317   FIFO_WRST_0_SET ;
318
319   //Reset Buffer 1
320   FIFO_WRST_1_CLR ;
321   FIFO_RCLK_1_CLR ;
322   //FIFO_nOE_1_CLR ;
323   FIFO_nRRST_1_SET ;
324   FIFO_WEN_1_CLR ;
325   _delay_us (10) ;
326   FIFO_RCLK_1_SET ;
327   _delay_us (10) ;
328   FIFO_RCLK_1_CLR ;
329   FIFO_nRRST_1_CLR ;
330   _delay_us (10) ;
331   FIFO_RCLK_1_SET ;
332   _delay_us (10) ;
333   FIFO_RCLK_1_CLR ;
334   FIFO_nRRST_1_SET ;
335   _delay_us (10) ;
336   FIFO_WRST_1_SET ;
337
338 }
339
340 //Write one pixel in AVR
341 uint16_t FIFO_TO_AVR (uint8_t ID)
342 {
343   uint16_t data = 0;
```

```
344
345    DDRA = 0;
346    if (ID == 1)
347    {
348       FIFO_RCLK_1_SET;
349       data = PINA;
350       FIFO_RCLK_1_CLR;
351       data <<= 8;
352       FIFO_RCLK_1_SET;
353       data |= PINA;
354       FIFO_RCLK_1_CLR;
355    }
356    else
357    {
358       FIFO_RCLK_0_SET;
359       data = PINA;
360       FIFO_RCLK_0_CLR;
361       data <<= 8;
362       FIFO_RCLK_0_SET;
363       data |= PINA;
364       FIFO_RCLK_0_CLR;
365    }
366    return (data);
367  }
368
369
370  //Resets both pointers
371  void FIFO_Reset(uint8_t CameraID)
372  {
373    FIFO_nOE_0_SET;
374    FIFO_nOE_1_SET;
375    if (CameraID == 0)
376    {
377       FIFO_WRST_0_CLR;
378       FIFO_nRRST_0_CLR;
379       FIFO_RCLK_0_SET;
380       FIFO_RCLK_0_CLR;
381       FIFO_nRRST_0_SET;
382       FIFO_WRST_0_SET;
383    }
384    else
385    {
386       FIFO_WRST_1_CLR;
387       FIFO_nRRST_1_CLR;
388       FIFO_RCLK_1_SET;
389       FIFO_RCLK_1_CLR;
390       FIFO_nRRST_1_SET;
391       FIFO_WRST_1_SET;
392    }
393
394  }
395  void LoadImagesToBuffer()
396  {
397    VSYNC_0_Count = 0;
398    VSYNC_1_Count = 0;
399    FIFO_Reset(0);
400    FIFO_Reset(1);
401    VSYNC_0_Count = 1;
402    VSYNC_1_Count = 1;
```

```
403
404  }
405  uint8_t GetImageIfAvailiable ( FIL *File , uint8_t CameraID )
406  {
407
408     if ( ( ( CameraID == 0) && ( VSYNC_0_Count == 3) ) ||
409        ( ( CameraID == 1) && ( VSYNC_1_Count == 3) ) )
410     {
411
412        //Write Bitmap Headers
413        WriteBMPHeader ( File ) ;
414        WriteDIBHeader ( File ) ;
415        if ( CameraID == 0)
416        {
417           //Enable output of Camera 0
418           FIFO_nOE_0_CLR ;
419           //Reset Read Pointer
420           FIFO_nRRST_0_CLR ;
421           FIFO_RCLK_0_SET ;
422           FIFO_RCLK_0_CLR ;
423           FIFO_nRRST_0_SET ;
424        }
425        else
426        {
427           //Enable output of Camera 0
428           FIFO_nOE_1_CLR ;
429           //Reset Read Pointer
430           FIFO_nRRST_1_CLR ;
431           FIFO_RCLK_1_SET ;
432           FIFO_RCLK_1_CLR ;
433           FIFO_nRRST_1_SET ;
434        }
435        int i , j ;
436        uint32_t pointer ;
437        uint16_t Temp ;
438        uint32_t p ;
439        FRESULT fr ;
440        //for ( j = HEIGHT ; j >0; j--)
441        for ( j = 0; j < HEIGHT ; j++)
442        {
443           pointer = 0;
444           for ( i = 0; i < WIDTH ; i++)
445           {
446              Temp = FIFO_TO_AVR ( CameraID ) ;
447              //USART0_Senduint16 ( Temp ) ;
448
449              Buff [ pointer++] = ( uint8_t ) ( Temp >> 8) ;
450              Buff [ pointer++] = ( uint8_t ) Temp ;
451           }
452           pointer = ( uint32_t ) j * ( uint32_t ) WIDTH * 2 + BMPHEADERSIZE + ↵
        DIBHEADERSIZE ;
453           f_lseek ( File , pointer ) ;
454           fr = f_write ( File , Buff , WIDTH * 2 , &p ) ;
455           if ( fr != FR_OK )
456           {
457              //printf ("Write Fail.\n") ;
458              VSYNC_0_Count = 0;
459              VSYNC_1_Count = 0;
460              FIFO_Reset ( CameraID ) ;
```

```
461            FIFO_nOE_0_SET;
462            FIFO_nOE_1_SET;
463            return 1;
464        }
465      }
466      FIFO_Reset(CameraID);
467      //fr = f_close(File);
468      FIFO_nOE_0_SET;
469      FIFO_nOE_1_SET;
470      return 0;
471    }
472    else
473    {
474      return 2;
475    }
476 }
```

C.1.1.8 PCA9542A.h

```
1  /*
2   * PCA9542A.h
3   *
4   * Created: 13/11/2012 23:24:48
5   *   Author: hslovett
6   */
7
8
9  #ifndef PCA9542A_H_
10 #define PCA9542A_H_
11 #include "Config.h"
12
13 #define A0  0
14 #define A1  0
15 #define A2  1
16 #define PCA9542A_ADDR (0x70 | (A2 << 2) | (A1 << 1) | A0)
17
18 #define NO_SELECT 0x00
19 #define CH0       0x04
20 #define CH1       0x05
21
22 unsigned char PCA9542A_Init();
23 unsigned char PCA9542A_SetChannel(uint8_t Channel);
24
25 #endif /* PCA9542A_H_ */
```

C.1.1.9 PCA9542A.c

```
1  /*
2   * PCA9542A.c
3   *
4   * Created: 13/11/2012 23:24:40
```

```
 5   *   Author: hslovett
 6   */
 7  #include "PCA9542A.h"
 8
 9
10  unsigned char PCA9542A_Init()
11  {
12    unsigned char messageBuf[TWI_BUFFER_SIZE];
13    messageBuf[0] = (PCA9542A_ADDR <<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); // ↵
         The first byte must always consit of General Call code or the TWI slave ↵
         address.
14    messageBuf[1] = NO_SELECT;              // The first byte is used for commands.
15    // The second byte is used for the data.
16    TWI_Start_Transceiver_With_Data( messageBuf, 2 );
17
18    while(TWI_Transceiver_Busy()) ; //Wait for transceiver to clear
19
20    return TWI_statusReg.lastTransOK;
21  }
22
23  unsigned char PCA9542A_SetChannel( uint8_t Channel )
24  {
25    unsigned char messageBuf[TWI_BUFFER_SIZE];
26    messageBuf[0] = (PCA9542A_ADDR <<TWI_ADR_BITS) | (FALSE<<TWI_READ_BIT); // ↵
         The first byte must always consit of General Call code or the TWI slave ↵
         address.
27    messageBuf[1] = Channel;               // The first byte is used for commands.
28                         // The second byte is used for the data.
29    TWI_Start_Transceiver_With_Data( messageBuf, 2 );
30
31    while(TWI_Transceiver_Busy()) ; //Wait for transceiver to clear
32
33    return TWI_statusReg.lastTransOK;
34  }
35
36  unsigned char PCA9542A_ReadChannel()
37  {
38    unsigned char messageBuf[TWI_BUFFER_SIZE];
39    messageBuf[0] = (PCA9542A_ADDR <<TWI_ADR_BITS) | (TRUE<<TWI_READ_BIT); // The↵
          first byte must always consit of General Call code or the TWI slave address↵
         .
40
41    TWI_Start_Transceiver_With_Data( messageBuf, 1 );
42
43    while(TWI_Transceiver_Busy()) ; //Wait for transceiver to clear
44    // Get the received data from the transceiver buffer
45    TWI_Get_Data_From_Transceiver( messageBuf, 2 );
46    return TWI_statusReg.lastTransOK;
47  }
```

C.1.1.10   TWI_Master.h

```
1  /******************************************************************************
2  *
3  * Atmel Corporation
```

```
 4  *
 5  * File              : TWI_Master.h
 6  * Compiler          : IAR EWAAVR 2.28a/3.10c
 7  * Revision          : Revision: 1.13
 8  * Date              : Date: 24. mai 2004 11:31:22
 9  * Updated by        : Author: ltwa
10  *
11  * Support mail      : avr@atmel.com
12  *
13  * Supported devices : All devices with a TWI module can be used.
14  *                     The example is written for the ATmega16
15  *
16  * AppNote           : AVR315 - TWI Master Implementation
17  *
18  * Description       : Header file for TWI_Master.c
19  *                     Include this file in the application.
20  *
21  *****************************************************************************/
22
23  /*  Modified by Henry Lovett (hl13g10@ecs.soton.ac.uk) to allow SCL frequency to↵
          be specified and TWBR calculated
24   *  Also allows AVR internal pull up resistors to be used.
25   */
26  #ifndef _TWI_MASTER_H
27  #define _TWI_MASTER_H
28  #include <avr/io.h>
29  #include <avr/interrupt.h>
30  #include "Config.h"
31  /*****************************************************************************
32     TWI Status/Control register definitions
33  *****************************************************************************/
34
35  #define INTERNAL_PULLUPS 0
36
37  #define TWI_BUFFER_SIZE 4   // Set this to the largest message size that will be↵
          sent including address byte.
38
39  #define SCL_Freq     100000    //SCL Frequency in Hertz
40  #define TWI_TWBR     (char)(F_CPU / 2 / SCL_Freq - 8) //Equation to calculate ↵
        TWBR Based on SCL Frequency and Clock Frequency
41
42  //#define TWI_TWBR            0x0C //400KHz        // TWI Bit rate Register ↵
        setting.
43  //#define TWI_TWBR        0x34 //100KHz                                   // ↵
        Se Application note for detailed
44                                            // information on setting this value.
45  // Not used defines!
46  //#define TWI_TWPS         0x00         // This driver presumes prescaler = 00
47
48  /*****************************************************************************
49     Global definitions
50  *****************************************************************************/
51
52  union TWI_statusReg                        // Status byte holding flags.
53  {
54      unsigned char all;
55      struct
56      {
57          unsigned char lastTransOK:1;
```

```
58          unsigned char unusedBits:7;
59      };
60  };
61
62  extern union TWI_statusReg TWI_statusReg;
63
64  /****************************************************************************
65    Function definitions
66  ****************************************************************************/
67  void TWI_Master_Initialise( void );
68  unsigned char TWI_Transceiver_Busy( void );
69  unsigned char TWI_Get_State_Info( void );
70  void TWI_Start_Transceiver_With_Data( unsigned char * , unsigned char );
71  void TWI_Start_Transceiver( void );
72  unsigned char TWI_Get_Data_From_Transceiver( unsigned char *, unsigned char );
73
74  /****************************************************************************
75    Bit and byte definitions
76  ****************************************************************************/
77  #define TWI_READ_BIT   0       // Bit position for R/W bit in "address byte".
78  #define TWI_ADR_BITS   1       // Bit position for LSB of the slave address bits ↩
        in the init byte.
79
80  #define TRUE           1
81  #define FALSE          0
82
83  /****************************************************************************
84    TWI State codes
85  ****************************************************************************/
86  // General TWI Master staus codes
87  #define TWI_START                  0x08  // START has been transmitted
88  #define TWI_REP_START              0x10  // Repeated START has been transmitted
89  #define TWI_ARB_LOST               0x38  // Arbitration lost
90
91  // TWI Master Transmitter staus codes
92  #define TWI_MTX_ADR_ACK            0x18  // SLA+W has been tramsmitted and ACK ↩
        received
93  #define TWI_MTX_ADR_NACK           0x20  // SLA+W has been tramsmitted and NACK ↩
        received
94  #define TWI_MTX_DATA_ACK           0x28  // Data byte has been tramsmitted and ↩
        ACK received
95  #define TWI_MTX_DATA_NACK          0x30  // Data byte has been tramsmitted and ↩
        NACK received
96
97  // TWI Master Receiver staus codes
98  #define TWI_MRX_ADR_ACK            0x40  // SLA+R has been tramsmitted and ACK ↩
        received
99  #define TWI_MRX_ADR_NACK           0x48  // SLA+R has been tramsmitted and NACK ↩
        received
100 #define TWI_MRX_DATA_ACK           0x50  // Data byte has been received and ACK ↩
        tramsmitted
101 #define TWI_MRX_DATA_NACK          0x58  // Data byte has been received and NACK↩
         tramsmitted
102
103 // TWI Slave Transmitter staus codes
104 #define TWI_STX_ADR_ACK            0xA8  // Own SLA+R has been received; ACK has↩
         been returned
105 #define TWI_STX_ADR_ACK_M_ARB_LOST 0xB0  // Arbitration lost in SLA+R/W as ↩
        Master; own SLA+R has been received; ACK has been returned
```

```
106  #define TWI_STX_DATA_ACK            0xB8   // Data byte in TWDR has been ←
          transmitted ; ACK has been received
107  #define TWI_STX_DATA_NACK           0xC0   // Data byte in TWDR has been ←
          transmitted ; NOT ACK has been received
108  #define TWI_STX_DATA_ACK_LAST_BYTE 0xC8   // Last data byte in TWDR has been ←
          transmitted (TWEA =   0 ); ACK has been received
109
110  // TWI Slave Receiver staus codes
111  #define TWI_SRX_ADR_ACK             0x60   // Own SLA+W has been received ACK has ←
          been returned
112  #define TWI_SRX_ADR_ACK_M_ARB_LOST 0x68   // Arbitration lost in SLA+R/W as ←
          Master ; own SLA+W has been received ; ACK has been returned
113  #define TWI_SRX_GEN_ACK             0x70   // General call address has been ←
          received ; ACK has been returned
114  #define TWI_SRX_GEN_ACK_M_ARB_LOST 0x78   // Arbitration lost in SLA+R/W as ←
          Master ; General call address has been received ; ACK has been returned
115  #define TWI_SRX_ADR_DATA_ACK        0x80   // Previously addressed with own SLA+W; ←
          data has been received ; ACK has been returned
116  #define TWI_SRX_ADR_DATA_NACK       0x88   // Previously addressed with own SLA+W; ←
          data has been received ; NOT ACK has been returned
117  #define TWI_SRX_GEN_DATA_ACK        0x90   // Previously addressed with general ←
          call ; data has been received ; ACK has been returned
118  #define TWI_SRX_GEN_DATA_NACK       0x98   // Previously addressed with general ←
          call ; data has been received ; NOT ACK has been returned
119  #define TWI_SRX_STOP_RESTART        0xA0   // A STOP condition or repeated START ←
          condition has been received while still addressed as Slave
120
121  // TWI Miscellaneous status codes
122  #define TWI_NO_STATE                0xF8   // No relevant state information ←
          available ; TWINT =   0
123  #define TWI_BUS_ERROR               0x00   // Bus error due to an illegal START or←
          STOP condition
124
125  #endif
```

C.1.1.11   TWI_Master.c

```
1   /******************************************************************************
2   *
3   *  Atmel Corporation
4   *
5   *  File              :  TWI_Master . c
6   *  Compiler          :  IAR EWAAVR 2.28a/3.10c
7   *  Revision          :  Revision : 1.13
8   *  Date              :  Date : 24. mai 2004 11:31:20
9   *  Updated by        :  Author : ltwa
10  *
11  *  Support mail      :  avr@atmel.com
12  *
13  *  Supported devices :  All devices with a TWI module can be used.
14  *                       The example is written for the ATmega16
15  *
16  *  AppNote           :  AVR315 − TWI Master Implementation
17  *
18  *  Description       :  This is a sample driver for the TWI hardware modules.
```

```
19  *                      It is interrupt driveren. All functionality is controlled ↩
        through
20  *                      passing information to and from functions. Se main.c for ↩
        samples
21  *                      of how to use the driver.
22  *
23  *
24  ***************************************************************************/
25
26
27  #include "TWI_Master.h"
28
29  static unsigned char TWI_buf[ TWI_BUFFER_SIZE ];    // Transceiver buffer
30  static unsigned char TWI_msgSize;                   // Number of bytes to be ↩
        transmitted.
31  static unsigned char TWI_state = TWI_NO_STATE;      // State byte. Default set ↩
        to TWI_NO_STATE.
32
33  union TWI_statusReg TWI_statusReg = {0};            // TWI_statusReg is defined ↩
        in TWI_Master.h
34
35  /***************************************************************************
36  Call this function to set up the TWI master to its initial standby state.
37  Remember to enable interrupts from the main application after initializing the ↩
        TWI.
38  ***************************************************************************/
39  void TWI_Master_Initialise(void)
40  {
41    #if INTERNAL_PULLUPS == 1//enable built in pullups for I2C Lines
42      DDRC = 0x00;
43      PORTC = (1 << PC0) | (1 << PC1);
44    #else
45      #pragma message("External I2C Pull Ups Required.")
46    #endif
47    TWBR = TWI_TWBR;                                   // Set bit rate register (↩
        Baudrate). Defined in header file.
48    // TWSR = TWI_TWPS;                                // Not used. Driver ↩
        presumes prescaler to be 00.
49    TWDR = 0xFF;                                       // Default content = SDA ↩
        released.
50    TWCR = (1<<TWEN)|                                  // Enable TWI-interface and↩
         release TWI pins.
51       (0<<TWIE)|(0<<TWINT)|                          // Disable Interupt.
52       (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|               // No Signal requests.
53       (0<<TWWC);                                     //
54  }
55
56  /***************************************************************************
57  Call this function to test if the TWI_ISR is busy transmitting.
58  ***************************************************************************/
59  unsigned char TWI_Transceiver_Busy( void )
60  {
61    return ( TWCR & (1<<TWIE) );                       // IF TWI Interrupt is enabled ↩
        then the Transceiver is busy
62  }
63
64  /***************************************************************************
65  Call this function to fetch the state information of the previous operation. The↩
        function will hold execution (loop)
```

```
66  until the TWI_ISR has completed with the previous operation. If there was an ↩
        error, then the function
67  will return the TWI State code.
68  *****************************************************************************/
69  unsigned char TWI_Get_State_Info( void )
70  {
71    while ( TWI_Transceiver_Busy() );                    // Wait until TWI has completed ↩
        the transmission.
72    return ( TWI_state );                                // Return error state.
73  }
74
75  /****************************************************************************
76  Call this function to send a prepared message. The first byte must contain the ↩
        slave address and the
77  read/write bit. Consecutive bytes contain the data to be sent, or empty ↩
        locations for data to be read
78  from the slave. Also include how many bytes that should be sent/read including ↩
        the address byte.
79  The function will hold execution (loop) until the TWI_ISR has completed with the↩
         previous operation,
80  then initialize the next operation and return.
81  *****************************************************************************/
82  void TWI_Start_Transceiver_With_Data( unsigned char *msg, unsigned char msgSize ↩
        )
83  {
84    unsigned char temp;
85
86    while ( TWI_Transceiver_Busy() );                    // Wait until TWI is ready for ↩
        next transmission.
87
88    TWI_msgSize = msgSize;                               // Number of data to transmit.
89    TWI_buf[0]  = msg[0];                                // Store slave address with R/W ↩
        setting.
90    if (!( msg[0] & (TRUE<<TWI_READ_BIT) ))              // If it is a write operation, ↩
        then also copy data.
91    {
92      for ( temp = 1; temp < msgSize; temp++ )
93        TWI_buf[ temp ] = msg[ temp ];
94    }
95    TWI_statusReg.all = 0;
96    TWI_state         = TWI_NO_STATE ;
97    TWCR = (1<<TWEN)|                                    // TWI Interface enabled.
98           (1<<TWIE)|(1<<TWINT)|                         // Enable TWI Interupt and clear↩
        the flag.
99           (0<<TWEA)|(1<<TWSTA)|(0<<TWSTO)|              // Initiate a START condition.
100          (0<<TWWC);                                    //
101 }
102
103 /****************************************************************************
104 Call this function to resend the last message. The driver will reuse the data ↩
        previously put in the transceiver buffers.
105 The function will hold execution (loop) until the TWI_ISR has completed with the↩
         previous operation,
106 then initialize the next operation and return.
107 *****************************************************************************/
108 void TWI_Start_Transceiver( void )
109 {
110   while ( TWI_Transceiver_Busy() );                    // Wait until TWI is ready for ↩
        next transmission.
```

```
111    TWI_statusReg.all = 0;
112    TWI_state          = TWI_NO_STATE ;
113    TWCR = (1<<TWEN)|                           // TWI Interface enabled.
114          (1<<TWIE)|(1<<TWINT)|                 // Enable TWI Interupt and clear↩
         the flag.
115          (0<<TWEA)|(1<<TWSTA)|(0<<TWSTO)|      // Initiate a START condition.
116          (0<<TWWC);                            //
117   }
118
119   /*********************************************************************************
120   Call this function to read out the requested data from the TWI transceiver ↩
         buffer. I.e. first call
121   TWI_Start_Transceiver to send a request for data to the slave. Then Run this ↩
         function to collect the
122   data when they have arrived. Include a pointer to where to place the data and ↩
         the number of bytes
123   requested (including the address field) in the function call. The function will ↩
         hold execution (loop)
124   until the TWI_ISR has completed with the previous operation, before reading out ↩
         the data and returning.
125   If there was an error in the previous transmission the function will return the ↩
         TWI error code.
126   *********************************************************************************/
127   unsigned char TWI_Get_Data_From_Transceiver( unsigned char *msg, unsigned char ↩
         msgSize )
128   {
129     unsigned char i;
130
131     while ( TWI_Transceiver_Busy() );          // Wait until TWI is ready for ↩
         next transmission.
132
133     if( TWI_statusReg.lastTransOK )            // Last transmission competed ↩
         successfully.
134     {
135       for ( i=0; i<msgSize; i++ )              // Copy data from Transceiver ↩
         buffer.
136       {
137         msg[ i ] = TWI_buf[ i ];
138       }
139     }
140     return( TWI_statusReg.lastTransOK );
141   }
142
143   // ********** Interrupt Handlers ********** //
144   /*********************************************************************************
145   This function is the Interrupt Service Routine (ISR), and called when the TWI ↩
         interrupt is triggered;
146   that is whenever a TWI event has occurred. This function should not be called ↩
         directly from the main
147   application.
148   *********************************************************************************/
149
150   ISR(TWI_vect)
151   {
152     static unsigned char TWI_bufPtr;
153
154     switch (TWSR)
155     {
156       case TWI_START:                // START has been transmitted
```

```
157        case TWI_REP_START:          // Repeated START has been transmitted
158          TWI_bufPtr = 0;                                    // Set buffer pointer ↩
        to the TWI Address location
159        case TWI_MTX_ADR_ACK:        // SLA+W has been tramsmitted and ACK received
160        case TWI_MTX_DATA_ACK:       // Data byte has been tramsmitted and ACK ↩
        received
161          if (TWI_bufPtr < TWI_msgSize)
162          {
163            TWDR = TWI_buf[TWI_bufPtr++];
164            TWCR = (1<<TWEN)|                                // TWI Interface ↩
        enabled
165                   (1<<TWIE)|(1<<TWINT)|                     // Enable TWI Interupt↩
         and clear the flag to send byte
166                   (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|          //
167                   (0<<TWWC);                                //
168          }else                       // Send STOP after last byte
169          {
170            TWI_statusReg.lastTransOK = TRUE;                // Set status bits to ↩
        completed successfully.
171            TWCR = (1<<TWEN)|                                // TWI Interface ↩
        enabled
172                   (0<<TWIE)|(1<<TWINT)|                     // Disable TWI ↩
        Interrupt and clear the flag
173                   (0<<TWEA)|(0<<TWSTA)|(1<<TWSTO)|          // Initiate a STOP ↩
        condition.
174                   (0<<TWWC);                                //
175          }
176          break;
177        case TWI_MRX_DATA_ACK:       // Data byte has been received and ACK ↩
        tramsmitted
178          TWI_buf[TWI_bufPtr++] = TWDR;
179        case TWI_MRX_ADR_ACK:        // SLA+R has been tramsmitted and ACK received
180          if (TWI_bufPtr < (TWI_msgSize-1) )               // Detect the last ↩
        byte to NACK it.
181          {
182            TWCR = (1<<TWEN)|                                // TWI Interface ↩
        enabled
183                   (1<<TWIE)|(1<<TWINT)|                     // Enable TWI Interupt↩
         and clear the flag to read next byte
184                   (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|          // Send ACK after ↩
        reception
185                   (0<<TWWC);                                //
186          }else                       // Send NACK after next reception
187          {
188            TWCR = (1<<TWEN)|                                // TWI Interface ↩
        enabled
189                   (1<<TWIE)|(1<<TWINT)|                     // Enable TWI Interupt↩
         and clear the flag to read next byte
190                   (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|          // Send NACK after ↩
        reception
191                   (0<<TWWC);                                //
192          }
193          break;
194        case TWI_MRX_DATA_NACK:      // Data byte has been received and NACK ↩
        tramsmitted
195          TWI_buf[TWI_bufPtr] = TWDR;
196          TWI_statusReg.lastTransOK = TRUE;                 // Set status bits to ↩
        completed successfully.
197          TWCR = (1<<TWEN)|                                 // TWI Interface enabled
```

```
198              (0<<TWIE)|(1<<TWINT)|                        // Disable TWI Interrupt↵
        and clear the flag
199              (0<<TWEA)|(0<<TWSTA)|(1<<TWSTO)|             // Initiate a STOP ↵
        condition.
200              (0<<TWWC);                                   //
201         break;
202       case TWI_ARB_LOST:          // Arbitration lost
203         TWCR = (1<<TWEN)|                                 // TWI Interface enabled
204              (1<<TWIE)|(1<<TWINT)|                        // Enable TWI Interupt ↵
        and clear the flag
205              (0<<TWEA)|(1<<TWSTA)|(0<<TWSTO)|             // Initiate a (RE)START ↵
        condition.
206              (0<<TWWC);                                   //
207         break;
208       case TWI_MTX_ADR_NACK:      // SLA+W has been tramsmitted and NACK received
209       case TWI_MRX_ADR_NACK:      // SLA+R has been tramsmitted and NACK received
210       case TWI_MTX_DATA_NACK:     // Data byte has been tramsmitted and NACK ↵
        received
211 //    case TWI_NO_STATE          // No relevant state information available;↵
        TWINT = 0
212       case TWI_BUS_ERROR:         // Bus error due to an illegal START or STOP ↵
        condition
213       default:
214         TWI_state = TWSR;                                 // Store TWSR and ↵
        automatically sets clears noErrors bit.
215                                                           // Reset TWI Interface
216         TWCR = (1<<TWEN)|                                 // Enable TWI-interface ↵
        and release TWI pins
217              (0<<TWIE)|(0<<TWINT)|                        // Disable Interupt
218              (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|             // No Signal requests
219              (0<<TWWC);                                   //
220     }
221 }
```

C.1.1.12   Usart.h

```
1  /*
2   * Usart.h
3   *
4   * Created: 25/10/2012 22:25:14
5   *  Author: hslovett
6   */
7
8
9  #ifndef USART_H_
10 #define USART_H_
11
12 #include "Config.h"
13 #include <stdio.h>
14 #include <avr/io.h>
15 #define USART0_BITRATE 57600
16 #define UBBR F_CPU/16/USART0_BITRATE-1
17
18 void USART0_Init ();
19 void Usart_SendChar(char data);
```

```
20  unsigned char Usart_Receive( void );
21  int Usart_printf(char var, FILE *stream);
22  void Usart_get_line (char *buff, int len);
23  void USART0_Senduint16 (uint16_t Data);
24  // void USART0_SendChar( unsigned char data );
25  // unsigned char USART0_Receive( void );
26  // void USART0_SendString(char str[]);
27
28  #endif /* USART_H_ */
```

C.1.1.13   Usart.c

```
1   /*
2    * Usart.c
3    *
4    * Created: 25/10/2012 22:25:04
5    *    Author: hl13g10@ecs.soton.ac.uk
6    */
7
8
9   #include "Usart.h"
10
11
12  void USART0_Init()
13  {
14    uint16_t ubrr = UBBR;
15    //Set baud rate
16    UBRR0H = (unsigned char)(ubrr >>8);
17    UBRR0L = (unsigned char)ubrr ;
18    //Enable receiver and transmitter
19    UCSR0B = (1<<RXEN0)|(1<<TXEN0);
20
21    UCSR0C = 0x06; //set asynchronous, no parity, one stop bit, 8 bit transfer.
22
23    //UCSR0B |= (1 << RXCIE0) | (1 << TXCIE0); //set RX and TX interrupt on
24  }
25  void Usart_SendChar(char data)
26  {
27      // Wait for empty transmit buffer
28      while ( !(UCSR0A & (1 << UDRE0)) );
29      // Start transmission
30      UDR0 = data;
31  }
32  unsigned char Usart_Receive( void )
33  {
34    /* Wait for data to be received */
35    while ( !(UCSR0A & (1<<RXC0)) )
36    ;
37    /* Get and return received data from buffer */
38    //Usart_SendChar(UDR0);
39    return UDR0;
40  }
41
42  //to use this copy the following as a global-
```

```
43 | //      static FILE mystdout = FDEV_SETUP_STREAM( Usart_printf , NULL, ↵
   |      _FDEV_SETUP_WRITE) ;
44 | // and add this line at the beginning of main:
45 | //      stdout = &mystdout ;
46 | //   stdio .h must be used.
47 | int Usart_printf (char var , FILE *stream) {
48 |     // translate \n to \r for br@y++ terminal
49 |     if (var == '\n') Usart_SendChar('\r');
50 |     Usart_SendChar (var);
51 |     return 0;
52 | }
53 |
54 | void Usart_get_line (char *buff , int len)
55 | {
56 |   cli ();
57 |   char c;
58 |   int i = 0;
59 |
60 |
61 |   for (;;) {
62 |     c = Usart_Receive ();
63 |     if (c == '\r') break;
64 |     if ((c == '\b') && i) {
65 |       i--;
66 |       Usart_SendChar (c);
67 |       continue ;
68 |     }
69 |     if (c >= ' ' && i < len - 1) {  /* Visible chars */
70 |       buff [i++] = c;
71 |       Usart_SendChar (c);
72 |     }
73 |   }
74 |   buff [i] = 0;
75 |   Usart_SendChar ('\n');
76 |   sei ();
77 | }
78 | void USART0_Senduint16 (uint16_t Data)
79 | {
80 |   Usart_SendChar (Data >> 8);
81 |   Usart_SendChar (Data & 0xFF);
82 | }
```

C.1.2 Dual Camera User Interface

C.1.2.1 DualCamera_UI.c

```
1 | /*
2 |  * DualCamera_UI . c
3 |  *
4 |  * Created: 12/11/2012 08:32:27
5 |  *  Author: hslovett
6 |  */
7 |
8 |
```

```c
9  #include <avr/io.h>
10 #include <avr/interrupt.h>
11 #include "TWI_slave.h"
12
13 #define ButtonMask   0x0F
14
15 #define TWI_CMD_MASTER_WRITE 0x10
16 #define TWI_CMD_MASTER_READ   0x20
17
18 // When there has been an error, this function is run and takes care of it
19 unsigned char TWI_Act_On_Failure_In_Last_Transmission ( unsigned char ←
       TWIerrorMsg );
20
21 int main(void)
22 {
23
24    char ButtonStatus = 0xFF;
25    unsigned char TWI_slaveAddress;
26    unsigned char messageBuff[TWI_BUFFER_SIZE];
27    DDRD = 0xFF;// Port D is the LED output
28    DDRC = 0x00; //PortC is the switch input
29    //PORTC = 0xFF;
30    TWI_slaveAddress = 0x15;
31    TWI_Slave_Initialise( (unsigned char)((TWI_slaveAddress<<TWI_ADR_BITS) | (TRUE←
      <<TWI_GEN_BIT) ));
32    sei();
33    TWI_Start_Transceiver();
34      while(1)
35      {
36
37      ButtonStatus = (ButtonStatus & PINC) & ButtonMask;
38      //PORTD = ButtonStatus;
39          // Check if the TWI Transceiver has completed an operation.
40          if ( ! TWI_Transceiver_Busy() )
41          {
42            // Check if the last operation was successful
43            if ( TWI_statusReg.lastTransOK )
44            {
45              // Check if the last operation was a reception
46              if ( TWI_statusReg.RxDataInBuf )
47              {
48                TWI_Get_Data_From_Transceiver(messageBuff, 2);
49                // Check if the last operation was a reception as General Call
50                if ( TWI_statusReg.genAddressCall )
51                {
52                  // Put data received out to PORTB as an example.
53                  PORTB = messageBuff[0];
54                }
55                else // Ends up here if the last operation was a reception as ←
      Slave Address Match
56                {
57                  // Example of how to interpret a command and respond.
58
59                  // TWI_CMD_MASTER_WRITE stores the data to PORTB
60                  if (messageBuff[0] == TWI_CMD_MASTER_WRITE)
61                  {
62                    PORTD = messageBuff[1];
63                  }
```

```
64                     // TWI_CMD_MASTER_READ prepares the data from PINB in the ↩
      transceiver buffer for the TWI master to fetch.
65                     if (messageBuff[0] == TWI_CMD_MASTER_READ)
66                     {
67                       messageBuff[0] = ButtonStatus;
68                       TWI_Start_Transceiver_With_Data( messageBuff, 1 );
69                   ButtonStatus = ButtonMask; //clear all logged button presses
70                     }
71                   }
72                 }
73               else // Ends up here if the last operation was a transmission
74               {
75                 //__no_operation(); // Put own code here.
76               }
77               // Check if the TWI Transceiver has already been started.
78               // If not then restart it to prepare it for new receptions.
79               if ( ! TWI_Transceiver_Busy() )
80               {
81                 TWI_Start_Transceiver();
82               }
83             }
84             else // Ends up here if the last operation completed unsuccessfully
85             {
86               //TWI_Act_On_Failure_In_Last_Transmission( TWI_Get_State_Info() );
87             }
88       }
89       }
90  }
91
92  unsigned char TWI_Act_On_Failure_In_Last_Transmission ( unsigned char ↩
      TWIerrorMsg )
93  {
94    // A failure has occurred, use TWIerrorMsg to determine the nature of the ↩
      failure
95    // and take appropriate actions.
96    // Se header file for a list of possible failures messages.
97
98    // This very simple example puts the error code on PORTB and restarts the ↩
      transceiver with
99    // all the same data in the transmission buffers.
100   //PORTB = TWIerrorMsg;
101   TWI_Start_Transceiver();
102
103   return TWIerrorMsg;
104 }
```

C.1.2.2   TWI slave.h

```
1  /*****************************************************************************
2  *
3  * Atmel Corporation
4  *
5  * File              : TWI_Slave.h
6  * Compiler          : IAR EWAAVR 2.28a/3.10c
7  * Revision          : Revision: 2475
```

```c
 8 | * Date              : Date: 2007−09−20 12:00:43 +0200 (to, 20 sep 2007)
 9 | * Updated by        : Author: mlarsson
10 |
11 | * Support mail      : avr@atmel.com
12 | *
13 | * Supported devices : All devices with a TWI module can be used.
14 | *                     The example is written for the ATmega16
15 | *
16 | * AppNote           : AVR311 − TWI Slave Implementation
17 | *
18 | * Description       : Header file for TWI_slave.c
19 | *                     Include this file in the application.
20 | *
21 | *****************************************************************************/
22 | /*! \page MISRA
23 |  *
24 |  * General disabling of MISRA rules:
25 |  * * (MISRA C rule 1) compiler is configured to allow extensions
26 |  * * (MISRA C rule 111) bit fields shall only be defined to be of type unsigned ↩
         int or signed int
27 |  * * (MISRA C rule 37) bitwise operations shall not be performed on signed ↩
         integer types
28 |  * As it does not work well with 8bit architecture and/or IAR
29 |
30 |  * Other disabled MISRA rules
31 |  * * (MISRA C rule 109) use of union − overlapping storage shall not be used
32 |  * * (MISRA C rule 61) every non−empty case clause in a switch statement shall ↩
         be terminated with a break statement
33 | */
34 |
35 | /*****************************************************************************
36 |   TWI Status/Control register definitions
37 | *****************************************************************************/
38 |
39 | #define TWI_BUFFER_SIZE 4      // Reserves memory for the drivers transceiver ↩
         buffer.
40 |                               // Set this to the largest message size that will↩
         be sent including address byte.
41 |
42 | /*****************************************************************************
43 |   Global definitions
44 | *****************************************************************************/
45 |
46 | union TWI_statusReg_t                              // Status byte holding flags.
47 | {
48 |     unsigned char all;
49 |     struct
50 |     {
51 |         unsigned char lastTransOK:1;
52 |         unsigned char RxDataInBuf:1;
53 |         unsigned char genAddressCall:1;                         // TRUE = General↩
         call, FALSE = TWI Address;
54 |         unsigned char unusedBits:5;
55 |     };
56 | };
57 |
58 | extern union TWI_statusReg_t TWI_statusReg;
59 |
60 | //static unsigned char dont_sleep = 0;
```

```
61
62  /*****************************************************************************
63     Function definitions
64  *****************************************************************************/
65  void TWI_Slave_Initialise( unsigned char );
66  unsigned char TWI_Transceiver_Busy( void );
67  unsigned char TWI_Get_State_Info( void );
68  void TWI_Start_Transceiver_With_Data( unsigned char * , unsigned char );
69  void TWI_Start_Transceiver( void );
70  unsigned char TWI_Get_Data_From_Transceiver( unsigned char *, unsigned char );
71
72  ISR( TWI_vect );
73
74  /*****************************************************************************
75     Bit and byte definitions
76  *****************************************************************************/
77  #define TWI_READ_BIT   0    // Bit position for R/W bit in "address byte".
78  #define TWI_ADR_BITS   1    // Bit position for LSB of the slave address bits in ↩
         the init byte.
79  #define TWI_GEN_BIT    0    // Bit position for LSB of the general call bit in the↩
          init byte.
80
81  #define TRUE           1
82  #define FALSE          0
83
84  /*****************************************************************************
85     TWI State codes
86  *****************************************************************************/
87  // General TWI Master staus codes
88  #define TWI_START                  0x08  // START has been transmitted
89  #define TWI_REP_START              0x10  // Repeated START has been transmitted
90  #define TWI_ARB_LOST               0x38  // Arbitration lost
91
92  // TWI Master Transmitter staus codes
93  #define TWI_MTX_ADR_ACK            0x18  // SLA+W has been tramsmitted and ACK ↩
         received
94  #define TWI_MTX_ADR_NACK           0x20  // SLA+W has been tramsmitted and NACK ↩
         received
95  #define TWI_MTX_DATA_ACK           0x28  // Data byte has been tramsmitted and ↩
         ACK received
96  #define TWI_MTX_DATA_NACK          0x30  // Data byte has been tramsmitted and ↩
         NACK received
97
98  // TWI Master Receiver staus codes
99  #define TWI_MRX_ADR_ACK            0x40  // SLA+R has been tramsmitted and ACK ↩
         received
100 #define TWI_MRX_ADR_NACK           0x48  // SLA+R has been tramsmitted and NACK ↩
         received
101 #define TWI_MRX_DATA_ACK           0x50  // Data byte has been received and ACK ↩
         tramsmitted
102 #define TWI_MRX_DATA_NACK          0x58  // Data byte has been received and NACK↩
          tramsmitted
103
104 // TWI Slave Transmitter staus codes
105 #define TWI_STX_ADR_ACK            0xA8  // Own SLA+R has been received; ACK has↩
          been returned
106 #define TWI_STX_ADR_ACK_M_ARB_LOST 0xB0  // Arbitration lost in SLA+R/W as ↩
         Master; own SLA+R has been received; ACK has been returned
```

```
107  #define TWI_STX_DATA_ACK             0xB8  // Data byte in TWDR has been ↵
          transmitted ; ACK has been received
108  #define TWI_STX_DATA_NACK            0xC0  // Data byte in TWDR has been ↵
          transmitted ; NOT ACK has been received
109  #define TWI_STX_DATA_ACK_LAST_BYTE 0xC8  // Last data byte in TWDR has been ↵
          transmitted (TWEA = 0 ) ; ACK has been received
110
111  // TWI Slave Receiver staus codes
112  #define TWI_SRX_ADR_ACK              0x60  // Own SLA+W has been received ACK has ↵
          been returned
113  #define TWI_SRX_ADR_ACK_M_ARB_LOST 0x68  // Arbitration lost in SLA+R/W as ↵
          Master ; own SLA+W has been received ; ACK has been returned
114  #define TWI_SRX_GEN_ACK              0x70  // General call address has been ↵
          received ; ACK has been returned
115  #define TWI_SRX_GEN_ACK_M_ARB_LOST 0x78  // Arbitration lost in SLA+R/W as ↵
          Master ; General call address has been received ; ACK has been returned
116  #define TWI_SRX_ADR_DATA_ACK         0x80  // Previously addressed with own SLA+W;↵
           data has been received ; ACK has been returned
117  #define TWI_SRX_ADR_DATA_NACK        0x88  // Previously addressed with own SLA+W;↵
           data has been received ; NOT ACK has been returned
118  #define TWI_SRX_GEN_DATA_ACK         0x90  // Previously addressed with general ↵
          call ; data has been received ; ACK has been returned
119  #define TWI_SRX_GEN_DATA_NACK        0x98  // Previously addressed with general ↵
          call ; data has been received ; NOT ACK has been returned
120  #define TWI_SRX_STOP_RESTART         0xA0  // A STOP condition or repeated START ↵
          condition has been received while still addressed as Slave
121
122  // TWI Miscellaneous status codes
123  #define TWI_NO_STATE                 0xF8  // No relevant state information ↵
          available ; TWINT = 0
124  #define TWI_BUS_ERROR                0x00  // Bus error due to an illegal START or↵
          STOP condition
```

C.1.2.3   TWI_slave.c

```
1   /****************************************************************************
2   *
3   * Atmel Corporation
4   *
5   * File            : TWI_Slave.c
6   * Compiler        : IAR EWAAVR 2.28a/3.10c
7   * Revision        : Revision: 2475
8   * Date            : Date: 2007−09−20 12:00:43 +0200 (to , 20 sep 2007)
9   * Updated by      : Author: mlarsson
10  *
11  * Support mail    : avr@atmel.com
12  *
13  * Supported devices : All devices with a TWI module can be used.
14  *                     The example is written for the ATmega16
15  *
16  * AppNote         : AVR311 − TWI Slave Implementation
17  *
18  * Description     : This is sample driver to AVRs TWI module.
19  *                   It is interupt driveren. All functionality is controlled ↵
          through
```

```
20  *                            passing information to and from functions. Se main.c for ↩
        samples
21  *                            of how to use the driver.
22  *
23  ****************************************************************************/
24  /*! \page MISRA
25   *
26   * General disabling of MISRA rules:
27   * * (MISRA C rule 1) compiler is configured to allow extensions
28   * * (MISRA C rule 111) bit fields shall only be defined to be of type unsigned ↩
        int or signed int
29   * * (MISRA C rule 37) bitwise operations shall not be performed on signed ↩
        integer types
30   * As it does not work well with 8bit architecture and/or IAR
31
32   * Other disabled MISRA rules
33   * * (MISRA C rule 109) use of union − overlapping storage shall not be used
34   * * (MISRA C rule 61) every non−empty case clause in a switch statement shall ↩
        be terminated with a break statement
35  */
36
37  #include <avr/io.h>
38  #include <avr/interrupt.h>
39  #include "TWI_slave.h"
40
41  static unsigned char TWI_buf[TWI_BUFFER_SIZE];      // Transceiver buffer. Set ↩
        the size in the header file
42  static unsigned char TWI_msgSize  = 0;              // Number of bytes to be ↩
        transmitted.
43  static unsigned char TWI_state    = TWI_NO_STATE;  // State byte. Default set to↩
         TWI_NO_STATE.
44
45  // This is true when the TWI is in the middle of a transfer
46  // and set to false when all bytes have been transmitted/received
47  // Also used to determine how deep we can sleep.
48  static unsigned char TWI_busy = 0;
49
50  union TWI_statusReg_t TWI_statusReg = {0};          // TWI_statusReg is defined↩
         in TWI_Slave.h
51
52  /****************************************************************************
53  Call this function to set up the TWI slave to its initial standby state.
54  Remember to enable interrupts from the main application after initializing the ↩
        TWI.
55  Pass both the slave address and the requrements for triggering on a general call↩
          in the
56  same byte. Use e.g. this notation when calling this function:
57  TWI_Slave_Initialise( (TWI_slaveAddress<<TWI_ADR_BITS) | (TRUE<<TWI_GEN_BIT) );
58  The TWI module is configured to NACK on any requests. Use a ↩
        TWI_Start_Transceiver function to
59  start the TWI.
60  ****************************************************************************/
61  void TWI_Slave_Initialise( unsigned char TWI_ownAddress )
62  {
63    TWAR = TWI_ownAddress;                            // Set own TWI slave address↩
        . Accept TWI General Calls.
64    TWCR = (1<<TWEN)|                                 // Enable TWI−interface and ↩
        release TWI pins.
65          (0<<TWIE)|(0<<TWINT)|                       // Disable TWI Interupt.
```

```
66          (0<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|              // Do not ACK on any ←
      requests , yet .
67          (0<<TWWC) ;                                    //
68    TWI_busy = 0;
69 }
70
71 /******************************************************************************
72 Call this function to test if the TWI_ISR is busy transmitting .
73 ******************************************************************************/
74 unsigned char TWI_Transceiver_Busy ( void )
75 {
76    return TWI_busy ;
77 }
78
79 /******************************************************************************
80 Call this function to fetch the state information of the previous operation . The←
        function will hold execution (loop)
81 until the TWI_ISR has completed with the previous operation . If there was an ←
      error , then the function
82 will return the TWI State code .
83 ******************************************************************************/
84 unsigned char TWI_Get_State_Info ( void )
85 {
86    while ( TWI_Transceiver_Busy () ) {}              // Wait until TWI has ←
      completed the transmission .
87    return ( TWI_state );                             // Return error state .
88 }
89
90 /******************************************************************************
91 Call this function to send a prepared message , or start the Transceiver for ←
        reception . Include
92 a pointer to the data to be sent if a SLA+W is received . The data will be copied←
         to the TWI buffer .
93 Also include how many bytes that should be sent . Note that unlike the similar ←
      Master function , the
94 Address byte is not included in the message buffers .
95 The function will hold execution (loop) until the TWI_ISR has completed with the←
         previous operation ,
96 then initialize the next operation and return .
97 ******************************************************************************/
98 void TWI_Start_Transceiver_With_Data ( unsigned char *msg , unsigned char msgSize ←
      )
99 {
100    unsigned char temp ;
101
102    while ( TWI_Transceiver_Busy () ) {}             // Wait until TWI is ready for←
        next transmission .
103
104    TWI_msgSize = msgSize ;                           // Number of data to transmit .
105    for ( temp = 0; temp < msgSize ; temp++ )       // Copy data that may be ←
      transmitted if the TWI Master requests data .
106    {
107      TWI_buf [ temp ] = msg [ temp ];
108    }
109    TWI_statusReg . all = 0;
110    TWI_state        = TWI_NO_STATE ;
111    TWCR = (1<<TWEN)|                                 // TWI Interface enabled .
112          (1<<TWIE)|(1<<TWINT)|                       // Enable TWI Interupt and clear←
      the flag .
```

```
113           (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|          // Prepare to ACK next time the ←
        Slave is addressed.
114           (0<<TWWC);                                //
115   TWI_busy = 1;
116 }
117
118 /*****************************************************************************
119 Call this function to start the Transceiver without specifing new transmission ←
         data. Useful for restarting
120 a transmission, or just starting the transceiver for reception. The driver will ←
         reuse the data previously put
121 in the transceiver buffers. The function will hold execution (loop) until the ←
         TWI_ISR has completed with the
122 previous operation, then initialize the next operation and return.
123 *****************************************************************************/
124 void TWI_Start_Transceiver( void )
125 {
126   while ( TWI_Transceiver_Busy() ) {}              // Wait until TWI is ready for←
         next transmission.
127   TWI_statusReg.all = 0;
128   TWI_state        = TWI_NO_STATE ;
129   TWCR = (1<<TWEN)|                                // TWI Interface enabled.
130           (1<<TWIE)|(1<<TWINT)|                    // Enable TWI Interupt and clear←
         the flag.
131           (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|          // Prepare to ACK next time the ←
        Slave is addressed.
132           (0<<TWWC);                                //
133   TWI_busy = 0;
134 }
135 /*****************************************************************************
136 Call this function to read out the received data from the TWI transceiver buffer←
         . I.e. first call
137 TWI_Start_Transceiver to get the TWI Transceiver to fetch data. Then Run this ←
         function to collect the
138 data when they have arrived. Include a pointer to where to place the data and ←
         the number of bytes
139 to fetch in the function call. The function will hold execution (loop) until the←
          TWI_ISR has completed
140 with the previous operation, before reading out the data and returning.
141 If there was an error in the previous transmission the function will return the ←
         TWI State code.
142 *****************************************************************************/
143 unsigned char TWI_Get_Data_From_Transceiver( unsigned char *msg, unsigned char ←
        msgSize )
144 {
145   unsigned char i;
146
147   while ( TWI_Transceiver_Busy() ) {}              // Wait until TWI is ready for←
         next transmission.
148
149   if ( TWI_statusReg.lastTransOK )                // Last transmission completed ←
        successfully.
150   {
151     for ( i=0; i<msgSize; i++ )                    // Copy data from Transceiver ←
        buffer.
152     {
153       msg[ i ] = TWI_buf[ i ];
154     }
```

```
155      TWI_statusReg.RxDataInBuf = FALSE;              // Slave Receive data has been ↵
         read from buffer.
156   }
157   return ( TWI_statusReg.lastTransOK );
158 }
159
160
161 // ********** Interrupt Handlers ********** //
162 /*****************************************************************************
163 This function is the Interrupt Service Routine (ISR), and called when the TWI ↵
         interrupt is triggered;
164 that is whenever a TWI event has occurred. This function should not be called ↵
         directly from the main
165 application.
166 *****************************************************************************/
167 ISR(TWI_vect)
168 {
169   static unsigned char TWI_bufPtr;
170
171   switch (TWSR)
172   {
173     case TWI_STX_ADR_ACK:             // Own SLA+R has been received; ACK has ↵
         been returned
174 //    case TWI_STX_ADR_ACK_M_ARB_LOST: // Arbitration lost in SLA+R/W as Master;↵
          own SLA+R has been received; ACK has been returned
175       TWI_bufPtr   = 0;                                    // Set buffer pointer to↵
          first data location
176     case TWI_STX_DATA_ACK:            // Data byte in TWDR has been transmitted; ↵
         ACK has been received
177       TWDR = TWI_buf[TWI_bufPtr++];
178       TWCR = (1<<TWEN)|                                   // TWI Interface enabled
179              (1<<TWIE)|(1<<TWINT)|                         // Enable TWI Interupt ↵
         and clear the flag to send byte
180              (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|              //
181              (0<<TWWC);                                    //
182       TWI_busy = 1;
183       break;
184     case TWI_STX_DATA_NACK:           // Data byte in TWDR has been transmitted; ↵
         NACK has been received.
185                                       // I.e. this could be the end of the ↵
         transmission.
186       if (TWI_bufPtr == TWI_msgSize) // Have we transceived all expected data?
187       {
188         TWI_statusReg.lastTransOK = TRUE;                 // Set status bits to ↵
         completed successfully.
189       }
190       else                           // Master has sent a NACK before all data ↵
         where sent.
191       {
192         TWI_state = TWSR;                                 // Store TWI State as ↵
         errormessage.
193       }
194
195       TWCR = (1<<TWEN)|                                   // Enable TWI-interface ↵
         and release TWI pins
196              (1<<TWIE)|(1<<TWINT)|                        // Keep interrupt ↵
         enabled and clear the flag
197              (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|             // Answer on next ↵
         address match
```

```
198                (0<<TWWC);                                      //
199
200          TWI_busy = 0;    // Transmit is finished, we are not busy anymore
201            break;
202        case TWI_SRX_GEN_ACK:               // General call address has been received; ←
      ACK has been returned
203  //    case TWI_SRX_GEN_ACK_M_ARB_LOST: // Arbitration lost in SLA+R/W as Master;←
       General call address has been received; ACK has been returned
204          TWI_statusReg.genAddressCall = TRUE;
205        case TWI_SRX_ADR_ACK:              // Own SLA+W has been received ACK has been←
       returned
206  //    case TWI_SRX_ADR_ACK_M_ARB_LOST: // Arbitration lost in SLA+R/W as Master;←
       own SLA+W has been received; ACK has been returned
207                                                             // Dont need to clear ←
      TWI_S_statusRegister.generalAddressCall due to that it is the default state.
208          TWI_statusReg.RxDataInBuf = TRUE;
209          TWI_bufPtr   = 0;                              // Set buffer pointer to←
       first data location
210
211                                                             // Reset the TWI ←
      Interupt to wait for a new event.
212          TWCR = (1<<TWEN)|                              // TWI Interface enabled
213                 (1<<TWIE)|(1<<TWINT)|                    // Enable TWI Interupt ←
      and clear the flag to send byte
214                 (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|         // Expect ACK on this ←
      transmission
215                 (0<<TWWC);
216          TWI_busy = 1;
217
218            break;
219        case TWI_SRX_ADR_DATA_ACK:       // Previously addressed with own SLA+W; ←
      data has been received; ACK has been returned
220        case TWI_SRX_GEN_DATA_ACK:       // Previously addressed with general call; ←
      data has been received; ACK has been returned
221          TWI_buf[TWI_bufPtr++]    = TWDR;
222          TWI_statusReg.lastTransOK = TRUE;             // Set flag transmission←
       successfull.
223                                                             // Reset the TWI ←
      Interupt to wait for a new event.
224          TWCR = (1<<TWEN)|                              // TWI Interface enabled
225                 (1<<TWIE)|(1<<TWINT)|                    // Enable TWI Interupt ←
      and clear the flag to send byte
226                 (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|         // Send ACK after next ←
      reception
227                 (0<<TWWC);                               //
228          TWI_busy = 1;
229            break;
230        case TWI_SRX_STOP_RESTART:       // A STOP condition or repeated START ←
      condition has been received while still addressed as Slave
231                                                             // Enter not addressed ←
      mode and listen to address match
232          TWCR = (1<<TWEN)|                              // Enable TWI-interface ←
      and release TWI pins
233                 (1<<TWIE)|(1<<TWINT)|                    // Enable interrupt and ←
      clear the flag
234                 (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|         // Wait for new address ←
      match
235                 (0<<TWWC);                               //
236
```

```
237        TWI_busy = 0;   // We are waiting for a new address match, so we are not ←
      busy

239        break;
240      case TWI_SRX_ADR_DATA_NACK:      // Previously addressed with own SLA+W; ←
      data has been received; NOT ACK has been returned
241      case TWI_SRX_GEN_DATA_NACK:        // Previously addressed with general call; ←
      data has been received; NOT ACK has been returned
242      case TWI_STX_DATA_ACK_LAST_BYTE: // Last data byte in TWDR has been ←
      transmitted (TWEA = 0 ); ACK has been received
243 //    case TWI_NO_STATE             // No relevant state information available;←
       TWINT = 0
244      case TWI_BUS_ERROR:          // Bus error due to an illegal START or STOP ←
      condition
245        TWI_state = TWSR;               //Store TWI State as errormessage, ←
      operation also clears noErrors bit
246        TWCR =   (1<<TWSTO)|(1<<TWINT);   //Recover from TWI_BUS_ERROR, this will ←
      release the SDA and SCL pins thus enabling other devices to use the bus
247        break;
248      default:
249        TWI_state = TWSR;                           // Store TWI State as ←
      errormessage, operation also clears the Success bit.
250        TWCR = (1<<TWEN)|                           // Enable TWI-interface ←
      and release TWI pins
251            (1<<TWIE)|(1<<TWINT)|                    // Keep interrupt ←
      enabled and clear the flag
252            (1<<TWEA)|(0<<TWSTA)|(0<<TWSTO)|         // Acknowledge on any ←
      new requests.
253            (0<<TWWC);                               //

255        TWI_busy = 0; // Unknown status, so we wait for a new address match that ←
      might be something we can handle
256    }
257 }
```

C.2   MATLAB Code for Image Algorithm Prototyping

C.2.0.4   loadimages.m

```
1  left = imread('viprectification_deskLeft.png');
2  right = imread('viprectification_deskRight.png');

4  % left = imread('battery_left.bmp');
5  % right = imread('battery_right.bmp');

7  % left = imread('square_left.bmp');
8  % right = imread('square_right.bmp');

10 % left = imread('fiftycm_left.bmp');
11 % right = imread('fiftycm_right.bmp');

13 % left = imread('2objs_left.bmp');
14 % right = imread('2objs_right.bmp');
```

C.2.0.5 GetSubImage.m

```matlab
function [ SubImage ] = GetSubImage( Image, BoxSize, StartCoordinates)
%GETSUBIMAGE Returns a sub section of the image according to the other
%inputs
%    Image - The image of which a subimage is to be taken from
%    BoxSize - A 2x1 matrix containing the size of the subImage
%    StartCoordinates - A 2x1 matrix with the start point of the image
%    Dimensions - How many planes - 3 for colour, 1 for grey scale

XLow = StartCoordinates(1)-(BoxSize(1)/2);
YLow = StartCoordinates(2)-(BoxSize(2)/2);
if(XLow<1)
    XLow = 1;
end

if(YLow < 1)
    YLow = 1;
end

XHigh = XLow + BoxSize(1);
YHigh = YLow + BoxSize(2);
[~, ~, LZ] = size(Image);

%SubImage = zeros(BoxSize);
for i = XLow:XHigh
    for j = YLow:YHigh
        if LZ == 3
            for z = 1:3
                SubImage(i-XLow+1,j-YLow+1,z) = Image(i,j,z);
            end
        elseif LZ == 1
            SubImage(i-XLow+1,j-YLow+1) = Image(i,j);
        else
            error('Number of Dimensions "%d" are not supported', LZ);
        end
    end
end

end
```

C.2.0.6 SADAll.m

```matlab
%function [ Results ] = SADAll( Left, Right )
%SADALL Function to compute all SADs of an image
%    The sum of absolute differences is calculated and returned on a mesh
%    graph to show how well matched the sub image is to the image. A box out
%    of the right image is taken and compared with the left image.
loadimages;
BoxSize = [50,50];
[~,~,C] = size(right);
[I,J,D] = size(left);
if C ~= D
```

```matlab
11          error ('Images have different number of colour planes ');
12  end
13
14  RightSub = GetSubImage (right , BoxSize , [190 ,190]) ;
15
16  for i = 25:( I−25)
17      for j = 25:( J−25)
18          LeftSub = GetSubImage (left , BoxSize , [i , j]) ;
19          Diff = LeftSub − RightSub ;
20
21          Results (i ,j) = sum( Diff (:) ) ;
22      end
23  end
24
25  %Display
26  figure ;
27  subplot (2 ,2 ,1) ;
28  imshow ( left ) ;
29  title ( 'Left Image ') ;
30
31  subplot (2 ,2 ,2) ;
32  imshow ( right ) ;
33  title ( 'Right Image ') ;
34
35  subplot (2 ,2 ,3) ;
36  imshow ( RightSub ) ;
37  title ( 'Right Sub ') ;
38
39  figure ;
40  surf ( Results ) ;
41  shading flat ;
42  %end
```

C.2.0.7   SSDAll.m

```matlab
1  %function [ Results ] = SADAll( Left , Right )
2  %SADALL Function to compute all SADs of an image
3  %    The sum of absolute differences is calculated and returned on a mesh
4  %    graph to show how well matched the sub image is to the image. A box out
5  %    of the right image is taken and compared with the left image.
6  loadimages ;
7  BoxSize = [50 ,50];
8  [~,~,C] = size ( right ) ;
9  [I ,J ,D] = size ( left ) ;
10  if C ~= D
11      error ('Images have different number of colour planes ');
12  end
13
14  RightSub = GetSubImage (right , BoxSize , [190 ,190]) ;
15
16  for i = 25:( I−25)
17      for j = 25:( J−25)
18          LeftSub = GetSubImage (left , BoxSize , [i , j]) ;
19          Diff = LeftSub − RightSub ;
20          Diff = Diff .^2;
```

```
21            Results(i,j) = sum(Diff(:));
22        end
23 end
24
25 %Display
26 figure;
27 subplot(2,2,1);
28 imshow(left);
29 title('Left Image');
30
31 subplot(2,2,2);
32 imshow(right);
33 title('Right Image');
34
35 subplot(2,2,3);
36 imshow(RightSub);
37 title('Right Sub');
38
39 figure;
40 surf(Results);
41 shading flat;
42 %end
```

C.2.0.8   NCC.m

```
1
2 loadimages;
3 show;
4 BoxSize = [50,50];
5 MaxConfMatches = 20;
6 %SubCoord = [145, 300];
7 figure(1);
8 %[rightSub, rect_Sub] = imcrop(right);
9 figure(2);
10 imshow(right);
11 rSubCoord = ginput(1);
12 rSubCoord = [190,190]; [rSubCoord(2), rSubCoord(1)];
13 rSubCoord = round(rSubCoord);
14 close;
15 tic;
16 rightSub = GetSubImage(right, BoxSize, rSubCoord);
17 %imshow(rightSub);
18 rightSubGray = rgb2gray(rightSub);
19 leftGray = rgb2gray(left);
20 rightGray = rgb2gray(right);
21 cL = normxcorr2(rightSubGray(:,:), leftGray(:,:));
22 figure(2);
23 % subplot(1,2,1);
24 surf(cL), shading flat;
25 title('Normalised Cross Correlation of Right Sub and Left Image');
26 toc;
27 % cR = normxcorr2(rightSubGray(:,:), rightGray(:,:));
28 % subplot(1,2,2);
29 % surf(cR), shading flat;
30 % title('Normalised Cross Correlation of Right Sub and Right Image');
```

```matlab
31
32  % cD = cL - cR;
33  %
34  % figure;
35  % surf(cD), shading flat;
36  % title('Differences of the Normalised Cross Correlation of Right and Left');
37
38  %Find coordintes of best match.
39  [Y,X] = size(cL);
40  maxValue = 0;
41  LeftMatchCoord = [0,0];
42  NumConfidentMatches = 0;
43
44  for i = 1:X
45      for j = 1:Y
46          Val = cL(j,i);
47          if Val > 0.9
48              NumConfidentMatches = NumConfidentMatches + 1;
49          end
50          if Val > maxValue
51              maxValue = Val;
52              LeftMatchCoord = [j-(BoxSize(1) / 2 ), i-(BoxSize(2) / 2 )];
53          end
54      end
55  end
56
57  Result = [maxValue, LeftMatchCoord];
58  figure(1);
59  if NumConfidentMatches >= 1 && NumConfidentMatches < MaxConfMatches
60      left(LeftMatchCoord(1)-(BoxSize(1)/2):LeftMatchCoord(1)+(BoxSize(1)/2),←
          LeftMatchCoord(2)-(BoxSize(2))/2)=255;
61      left(LeftMatchCoord(1)-(BoxSize(1)/2):LeftMatchCoord(1)+(BoxSize(1)/2),←
          LeftMatchCoord(2)+(BoxSize(2))/2)=255;
62      left(LeftMatchCoord(1)-(BoxSize(1)/2),LeftMatchCoord(2)-(BoxSize(2)/2):←
          LeftMatchCoord(2)+(BoxSize(2))/2)=255;
63      left(LeftMatchCoord(1)+(BoxSize(1)/2),LeftMatchCoord(2)-(BoxSize(2)/2):←
          LeftMatchCoord(2)+(BoxSize(2)/2))=255;
64
65      right(rSubCoord(1)-(BoxSize(1)/2):rSubCoord(1)+(BoxSize(1)/2),rSubCoord(2)-(←
          BoxSize(2)/2))=255;
66      right(rSubCoord(1)-(BoxSize(1)/2):rSubCoord(1)+(BoxSize(1)/2),rSubCoord(2)+(←
          BoxSize(2)/2))=255;
67      right(rSubCoord(1)-(BoxSize(1)/2),rSubCoord(2)-(BoxSize(2)/2):rSubCoord(2)+(←
          BoxSize(2)/2))=255;
68      right(rSubCoord(1)+(BoxSize(1)/2),rSubCoord(2)-(BoxSize(2)/2):rSubCoord(2)+(←
          BoxSize(2)/2))=255;
69
70      subplot(1,2,1);
71      imshow(left);
72      subplot(1,2,2);
73      imshow(right);
74  %       LeftMatchCoord
75  %       rSubCoord
76  %       NumConfidentMatches
77      Distance = Range(rSubCoord(2), LeftMatchCoord(2));
78      sprintf('Distance to Object = %d metres', Distance)
79  elseif NumConfidentMatches >= MaxConfMatches
80      title(sprintf('Too many matches found : %d', NumConfidentMatches));
81  else
```

```
82        title ( sprintf ( 'No Reliable Match Found' ) ) ;
83
84   end
```

References

Wayne Fulton. Image file formats - jpg, tif, png, gif. which to use?, 2010.

Patrick Goebel. Robot cartography: Ros + slam, 2012.

Rostam Affendi Hamzah, Sani Irwan Md Salim, and Hasrul Nisham Rosly. An effective distance detection of obstacles in stereo vision application. *Canadian Journal on Electrical and Electronics Engineering*, 1(3):49–53, 2010.

Electronic Lives Manufacturing. Fatfs - generic fat file system module, 2012.

Jernej Mrovlje and Damir Vrančić. Distance measuring based on stereoscopic pictures. Technical report, University of Ljubljana, 2008.

OmniVision. *OmniVision Serial Camera Control Bus (SCCB) Functional Specification*, 2007.

Phillips. *PCA9542A : 2-channel I2C-bus multiplexer and interrupt logic*, 2009.

D.M. Tsai and C.T. Lin. Fast normalized cross correlation for defect detection, .