



## Machine-Level Programming I: Basics

These slides adapted from materials provided by the textbook authors.

## **Machine Programming I: Basics**

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

## **Intel x86 Processors**

### Dominate laptop/desktop/server market

#### Evolutionary design

- Backwards compatible up until 8086, introduced in 1978
- Added more features as time goes on

### Complex instruction set computer (CISC)

- Many different instructions with many different formats
  - But, only small subset encountered with Linux programs
- Hard to match performance of Reduced Instruction Set Computers (RISC)
- But, Intel has done just that!
  - In terms of speed. Less so for low power.

## **Machine Programming I: Basics**

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

## **Definitions**

- Architecture: (also ISA: instruction set architecture) The parts of a processor design that one needs to understand or write assembly/machine code.
  - Examples: instruction set specification, registers.
- Microarchitecture: Implementation of the architecture.
  - Examples: cache sizes and core frequency.


#### Code Forms:

- Machine Code: The byte-level programs that a processor executes
- Assembly Code: A text representation of machine code

#### Example ISAs:

- Intel: x86, IA32, Itanium, x86-64
- ARM: Used in almost all mobile phones

## **Assembly/Machine Code View**



#### **Programmer-Visible State**


- PC: Program counter
  - Address of next instruction
  - Called "RIP" (x86-64)
- Register file
  - Heavily used program data
- Condition codes
  - Store status information about most recent arithmetic or logical operation
  - Used for conditional branching

#### Memory

- Byte addressable array
- Code and user data
- Stack to support procedures

## **Turning C into Object Code**

- Code in files p1.c p2.c
- Compile with command: gcc -Og p1.c p2.c -o p
  - Use basic optimizations (-Og) [New to recent versions of GCC]
  - Put resulting binary in file p



## **Compiling Into Assembly**

#### C Code (sum.c)

#### **Generated x86-64 Assembly**

```
sumstore:
   pushq %rbx
   movq %rdx, %rbx
   call plus
   movq %rax, (%rbx)
   popq %rbx
   ret
```

## Obtain (on VM) with command

Produces file sum.s

Warning: May get very different results on other machines, even other Linux machines, due to different versions of gcc and different compiler settings.

## Aside: Assembly 'Syntax'

- Different ways to write down assembly.
- AT&T / GAS Syntax
  - Used by gcc.
  - Used in this course.

```
mnemonic source, destination
```

- Intel / MASM Syntax
  - Might get if you google (try your Textbook instead)
  - Doesn't use size suffixes (ie, 'q')

```
mnemonic destination, source
```

## One more time, just to be clear

#### In this course:

```
mnemonic source, destination
```

#### So:

```
addq %rax, %rbx
```

## Is equivalent to:

```
%rbx = %rbx+%rax
```

## **Assembly Characteristics: Data Types**

- "Integer" data of 1, 2, 4, or 8 bytes
  - Data values
  - Addresses (untyped pointers)
- Floating point data of 4 or 8 bytes
- Code: Byte sequences encoding series of instructions
- No aggregate types such as arrays or structures
  - Just contiguously allocated bytes in memory

## **Assembly Characteristics: Operations**

- Perform arithmetic function on register or memory data
- Transfer data between memory and register
  - Load data from memory into register
  - Store register data into memory
- Transfer control
  - Unconditional jumps to/from procedures
  - Conditional branches

## **Object Code**

#### Code for sumstore

# 0x0400595: 0x53 0x48 0x89 0xd3 0xe8 0xf2 0xff

0xff

 $0 \times 48$ 

0x5b

0xc3

- Total of 14 bytes
- 0x89 Each instruction 0x03 1, 3, or 5 bytes
  - Starts at address
     0x0400595

#### Assembler

- Translates .s into .o
- Binary encoding of each instruction
- Nearly-complete image of executable code
- Missing linkages between code in different files

#### Linker

- Resolves references between files
- Combines with static run-time libraries
  - E.g., code for malloc, printf
- Some libraries are dynamically linked
  - Linking occurs when program begins execution

## **Machine Instruction Example**

0x40059e: 48 89 03

#### C Code

 Store value t where designated by dest

### Assembly

- Move 8-byte value to memory
  - Quad words in x86-64 parlance
- Operands:

t: Register %rax

dest: Register %rbx

\*dest: Memory M[%rbx]

#### Object Code

- 3-byte instruction
- Stored at address 0x40059e

## **Disassembling Object Code**

#### Disassembled


```
0000000000400595 <sumstore>:
 400595:
          53
                          push
                                %rbx
 400596: 48 89 d3
                         mov
                                %rdx,%rbx
 400599: e8 f2 ff ff ff callq 400590 <plus>
 40059e: 48 89 03
                                %rax, (%rbx)
                         mov
 4005a1: 5b
                                %rbx
                         pop
 4005a2: c3
                          reta
```

#### Disassembler

```
objdump -d sum
```

- Useful tool for examining object code
- Analyzes bit pattern of series of instructions
- Produces approximate rendition of assembly code
- Can be run on either a . out (complete executable) or . o file

# Web-Based https://onlinedisassembler.com



## **Alternate Disassembly**

### **Object**

#### Disassembled

```
0 \times 0400595:
    0 \times 53
    0x48
    0x89
    0xd3
    0xe8
    0xf2
    0xff
    Oxff
    0xff
    0x48
    0x89
    0 \times 03
    0x5b
    0xc3
```

Within gdb Debugger

```
gdb sum
disassemble sumstore
```

Disassemble procedure

```
x/14xb sumstore
```

Examine the 14 bytes starting at sumstore

## What Can be Disassembled?

```
% objdump -d WINWORD.EXE
WINWORD.EXE: file format pei-i386
No symbols in "WINWORD.EXE".
Disassembly of section .text:
30001000 <.text>:
30001000:
30001001:
               Reverse engineering forbidden by
30001003:
             Microsoft End User License Agreement
30001005:
3000100a:
```

- Anything that can be interpreted as executable code
- Disassembler examines bytes and reconstructs assembly source

## **Machine Programming I: Basics**


- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

## x86-64 Integer Registers

%rax	%eax	%r8	%r8d
%rbx	%ebx	% <b>r9</b>	%r9d
%rcx	%ecx	%r10	%r10d
%rdx	%edx	%r11	%r11d
%rsi	%esi	%r12	%r12d
%rdi	%edi	%r13	%r13d
%rsp	%esp	% <b>r14</b>	%r14d
%rbp	%ebp	%r15	%r15d

Can reference low-order 4 bytes (also low-order 1 & 2 bytes)

Some History: IA32 Registers



Origin (mostly obsolete)

accumulate

counter

data

base

source index

destination index

stack pointer base pointer

(backwards compatibility)

## **Moving Data**

- Moving Data movq Source, Dest:
- Operand Types
  - Immediate: Constant integer data
    - Example: \$0x400, \$-533
    - Like C constant, but prefixed with `\$'
    - Encoded with 1, 2, or 4 bytes
  - Register: One of 16 integer registers
    - Example: %rax, %r13
    - But %rsp reserved for special use
    - Others have special uses for particular instructions
  - Memory: 8 consecutive bytes of memory at address given by register
    - Simplest example: (%rax)
    - Various other "address modes"

- %rax
  %rcx
  %rdx
  %rbx
  %rsi
  %rdi
  - %rsp %rbp
  - %rN

## movq Operand Combinations

Cannot do memory-memory transfer with a single instruction

## **Simple Memory Addressing Modes**

- Normal (R) Mem[Reg[R]]
  - Register R specifies memory address
  - Aha! Pointer dereferencing in C

```
movq (%rcx),%rax
```

- Displacement D(R) Mem[Reg[R]+D]
  - Register R specifies start of memory region
  - Constant displacement D specifies offset


```
movq 8(%rbp),%rdx
```

## **Example of Simple Addressing Modes**

```
void swap
   (long *xp, long *yp)
{
   long t0 = *xp;
   long t1 = *yp;
   *xp = t1;
   *yp = t0;
}
```

#### Memory

```
void swap
  (long *xp, long *yp)
{
  long t0 = *xp;
  long t1 = *yp;
  *xp = t1;
  *yp = t0;
}
```



Register	Value
%rdi	хр
%rsi	ур
%rax	t0
%rdx	t1

### **Registers**


%rdi	0x120
%rsi	0x100
%rax	
%rdx	

#### **Memory**

	Address
123	0x120
	0x118
	0x110
	0x108
456	0x100


#### swap:


```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```




#### swap:

```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```







```
swap:
    movq (%rdi), %rax # t0 = *xp
```

movq (%rsi), %rdx # t1 = \*yp movq %rdx, (%rdi) # \*xp = t1 movq %rax, (%rsi) # \*yp = t0

ret

## **Simple Memory Addressing Modes**

- Normal (R) Mem[Reg[R]]
  - Register R specifies memory address
  - Aha! Pointer dereferencing in C

```
movq (%rcx),%rax
```

- Displacement D(R) Mem[Reg[R]+D]
  - Register R specifies start of memory region
  - Constant displacement D specifies offset

```
movq 8(%rbp),%rdx
```

## **Complete Memory Addressing Modes**

#### Most General Form

D(Rb,Ri,S) Mem[Reg[Rb]+S\*Reg[Ri]+D]

- D: Constant "displacement" 1, 2, or 4 bytes
- Rb: Base register: Any of 16 integer registers
- Ri: Index register: Any, except for %rsp
- S: Scale: 1, 2, 4, or 8 (why these numbers?)

### Special Cases

(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]]

D(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]+D]

(Rb,Ri,S) Mem[Reg[Rb]+S\*Reg[Ri]]

## **Address Computation Examples**

%rdx	0xf000
%rcx	0x0100

Expression	Address Computation	Address
0x8 (%rdx)	0xf000 + 0x8	0xf008
(%rdx,%rcx)	0xf000 + 0x100	0xf100
(%rdx,%rcx,4)	0xf000 + 4*0x100	0xf400
0x80(,%rdx,2)	2*0xf000 + 0x80	0x1e080

## **Machine Programming I: Basics**

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

## **Some Arithmetic Operations**

#### Two Operand Instructions:

Format	Computation		
addq	Src,Dest	Dest = Dest + Src	
subq	Src,Dest	Dest = Dest – Src	
imulq	Src,Dest	Dest = Dest * Src	
salq	Src,Dest	Dest = Dest << Src	Also called shiq
sarq	Src,Dest	Dest = Dest >> Src	Arithmetic
shrq	Src,Dest	Dest = Dest >> Src	Logical
xorq	Src,Dest	Dest = Dest ^ Src	
andq	Src,Dest	Dest = Dest & Src	
orq	Src,Dest	Dest = Dest   Src	

- Watch out for argument order!
- No distinction between signed and unsigned int (why?)

## **Some Arithmetic Operations**

One Operand Instructions

```
incq Dest Dest = Dest + 1

decq Dest Dest = Dest - 1

negq Dest Dest = -Dest

notq Dest Dest = \sim Dest
```

See book for more instructions

## **Address Computation Instruction**

#### leaq Src, Dst

- Src is address mode expression
- Set Dst to address denoted by expression

## Dumbest Op Name Possible

#### Uses

- Computing addresses without a memory reference
  - E.g., translation of p = &x[i];
- Computing arithmetic expressions of the form x + k\*y
  - k = 1, 2, 4, or 8

#### Example

```
long m12(long x)
{
   return x*12;
}
```

#### **Converted to ASM by compiler:**

```
leaq (%rdi,%rdi,2), %rax # t <- x+x*2
salq $2, %rax # return t<<2</pre>
```

## **Arithmetic Expression Example**

```
long arith
(long x, long y, long z)
{
  long t1 = x+y;
  long t2 = z+t1;
  long t3 = x+4;
  long t4 = y * 48;
  long t5 = t3 + t4;
  long rval = t2 * t5;
  return rval;
}
```

```
arith:
  leaq (%rdi,%rsi), %rax
  addq %rdx, %rax
  leaq (%rsi,%rsi,2), %rdx
  salq $4, %rdx
  leaq 4(%rdi,%rdx), %rcx
  imulq %rcx, %rax
  ret
```

#### **Interesting Instructions**

- leaq: address computation
- salq: shift
- imulq: multiplication
  - But, only used once

# Understanding Arithmetic Expression Example

```
long arith
(long x, long y, long z)
  long t1 = x+y;
  long t2 = z+t1;
  long t3 = x+4;
  long t4 = y * 48;
  long t5 = t3 + t4;
  long rval = t2 * t5;
  return rval;
```

```
arith:
  leaq (%rdi,%rsi), %rax # t1
  addq %rdx, %rax # t2
  leaq (%rsi,%rsi,2), %rdx
  salq $4, %rdx # t4
  leaq 4(%rdi,%rdx), %rcx # t5
  imulq %rcx, %rax # rval
  ret
```

Register	Use(s)
%rdi	Argument <b>x</b>
%rsi	Argument <b>y</b>
%rdx	Argument <b>z</b>
%rax	t1, t2, rval
%rdx	t4
%rcx	t5

## **Machine Programming I: Summary**

#### History of Intel processors and architectures

Evolutionary design leads to many quirks and artifacts

#### C, assembly, machine code

- New forms of visible state: program counter, registers, ...
- Compiler must transform statements, expressions, procedures into low-level instruction sequences

#### Assembly Basics: Registers, operands, move

The x86-64 move instructions cover wide range of data movement forms

#### Arithmetic

 C compiler will figure out different instruction combinations to carry out computation