16/05/2014

CC3000 driver notes

CC3000 is a WiFi module by TI (see http://processors.wiki.ti.com/index.php/CC3000) providing a (supposedly friendly) socket-style interface for implementing Internet connections from small-footprint applications running in microcontrollers. From our point of view, the module is disappointing. It comes with its own software driver, the idea being that the driver should not be difficult to port to "typical" operating systems used in the micro world. Unfortunately, the driver is completely useless from our point of view, because we don't do things that way. As a matter of fact, the driver illustrates how things should not be done. The really unfortunate bit is that the module's low-level functionality seems to be rather strongly inspired by the driver.

Having said that, let me quickly add that there is a way to make the device work with PicOS. Considering that it is pointless to try to be power frugal while a WiFi module is active, we can afford to do a bit of polling in the driver without which nothing can be accomplished with the device. The present PicOS driver makes it possible to connect to a TCP or UDP socket and exchange packets as reliably as generally possible over a WiFi Internet connection (or at least it appears so based on my rather superficial tests so far).

The device does provide interrupts to signal some events. Those events (formal interrupts) are triggered in a messy way whereby some of them are responses to previously issued requests (these events are called "solicited") and some others can be raised spontaneously (asynchronously from the viewpoint of the driver) – those are called "unsolicited". Generally, when you issue a request (a command) to the module, the formal acceptance (sometimes it is in fact the completion) of the request will be marked by some specific (corresponding) synchronous event. The problem is that you have to know exactly what to expect and, what is truly disastrous, you cannot expect anything else until the command cycle runs to its prescribed completion. The design has the flavor of a student project where a sane and sound concept has been tweaked in a messy way to accomplish some momentary goal, which probably was to match the module's behavior to the expectations of the driver implementing a strictly sequential set of operations. The objective of the TI (reference) driver was to allow a sequential program to reference functions looking like standard BSD operations on sockets. The possible coexistence of that program with other processes or activities in the system was of no concern to the designers. This illustrates the kind of philosophy one would expect from the forthcoming generation of microprogramming experts educated on arduinos (where one cannot tell [or rather doesn't care about] the difference between an interrupt/event and a condition).

For illustration, to receive a packet, you have to issue a *receive* command. In a normal situation, the arrival of a packet would be signaled by an event (interrupt) to which the driver would respond by reading the data from the module into some buffer. While waiting for a packet to receive, the driver would be free to use the device for other tasks considered normal by most people, e.g., sending a packet out. In this case, once you have issued *receive*, the module becomes essentially blocked until a packet is in fact received! A reception event will be triggered all right when that happens (as one would expect), but you cannot do anything while waiting for that event! For example, if you decide that you have waited long enough without the reception having materialized, you may be tempted to ignore the outstanding *receive* command and issue another one. Now way! When you do that, the module will get into a weird state from which the only way out is through a reset.

With this approach it would have been impossible to implement any kind of operation (except for some truly stupid, blocking, sequential scenarios too brain damaged even for arduino), if not for just one life-saving option: there is an operation mimicking BSD *select*. So the messy way to implement (safe) reception is this:

- 1. do *select* specifying a timeout
- 2. when the select says that that there is data available, issue *receive* (now you know that the operation will be responded to right away)
- 3. read the received packet
- 4. after a timeout do other things (like checking for an outgoing packet and transmitting it) and issue *select* again

Thus the driver must necessarily poll the module in a tight loop to be able to transmit and receive without rigidly ordering these operations in a blocking/stalling fashion. It looks like implementing an event driven driver having for the starting point a sequential program using a subset of BSD operations on sockets. Even worse, because the standard operations allow for non-blocking socket read. No such luck here. The select command is in fact one of the most complex operations for the device, so the polling cycle is far from economical.

Compilation options

The symbolic constant **wifi_options** is a collection of flags selecting the high-level modes of the driver. Two such flags are used at present:

Selects the TCP connection mode, rather than the (default) UDP mode. A connection functionally appears like a BSD socket. Two types of such sockets are available: UDP and TCP. We probably prefer UDP connections, because of their inherently packetized nature.

WIFI OPTION NETID
$$(0x02)$$

When set, indicates that the Network Id field of packets (the first two bytes) will be interpreted in the same way as for packets transmitted by our standard RF modules. That is, a received packet whose Network Id doesn't match the Network Id assigned to the PHY will be ignored. For an outgoing packet, the Network Id will be automatically inserted by the driver into the first two bytes. The standard interpretations of the special Id's 0x000 and 0xFFFF will also apply.

By default, there is no Network Id, i.e., all bytes of a packet are treated as payload bytes. This makes sense for point-to-point communication, e.g., providing a wireless OSS link.

The length of the polling interval (for receiving packets) is determined by two symbolic constants, cc3000_pollint_min and cc3000_pollint_max whose default values are 1 and 15, respectively. They are translated into seconds by multiplying them by 0.065536 (they are in microseconds times 64K). The default minimum interval corresponds to about 15.28 times per second and the maximum is 15 times longer, i.e., yielding slightly more than one poll per second. Any activity (transmission/reception) resets the interval to the minimum; then after every idle cycle, the delay increases linearly by one unit (0.065536 of a second) until it reaches the maximum where it stays put.

Note that the polling interval also determines how often you can transmit. Recall that once the driver starts the polling cycle, it can do nothing until the select timer expires. Thus, the average delay for transmitting a spontaneous packet is about 0.5s. But two (or more) packets in a row will be transmitted back to back, if the second one is queued before the first one is transmitted.

By default, the driver issues keep-alive packets at regular intervals. If there is no activity (transmission/reception) the connection will die (somewhere within the module) in about two minutes. This happens without a notice, but with a stubborn regularity suggesting its being some kind of feature. Keep-alive packets seem to solve the problem. They may be generally a good idea, especially for UDP communication.

The constant wifi_kal_interval determines the frequency of keep-alive packets in the units of polling interval increments (i.e., 0.065536s). In fact, the actual frequency will be slightly lower (the interval between keep-alive packets will be slightly higher), because the time for issuing the polling commands counts extra. The default value of the constant is 240 amounting to about 16 seconds.

If the NETID option (see above) is inactive, a keep-alive packet consists of exactly four zero bytes. With the option compiled in, the packet consists of the Network Id followed by the Node Id (i.e., the lower word of the 32-bit Host Id). It is four bytes in both cases.

Note that the time until the next keep-alive packet is reset after every packet transmission. In particular, a continuous supply of outgoing packets showing up faster than the keep-alive interval will result in no keep-alive packets being sent at all.

If wifi_kal_interval is defined as zero, no keep-alive packets are sent automatically. This is OK, e.g., is the user program makes sure to send enough regular packets to keep the connection up.

Controlling the driver

The module is visible to the system as a standard PHY. Here is a sample initialization sequence (copied form App/TEST/CC3000/app.cc):

The first two arguments of phys_cc3000 are standard. The second argument specifies the maximum length of a packet payload. There is no CRC (and no room should be reserved in the packet for any extra attributes). If the NETID option is compiled in, the Network Id formally counts to the payload (as for other RF modules).

The driver reserves (malloc's) a buffer for receiving packets. The length of that buffer equals maxplen + 30 bytes.

The last two arguments of phys_cc3000 are special and provide for identifying the network and the server. Here is how the respective structures are defined (in phys_cc3000.h):

```
typedef struct {
    byte policy;
    byte security_mode;
    byte ssid_length;
    char ssid_n_key [33];
} cc3000_wlan_params_t;

typedef struct {
    byte ip [4];
    word port;
} cc3000 server params t;
```

The first structure describes the network. Note that the actual length of the last attribute can be less or more: it is supposed to be a string terminated by a NULL byte. Here is what the attributes mean:

The first attribute, policy, stands for the so-called connection policy and can be one of these:

```
CC3000 POLICY DIRECT (0)
```

Connect to the specified network (and make it the standard policy).

```
CC3000 POLICY PROFILE (1)
```

Connect to the specified network, store the network in a profile, and make it the standard policy to connect to one of the networks stored in the profile (whichever is available). Profiles can be also created and stored in the module using a smartphone configuration tool. I haven't tried it yet. If needed, the driver can be (relatively easily) extended by a function to put the module into a state whereby it will accept profiles over RF from a smartphone.

```
CC3000 POLICY LAST (2)
```

Connect to the specified network and make it the standard policy to connect to the last network connected to.

```
CC3000 POLICY ANY (3)
```

Connect to the specified network, and make it the standard policy to connect to any network you can connect to.

```
CC3000 POLICY OLD (4)
```

Connect to the specified network and do not change the standard connection policy.

```
CC3000 POLICY DONT (5)
```

Connect automatically according to the current (last set) connection policy. The remaining specification is ignored.

Note that I haven't tested everything yet (and there are probably things I don't understand). All I have tested is connecting to a specific network (my home network), setting the policy to LAST, and then using DONT to connect to the same network without having to specify its parameters. Note that in the last case (e.g., if you have preset the module to always connect to the same network), the data structure may consist of a single byte (the remaining attributes are never looked up).

If the network parameters are needed, then the second attribute, security mode, must be one of these:

```
CC3000_WLAN_SEC_UNSEC (0)
CC3000_WLAN_SEC_WEP (1)
CC3000_WLAN_SEC_WPA (2)
CC3000_WLAN_SEC_WPA2 (3)
```

to select the security mode of the network (the first value stands for an unsecured network).

The network's SSID is combined into a single string with the password (if a password is needed). Attribute ssid_length tells the length of the SSID part in the string. Thus, in the above example, the SSID is "OLSONET" and the password is "bacabacaba".

The data structure describing the server consists of the IP address and the port number in the most straightforward way. Note that no connection occurs immediately. The PHY starts in the OFF state with the module powered down. To turn it on, execute:

```
tcv control (SFD, PHYSOPT ON, NULL);
```

In contrast to a typical RF module, the operation of switching CC3000 on and off is rather complicated and may take time. When you switch the PHY on, the driver will try to connect to the network (according to the policy) and then connect to the server. The operation takes several stages and will be retried on timeouts until it succeeds, or until the PHY is turned off. When you turn the PHY off (and it has been on before), the driver will try to gracefully close the socket and go through some prescribed drill. Owing to the complexity and the somewhat special nature of WiFi communication, the device is not turned on (powered up) automatically when a packet is put into the output queue (by tcv_wnp), nor is the output queue emptied before formally turning off the module. Note that when the module gets disassociated from the network or from the server (which may happen for a completely external reason), there is no way to sensibly expedite the packets waiting in the output queue. The only way to make sense out of it is to let the user program detect the situation and decide what to do, e.g., to empty the packet queue manually via explicit operations of VNETI.

The only way for the program to know the actual (and possibly momentary) state of the PHY is to issue a status request, like this:

```
stat = tcv_control (SFD, PHYSOPT_STATUS, (address)&dstat);
where the argument points to this data structure:
    typedef struct {
        byte dstate;
        byte freebuffers;
        word mkalcnt;
        word dkalcnt;
} cc3000_phy_status_t;
```

Attribute dstate shows the current state of the driver which can be one of these:

```
#define
           CC3000 STATE DEAD 0
                                         // Disabled, switched off
#define
           CC3000 STATE INIT 1
                                         // Initializing
           CC3000 STATE WBIN 2
                                         // Waiting for buffer info
#define
#define
           CC3000 STATE POLI 3
                                         // Setting connection policy
#define
           CC3000 STATE RCON 4
                                         // Connecting to AP
#define
           CC3000 STATE APCN 5
                                         // Connected to AP
#define
           CC3000 STATE SOKA 6
                                         // Socket available
           CC3000 STATE CSNG 7
                                         // Closing server connection
#define
           CC3000 STATE ESTB 8
#define
                                         // Connection established
           CC3000 STATE RECV 9
                                         // Receive poll
#define
           CC3000 STATE READ 10
#define
                                         // Read received packet
#define
           CC3000 STATE SENT 11
                                         // Packet sent
```

The connection is healthy when dstate >= CC3000_STATE_ESTB (it makes sense to try to send packets out). Any other value means that the connection is being established or the PHY is off. In the latter case, dstate will be CC3000_STATE_DEAD. Note, however, that that state will not be assumed immediately when you execute

```
tcv control (SFD, PHYSOPT OFF, NULL);
```

although it is guaranteed to settle there after some finite time. On the other hand, when you turn the module on, it will reach one of the last four connected states if the network is available and (for the TCP mode) the server is willing to receive TCP connections.

Attribute freebuffers tells the number of free buffers of the device available for sending packets out. The maximum is 6. A transmission occupies one buffer until the packet can be discarded from the device.

Attribute mkalcnt tells the number of keep-alive events generated by the device (don't confuse them with the driver's keep-alive packets). The device periodically (about every 15 seconds) triggers an (unsolicited) event to tell the driver that it is operational.

Attribute dkalcnt tells the number of elapsed units of polling time. Each time a polling cycle completes, this value is incremented by the last setting of the select timer. So this value increments rather fast and wraps around quite often. This attribute is only set if **WIFI KAL INTERVAL** is nonzero.

The function value returned by the status query is the standard simple on/off value, i.e., 2 for off and 3 for on, reflecting the formal on/off status of the PHY. This value is updated immediately after formally turning the PHY on or off.

In addition to the control calls mentioned above, the driver implements:

PHYSOPT GETMAXPL

returning the maximum packet length that was specified as the second argument for phys cc3000

PHYSOPT SETSID and PHYSOPT GETID

to set and read the Network Id; these calls are only available if the NETID option has been compiled in.