


# IN THE BLINK OF AN LED:

## AN INTRODUCTION TO PHYSICAL COMPUTING



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# OVERVIEW OF CLASS

## Getting Started:

- Context
- Components
- Software Installation



## Electrical:

- Ohm's Law
- Circuits
- Multimeters
- Inputs and Outputs
- Analog vs Digital



## Microcontrollers:


- Digital Outputs
- Analog Outputs
- Digital Inputs
- Analog Inputs
- Serial Communication



# WIRING LIBRARY, PROCESSING (and ARDUINO)

Open Source Hardware/Software

 Processor



Coding is accessible & transferrable

(C++, Processing, java)



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# QUICK DEFINITIONS

Arduino – can refer to the Atmel ATMEGA328p microcontroller, the development board or the programming environment




microcontroller – shitty computer, but generally one with GPIO and analog input pins

GPIO pins – general purpose input/output pins, send and receive signals from outside the chip

physical computing – using a computer to interact with the real world


development board – microcontroller with connectors to easily access the GPIO, analog input and power








# ARDUINO & ARDUINO COMPATIBLE BOARDS



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# INCLUDED COMPONENTS

Name	Image	Type	Function	Notes
Push Button		Digital Input	Switch - Closes or opens circuit	
Trim potentiometer		Analog Input	Variable resistor	Also called a Trimpot.
Resistor		Passive Component	Drops Voltage	Color-Coded for Different Values
Photoresistor		Analog Input	Light Dependent Resistor (LDR)	Resistance varies with light.
LED		Digital & Analog Output	Emits a single wavelength light	
RGB LED		Digital & Analog Output	16,777,216 different colors	Ooh... So pretty.
Jumper Wires		Interconnect	Connects other components	Your extroverted friend
Breadboard		Interconnect	Where the connections happen	The neighborhood pub



# GETTING STARTED

<https://microcontrollers.smartypantsconsulting.ltd>


- Sample Code
- Schematic/Wiring Diagrams
- Web Resources



[This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.](#)

# GETTING STARTED

# WHAT IF I TOLD YOU







YOU CAN'T MESS ANYTHING UP  
BAD ENOUGH THAT WE'LL BE MAD AT YOU  
OR THINK YOU'RE DUMB?



# ELECTRICITY / ELECTRONICS Basic Concepts

- Voltage
- Current
- Resistance
- Ohm's Law
- Using a Multimeter

$$\oint_{\partial\Omega} \mathbf{E} \cdot d\mathbf{S} = \frac{1}{\epsilon_0} \iiint_{\Omega} \rho dV$$

$$\nabla \cdot \mathbf{E} = \frac{\rho}{\epsilon_0}$$
$$\oint_{\partial\Omega} \mathbf{B} \cdot d\mathbf{S} = 0$$

$$\nabla \cdot \mathbf{B} = 0$$
$$\oint_{\partial\Sigma} \mathbf{E} \cdot d\mathbf{l} = -\frac{d}{dt} \iint_{\Sigma} \mathbf{B} \cdot d\mathbf{S}$$

$$\nabla \times \mathbf{E} = -\frac{\partial \mathbf{B}}{\partial t}$$
$$\oint_{\partial\Sigma} \mathbf{B} \cdot d\mathbf{l} = \iint_{\Sigma} \left( \mu_0 \mathbf{J} + \epsilon_0 \mu_0 \frac{\partial \mathbf{E}}{\partial t} \right) \cdot d\mathbf{S}$$

$$\nabla \times \mathbf{B} = \mu_0 \mathbf{J} + \epsilon_0 \mu_0 \frac{\partial \mathbf{E}}{\partial t}$$



# ELECTRICAL PROPERTIES

Voltage

V

- The amount of potential energy in a circuit (how “hard” it can push electrons)
- Units: Volts (V)

Current

I

- Related to number of electrons that flow through a circuit every second
- Units: Amperes (A)


Resistance

R

- How difficult it is for electrons to flow through a circuit
- Units: Ohms ( $\Omega$ )



# OHM'S Law



$$V = I \times R$$

$$I = V \div R$$

$$R = V \div I$$



$$V = I R$$

## CURRENT FLOW ANALOGY



High Current




Low Current




$$V = I R$$

## VOLTAGE ANALOGY



More Energy == Higher Voltage

$$V = I R$$




Less Energy == Lower Voltage



$$V = I R$$


$$V = I R$$

## RESISTANCE ANALOGY



Big Pipe == Lower Resistance

$$V=IR$$



Small Pipe == Higher Resistance


$$V=IR$$




# CONTINUITY – IS IT a CIRCUIT?

The word “circuit” is derived from the circle. An Electrical Circuit must have a continuous LOOP from Power ( $V_{cc}$ ) to Ground (GND).




Continuity- it is important to make sure all the portions of circuits are connected. Continuity is the simplest and possibly the most important setting on your multimeter. Sometimes we call this “ringing out” a circuit.






# MEASURING ELECTRICITY – VOLTAGE

Voltage is a measure of potential electrical energy.  
A voltage is also called a potential difference – it  
is measured between two points in a circuit –  
across a device.




# MEASURING ELECTRICITY -- CURRENT



Current is the measure of the rate of charge flow. For Electrical Engineers – we consider this to be the movement of electrons.

In order to measure this – you must break the circuit or insert the meter in-line (series).






# MEASURING ELECTRICITY -- RESISTANCE

Resistance is the measure of how much opposition to current flow is in a circuit.

Components should be removed entirely from the circuit to measure resistance. Note the settings on the multimeter. Make sure that you are set for the appropriate range.




# PROTOTYPING CIRCUITS


## Solderless Breadboard

One of the most useful tools in  
an engineer or Maker's toolkit.  
Good things to remember:

- A breadboard is easier than soldering
- A breadboard isn't the same as soldering
  - Sometimes breadboards break
  - Sometimes breadboards don't make good connections
  - They're not good for high-speed applications
- Know what dots are connected to each other



# WHY a Breadboard?




Atwater Kent Radios (ca 1923)




This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# What's a Breadboard?




This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# How It's All Connected




Each row (horizontal) of 5 holes are connected

Vertical columns- called power buses- are connected vertically




# COMPONENT SPOTLIGHT: THE RESISTOR



Ohms( $\Omega$ )





# Decoding Resistor Values





# COMPONENT SPOTLIGHT: The LED

Diode




# COMPONENT SPOTLIGHT: The LED

Light Emitting Diode




# COMPONENT SPOTLIGHT: The LED



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# LED MNEMONIC




anode (+)      cathode (-)

short lead

Cathode, like Kathy, is short and  
negative



# USING THE Breadboard TO BUILT a SIMPLE CIRCUIT



Use the breadboard to wire up

- a single LED
- a 220  $\Omega$  Resistor

(Red-Red-Black-Black-Gold)


or

(Red-Red-Brown-Gold)

fritzing




# USING THE Breadboard TO BUILT a SIMPLE CIRCUIT




This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# Go ahead and PLUG YOUR board IN!



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# ADDING CONTROL



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# CONCEPTS: INPUT vs. OUTPUT

Referenced from the perspective of the microcontroller

**Input** is a signal / information going into the board.



**Output** is any signal exiting the board.



Almost all systems that use physical computing will have an output

What are some examples of inputs and outputs?



# CONCEPTS: INPUT vs. OUTPUT

Referenced from the perspective of the microcontroller

**Input** is a signal / information going into the board.

**Output** is any signal exiting the board.

Examples: Buttons, Switches, Microphones, Light Sensors, Touch Sensors, Flex Sensors, Humidity Sensors, Temperature Sensors...



Examples: LEDs, RGB LEDs, monitors, relays, DC motors, servo motors, buzzers, speakers




## CONCEPTS: ANALOG VS. DIGITAL

Microcontrollers are **digital** devices – ON or OFF.  
Also called discrete.

**Analog** signals are anything that can be a full range of values. What are some examples?




# BIG 6 CONCEPTS



## `digitalWrite()`



## `analogWrite()`




## `if() statements / Boolean logic`



## `digitalRead()`




## `analogRead()`



## Serial communication






# digitalWrite()

## PROJECT # 1 - BLINK

“Hello World” of Physical Computing

*Pseudo-code – how should this work?*





# digitalWrite()

## PROJECT # 1 - BLINK

“Hello World” of Physical Computing

*Pseudo-code – how should this work?*



# PROJECT # 1 - BLINK

## INPUTS AND OUTPUTS




Inputs	Outputs
None	LED/resistor



# PROJECT # 1 - BLINK

## SCHEMATIC




Move the blue wire from the power bus to pin 12 (or any other Digital I/O pin) on the microcontroller board.



# PROJECT # 1 - BLINK

## WIRING DIAGRAM




fritzing



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# OPEN UP ARDUINO IDE



BareMinimum | Arduino 1.8.16

File Edit Sketch Tools Help


BareMinimum

```
void setup() {  
  // put your setup code here, to run once:  
}  
  
void loop() {  
  // put your main code here, to run repeatedly:  
}
```

1 Arduino Uno on /dev/ttyACM0

IDE → Integrated Development Environment  
Lets you write, compile (and upload) code all in the same place

Versions 1 and 2 are aesthetically different, functionally the same (for our purposes)



sketch\_sep2a | Arduino IDE 2.2.1

File Edit Sketch Tools Help

Select Board

sketch\_sep2a.ino


```
1 void setup() {  
2   // put your setup code here, to run once:  
3 }  
4  
5 void loop() {  
6   // put your main code here, to run repeatedly:  
7 }  
8  
9 }  
10
```

Output

Ln 1, Col 1 × No board selected



# EXPLORING THE ARDUINO IDE



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# Coding

This is like trying to learn ‘sports’ in a few hours, or  
‘cooking’ or anything else that is a field of study unto itself

We’re going to go over some very broad concepts, in the  
form of commands and function, giving you just enough to  
be dangerous

You can copy/paste the examples, or type them in yourself,  
then we’ll review what each is doing line by line

LIKE YOU READ TURING’S  
1936 PAPER ON COMPUTING  
AND A PAGE OF JAVASCRIPT  
EXAMPLE CODE AND GUESSED  
AT EVERYTHING IN BETWEEN.



# COMMANDS

Commands are what you want the microcontroller to do.  
They're a code to translate between English and computer-speak

Only one command can go on a line

Because it's a code, the **syntax** or how you type the commands, is very important

If you don't get it just right, the output at the bottom of the IDE will try to tell you what's wrong

```
Output
/tmp/.arduinoIDE-unsaved2023822-13880-17ueswm.p19o/Blink/Blink.ino: In function 'void setup()':
/tmp/.arduinoIDE-unsaved2023822-13880-17ueswm.p19o/Blink/Blink.ino:29:1: error: expected ';' before '
}
^

exit status 1

Compilation error: expected ';' before '}' token
```



# PROJECT # 1 - BLINK

## THREE COMMAND TO START

```
pinMode(pin, INPUT/OUTPUT);
```

// NOTE: -> commands are CASE-sensitive



# PROJECT # 1 - BLINK

## THREE COMMAND TO START

**pinMode(pin, INPUT/OUTPUT);**

ex: **pinMode(12, OUTPUT);**

**// NOTE: -> commands are CASE-sensitive**



# PROJECT # 1 - BLINK

## THREE COMMAND TO START

**pinMode(pin, INPUT/OUTPUT);**

ex: **pinMode(12, OUTPUT);**

**digitalWrite(pin, HIGH/LOW);**

**// NOTE: -> commands are CASE-sensitive**



# PROJECT # 1 - BLINK

## THREE COMMAND TO START

**pinMode(pin, INPUT/OUTPUT);**

ex: **pinMode(12, OUTPUT);**

**digitalWrite(pin, HIGH/LOW);**

ex: **digitalWrite(12, HIGH);**

**// NOTE: -> commands are CASE-sensitive**



# PROJECT # 1 - BLINK

## THREE COMMAND TO START

**pinMode(pin, INPUT/OUTPUT);**

ex: **pinMode(12, OUTPUT);**

**digitalWrite(pin, HIGH/LOW);**

ex: **digitalWrite(12, HIGH);**

**delay(time\_ms);**

**// NOTE: -> commands are CASE-sensitive**



# PROJECT # 1 - BLINK

## THREE COMMAND TO START

**pinMode(pin, INPUT/OUTPUT);**

ex: **pinMode(12, OUTPUT);**

**digitalWrite(pin, HIGH/LOW);**

ex: **digitalWrite(12, HIGH);**

**delay(time\_ms);**

ex: **delay(2500);**

**// NOTE: -> commands are CASE-sensitive**



# FUNCTIONS

Functions are groups of commands

- They need a unique name
- They *can* take numbers as inputs (arguments) and spit out a number as an output (return) but don't have to
- They begin and end with curly brackets → { }
- We wont be dealing with them in too much more detail, save every Arduino program **requires** two functions, the **setup( )** function and the **loop( )** function



File Edit Sketch Tools Help

Arduino Uno

BareMinimum.ino

```
1 void setup() {
2     // put your setup code here, to run once:
3 }
4
5 void loop() {
6     // put your main code here, to run repeatedly:
7 }
8
```

Ln 8, Col 1 Arduino Uno on /dev/ttyUSB0 [not connected] ⚙



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# COMMENTS, COMMENTS, COMMENTS

Comments are ignored by the microcontroller. They're just for you – the programmer and your friends...or anyone else human that might read your code.

```
// this is for single line comments
```

```
/* this is for multi-line comments
```

```
    Like this...
```

```
    And this....
```

```
*/
```



BareMinimum | Arduino 1.0.5

File Edit Sketch Tools Help


BareMinimum §

```
// Name of sketch
// Brief Description
// Date:
//  
  
void setup()
{
    // put your setup code here, to run once:  
  
}  
  
void loop()
{
    // put your main code here, to run repeatedly:  
  
}
```



# PROJECT # 1 - BLINK

## Code Review



The screenshot shows the Arduino IDE interface with the file 'blink.ino' selected. The code is as follows:

```
1  /*
2   * Blink an LED off and on for 1 second
3   */
4
5
6 // the setup function runs once when you press reset or power the board
7 void setup() {
8     // initialize digital pin 12 as an output
9     pinMode(12, OUTPUT);
10 }
11
12 // the loop function runs over and over again forever
13 void loop() {
14     digitalWrite(12, HIGH);      // turn the LED on (HIGH is the voltage level)
15     delay(1000);                // wait for a second
16     digitalWrite(12, LOW);       // turn the LED off by making the voltage LOW
17     delay(1000);                // wait for a second
18 }
19
```



# PROJECT # 1 - BLINK PUZZLES

**Challenge 1a** – blink with a 200 ms second interval.

**Challenge 1b** – find the fastest blink that the human eye can still detect...

1 ms delay? 2 ms delay? 3 ms delay???

**Challenge 1c** – blink to mimic a heartbeat

**Challenge 1d** – change the output pin






# analogWrite()

## Project # 2 - Fade

Not so fast, Jack

*Pseudo-code - how should this work?*




# Project # 2 - Fade INPUTS and OUTPUTS



Inputs	Outputs
None	LED/resistor



# PROJECT # 2 - Fade SCHEMATIC




Move the blue wire to pin 9 (or 3, 5, 6, 10 or 11) on the microcontroller board.



# PROJECT # 2 - Fade

## WIRING DIAGRAM



fritzing

fritzing



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# FADING IN AND FADING OUT (ANALOG OR DIGITAL?)


A few pins on the Arduino allow for us to modify the output to “mimic” an analog signal.

This is done by a technique called:  
Pulse Width Modulation (PWM)



# CONCEPTS: ANALOG vs. DIGITAL

To create an analog signal, the microcontroller uses a technique called PWM. By varying the duty cycle, we can fool the eye into seeing an average brightness.



# PROGRAMMING CONCEPTS: Variable



```
1 char varA;  
2 int varB = 5;  
3 long varC = varB;  
4  
5 varA = 2 * 7;  
6 varB = varB + 1;  
7 varC = varA - varB;
```



# PROGRAMMING CONCEPTS: VARIABLE TYPES

## Variable Types:



8 bits



16 bits



32 bits

byte/char

int/ unsigned int

long/unsigned long

$2^8 = 256$  values  
(0 - 255)

$2^{16} = 65,536$  values  
(-32728 – 32727)  
(0 – 65535)

$2^{32} = 4,294,967,296$   
(-2147483648 –  
2147483647)  
(0 – 4294967295)



# How BIG Is $2^{32}$ ?

The function millis()  
returns the number of  
milliseconds since the  
program started

The type of data millis()  
returns is an unsigned  
long int

4,294,967,296  
milliseconds is 49.71  
days



# Variables: Which Cup Should You Choose?

## Variable Types:



8 bits



16 bits



32 bits

byte/char

$2^8 = 256$  values  
(0 - 255)

int/ unsigned int

$2^{16} = 65,536$  values  
(-32728 – 32727)  
(0 – 65535)

long/unsigned long

$2^{32} = 4,294,967,296$   
(-2147483648 –  
2147483647)  
(0 – 4294967295)



# VARIABLES: WHICH CUP SHOULD YOU CHOOSE?

## Variable Types:



8 bits

byte/char

$2^8 = 256$  values  
(0 - 255)



16 bits

int/ unsigned int

$2^{16} = 65,536$  values  
(-32728 – 32727)  
(0 – 65535)



32 bits

long/unsigned long

$2^{32} = 4,294,967,296$   
(-2147483648 –  
2147483647)  
(0 – 4294967295)



# PROJECT # 2 - Fade


## New COMMAND!

```
analogWrite(pin, val);
```


**pin** – refers to the OUTPUT pin  
(limited to pins 3, 5, 6, 9, 10, 11.) –  
denoted by a ~ symbol

**val** – byte/char value (0 – 255).

0 => 0V | 255 => 5V



# Fade - Code Review



The image shows the Arduino IDE interface with the file 'fade.ino' open. The code is a simple program that fades an LED connected to pin 9. It includes a setup function to initialize the pin as an output and a loop function to repeatedly update the brightness of the LED.

```
fade.ino
1 /*
2  * Gradually fade an LED on and off
3  */
4
5 // assign pin based off circuit
6 int led = 9;
7
8 int brightness = 0;      // holds the value for how bright the led is
9 int fade_amount = 5;     // how much the brightness changes each loop
10
11 // the setup function runs once when you press reset or power the board
12 void setup() {
13     // initialize digital pin 9 as an output.
14     pinMode(led, OUTPUT);
15 }
16
17 // the loop function runs over and over again forever
18 void loop() {
19     analogWrite(led, brightness);          // set the brightness of pin 9
20
21     brightness = brightness + fade_amount; // update the brightness for the next loop
22
23     if (brightness <= 0 || brightness >= 255) { // if the LED is all the way off or on
24         fade_amount = fade_amount * -1;        // change the direction of the fade
25     }
26     delay(30);                            // pause to see the dimming effect
27 }
28
```




# PROJECT # 2 - Fade Puzzles

**Challenge 2a** – Change the rate of the fading in and out.  
There are at least two different ways to do this – can you figure them out?

**Challenge 2b** – Use 2 (or more) LEDs – so that one fades in as the other one fades out.






## PROJECT # 2.1- COLOR MIXING RGB LED





### Common Cathode LED

This means the negative side of the LED is all tied to Ground.



# Project # 2.1 - COLOR MIXING SCHEMATIC



Note: The longest leg of the RGB LED is the Common Cathode. This goes to GND.



fritzing

Use pins 5, 6, & 9



# Project # 2.1 - COLOR MIXING

## WIRING DIAGRAM



fritzing



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

# Project # 2.1 - COLOR MIXING

## Code Review

rgb\_led.ino

```
/*
 * blend the colors of an RGB LED
 */

// assign pins based off circuit
int redPin = 3;
int greenPin = 5;
int bluePin = 6;

int red_val = 209;
int green_val = 5;
int blue_val = 249;

// the setup function runs once when you press reset or power the board
void setup() {
    // initialize all three pins as outputs.
    pinMode(redPin, OUTPUT);
    pinMode(greenPin, OUTPUT);
    pinMode(bluePin, OUTPUT);


    // set the different levels of red, green and blue to make your color
    analogWrite(redPin, red_val);
    analogWrite(greenPin, green_val);
    analogWrite(bluePin, blue_val);
}

// the loop function runs over and over again forever
void loop() {
    // nothing to do here
}
```



# HOW MANY UNIQUE COLORS CAN YOU CREATE?

$$\begin{aligned}\# \text{ of unique colors} &= 256 \cdot 256 \cdot 256 \\ &= 16,777,216 \text{ colors!}\end{aligned}$$



Click the “Color Picker” link at [microcontrollers.smartypantsconsulting.ltd](http://microcontrollers.smartypantsconsulting.ltd)

Pick out a few colors that you want to try re-creating for a lamp or lighting display...

Play around with this and the **analogWrite()** command.



# Project # 2.1 - COLOR MIXING

## Code Review

rgb\_led.ino

```
/*
 * blend the colors of an RGB LED
 */

// assign pins based off circuit
int redPin = 3;
int greenPin = 5;
int bluePin = 6;

int red_val = 209;
int green_val = 5;
int blue_val = 249;



// the setup function runs once when you press reset or power the board
void setup() {
    // initialize all three pins as outputs.
    pinMode(redPin, OUTPUT);
    pinMode(greenPin, OUTPUT);
    pinMode(bluePin, OUTPUT);

    // set the different levels of red, green and blue to make your color
    analogWrite(redPin, red_val);
    analogWrite(greenPin, green_val);
    analogWrite(bluePin, blue_val);
}

// the loop function runs over and over again forever
void loop() {
    // nothing to do here
}
```



# PROJECT: Mood Lamp / Light Sculpture



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.

The Story Continues  
on Disc Two...



[This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.](#)

# SPECIAL THANKS:



www.sparkfun.com  
6175 Longbow Drive, Suite 200  
Boulder, Colorado 80301



This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 United States License.