#### Shaira Alam

UID: 506302126

Homework 1

Dr. Danijela Cabric

ECE 233: Wireless Communications System Design, Modeling, and Implementation

Summer 2024

## **Part 1: SSB Generation**

#### **Table of Contents**

arameters	. ]
SS	. 1
SS	
BCH Pilot	
BCH Data	
Concatenation	2
Channel and Noise	2
a) s(n) Transmitted Signal	. :
b) y(n) Received Signal	
Function Definitions	

#### **Parameters**

```
FFT_size = 4096;
CP_length = 288;
CP_OFDM_length = FFT_size+CP_length;
SCS = 30e3;
Ts = 1/FFT_size/SCS;
delta_f = 2.03e3; % kHz

QAM_mod = 4;
num_sc = 240;
N_id_1 = 77;
N_id_2 = 2;
c_init = 120897;

SNR = 20;
h = [0 0 0 0 1 0.5]';
```

#### **PSS**

```
% OFDM Modulation
PSS_stream = generate_PSS_BPSK(N_id_2);
% Map symbol to subcarrier
d_PSS = [zeros(56,1);PSS_stream;zeros(FFT_size-183,1)];
% FFT
OFDM_PSS_body = ifft(d_PSS)*sqrt(FFT_size);
% Add CP
CP_OFDM_PSS = [OFDM_PSS_body(end-CP_length+1:end);OFDM_PSS_body];
```

#### SSS

```
% OFDM Modulation
SSS_stream = generate_SSS_BPSK(N_id_1, N_id_2);
```

```
% Map symbol to subcarrier
d_SSS = [zeros(56,1);SSS_stream;zeros(FFT_size-183,1)];
% FFT
OFDM_SSS_body = ifft(d_SSS)*sqrt(FFT_size);
% Add CP
CP OFDM SSS = [OFDM SSS body(end-CP length+1:end);OFDM SSS body];
```

#### **PBCH Pilot**

```
% OFDM Modulation
PBCH_pilot_stream = generate_PBCH_pilot(c_init);
% Map symbol to subcarrier
d_PBCH_pilot = zeros(FFT_size,1);
k = 0:59;
d_PBCH_pilot(1+4*k+1) = PBCH_pilot_stream;
% FFT
OFDM_PBCH_pilot_body = ifft(d_PBCH_pilot)*sqrt(FFT_size);
% Add CP
CP_OFDM_PBCH_pilot = [OFDM_PBCH_pilot_body(end-CP_length+1:end);OFDM_PBCH_pilot_body];
```

#### **PBCH Data**

```
% OFDM Modulation
PBCH_data_stream = generate_PBCH_data(num_sc, QAM_mod);
% Map symbol to subcarrier
d_PBCH_data = [PBCH_data_stream; zeros(FFT_size-num_sc,1)];
% FFT
OFDM_PBCH_data_body = ifft(d_PBCH_data)*sqrt(FFT_size);
% Add CP
CP_OFDM_PBCH_data = [OFDM_PBCH_data_body(end-CP_length+1:end);OFDM_PBCH_data_body];
```

#### Concatenation


```
CP_OFDM_chain = [CP_OFDM_PSS; CP_OFDM_PBCH_pilot; CP_OFDM_SSS;
CP_OFDM_PBCH_data];
```

#### **Channel and Noise**

```
signal_after_channel = conv(CP_OFDM_chain,h);
N_0 = 10^(-SNR/10) * (norm(signal_after_channel)^2/
length(signal_after_channel));
noise = sqrt(N_0/2)*(randn(length(signal_after_channel),1) +
1j*randn(length(signal_after_channel),1));
received_signal = signal_after_channel .*
exp(1j*2*pi*delta f*(0:length(signal after_channel)-1)'*Ts) + noise;
```


## (a) s(n) Transmitted Signal

```
figure;
plot(abs(CP_OFDM_chain));
xlabel('Sample Index'); % X-axis label
ylabel('Magnitude'); % Y-axis label
title('(1a) Transmitted Signal s(n)');
```



## (b) y(n) Received Signal

```
figure;
plot(abs(received_signal));
xlabel('Sample Index'); % X-axis label
ylabel('Magnitude'); % Y-axis label
title('(1b) Received Signal y(n)');
```



#### **Function Definitions**

```
function PSS_BPSK = generate_PSS_BPSK(N_id_2)
    x = zeros(127,1);
    PSS BPSK = zeros(127,1);
    x init = [0 1 1 0 1 1 1];
    x(1:7) = x init;
    for i = 1:120
        x(i+7) = mod(x(i+4)+x(i),2);
    end
    for n = 0:126
        m = mod(n + 43*N id 2,127);
        PSS BPSK(n+1) = 1-2*x(m+1);
    end
end
function SSS BPSK = generate_SSS_BPSK(N_id_1,N_id_2)
    x 0 = zeros(127,1);
    x_1 = zeros(127,1);
    SSS_BPSK = zeros(127,1);
    x init = [1 0 0 0 0 0 0];
    x_0(1:7) = x_{init};
    x_1(1:7) = x_{init};
    for i = 1:120
```

```
x \ 0(i+7) = mod(x \ 0(i+4)+x \ 0(i),2);
        x 1(i+7) = mod(x 1(i+1)+x 1(i),2);
    end
    for n = 0:126
        m = 0 = mod(n + 15* floor(N id 1/112) + 5*N id 2,127);
        m 1 = mod(n + mod(N id 1, 112), 127);
        SSS BPSK(n+1) = (1-2*x 0 (m 0+1))*(1-2*x 1 (m 1+1));
    end
end
function QPSK pilot stream = generate PBCH pilot(c init)
    c = zeros(120,1);
    QPSK pilot stream = zeros(60,1);
    x 1 = zeros(1800,1);
    x 2 = zeros(1800,1);
    x 1 init = [1; zeros(30,1)];
    x 1(1:31) = x 1 init;
    x 2 init = zeros(31,1);
    x 2 init char = dec2bin(c init);
    for i = 1:length(x 2 init char)
        \times 2 init(length(x 2 init char)-i+1) = str2double(x 2 init char(i));
    end
    x 2(1:31) = x 2 init;
    for n = 1:1800
        x 1(n+31) = mod(x 1(n+3)+x 1(n),2);
        x \ 2(n+31) = mod(x \ 2(n+3)+x \ 2(n+2)+x \ 2(n+1)+x \ 2(n),2);
    end
    for n = 0:119
        c(n+1) = mod(x 1(n+1600+1)+x 2(n+1600+1), 2);
    end
    for n = 0:59
        QPSK pilot stream(n+1) = 1/sqrt(2)*(1-2*c(2*n+1)) + 1j/
sqrt(2)*(1-2*c(2*n+2));
    end
end
function QPSK data stream = generate PBCH data(num sc, QAM mod)
    data bit stream = randi([0 1], num sc*log2(QAM mod),1);
    QPSK data stream =
qammod(data bit stream, QAM mod, InputType='bit', UnitAveragePower=true);
```

Published with MATLAB® R2024a

## Part 2: Frequency offset compensation & PSS search

#### **Table of Contents**

arameters	]
SS	1
hannel and Noise	2
oarse frequency offset estimation	2
ine Frequency Offset Estimation	
a) Determine (NID2, Frequency offset estimation)	3
alculate root mean square	
ine Frequency Offset Estimation	
alculate RMSE	4
o) Plot RMSE vs SNR	
unction Definitions	2

#### **Parameters**

```
FFT_size = 4096;
CP_length = 288;
SCS = 30e3;
Ts = 1/FFT_size/SCS;
CP_OFDM_length = FFT_size+CP_length;
num_sc = 240; % number of subcarriers
N_id_2 = 2
delta_f = 2.03e3; % kHz
N_id_2 =
2
```

#### **PSS**

```
% OFDM Modulation
PSS_stream = PSS_BPSK(N_id_2);
% Map symbol to subcarrier
d_PSS = [zeros(56,1);PSS_stream;zeros(FFT_size-183,1)];
% FFT
OFDM_PSS_body = ifft(d_PSS)*sqrt(FFT_size);
% Add CP
CP_OFDM_PSS = [OFDM_PSS_body(end-CP_length+1:end);OFDM_PSS_body];
```

#### **Channel and Noise**

```
h = 1;
signal_after_channel = conv(CP_OFDM_PSS,h);

SNR = 20;
N_0 = 10^(-SNR/10) * (norm(signal_after_channel)^2/
length(signal_after_channel));
noise = sqrt(N_0/2)*(randn(length(signal_after_channel),1) +
1j*randn(length(signal_after_channel),1));
received_PSS_signal = signal_after_channel .*
exp(1j*2*pi*delta f*(0:length(signal_after_channel)-1)'*Ts) + noise;
```

## Coarse frequency offset estimation

```
% Searches from -15kHz to 15kHz with 100 Hz incremenets
freq offset = -SCS/2:100:SCS/2;
% Correlation results between received signal and reference signals for each
value of NiD2: 3 row matrix (0-2) for NID2 corresponding frequency offsets
corr = zeros(3,length(freq offset));
for i = 0:2 % iterates through each NID2 value
    PSS ref stream = PSS BPSK(i); % reference waveform for NID2 value
    d PSS ref = [zeros(56,1); PSS ref stream; zeros(FFT size-183,1)]; %
prepares for modulation
    OFDM PSS ref body = ifft(d PSS ref); % converts to frequency domain
    CP OFDM PSS ref = [OFDM PSS ref body(end-
CP length+1:end);OFDM PSS ref body]; % adds CP to OFDM signal
    for j = 1:numel(freq offset) % itereates thorugh each frequency offset
value to compute correlation for different frequency offsets
        % Calculates correlation between received signal and reference
signal with frequency offset
       corr(i+1,j) = abs(received PSS signal' * (CP OFDM PSS ref .*
exp(1j*2*pi*freq offset(j)*(0:length(CP OFDM PSS ref)-1)'*Ts)));
    end
% Finds position of maximum correlation value
[\sim, N \text{ id } 2 \text{ est pos}] = \max(\max(abs(corr), [], 2));
% converts index position to actual NID2 value
N id 2 est = N id 2 est pos - 1;
```

## **Fine Frequency Offset Estimation**

```
freq_offset_est = -angle(received_PSS_signal(FFT_size+1:FFT_size+CP_length)'
* received_PSS_signal(1:CP_length))/2/pi*SCS;
freq_offset_est_kHz = freq_offset_est / 1e3;
```

## (a) Determine (NID2, Frequency offset estimation)

```
disp('(2a) Determine N(2)_ID and Estimated Frequency Offset: ');
disp(['Estimated N(2)_ID: ', num2str(N_id_2_est)]); % from course frequency
offset estimation
disp(['Estimated Frequency Offset (Hz): ', num2str(freq_offset_est)]); %
from fine frequency offset estimation
disp(['Estimated Frequency Offset (kHz): ', num2str(freq_offset_est_kHz)]);

(2a) Determine N(2)_ID and Estimated Frequency Offset:
Estimated N(2)_ID: 2
Estimated Frequency Offset (Hz): 2043.1866
Estimated Frequency Offset (kHz): 2.0432
```

## Calculate root mean square

```
FFT size = 4096;
CP length = 288;
SCS = 30e3;
Ts = 1/FFT size/SCS;
CP OFDM length = FFT size + CP length;
num sc = 240; % number of subcarriers
N id 2 = 2;
delta_f = 2.03e3; % kHz
num MC = 1000;
SNR range = 0:2:20; % SNR values in dB
num SNR = length(SNR range);
RMSE = zeros(num MC, num SNR); % Root Mean Square Error
for SNR id = 1:num SNR
    for MC id = 1:num MC
        SNR = SNR range(SNR id);
        N = 10^{-5}NR/10) * (norm(signal after channel)^2/
length(signal after channel));
        noise = sqrt(N 0/2)*(randn(length(signal after channel),1) +
1j*randn(length(signal after channel),1));
        received PSS signal = signal after channel .*
exp(1j*2*pi*delta f*(0:length(signal after channel)-1)'*Ts) + noise;
```


## **Fine Frequency Offset Estimation**

#### **Calculate RMSE**

```
RMSE(MC_id, SNR_id) = (freq_offset_est - delta_f)^2;
end
end
mean_RMSE = sqrt(mean(RMSE, 1));
```

## (b) Plot RMSE vs SNR

```
figure;
plot(SNR_range, mean_RMSE);
xlabel('SNR (dB)');
ylabel('Root Mean Square Error (Hz)');
title('(2b) RMSE vs SNR for Frequency Offset Estimation');
grid on;
```



#### **Function Definitions**

```
function BPSK_stream = PSS_BPSK(N_id_2)
    x = zeros(127,1);
    BPSK_stream = zeros(127,1);
    x init = [0 1 1 0 1 1 1];
```

## Part 2: Frequency offset compensation & PSS search

```
x(1:7) = x_init;
for i = 1:120
      x(i+7) = mod(x(i+4)+x(i),2);
end
for n = 0:126
    m = mod(n + 43*N_id_2,127);
    BPSK_stream(n+1) = 1-2*x(m+1);
end
end
```

Published with MATLAB® R2024a

## **Part 3: Timing synchronization**

#### **Table of Contents**

arameters	]
SS and PBCH_pilot	
Concatenation	]
Channel and Noise	2
iming Synchronization	2
a) Plot Correlation for all SNR values	2

#### **Parameters**

```
FFT_size = 4096;
CP_length = 288;
SCS = 30e3;
Ts = 1/FFT_size/SCS;
CP_OFDM_length = FFT_size+CP_length;
num_sc = 240;
N_id_2 = 2;
c init = 120897;
```

## **PSS and PBCH\_pilot**

```
% OFDM Modulation
PSS_stream = PSS_BPSK(N_id_2);
PBCH_pilot_stream = PBCH_QPSK(c_init);

% Map symbol to subcarrier
d_PSS = [zeros(56,1);PSS_stream;zeros(FFT_size-183,1)];
d_PBCH_pilot = zeros(FFT_size,1);
k = 0:59;
d_PBCH_pilot(1+4*k+1) = PBCH_pilot_stream(1:60);

% FFT
OFDM_PSS_body = ifft(d_PSS)*sqrt(FFT_size);
OFDM_PBCH_pilot_body = ifft(d_PBCH_pilot)*sqrt(FFT_size);

% Add CP
CP_OFDM_PSS = [OFDM_PSS_body(end-CP_length+1:end);OFDM_PSS_body];
CP_OFDM_PBCH_pilot = [OFDM_PBCH_pilot_body(end-CP_length+1:end);OFDM_PSS_body];
```

#### **Concatenation**

```
CP_OFDM_chain = [CP_OFDM_PSS;CP_OFDM_PBCH_pilot];
```

#### **Channel and Noise**

```
h = [0 0 0 0 1 0.5]';
signal_after_channel = conv(CP_OFDM_chain,h);

SNR_values = [-5, 20]; % SNR values in dB
corr_all = zeros(length(SNR_values), FFT_size + 1);

for snr_idx = 1:length(SNR_values)

    SNR = SNR_values(snr_idx);
    N_0 = 10^(-SNR/10) * (norm(signal_after_channel)^2/
length(signal_after_channel));
    noise = sqrt(N_0/2)*(randn(length(signal_after_channel),1) +
1j*randn(length(signal_after_channel),1));
    received_signal = signal_after_channel + noise;
```


### **Timing Synchronization**

## (a) Plot Correlation for all SNR values

```
figure;
plot(0:FFT_size, corr_all(1, :), 'r', 'DisplayName', 'SNR = -5 dB');
hold on;
plot(0:FFT_size, corr_all(2, :), 'b', 'DisplayName', 'SNR = 20 dB');
xlabel("Timing Offset (sample)")
ylabel("Correlation")
title('(3a) Correlation for Different SNR Values')
legend show;
grid on;

function BPSK_stream = PSS_BPSK(N_id_2)
    x = zeros(127,1);
    BPSK_stream = zeros(127,1);
    x_init = [0 1 1 0 1 1 1];
```

```
x(1:7) = x init;
    for i = 1:120
        x(i+7) = mod(x(i+4)+x(i),2);
    end
    for n = 0:126
        m = mod(n + 43*N id 2,127);
        BPSK stream(n+1) = 1-2*x(m+1);
    end
end
function QPSK stream = PBCH QPSK(c init)
    c = zeros(120,1);
    QPSK stream = zeros(60,1);
    x 1 = zeros(1800,1);
    x 2 = zeros(1800,1);
    x 1 init = [1; zeros(30,1)];
    x 1(1:31) = x 1 init;
    x 2 init = zeros(31,1);
    x 2 init char = dec2bin(c init);
    for i = 1:length(x 2 init char)
        \times 2 init(length(x 2 init char)-i+1) = str2double(x 2 init char(i));
    end
    x 2(1:31) = x 2 init;
    for n = 1:1800
        x 1(n+31) = mod(x 1(n+3)+x 1(n),2);
        x \ 2(n+31) = mod(x \ 2(n+3)+x \ 2(n+2)+x \ 2(n+1)+x \ 2(n),2);
    end
    for n = 0:119
        c(n+1) = mod(x 1(n+1600+1)+x 2(n+1600+1),2);
    end
    for n = 0:59
        QPSK stream(n+1) = 1/sqrt(2)*(1-2*c(2*n+1)) + 1j/
sqrt(2)*(1-2*c(2*n+2));
    end
end
```



Published with MATLAB® R2024a

### Part 4: SSS search & Cell Id Detection

#### **Table of Contents**

Parameters	]
SSS	
Channel and Noise	
(a) Plot Correlation for all SNR values	

#### **Parameters**

```
FFT_size = 4096;
CP_length = 288;
SCS = 30e3;
Ts = 1/FFT_size/SCS;
CP_OFDM_length = FFT_size+CP_length;
num_sc = 240;
N_id_1 = 77;
N_id_2 = 2;
```

#### SSS

```
% OFDM Modulation
SSS_stream = SSS_BPSK(N_id_1,N_id_2);
% Map symbol to subcarrier
d_SSS = [zeros(56,1);SSS_stream;zeros(FFT_size-183,1)];
% FFT
OFDM_SSS_body = ifft(d_SSS)*sqrt(FFT_size);
% Add CP
CP_OFDM_SSS = [OFDM_SSS_body(end-CP_length+1:end);OFDM_SSS_body];
```

#### **Channel and Noise**

```
h = 1;
signal_after_channel = conv(CP_OFDM_SSS,h);

SNR_values = [-5, 20]; % SNR values in dB
corr_all = zeros(length(SNR_values), 336);


for snr_idx = 1:length(SNR_values)
        SNR = SNR_values(snr_idx);
        N_0 = 10^(-SNR/10) * (norm(signal_after_channel)^2/
length(signal_after_channel));
        noise = sqrt(N_0/2)*(randn(length(signal_after_channel),1) +
1j*randn(length(signal_after_channel),1));
        received_SSS_signal = signal_after_channel + noise;
        corr = zeros(1,336);
```

```
for i = 0:335
        SSS ref stream = SSS BPSK(i,N id 2);
        d SSS ref = [zeros(56,1); SSS ref stream; zeros(FFT size-183,1)];
        OFDM SSS ref body = ifft(d SSS ref);
        CP OFDM SSS ref = [OFDM SSS ref body(end-
CP length+1:end);OFDM SSS ref body];
        corr(i+1) = abs(received SSS signal' * CP OFDM SSS ref);
    end
    [\sim, N \text{ id } 1 \text{ est pos}] = \max(\text{corr});
    N id 1 est = N id 1 est pos - 1;
    disp(['N ID1 for SNR = ', num2str(SNR), ' dB: ', num2str(N id 1 est)]);
    % Compute Cell ID using the formula
    Cell ID = 3 * N id 1 est + N id 2;
    disp(['Cell ID for SNR = ', num2str(SNR), ' dB: ', num2str(Cell ID)]);
    % Store correlation results
    corr all(snr idx, :) = corr;
end
N ID1 for SNR = -5 dB: 77
Cell ID for SNR = -5 dB: 233
N ID1 for SNR = 20 dB: 77
Cell ID for SNR = 20 dB: 233
```

## (a) Plot Correlation for all SNR values

```
figure;
plot(0:335, corr all(1, :), 'r', 'DisplayName', 'SNR = -5 dB');
hold on;
plot(0:335, corr all(2, :), 'b', 'DisplayName', 'SNR = 20 dB');
xlabel("Timing Offset (sample)")
ylabel("Correlation")
title('(4a) Correlation for Different SNR Values')
legend show;
grid on;
function BPSK stream = SSS BPSK(N id 1,N id 2)
    x 0 = zeros(127,1);
    x 1 = zeros(127,1);
    BPSK stream = zeros(127,1);
    x init = [1 0 0 0 0 0 0];
    x \ 0 (1:7) = x init;
    x 1(1:7) = x init;
    for i = 1:120
        x \ 0(i+7) = mod(x \ 0(i+4)+x \ 0(i),2);
        x 1(i+7) = mod(x 1(i+1)+x 1(i),2);
    for n = 0:126
        m = 0 = mod(n + 15* floor(N id 1/112) + 5*N id 2,127);
```

```
 \begin{array}{lll} & \texttt{m\_1} = \texttt{mod} \, (\texttt{n} + \texttt{mod} \, (\texttt{N\_id\_1,112),127}) \, ; \\ & \texttt{BPSK\_stream} \, (\texttt{n+1}) = (1 - 2 * \texttt{x\_0} \, (\texttt{m\_0+1})) * (1 - 2 * \texttt{x\_1} \, (\texttt{m\_1+1})) \, ; \\ & \texttt{end} \\ \end{array}
```



Published with MATLAB® R2024a

# Part 5: Channel Estimation & Equalization

#### **Table of Contents**

arameters	
BCH Pilot	, 1
BCH Data	
Concatenation	. 2
Channel without Noise	
ilot Subcarriers	. :
All Subcarriers	. :
a) Plot Mean Squared Estimation Error	. :
b) Plot SER vs. SNR	

#### **Parameters**

```
FFT_size = 4096;
CP_length = 288;
CP_OFDM_length = FFT_size+CP_length;
num_sc = 240;
SNR = -10:2:10;
num_MC = 1000;

QAM_mod = 4;
c_init = 120897;
h = [1 0.5]';
pilot_subcarriers = 1 + 4 * (0:59) + 1;
data_subcarriers = 1:num_sc;
```

#### **PBCH Pilot**

```
% OFDM Modulation
PBCH_pilot_stream = generate_PBCH_pilot(c_init);
% Map symbol to subcarrier
d_PBCH_pilot = zeros(FFT_size,1);
k = 0:59;
d_PBCH_pilot(1+4*k+1) = PBCH_pilot_stream;
% FFT
OFDM_PBCH_pilot_body = ifft(d_PBCH_pilot)*sqrt(FFT_size);
% Add CP
CP_OFDM_PBCH_pilot = [OFDM_PBCH_pilot_body(end-CP_length+1:end);OFDM_PBCH_pilot_body];
```

#### **PBCH Data**

```
% OFDM Modulation
PBCH_data_stream = generate_PBCH_data(num_sc, QAM_mod);
% Map symbol to subcarrier
d_PBCH_data = [PBCH_data_stream;zeros(FFT_size-num_sc,1)];
% FFT
OFDM_PBCH_data_body = ifft(d_PBCH_data)*sqrt(FFT_size);
% Add CP
CP_OFDM_PBCH_data = [OFDM_PBCH_data_body(end-CP_length+1:end);OFDM_PBCH_data_body];
```

#### Concatenation

```
CP OFDM chain = [CP OFDM PBCH pilot; CP OFDM PBCH data];
```

#### **Channel without Noise**

```
received signal = conv(CP OFDM chain,h);
% OFDM Demodulation
received CP OFDM chain = received signal(1:CP OFDM length*2);
% Remove CP
received OFDM pilot body =
received CP OFDM chain (CP length+1:CP OFDM length);
received pilot = fft(received OFDM pilot body);
% Actual H (actual channel)
H actual = received pilot(pilot subcarriers) ./ PBCH pilot stream;
NMSE = zeros(num MC, length(SNR));
SER = zeros(num MC, length(SNR));
SER all = zeros(num MC, length(SNR));
for SNR id = 1:length(SNR)
    for MC id = 1:num MC
        % Noise
        received signal noisy = awgn(received signal, SNR(SNR id), 'measured');
        % OFDM Demodulation
        received CP OFDM chain = received signal noisy(1:CP OFDM length*2);
        % Remove CP
        received OFDM pilot body =
received CP OFDM chain (CP length+1:CP OFDM length);
        received OFDM data body =
received CP OFDM chain(CP OFDM length+CP length+1:end);
        % FFT
        received pilot = fft(received OFDM pilot body);
        received data = fft(received OFDM data body);
```

#### **Pilot Subcarriers**

```
% Channel Estimation
ch_est = received_pilot(pilot_subcarriers) ./ PBCH_pilot_stream;
% Normalized Squared Error -->
NMSE(MC_id, SNR_id) = calculate_NMSE(H_actual, ch_est);
% Equalization
equalized_pilot_data = received_data(pilot_subcarriers) ./ ch_est;
% Symbol Error Rate
    SER(MC_id, SNR_id) = calculate_SER(equalized_pilot_data,
PBCH data stream(pilot subcarriers), QAM mod);
```

#### **All Subcarriers**

```
% Channel Estimation
    ch_est_full = interp1(pilot_subcarriers, ch_est,
(data_subcarriers)', 'linear', 'extrap');


% Equalization
    equalized_data = received_data(data_subcarriers) ./ ch_est_full;

% Symbol Error Rate
    SER_all(MC_id, SNR_id) = calculate_SER(equalized_data,
PBCH_data_stream, QAM_mod);

end
end
mean_NMSE = mean(NSE, 1);
mean_SER = mean(SER, 1);
mean_SER = mean(SER, 1);
mean_SER all = mean(SER all, 1);
```

## (a) Plot Mean Squared Estimation Error


```
figure;
semilogy(SNR, mean_NMSE);
grid on;
xlabel("SNR (dB)");
ylabel("Mean Squared Estimation Error");
title("(5a) Mean Squared Estimation Error vs SNR for Channel Estimation")
```




## (b) Plot SER vs. SNR

```
figure;
semilogy(SNR, mean SER);
grid on;
xlabel('SNR (dB)');
ylabel('Symbol Error Rate (SER)');
title('(5b) Symbol Error Rate vs. SNR for Pilot Subcarriers');
% (c) Plot SER vs. SNR
figure;
semilogy(SNR, mean SER all);
grid on;
xlabel('SNR (dB)');
ylabel('Symbol Error Rate (SER)');
title('(5c) Symbol Error Rate vs. SNR for All Subcarriers');
function QPSK pilot stream = generate PBCH pilot(c init)
    c = zeros(120,1);
    QPSK pilot stream = zeros(60,1);
    x 1 = zeros(1800,1);
    x 2 = zeros(1800,1);
    x 1 init = [1; zeros(30,1)];
    x_1(1:31) = x_1_init;
    x_2_{init} = zeros(31,1);
```

```
x 2 init char = dec2bin(c_init);
    for i = 1:length(x 2 init char)
        x 2 init(length(x 2 init char)-i+1) = str2double(x 2 init char(i));
    end
    x 2(1:31) = x 2 init;
    for n = 1:1800
        x 1(n+31) = mod(x 1(n+3)+x 1(n),2);
        x \ 2(n+31) = mod(x \ 2(n+3)+x \ 2(n+2)+x \ 2(n+1)+x \ 2(n),2);
    end
    for n = 0:119
        c(n+1) = mod(x 1(n+1600+1)+x 2(n+1600+1), 2);
    end
    for n = 0:59
        QPSK pilot stream(n+1) = 1/sqrt(2)*(1-2*c(2*n+1)) + 1j/
sqrt(2)*(1-2*c(2*n+2));
    end
end
function QPSK data stream = generate PBCH data(num sc, QAM mod)
    data bit stream = randi([0 1], num sc*log2(QAM mod), 1);
    QPSK data stream =
qammod(data bit stream, QAM mod, InputType='bit', UnitAveragePower=true);
end
function nsme = calculate NMSE(H actual, H estimated)
    % Calculate the squared error between the actual and estimated channel
responses
    error = H estimated - H actual;
    squared error = abs(error).^2;
    % Calculate the true power of the actual channel response
    squared actual = abs(H actual).^2;
   % Normalize the squared error by the true power --> TODO: Don't need to
   nsme = mean(squared error ./ squared actual);
end
function ser = calculate SER(equalized data, true data, QAM mod)
    % QPSK demodulation for both equalized and true data
   estimated symbols = gamdemod(equalized data, QAM mod, 'OutputType',
'bit', 'UnitAveragePower', true);
    true symbols = qamdemod(true data, QAM mod, 'OutputType', 'bit',
'UnitAveragePower', true);
    % Calculate SER
    ser = sum(estimated symbols ~= true symbols) / length(true symbols);
end
```





## Part 5: Channel Estimation & Equalization

