

# 8086 Addressing Modes

Dept. of Computer Science and Engineering BRAC University

**CSE 341 Team** 





### Lecture References:

#### ? Book:

- ? Microprocessors and Interfacing: Programming and Hardware, Chapter # 2, Author: Douglas V. Hall
- ? The 8086/8088 Family: Design, Programming, And Interfacing, Chapter # 2, Author: John Uffenbeck.





# Addressing Mode and Categories

- ? The different ways in which a microprocessor can access data are referred to as its addressing modes.
- ? Addressing modes of 8086 Microprocessor are categorized as:
  - ? Addressing Data
  - ? Addressing Program codes in memory
  - ? Addressing Stack in memory
  - ? Addressing I/O
  - ? Implied addressing





# Things to know...

? Instruction format

- ? Instructions can have 1, 2 or no operands
  - ? INCAX; I operand
  - ? ADD CX, DX; 2 operands



$$CX = CX + DX$$

- ? HLiTurteno operand
- ? Instruction cannot have:
  - SUB [DI], [I234h]; memory locations as both operands
  - ? MOV 1234, AX; immediate data as destination operand



- I. Immediate addressing
- II. Direct addressing
- III. Register [direct] addressing
- IV. Register indirect addressing
- v. Base-plus-index addressing
- VI. Register relative addressing
- VII. Base-relative-plus-index addressing





### I. Immediate addressing

? Data is immediately given in the instruction

MOV BL, II b

### II. Direct addressing

? Data address is directly given in the instruction

**MOV BX**, [437AH]





### III. Register [direct] addressing

? Data is in a register (here BX register contains the data)

MOV AX, BX

**MOVAL, BX** 

### IV. Register [indirect] addressing

? Register supplies the address of the required data

MOV CX, [BX]





### v. Base-plus-index addressing

- ? Base register is either BX or BP
- ? Index register is either DI or SI

### MOV DX, [BX+DI]

### v. Register relative addressing

- Register can be a base (BX, BP) or an index register (DI, SI)
- ? Mainly suitable to address array data

MOV AX, [BX+1000]





### VII. Base-relative-plus-index addressing

? Suitable for array addressing

**MOV AX, [BX+DI+10]** 



# 2. Addressing Program Codes in Memory

- ? Used with JMP and CALL instructions
- ? 3 distinct forms:
  - I. Direct
  - II. Indirect
- III. Relative

# 2. Addressing Program Codes in Memory

? Address is directly given in the instruction

JMP 1000: 0000

JMP doagain; doagain is a label in code

**CALL 1000:0000** 

CALL doagain; doagain is a procedure in code

? Often known as far jump or far call



# 2. Addressing Program Codes in Memory, spiring Ex

- ? Address can be obtained from
  - a) any GP registers (AX,BX,CX,DX,SP,BP,DI,SI)

```
    \int MP AX

    IP = AX; then CS:
    IP
```

**b)** any relative registers ([BP],[BX],[DI],[SI])

```
JMP [BX]

IP = what is inside the physical address of DS: BX; then CS: IP
```

? c) any relative register with displacement

```
JMP [BX + 100h]

IP = what is inside the physical address of DS: BX +100h; then CS: IP
```





# 3. Addressing Stack in Memory

 PUSH and POP instructions are used to move data to and from stack (in particular from stack segment).

**PUSH AX** 

POP CX

 CALL also uses the stack to hold the return address for procedure.

CALL SUM; SUM is a procedure name



# 4. Addressing Input and Output Porting Excellence

- ? IN and OUT instructions are used to address I/O ports
- ? Could be direct addressing

IN AL, 05h; Here 05h is a input port number

? or indirect addressing

**OUT DX, AL**; DX contains the address of I/O port

? Only DX register can be used to point a I/O port





# 5. Implied Addressing

- ? No explicit address is given with the instruction
- ? implied within the instruction itself
- ? Examples:

**CLC**; clear carry flag

**HLT**; halts the program

**RET**; return to DOS





### 8086 Machine Codes

Dept. of Computer Science and Engineering BRAC University

**CSE 341 Team** 





- ? For 8085: Just look up the hex code for each instruction.
- ? For 8086 it is not simple.
- ? E.g 32 ways to specify the source in MOV CX, source.
- ? MOV CX, source

a 16-bit register (8 in number)
a memory location (24 possible memory addressing modes)


- ? Each of these 32 instructions require different binary code.
- ? Impractical to list them all in a table.
- ? Instruction templates help code the instruction properly.







# Instruction template (6 bytes)



An instruction after conversion can have I to 6 bytes long of machine code

# Constructing Machine Codes for 8086

- ? Each instruction in 8086 is associated with the binary code.
- ? You need to locate the codes appropriately.
- ? Most of the time this work will be done by assembler
- ? The things needed to keep in mind is:
  - ? Instruction templates and coding formats
  - ? MOD and R/M Bit patterns for particular instruction






# **MOV Instruction Coding**

? MOV data from a register to a register/to a memory location or from a memory location to a register.

(Operation Code of MOV: 100010)







### MOD and R/M Field

- ? 2-bit Mode (MOD) and 3-bit Register/Memory (R/M) fields specify the other operand.
- ? Also specify the addressing mode.

RM MOO	00	01	10	11	
				W = 0	W = 1
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX
001	[BXI+[DI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a.	cx
010	[BP]+[SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP
101	[D]	[DI] + d8	[DI]+d16	aн	BP
110	d16 (direct address)	(BP)+d8	[BP] +d16	DH	SI
111	[BX]	[BX] + d8	[BX] + d16	BH	DI





### MOD and R/M Field

- ? If the other operand in the instruction is also one of the eight register then put in II for MOD bits in the instruction code.
- ? If the other operand is memory location, there are 24 ways of specifying how the execution unit should compute the effective address of the operand in the main memory.
- ? If the effective address specified in the instruction contains displacement less than 256 along with the reference to the contents of the register then put in 01 as the MOD bits.
- ? If the expression for the effective address contains a displacement which is too large to fit in 8 bits then out in 10 in MOD bits.








? REG field is used to identify the register of the one operand

REG	W = 0	W = 1
000	AL	AX
001	CL	CX
010	DL	DX
011	BL	BX
100	AH	SP
101	СН	BP
110	DH	SI
111	ВН	DI







**D** - direction

If **D=0**, then direction is from a register (source)

If **D=1**, then direction is to a register (destination)

W - word

If **W=0**, then only a byte is being transferred (8 bits)

If **W=1**, them a whole word is being transferred (16 bits)

34h here is an 8-bit displacement
[BX+34h] is a memory/offset address
MOV [BX + 34h], AL

MODE	OPERAND NATURE	T
00	Memory with no displacement	→ MOV AX, [BX]
01	Memory with 8-bit displacement	→ MOV AX, [BX + 12h]
10	Memory with 16-bit displacement	→ MOV AX, [BX + 1234h]
11	Both are registers	→ MOV AX, BX


MOV AX, 1234 h

• 1234h here is a 16-bit immediate data

CSE – 341: Microprocessors BRAC University



# Instruction template



- Value for R/M with corresponding MOD value
- Value for REG with corresponding W value and the register considered in D


Check column that matches with MOD value

M	XO TOTAL				<u> </u>
RM	00	01	10	11	
				W = 0	W = 1
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX
001	[BXI+[DI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a	cx
010	[BP]+[SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP
101	[DI]	[DI] + d8	[DI]+d16	ан	BP
110	d16 (direct address)	(BP) + d8	[BP] +d16	DH	SI
111	[BX]	[BX] + d8	[BX] + d16	BH	DI





? MOV 8B43H [SI], DH: Copy a byte from DH to memory with 16 bit displacement given the opcode for MOV=100010




HIGH BYTE DISPLACEMENT / DATA

LOW BYTE DISPLACEMENT / DATA





? MOV 8B43H [SI], DH: Copy a byte from DH to memory with 16 bit displacement given the opcode for MOV=100010




MOV [SI + 8B43H] ,

RM MOD	00	01	10	11	
				W = 0	W = 1
000	[BX] + [SI]	[BX]+[SI]+d8	[BX] + [SI] + d16	AL	AX
001	[BXI+[D]]	[BX] + [Di] + d8	[BX] + [DI] + d16	a	cx
010	[BP] + [SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX
011	(BP)+[DI)	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP
101	[DI]	[DI] + d8	[DI]+d16	ан	BP
110	d16 (direct address)	(BP) + d8	[BP] +d16	DH	SI
111	[BX]	[BX] + d8	[BX] + d16	BH	DI





? MOV 8B43H [SI], DH: Copy a byte from DH to memory with \16 bit displacement given the opcode for MOV=100010




MOV [SI + 8B43H] , DH

RM M	00	01	10	11	
				W = 0	W = 1
000	[BX] + [SI]	[BX]+[SI]+d8	[BX] + [SI] + d16	AL	AX
001	[BXI+[OI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a.	cx
010	(BP)+[SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP
101	[DI]	[DI] + d8	[DI] +d16	ан	BP
110	d16 (direct address)	(BP) + d8	[BP]+d16	DH	SI
111	[BX]	[BX] + d8	[BX] + d16	BH	DI





? MOV 8B43H [SI], DH: Copy a byte from DH to memory with 16 bit displacement given the opcode for MOV=100010





BYTE 3


Machine Code: 1000 1000 1011 0100 0100 0011 1000 10112 or 88 B4 43 8B16








#### ? MOV AX, BX: given the opcode for MOV=100010







### ? MOV AX, BX: given the opcode for MOV=100010




## Example 2

Machine Code: 1000 1011 1100 00112 or 88 C316

UNIVERSITY

? MOV AX, BX: given the opcode for MOV=100010



RM MOD	00	01	10	11		
				W = 0	W = 1	
000	[BX]+[SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX	
001	[BXI+(OI)	[BX] + [DI] + d8	(BX) + (DI) + d16	a	cx	
010	[BP]+[SI]	(BP)+(SI)+d8	[BP] + [SI] + d16	DŁ.	DX	
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX	
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP	
101	[D]	[DI] + d3	[DI]+d16	ан	BP	
110	d16 (direct address)	(BP) + d8	[BP] +d16	DH	SI	
111	[BX]	[BX] + d8	[BX] + d16	BH	DI	








? The Intel literature shows two different formats for coding 8086 instructions.

? Instruction templates helps you to code the instruction

properly.

? Example:

**IN AL, 05H** 








- MOV BL,AL
- Opcode for MOV = 100010
- We'll encode AL so
  - D = 0 (AL source operand)
- W bit = 0 (8-bits)
- MOD = 11 (register mode)
- REG = 000 (code for AL)
- R/M = 011

OPCODE		W	MOD	REG	R/M
100010	0	0	11	000	011



# Example


? MOV 43H [SI], DH: Copy a byte from DH register to memory location.





# Example 3

? MOV CX, [437AH]: Copy the contents of the two memory locations to the register CX.





### QUIZ



Compute the machine code for the following using the table below and the opcode for MOV as 100010

a) MOV AX, 5E9Ch

b) MOV DH, [BP+SI+7Dh]

RM MOD	00	01	10	11	
				W=0	W = 1
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX
001	[BXI+[DI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a	cx
010	[BP] + [SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP
101	[DI]	[DI] + d8	[DI]+d16	ан	BP
110	d16 (direct address)	(BP)+d8	[BP] +d16	DH	SI
111	[BX]	[BX] + d8	[BX] + d16	BH	DI





# Thank You!!!