# Accessing memory



#### R. Ferrero

#### Politecnico di Torino

Dipartimento di Automatica e Informatica (DAUIN)

Torino - Italy

This work is licensed under the Creative Commons (CC BY-SA) License. To view a copy of this license, visit http://creativecommons.org/licenses/by-sa/3.0/



# **Memory map**

u u	Vendor specific		0xFFFFFFF 0xE0100000	≈ 0.5 GB
system	Private	debug/external	0xE00FFFFF 0xE0040000	1 MB, 256 kB
S	peripheral bus	internal	0xE003FFFF 0xE0000000	256 kB
off chip	External device		0xDFFFFFF 0xA0000000	1 GB
off (	External RAM		0x9FFFFFFF 0x60000000	1 GB
Ω	Peripherals		0x5FFFFFFF 0x40000000	0.5 GB
on chip	SRA	AM	0x3FFFFFFF 0x20000000	0.5 GB
0	Cod	de	0x1FFFFFFF 0x00000000	0.5 GB

## Memory access attributes

Region	Bufferable	Cacheable	Executable
Code	yes	write through	yes
SRAM	yes	write back	yes
Peripherals	no	no	no
External RAM	no	write back	yes
External device	no	no	no
System	no	no	no

## Load and store pseudo-intructions

load/store <Rd>, <addressing\_mode>

Load	Store	Size and type
LDR	STR	word (32 bits)
LDRB	STRB	byte (8 bits)
LDRH	STRH	halfword (16 bits)
LDRSB	_	signed byte
LDRSH	_	signed halfword
LDRD	STRD	two words
LDM	STM	multiple words

#### **Exercise**

If r0 = 0x00008004, what are the values of the registers r1-r5 after the following instructions?

LDR r	1, [	[r0]
LDRB	r2,	[r0]
LDRH	r3,	[r0]
LDRSB	r4,	[r0]
LDRSH	r5,	[r0]

	_
0x41	0x00008000
0x73	0x00008001
0x73	0x00008002
0x65	0x00008003
0x8D	0x00008004
0x62	0x00008005
0x6C	0x00008006
0x79	0x00008007

#### **LDRD**

LDRD <Rd1>, <Rd2>, <addressing mode>

- It loads two registers
- Example:

if r0 = 0x00008000 then

r1 = 0x65737341

r2 = 0x796C628D

	_
0x41	0x00008000
0x73	0x00008001
0x73	0x00008002
0x65	0x00008003
0x8D	0x00008004
0x62	0x00008005
0x6C	0x00008006
0x79	0x00008007
<del></del>	•

#### STR

- It copies the content of a register into four consecutive memory locations.
- Example:

$$r0 = 0x20000000$$

$$r1 = 0x65737341$$

$$r2 = 0x796C628D$$

	<u>-</u>
0x41	0x20000000
0x73	0x20000001
0x73	0x20000002
0x65	0x20000003
0x00	0x20000004
0x00	0x20000005
0x00	0x20000006
0x00	0x20000007
	•

#### **STRB**

- It copies the least significant byte (LSB) of a register into the memory location.
- Example:

$$r0 = 0x20000000$$

$$r1 = 0x65737341$$

$$r2 = 0x796C628D$$

STRB r1, [r0]

	_
0x41	0x20000000
0x00	0x20000001
0x00	0x20000002
0x00	0x20000003
0x00	0x20000004
0x00	0x20000005
0x00	0x20000006
0x00	0x20000007

#### **STRH**

- It copies the lower 16-bit content of a register into two consecutive memory locations.
- Example:

$$r0 = 0x20000000$$

$$r1 = 0x65737341$$

$$r2 = 0x796C628D$$

STRH r1, [r0]

	-
0x41	0x20000000
0x73	0x20000001
0x00	0x20000002
0x00	0x20000003
0x00	0x20000004
0x00	0x20000005
0x00	0x20000006
0x00	0x20000007
	•

#### **STRD**

- It copies the content of two registers into eight consecutive memory locations.
- Example:

$$r0 = 0x20000000$$

$$r1 = 0x65737341$$

$$r2 = 0x796C628D$$

STRD r1, r2, [r0]

	_
0x41	0x20000000
0x73	0x20000001
0x73	0x20000002
0x65	0x20000003
0x8D	0x20000004
0x62	0x20000005
0x6C	0x20000006
0x79	0x20000007
	-

# Addressing mode

Addressing	Offset		
mode	immediate	register	
	with writeback	voo loft	
pre-indexed	without writeback	yes, left- shiftable	
post-indexed	yes	no	

## Pre-indexed addressing

 The address is computed by summing the offset to the value in the base register Rn:

```
load/store <Rd>, [<Rn>,<offset>]{!}
```

- If offset is a register, it can be shifted left up to 3 positions (with LSL #number).
- If offset is an immediate, its range is:
  - [-255, +4095] without writeback
  - [-255, +255] with writeback: ! is added at the end. With !, Rn is updated after the instruction.

## Pre-indexed addressing: example

- Using pre-indexed addressing, write the instructions for loading 4 words from memory into registers r2-r5.
- Register  $r_0$  contains the address of the first byte of the block of memory. e.g.,  $r_0 = 0x00008000$ .

#### With immediate offset

```
LDR r2, [r0]

LDR r3, [r0, #4]

LDR r4, [r0, #8]

LDR r5, [r0, #12]
```

At the end, r0 = 0x00008000

#### With immediate offset and writeback

```
LDR r2, [r0]

LDR r3, [r0, #4]!

LDR r4, [r0, #4]!

LDR r5, [r0, #4]!
```

At the end, r0 = 0x0000800C

## With register as offset

```
LDR r2, [r0]

MOV r1, #4

LDR r3, [r0, r1]

MOV r1, #8

LDR r4, [r0, r1]

MOV r1, #12

LDR r5, [r0, r1]
```

## With shifted register as offset

```
LDR r2, [r0]
MOV r1, #4

LDR r3, [r0, r1]

LDR r4, [r0, r1, LSL #1]

MOV r1, #12

LDR r5, [r0, r1]
```

## Post-indexed addressing

The address is given by the base register Rn:

```
load/store <Rd>, [<Rn>], <offset>
```

- Then Rn is updated by adding the offset.
- The offset is an 8-bit immediate value.
- ! is missing because Rn is always updated.

## Post-indexed addressing: example

- Using post-indexed addressing, write the instructions for loading 4 words from memory into registers r2-r5.
- Register  $r_0$  contains the address of the first byte of the block of memory. e.g.,  $r_0 = 0x00008000$ .

#### With immediate offset

```
LDR r2, [r0], #4

LDR r3, [r0], #4

LDR r4, [r0], #4

LDR r5, [r0], #4
```

At the end, r0 = 0x00008010

### Look-up table

- A look-up table is an array of pre-calculated constants.
- Pro: frequently used values are not computed at run-time or are computed only the first time
- Con: additional memory space is required.
- The look-up table can be easily accessed with indexed addressing.

## Example: look-up table of bytes

- Write a program that uses the x value contained in r2 and sets r4 with the value of  $x^2 + 2x + 1$ .
- Assume  $0 \le x \le 10$ .

## Example: look-up table of bytes

```
AREA | .text|, CODE, READONLY
Reset Handler PROC
    EXPORT Reset Handler [WEAK]
    MOV r2, #8 ; after some calculus
    LDR r0, =lookup
    LDRB r4, [r0, r2]
stop B stop ;stop program
lookup DCB 1, 4, 9, 16, 25, 36, 49,
64, 81, 100, 121
    ENDP
```

## **Example: look-up table of words**

- Write a program that uses the x value contained in r2 and sets r4 with the factorial of x.
- Assume  $0 \le x \le 10$ .

### **Example: look-up table of words**

```
AREA | .text|, CODE, READONLY
Reset Handler PROC
    EXPORT Reset Handler [WEAK]
    MOV r2, #8 ; after some calculus
    LDR r0, =lookup
    LDR r4, [r0, r2, LSL #2]
stop B stop ;stop program
lookup DCD 1, 1, 2, 6, 24, 120, 720,
5040, 40320, 362880, 3628800
    ENDP
```