
Designing Circular and Non-Circular Gears for FDM 3d-Printing



Contents

1	Too	th Profile	3
2	Drawing a Gear		3
3	Not	ation	4
4	Cal	culating Gear and teeth Size	5
	4.1	Circular Gears	5
	4.2	Rectangular Gears	6
	4.3	Other Non Circular Gears	6
	4.4	Examples	7
		Circular gears with given gear ratio and centerdistance	7
		Internal ring gear	8
		Planetary gears (epicyclic gear train)	9
		Rectangular gear with given tooth size r	9
		Rectangular and circular gears with given gear ratio and centerdis-	
		tance	9
5	Rac	k and Pinion	10
	5.1	Constant rotational Speed	10
	5.2	Non-constant rotational Speed	11
	5.3	Non-constant shaft position	
	5.4	Examples	
		Shaft following a Sinus(t) curve	
		$\cos(t)$	12

1 Tooth Profile

Since FDM 3d printed gears are weak and therefore torque and transmission efficiency is not as important we are going to use a circular tooth profile. Please note that this profile is not optimal but it makes it incredibly easy to calculate and draw non circular gears. It is sufficient for most 3d printed parts. If this is not suitable for your design take a look at involute gears.




Figure 1: Gear profile construction using circles

2 Drawing a Gear

Start by drawing the general shape of the gear. As we will see in section 4.3 this can be any convex shape. As an example we will take a look at a circular gear. Then, using a compas, mark points with distance r on the outline of your shape and draw a circle with radius r on every second mark.




Figure 2: Drawing a circular gear

3 Notation

A gear can be represented as a tupel which consists of the gear shape together with the number of teeth, the radius of each tooth, a set containing the centerpoints of each tooth and the centerpoint of the gear itself.

Definition 3.1

A tupel $(\gamma, n, r, (m_i)_{i \in \mathbb{Z}_{2n}}, M)$ where $\gamma : [0, 2\pi) \to \mathbb{R}^k$, $k \in \mathbb{N}, n \in 2\mathbb{N}, r \in \mathbb{R}$, $m_i \in \gamma[[0, 2\pi)] : d(m_i, m_{i+1}) = r$ and $M \in \mathbb{R}^k$ is called a gear.

If γ is a circle we will sometimes replace it with its radius $R \in \mathbb{R}$. Furthermore M is defined as point with distance $d(M, \gamma(\varphi)) = ||\gamma(\varphi)||_2, \forall \varphi \in [0, 2\pi)$. Since M is defined by γ it is not required. However we will only omit M if it is 0.

Definition 3.2

Two gears are of the same size or shape, if it is possible to map the image of γ_A to the image of γ_B without changing its size:

$$\exists \iota : d(\iota(x), \iota(y)) = d(x, y) \land \iota(\gamma_A[[0, 2\pi)]) = \gamma_B[[0, 2\pi)]. \tag{3.1}$$

We call two gears A and B similar and write $A \sim B$ if they are of the same size and

$$n_A = n_B$$

$$r_A = r_B$$

$$\iota[(m_{A,i})_{i \in \mathbb{Z}_{2n_A}}] = (m_{B,j})_{j \in \mathbb{Z}_{2n_B}}$$

where ι is an isometric function that satisfies (3.1).

PROOF

For this definition to make sense \sim needs to be reflexive, symmetric and transitive.

" $A \sim A$ ":

Let ι be the identity.

"
$$A \sim B \implies B \sim A$$
":

As ι is an isometric isomorphism it is bijective and therefore its inverse ι^{-1} exists. Using ι^{-1} , $B \sim A$.

$$"A \sim B \wedge B \sim C \implies A \sim C"$$
:

The composition of two isometric isomorphisms is an isometric isomorphism and therefore $A \sim C$.

DEFINITION 3.3

Two gears A and B fit together if

$$r_A = r_B$$
.

4 Calculating Gear and teeth Size

4.1 Circular Gears

Designing a circular gear is straightforward. We start by drawing a circle K with radius R. This will be the size of our final gear. We then look for a sequence of smaller circles $(k_i)_{i\in I}$ with radius r such that their center is on K, they intersect each other on K, they cover K completely and the number of k_i must be even $(|I| = 2n : n \in \mathbb{N})$. This is important since the number of teeth has to be a positive integer.

THEOREM 4.1

Given a circle K with radius R and $n \in \mathbb{N}$, it is possible to find a sequence of n circles $(k_i)_{i \in I}$ with radius r and center $(m_i)_{i \in I} \in K$ such that $|\{x \in K : d(x, m_i) > r, \forall i \in I\}| = 0$ and $|\{x \in K : \exists i, j \in I, d(x, m_i) \leq r \land d(x, m_j) \leq r\}| = n$. Where d(x, y) is the distance between x and y. Let $\varphi = \frac{2P_i}{n}$ then


$$R = \frac{r \cdot \cos\left(\frac{\varphi}{4}\right)}{\sin\left(\frac{\varphi}{2}\right)}. (4.1)$$

Proof

Let K be a circle with radius R and center (0,0) and $n=2k, k \in \mathbb{N}$ we can, using polar coordinates, construct a sequence $(m_i)_{i \in \mathbb{Z}_{2n}}, m_i = (R, i \cdot \frac{\pi}{n} \text{rad})$ of 2n points on K. They are evenly spaced and $r \coloneqq d(m_0, m_1)$. We can now construct a sequence $(k_j)_{j \in \mathbb{Z}_n}$ of n circles with radius r and center $m_j : j \equiv 0 \pmod{2}$. Therefore $\{x \in K : \exists i, j \in \mathbb{Z}_{2n} : d(x, m_{2i}) \leq r \land d(x, m_{2j}) \leq r\} = \{m_i : i \equiv 1 \pmod{2}, i \in \mathbb{Z}_{2n}\}$ and $|\{m_i : i \equiv 1 \pmod{2}, i \in \mathbb{Z}_{2n}\}| = n$.

Let $\alpha := \langle m_3 m_2 m_1, \varphi := \langle m_1 M m_3 \text{ and } d := \overline{m_3 m_1}$. Using the inscribed angle theorem(**inscribedangle**), we know that $\alpha = \frac{2\pi - \varphi}{2}$. By drawing a line from M to m we get two right triangles. $\overline{Mm_2}$ also halves φ , α and d. Thus

$$\frac{d}{2} = r \cdot \sin\left(\frac{\alpha}{2}\right) \tag{4.2}$$



and

$$R = \frac{d}{2\sin\left(\frac{\varphi}{2}\right)}. (4.3)$$

By substituting in α in eq. (4.2) and using $\cos(x) = \sin(\frac{\pi}{2} - x)$, we see that

$$R = \frac{r \cdot \cos\left(\frac{\varphi}{4}\right)}{\sin\left(\frac{\varphi}{2}\right)}.\tag{4.4}$$

4.2 Rectangular Gears

THEOREM 4.2

Let K be a rectangle with side lengths of a and b. It is possible to find a sequence of circles $(k_i)_{i\in I}$ with the same properties as in theorem 4.1 if $4r \mid a$ and $4r \mid b$. Furthermore all four corners of K are in $\{m_i : i \in I\}$, where m_i is the center of k_i .

PROOF It is easy to see that theorem 4.2 holds true.

4.3 Other Non Circular Gears

THEOREM 4.3

Let γ be a simple, closed curve where the enclosed area is convex. γ can be used as a gear outline. Furthermore the sequence of circlecenters $\{m_i : i \in I\}$ can be calculated using:

Algorithm 1: Calculating $\{m_i : i \in I\}$ Result: Write here the result I = 2 times number of teeth; while While condition do instructions; if condition then instructions1; instructions2; else instructions3; end end

4.4 Examples

EXAMPLE 4.4.1 Circular gears with given gear ratio and centerdistance Lets say we want a 3:1 gear reduction and the center points of each gear should be 30mm apart. We can now start to build a system of equations:

$$R_1 + R_2 = 30$$
$$n_1 = 3n_2$$

Where R_1 and R_2 are the radii of the two gears and n_1 and n_2 denote the number of teeth on each. Using eq. (4.1) we also know that:

$$\varphi_1 = \frac{2Pi}{n_1}$$

$$R_1 = \frac{r * \cos\left(\frac{\varphi_1}{4}\right)}{\sin\left(\frac{\varphi_1}{2}\right)}$$

$$\varphi_2 = \frac{2Pi}{n_2}$$

$$R_2 = \frac{r * \cos\left(\frac{\varphi_2}{4}\right)}{\sin\left(\frac{\varphi_2}{2}\right)}$$

If we specify the number of teeth on either one of them lets say

$$n_2 = 16.$$

we can solve the system of equations using wolframalpha, maple or another computerprogram to find a unique solution. In this example we get:

$$r = 1.471832758$$

$$R_1 = 22.49196236$$

$$R_2 = 7.508037642$$

$$n_1 = 48$$

$$n_2 = 16$$

$$\varphi_1 = 0.1308996939$$

$$\varphi_2 = 0.3926990818$$

If r is too small/large change the number of teeth you specified.




Figure 3: Resulting Gears

Example 4.4.2 Internal ring gear

A internal ring gear K_r with outer diameter $D_r = 5$ should be calculated such that a smaller gear K can be used to archive a 5:1 gear reduction. The two shafts should be 1cm apart.

As the two shafts are 15mm apart we know that

$$R_r - R = 15.$$

Furthermore

$$n_r = 5 \cdot n$$

to achieve the required 5:1 ratio. Using eq. (4.1) we also know that:

$$\varphi_r = \frac{2Pi}{n_r}$$

$$R_r = \frac{r * \cos\left(\frac{\varphi_r}{4}\right)}{\sin\left(\frac{\varphi_r}{2}\right)}$$

$$\varphi = \frac{2Pi}{n}$$

$$R = \frac{r * \cos\left(\frac{\varphi}{4}\right)}{\sin\left(\frac{\varphi}{2}\right)}$$

If we specify the number of teeth on either one of them lets say

$$n = 8$$
,

we can solve the system of equations using wolframalpha, maple or another computerprogram to find a unique solution. In this example we get:

$$r = 1.474527091$$

$$R_r = 18.77908826$$

$$R = 3.779088256$$

$$n_r = 40$$

$$n = 8$$

$$\varphi_r = 0.1570796327$$

$$\varphi = 0.7853981635$$




Figure 4: Resulting internal ring gear

EXAMPLE 4.4.3 Planetary gears (epicyclic gear train)

EXAMPLE 4.4.4 Rectangular gear with given tooth size r

EXAMPLE 4.4.5 Rectangular and circular gears with given gear ratio and centerdistance

5 Rack and Pinion

In order to translate linear motion to rotation and vice versa a rack and pinion can be used. As seen in section 4 it is possible to calculate and draw a gearprofile.




Figure 5: Rack and Pinion

5.1 Constant rotational Speed

THEOREM 5.1

Let K be a circular gear with not moving center M and R a corresponding rack. There exists a homomorphism Ψ such that $\Psi(s) = \varphi$, where s is the distance R is moved and φ the angle K is rotated around M. If R is moved at a constant speed, the rotational speed of K will be constant.

PROOF Assuming there is no play in this system K can be viewed as a circle with radius r and the rack R as a tangent line. The length of an arc can be calculated using

$$l = r \cdot \varphi$$

and therefore

$$\varphi = \frac{l}{r}.$$

Since there is no play, the length l of the arc will be equal to the distance s, R was moved and

$$\Psi(s) = \frac{s}{r}.$$

It is easy to see that $\Psi(\lambda \cdot s) = \lambda \cdot \Psi(s)$. As Ψ is a composition of continuous functions it is continuous.

If R is moving with constant speed $v(t) = \frac{s(t)}{t} = s(1), v' = 0$. The rotational speed of K, $\omega(t) = \frac{\varphi}{t}$ can be calculated using Ψ .

$$\omega(t) = \frac{\Psi(s(t))}{t} = \frac{t \cdot \Psi(s(1))}{t} = \Psi(s(1)) = \Psi(v(t))$$

As v is constant so is $\Psi(v)$ and thus ω is constant.

5.2 Non-constant rotational Speed

If a non-circular gear is used as a pinion and a rack is made in a way that the center of the gear does not move the resulting rotational speed will be non constant. This behavior can be used to calculate a special gear shape such that the rotational speed follows a given curve. Leading to the following theorem:

THEOREM 5.2

Given a periodic, continuous function f. If $\gamma''(\varphi) \leq K''(\varphi)$ where

$$\gamma(\varphi) = \begin{pmatrix} \frac{1}{f(\varphi)} \cos(\varphi) \\ \frac{1}{f(\varphi)} \sin(\varphi) \end{pmatrix}, \tag{5.1}$$

 γ will be simple, closed and the enclosed area will be convex. γ can therefore be used as a gear outline. Furthermore, if a fitting rack moves with constant speed c, the rotational speed of this gear will be $cf(\varphi)$.

Proof

5.3 Non-constant shaft position

If it is necessary that the shaft rotates and changes position a control cam can be used (fig. 6). By restricting the shaft position in the x direction it will follow the racks shape if they stay in contact. If no rotation is required a control cam in the required shape should be used on its own.

Sebastian Hirnschall 11




Figure 6: Rack and Pinion

THEOREM 5.3

Let K be a circular gear with radius r and center m where m_x is constant and $f \in C^2([0, 2\pi))$ with $|f''(\varphi)| < |K''(\varphi)|$. f can be used as an outline for a rack R and m_y will follow the curve $f + c, c \in \mathbb{R}$.

PROOF Using theorem 4.3 it is possible to calculate a gear profile for K and R. Since K is circular and always touching R, the distance between m and R is r. It is easy to see that $|f''(\varphi)| < |K''(\varphi)|$ implies that K is touching R in no more than one point. Thus $m_y = f(\varphi) + r + c$ where c depends on the total thickness of R. A proper proof is omitted since it is easy to see that section 5.3 holds true. \square

5.4 Examples

Example 5.4.1 Shaft following a Sinus(t) curve

We want a gear such that the shaft is following a $\sin(t)$ curve. We know that $\sin(t)$ is a 2π periodic function with $\sin(t) > 0$, $t \in (0,\pi)$ and $\sin(t) < 0$, $t \in (\pi, 2\pi)$. As seen in ?? this will result in a non convex gear shape. To use the method described in section 4.3 we need a new function $g(t) := \sin(t) + |\min(\sin[0, 2\pi])|$. Thus $g(t) \geq 0$, $t \in (0, 2\pi)$ resulting in a convex gear shape. However the shaft will now follow g(t) and not $\sin(t)$. Therefore we need to offset both the rack and pinion by $|\min(\sin[0, 2\pi])|$.

We can now start by choosing a minimum radius R := 5 for the gear.

Example $5.4.2 \cos(t)$

List of Figures

1	Gear profile construction using circles	3
2	Drawing a circular gear	3
3	Resulting Gears	8
4	Resulting internal ring gear	9
5	Rack and Pinion	10
6	Rack and Pinion	12

List of Tables