

# Four-Barrel Carburetor Rebuild, Working Notes

My own shorthand for the 1987 C10 build. Pulled from forum threads and the rebuild kit instructions.

---

## WHY THE FOUR-BARREL

Going from throttle body injection to a carburetor on the 87 C10. The spread bore four-barrel has small primaries for economy and big secondaries for when you get into it. Right call for a stock 350 that is not chasing big power, just a clean, honest running truck. Simpler to tune by hand at the garage than the old injection setup, and parts are easy to get through the counter.

## BEFORE YOU START

- Take photos of every linkage and vacuum line before anything comes off. You will forget.
- Lay parts out in order. An egg carton or a muffin tin works for the small stuff.
- Work clean. One speck of grit in a jet and you chase a problem for a week.
- Fresh gasket kit on the bench, and a clean drain pan under the carb for the old fuel.

## TEARDOWN ORDER

- Air horn screws, lift the top straight up so you do not bend the floats.
- Note the float level and which accelerator pump linkage hole is being used.
- Primary and secondary metering rods, keep them paired to their springs.
- Jets out, label primary versus secondary. Do not mix them.
- Power piston, check it moves free and springs back.

## THE TWO KNOWN WEAK SPOTS

Fuel well plugs in the bottom of the float bowl leak with age. Epoxy the wells on reassembly, which lines up with what the carb-build channel does and what the forum keeps repeating. The throttle shaft wears and pulls a vacuum leak. Check for slop before you trust it, and plan to bush it later if it is loose.

## REASSEMBLY

- New float, set the level to spec with the kit gauge. Too high floods, too low starves.
- New accelerator pump, work it by hand, you should see a clean squirt.
- Idle mixture screws, seat gently then back out about 2.5 turns to start.
- New gaskets throughout, do not reuse the old bowl gasket even if it looks fine.

## BENCH SETTINGS TO START WITH

| Setting               | Starting point                |
|-----------------------|-------------------------------|
| Idle mixture screws   | 2.5 turns out from seated     |
| Float level           | to kit gauge spec             |
| Idle speed (warm)     | 650 to 700 rpm in drive       |
| Fuel pressure (carb)  | 5 to 7 psi, low pressure pump |
| Accelerator pump shot | clean stream, no dribble      |

## TUNING ONCE RUNNING

Warm it up first. Set idle speed, then set idle mixture by vacuum for the highest steady reading, backing each screw a hair at a time. Watch for a stumble off idle, which is usually the accelerator pump shot or the squirter size. Small changes, then drive it, then adjust again. Do not chase everything at once.

### **FIRST START CHECKLIST**

- Prime the bowl, do not crank it dry forever.
- Fire extinguisher within reach. Fuel up top, take it seriously.
- Watch every fitting for leaks before you let it idle.
- Set timing once it catches and warms.

### **PARTS STILL TO SORT**

Confirm the carb to intake bolt pattern with Jake before ordering the gasket set. Decide whether to keep the throttle body distributor with a module or step up to a vacuum advance unit for the carburetor. Leaning toward the simpler distributor route to save money and keep the first start uncomplicated.

### **QUESTIONS FOR JAKE**

Will the stock alternator keep up once it is running again? Is the old fuel line worth reusing, or should the whole run go to a carb friendly low pressure setup? He sees this stuff all day at the parts counter, so a two minute call saves a wrong order. Text him before the next garage Saturday so the parts are in when Dad is around.