



William Stallings
Computer Organization
and Architecture
10th Edition



+ Chapter 2 Performance Issues

Designing for Performance

- The cost of computer systems continues to drop dramatically, while the performance and capacity of those systems continue to rise equally dramatically
- Today's laptops have the computing power of an IBM mainframe from 10 or 15 years ago
- Processors are so inexpensive that we now have microprocessors we throw away
- Desktop applications that require the great power of today's microprocessor-based systems include:
 - Image processing
 - Three-dimensional rendering
 - Speech recognition
 - Videoconferencing
 - Multimedia authoring
 - Voice and video annotation of files
 - Simulation modeling




 Cloud service providers use massive high-performance banks of servers to satisfy high-volume, high-transaction-rate applications for a broad spectrum of clients



Microprocessor Speed

Techniques built into contemporary processors include:



Performance Balance

■ Adjust the organization and architecture to compensate for the mismatch among the capabilities of the various components

Architectural examples include:

Increase the number of bits that are retrieved at one time by making DRAMs "wider" rather than "deeper" and by using wide bus data paths

Reduce the frequency
of memory access by
incorporating
increasingly complex
and efficient cache
structures between
the processor and
main memory

Change the DRAM
interface to make it
more efficient by
including a cache or
other buffering
scheme on the DRAM
chip

Increase the interconnect bandwidth between processors and memory by using higher speed buses and a hierarchy of buses to buffer and structure data flow




Figure 2.1 Typical I/O Device Data Rates

Improvements in Chip Organization and Architecture

- Increase hardware speed of processor
 - Fundamentally due to shrinking logic gate size
 - More gates, packed more tightly, increasing clock rate
 - Propagation time for signals reduced
- Increase size and speed of caches
 - Dedicating part of processor chip
 - Cache access times drop significantly
- Change processor organization and architecture
 - Increase effective speed of instruction execution
 - Parallelism



Problems with Clock Speed and Login Density

■ Power

- Power density increases with density of logic and clock speed
- Dissipating heat

delay

- Speed at which electrons flow limited by resistance and capacitance of metal wires connecting them
- Delay increases as the RC product increases
- As components on the chip decrease in size, the wire interconnects become thinner, increasing resistance
- Also, the wires are closer together, increasing capacitance
- Memory latency
 - Memory speeds lag processor speeds




Figure 2.2 Processor Trends



Amdahl's Law



- Gene Amdahl
- Deals with the potential speedup of a program using multiple processors compared to a single processor
- Illustrates the problems facing industry in the development of multi-core machines
 - Software must be adapted to a highly parallel execution environment to exploit the power of parallel processing
- Can be generalized to evaluate and design technical improvement in a computer system