
SI-2024: Introduction to CubeSat and Satellite Communication

Introduction to Antennas


3rd July **2024** NEW SACE REVILUTION

SiliconTech


CubeSat Minimal Architecture



LoRa Transceiver (Radio) Architecture



LoRa Transceiver (Radio) Architecture



Mechanism for Radiation

- ❖ The primary mechanism of radiation is due to accelerating (or deceleration) of charge
- Current in a conductor:

$$\rightarrow J_z = q_v v_z$$


Current in an ideal conductor:

$$\rightarrow J_S = q_S v_Z$$

Current in an thin conductor:

$$\rightarrow I_z = q_l v_z$$


For a time-varying current:




To create radiation, there must be time-varying current OR accelerating (or deceleration) of charge

Mechanism for Radiation (Derived Facts)


- ✓ If a charge is not moving, current is not created and there is no radiation.
- ✓ If charge is moving with a uniform velocity:
 - ☑ There is no radiation if the wire is straight, and infinite in extent.
 - ✓ There is radiation if the wire is curved, bent, discontinuous, terminated, or truncated.
- ✓ If charge is oscillating in a time-motion, it radiates even if the wire is straight.




Two-Wire Antenna and Electric-Field Lines




Two-Wire Antenna and Free-Space Wave




Detached Wave Visualization




Two-Wire Antenna and Free-Space Wave




Thevenin Equivalent of Source-TransmissionLine-Antenna




Formation and Detachment of Free-Waves from a Dipole Antenna



Radiation Pattern




Dipole Antennas




Horn Antennas


Polarization




Linear-Polarized EM Wave




Circular-Polarized EM Wave



Types of Antennas






Wire Antennas

Aperture Antennas


Types of Antennas




Patch (Microstrip) Antennas


Array Antennas

Types of Antennas






(b) Parabolic reflector with Cassegrain feed




Reflector Antennas




Deployable CubeSat Antennas




CubeSat Turnstile Antennas




CubeSat Patch Antennas







V₁‡


- Impedance is the radiation 374 42 resistance. Typical 50-ohm or 75-ohm
- For effective signal transmission (or reception) this reflection should be minimum.
- The reflection is measured through VSWR (Voltage Standing Wave Ratio). Ideal VSWR = 1.0 but realistically < 2.0
- Antenna is tuned using Vector
 Network Analyzer (VNA) by
 measuring the VSWR while
 resizing the antenna elements or
 adjusting RLC circuit parameters.








Output



$$VSWR = \frac{1 + \frac{V_2}{V_1}}{1 - \frac{V_2}{V_1}}$$

example of antenna tuning Using a network analyzer




Appendix




SiliconTech

Tiny Satellite Ground Station



CubeSat Standard Sizes



Our target <1U

Minimal Payload

